Part Number	Model	Description	Manufacturer	Capability
124.013	209-070-262-3	Dual Temp & Pressure Indicator	Kratos	Repair
124.013	209-070-262-003	Dual Temp & Pressure Indicator	Kratos	Repair
124.014	212-070-116-5	Dual Temp & Pressure Indicator	Kratos	Repair
124.039	209-070-264-3	Dual Ammeter	Kratos	Repair
124.039	209-070-264-003	Dual Ammeter	Kratos	Repair
124.041	212-070-116-7	Dual Temp & Pressure Indicator	Kratos	Repair
124.043	-	Dual Temp & Pressure Indicator	Kratos	Repair
124.044	-	Fuel Pressure Indicator	Kratos	Repair
124.045	212-070-116-9	Dual Temp & Pressure Indicator	Kratos	Repair
124.045	212-070-116-009	Dual Temp & Pressure Indicator	Kratos	Repair
124.067	212-075-420-1	ITT Indicator	Kratos	Repair
124.067	212-075-420-001	ITT Indicator	Kratos	Repair
124.115	209-070-262-9	Dual Temp & Pressure Indicator	Kratos	Repair
124.115	209-070-262-009	Dual Temp & Pressure Indicator	Kratos	Repair
124.273	214-075-222-1	Dual Temp & Pressure Indicator	Kratos	Repair
124.412	214-075-261-1	EGT Indicator	Kratos	Repair
124.412	214-075-261-001	EGT Indicator	Kratos	Repair
449	-	Power Supply	Astronics	Repair
3935	-	Turn & Slip Indicator	General Design	Repair
4000	-	ELT, Pointer Sentry	Pointer	Test/Recert
5932	-	Altimeter, Pressure	United Instruments	Repair
5934	-	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
6111	-	Manifold Pressure Indicator, Single	United Instruments	Repair
6112	-	Manifold Pressure Indicator, Single	United Instruments	Repair
6121	-	Manifold Pressure Indicator, Dual	United Instruments	Repair
6122	-	Manifold Pressure Indicator, Dual	United Instruments	Repair
6211	-	Fuel Pressure Indicator, Single	United Instruments	Repair
6212	-	Fuel Pressure Indicator, Single	United Instruments	Repair
6213	-	Fuel Pressure Indicator, Single	United Instruments	Repair
6221	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6222	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6223	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6224	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6225	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6311	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6312	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6313	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6314	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6315	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6332	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6406	4000D-6	Directional Gyro, Lighted	S-TEC	Repair
8000	-	Airspeed Indicator	United Instruments	Repair
8025	-	Airspeed Indicator	United Instruments	Repair
8030	-	Airspeed Indicator	United Instruments	Repair
8040	-	Airspeed Indicator	United Instruments	Repair
8047	-	Altimeter (-1k-15k ft, in.Hg, Lighted)	Horizon	Repair
8048	-	Altimeter (-1k-15k ft, mbar, Lighted)	Horizon	Repair
8100	-	Airspeed Indicator, True	United Instruments	Repair
8125	-	Airspeed Indicator, True	United Instruments	Repair
8130	-	Airspeed Indicator, True	United Instruments	Repair
8140	-	Airspeed Indicator, True	United Instruments	Repair
8503	-	Altimeter (-1k-20k ft, in.Hg)	Aero Mechanism	Repair
10962	S6155-61198-101	Frequency Sensor	Sikorsky	Repair
12003	-	Altimeter (-1k-20k ft, in.Hg)	MacLeod	Repair
13503	-	Altimeter (-1k-35k ft, in.Hg)	MacLeod	Repair
31853	-	Manifold Pressure Gauge	US Gauge	Test/Recert
53083	4000D-4	Directional Gyro, Lighted	ARC	Repair
107500	ARU-12/A	Attitude Remote Indicator	Astronautics	Repair
117800	214-075-243-3	Remote Attitude Indicator	Astronautics	Repair
117800	214-075-243-003	Remote Attitude Indicator	Astronautics	Repair
155751	-	Encoding Altimeter (-1k-20k ft, in.Hg, Lighted)	Aero Mechanism	Repair
473051	-	Smoke Detector	Kidde	Repair
473054	-	Smoke Detector	Kidde	Repair
656767	CS-212	Magnetic Compensator	Sperry	Test/Recert

Part Number	Model	Description	Manufacturer	Capability
749753	704A47-650-116	Fuel Quantity Indicator	Intertechnique	Repair
820123	5000D	Attitude Gyro	Mooney	Repair
820192	5000D-1	Attitude Gyro	Mooney	Repair
820203	4000B-5	Directional Gyro	Mooney	Repair
843766	76550-01001-104	Master Caution/Warning Panel	Teledyne	Repair
843766	76550-01001-102	Master Caution/Warning Panel	Teledyne	Repair
6405-8-14	-	Turn Coordinator	S-TEC	Repair
6405-8-28	-	Turn Coordinator	S-TEC	Repair
6407-8-14	-	Turn Coordinator	S-TEC	Repair
6407-8-28	-	Turn Coordinator	S-TEC	Repair
2593691	VG-401	Attitude Reference	Sperry	Repair
3850096	5000B-12	Attitude Gyro	Aero Commander	Repair
3850097	4000B-13	Directional Gyro	Aero Commander	Repair
4013290	HZ-6	Servo Amplifier	Sperry	Repair
365050111	5000B-71	Attitude Gyro	Britten-Norman	Repair
365050120	4000B-45	Directional Gyro	Britten-Norman	Repair
762213020	5000B-69	Attitude Gyro	Robin	Repair
762214010	4000B-44	Directional Gyro	Robin	Repair
5040017901	510-1A	Attitude Gyro	AIM	Repair
5040017903	510-3A	Attitude Gyro	AIM	Repair
5040017905	510-5A	Attitude Gyro	AIM	Repair
5040017907	510-7A	Attitude Gyro	AIM	Repair
5040017908	510-1B	Attitude Gyro	AIM	Repair
5040017909	510-8A	Attitude Gyro	AIM	Repair
5040017910	510-10A/B	Attitude Gyro	AIM	Repair
5040017911	510-10C	Attitude Gyro	AIM	Repair
5040017912	510-7C	Attitude Gyro	AIM	Repair
5040017913	510-17A	Attitude Gyro	AIM	Repair
5040017914	510-17B	Attitude Gyro	AIM	Repair
5040017916	510-8B	Attitude Gyro	AIM	Repair
5040017917	510-8C	Attitude Gyro	AIM	Repair
5040017918	510-1F	Attitude Gyro	AIM	Repair
5040017921	510-8D	Attitude Gyro	AIM	Repair
5040017922	510-8E	Attitude Gyro	AIM	Repair
5040017923	510-8F	Attitude Gyro	AIM	Repair
5040017924	510-8G	Attitude Gyro	AIM	Repair
5040017925	510-8H	Attitude Gyro	AIM	Repair
5040017926	510-1G	Attitude Gyro	AIM	Repair
5040017928	510-1J17	Attitude Gyro	AIM	Repair
5040017930	510-1K	Attitude Gyro	AIM	Repair
5040017931	510-1M	Attitude Gyro	AIM	Repair
5040017932	510-1N	Attitude Gyro	AIM	Repair
5040017933	510-1P	Attitude Gyro	AIM	Repair
5040017934	510-1R	Attitude Gyro	AIM	Repair
5040024901	510-21A/AH	Attitude Gyro	AIM	Repair
5040024902	510-21B/BH	Attitude Gyro	AIM	Repair
5040024903	510-21C/CH	Attitude Gyro	AIM	Repair
5040024904	510-21D/DH	Attitude Gyro	AIM	Repair
5040024905	510-21E/EH	Attitude Gyro	AIM	Repair
5040024906	510-21F	Attitude Gyro	AIM	Repair
5040024907	510-21G	Attitude Gyro	AIM	Repair
5040028901	510-22A/AH	Attitude Gyro	AIM	Repair
5040028902	510-22B/BH	Attitude Gyro	AIM	Repair
5040028903	510-22C/CH	Attitude Gyro	AIM	Repair
5040028904	510-22D/DH	Attitude Gyro	AIM	Repair
5040028905	510-22E/EH	Attitude Gyro	AIM	Repair
5040028906	510-22F/FH	Attitude Gyro	AIM	Repair
5040028907	510-22G/GH	Attitude Gyro	AIM	Repair
5040028908	510-22H/HH	Attitude Gyro	AIM	Repair
5040028909	510-22J	Attitude Gyro	AIM	Repair
5040028910	510-22K	Attitude Gyro	AIM	Repair
5040028911	510-22LH	Attitude Gyro	AIM	Repair
5040028912	510-22M	Attitude Gyro	AIM	Repair
5040028913	510-22N	Attitude Gyro	AIM	Repair
5040028914	510-22P	Attitude Gyro	AIM	Repair
5040030909	510-24J/JH	Attitude Gyro	AIM	Repair

Part Number	Model	Description	Manufacturer	Capability
5040030910	510-24K/KH	Attitude Gyro	AIM	Repair
5040030911	510-24L/LH	Attitude Gyro	AIM	Repair
5040030912	510-24M/MH	Attitude Gyro	AIM	Repair
5040030913	510-24N	Attitude Gyro	AIM	Repair
5040030914	510-24P	Attitude Gyro	AIM	Repair
5040030915	510-24R	Attitude Gyro	AIM	Repair
5040030916	510-24S	Attitude Gyro	AIM	Repair
5040030918	510-24V	Attitude Gyro	AIM	Repair
5040030919	510-24W	Attitude Gyro	AIM	Repair
5040030920	510-24L2	Attitude Gyro	AIM	Repair
5040031901	510-25A	Attitude Gyro	AIM	Repair
5040031902	510-27A	Attitude Gyro	AIM	Repair
5040031903	510-27B	Attitude Gyro	AIM	Repair
5040031904	510-27C	Attitude Gyro	AIM	Repair
5040031906	510-27E	Attitude Gyro	AIM	Repair
5040031907	510-27F	Attitude Gyro	AIM	Repair
5040031908	510-27G	Attitude Gyro	AIM	Repair
5040031909	510-27H	Attitude Gyro	AIM	Repair
5040031910	510-27J	Attitude Gyro	AIM	Repair
5040031911	510-27K	Attitude Gyro	AIM	Repair
5040031912	510-27L	Attitude Gyro	AIM	Repair
5040031913	510-27M	Attitude Gyro	AIM	Repair
5040031914	510-27N	Attitude Gyro	AIM	Repair
5040031915	510-27P	Attitude Gyro	AIM	Repair
5040031916	510-27R	Attitude Gyro	AIM	Repair
5040031917	510-27T	Attitude Gyro	AIM	Repair
5040037901	510-29A/AH	Attitude Gyro	AIM	Repair
5040037902	510-29B/BH	Attitude Gyro	AIM	Repair
5040037903	510-29C/CH	Attitude Gyro	AIM	Repair
5040037904	510-29D/DH	Attitude Gyro	AIM	Repair
5040037905	510-29E	Attitude Gyro	AIM	Repair
5040038902	510-30B	Attitude Gyro	AIM	Repair
5040038903	510-30BK	Attitude Gyro	AIM	Repair
5040038904	510-30BW	Attitude Gyro	AIM	Repair
5040038905	510-30BKW	Attitude Gyro	AIM	Repair
5040038906	510-30C	Attitude Gyro	AIM	Repair
5040038907	510-30D	Attitude Gyro	AIM	Repair
5040038908	510-30DK	Attitude Gyro	AIM	Repair
5040038909	510-30DW	Attitude Gyro	AIM	Repair
5040038910	510-30DKW	Attitude Gyro	AIM	Repair
5040038911	510-30E	Attitude Gyro	AIM	Repair
5040038913	510-30G	Attitude Gyro	AIM	Repair
5040038914	510-30H	Attitude Gyro	AIM	Repair
5040041901	510-31A	Attitude Gyro	AIM	Repair
5040041902	510-31B	Attitude Gyro	AIM	Repair
5040042901	510-32A	Attitude Gyro	AIM	Repair
5040042902	510-32AK	Attitude Gyro	AIM	Repair
5040042903	510-32B	Attitude Gyro	AIM	Repair
5040042904	510-32BK	Attitude Gyro	AIM	Repair
5040042905	510-32C	Attitude Gyro	AIM	Repair
5040043901	510-33A	Attitude Gyro	AIM	Repair
5040044901	510-34A	Attitude Gyro	AIM	Repair
5040045901	510-35A	Attitude Gyro	AIM	Repair
5040045902	510-35B	Attitude Gyro	AIM	Repair
5040045903	510-35C	Attitude Gyro	AIM	Repair
5040045904	510-35D	Attitude Gyro	AIM	Repair
5040046901	510-36A	Attitude Gyro	AIM	Repair
5040048901	510-37A	Attitude Gyro	AIM	Repair
5040048902	510-37B	Attitude Gyro	AIM	Repair
5040048903	510-37C	Attitude Gyro	AIM	Repair
5040051901	510-39A	Attitude Gyro	AIM	Repair
5040052901	510-40A	Attitude Gyro	AIM	Repair
5040053901	510-41A	Attitude Gyro	AIM	Repair
5040057901	510-44A	Attitude Gyro	AIM	Repair
8033100095	RE-800	HF Receiver/Exciter	Sunair Electronics	Repair
8033200090	SCU-80	HF Control Unit	Sunair Electronics	Repair

Part Number	Model	Description	Manufacturer	Capability
8033300094	ACU-810	HF Amplifier/Coupler	Sunair Electronics	Repair
8099300092	ACU-810A	HF Amplifier/Coupler	Sunair Electronics	Repair
011-00280-00	GNS430	GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-00280-10	GNS430	GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-00280-30	GNS430	GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-00295-00	GNC250XL	GPS/COMM Transceiver	Garmin	Limited Repair
011-00401-00	GMA340	Audio Panel	Garmin	Test/Recert
011-00401-01	GMA340H	Audio Panel	Garmin	Test/Recert
011-00401-10	GMA340	Audio Panel	Garmin	Test/Recert
011-00401-20	GMA340	Audio Panel	Garmin	Test/Recert
011-00412-00	GPS155XL	GPS Receiver	Garmin	Limited Repair
011-00455-00	GTX330	Transponder	Garmin	Test/Recert
011-00455-10	GTX330D	Transponder	Garmin	Test/Recert
011-00455-20	GTX330	Transponder	Garmin	Test/Recert
011-00455-30	GTX330D	Transponder	Garmin	Test/Recert
011-00455-60	GTX330	Transponder w/ ES	Garmin	Test/Recert
011-00455-70	GTX330D	Transponder w/ ES	Garmin	Test/Recert
011-00455-80	GTX330	Transponder w/ ES	Garmin	Test/Recert
011-00455-90	GTX330D	Transponder w/ ES	Garmin	Test/Recert
011-00490-00	GTX327	Transponder	Garmin	Test/Recert
011-00490-10	GTX327	Transponder	Garmin	Test/Recert
011-00504-00	GPS400	GPS Receiver	Garmin	Test/Recert
011-00504-10	GPS400	GPS Receiver	Garmin	Test/Recert
011-00506-00	GNC420	GPS/COMM Transceiver	Garmin	Test/Recert
011-00506-10	GNC420	GPS/COMM Transceiver	Garmin	Test/Recert
011-00506-30	GNC420	GPS/COMM Transceiver	Garmin	Test/Recert
011-00550-00	GNS530	GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-00550-10	GNS530	GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-00550-30	GNS530	GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-00562-00	GPS500	GPS Receiver	Garmin	Test/Recert
011-00562-10	GPS500	GPS Receiver	Garmin	Test/Recert
011-00728-00	GTX320A	ATC Transponder	Garmin	Test/Recert
011-00835-00	GNS530A	GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-00835-10	GNS530A	GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-00836-00	GNS430A	GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-00836-10	GNS430A	GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-00837-00	GNC420A	GPS/COMM Transceiver	Garmin	Test/Recert
011-00837-10	GNC420A	GPS/COMM Transceiver	Garmin	Test/Recert
011-01057-00	GPS400W	WAAS/GPS Receiver	Garmin	Test/Recert
011-01057-10	GPS400W	WAAS/GPS Receiver	Garmin	Test/Recert
011-01057-40	GPS400W	WAAS/GPS Receiver	Garmin	Test/Recert
011-01057-50	GPS400W	WAAS/GPS Receiver	Garmin	Test/Recert
011-01058-00	GNC420W	WAAS/GPS/COMM Transceiver	Garmin	Test/Recert
011-01058-10	GNC420W	WAAS/GPS/COMM Transceiver	Garmin	Test/Recert
011-01058-40	GNC420W	WAAS/GPS/COMM Transceiver	Garmin	Test/Recert
011-01058-45	GNC420W	WAAS/GPS/COMM Transceiver	Garmin	Test/Recert
011-01058-50	GNC420W	WAAS/GPS/COMM Transceiver	Garmin	Test/Recert
011-01059-00	GNC420AW	WAAS/GPS/COMM Transceiver	Garmin	Test/Recert
011-01059-10	GNC420AW	WAAS/GPS/COMM Transceiver	Garmin	Test/Recert
011-01059-40	GNC420AW	WAAS/GPS/COMM Transceiver	Garmin	Test/Recert
011-01059-50	GNC420AW	WAAS/GPS/COMM Transceiver	Garmin	Test/Recert
011-01060-00	GNS430W	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01060-10	GNS430W	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01060-40	GNS430W	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01060-45	GNS430W	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01060-50	GNS430W	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01061-00	GNS430AW	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01061-10	GNS430AW	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01061-40	GNS430AW	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01061-50	GNS430AW	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01062-00	GPS500W	WAAS/GPS Receiver	Garmin	Test/Recert
011-01062-10	GPS500W	WAAS/GPS Receiver	Garmin	Test/Recert
011-01062-40	GPS500W	WAAS/GPS Receiver	Garmin	Test/Recert
011-01062-50	GPS500W	WAAS/GPS Receiver	Garmin	Test/Recert
011-01064-00	GNS530W	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01064-10	GNS530W	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert

Part Number	Model	Description	Manufacturer	Capability
011-01064-40	GNS530W	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01064-45	GNS530W	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01064-50	GNS530W	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01066-00	GNS530AW	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01066-10	GNS530AW	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01066-40	GNS530AW	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01066-50	GNS530AW	WAAS/GPS/NAV/COMM Transceiver	Garmin	Test/Recert
011-01684-00	GTX328	Transponder	Garmin	Test/Recert
011-02254-00	GTN625	WAAS/GPS Multifunction Display	Garmin	Test/Recert
011-02255-00	GTN635	WAAS/GPS/COMM Multifunction Display	Garmin	Test/Recert
011-02256-00	GTN650	WAAS/GPS/NAV/COMM Multifunction Display	Garmin	Test/Recert
011-02256-50	GTN650	WAAS/GPS/NAV/COMM Multifunction Display	Garmin	Test/Recert
011-02256-A0	GTN650	WAAS/GPS/NAV/COMM Multifunction Display	Garmin	Test/Recert
011-02281-00	GTN725	WAAS/GPS Multifunction Display	Garmin	Test/Recert
011-02282-00	GTN750	WAAS/GPS/NAV/COMM Multifunction Display	Garmin	Test/Recert
011-02282-50	GTN750	WAAS/GPS/NAV/COMM Multifunction Display	Garmin	Test/Recert
011-02282-A0	GTN750	WAAS/GPS/NAV/COMM Multifunction Display	Garmin	Test/Recert
011-02718-00	GTR225	VHF COMM Transceiver	Garmin	Test/Recert
011-02718-40	GTR225	VHF COMM Transceiver	Garmin	Test/Recert
011-02719-00	GNC255B	VHF NAV/COMM Transceiver	Garmin	Test/Recert
011-02719-20	GNC255B	VHF NAV/COMM Transceiver	Garmin	Test/Recert
011-02719-40	GNC255B	VHF NAV/COMM Transceiver	Garmin	Test/Recert
011-02719-60	GNC255B	VHF NAV/COMM Transceiver	Garmin	Test/Recert
011-02806-00	GNC255A	VHF NAV/COMM Transceiver	Garmin	Test/Recert
011-02806-40	GNC255A	VHF NAV/COMM Transceiver	Garmin	Test/Recert
011-02807-00	GTR225A	VHF COMM Transceiver	Garmin	Test/Recert
011-02807-40	GTR225A	VHF COMM Transceiver	Garmin	Test/Recert
011-02808-00	GTR225B	VHF COMM Transceiver	Garmin	Test/Recert
011-02808-20	GTR225B	VHF COMM Transceiver	Garmin	Test/Recert
011-02808-40	GTR225B	VHF COMM Transceiver	Garmin	Test/Recert
011-02808-60	GTR225B	VHF COMM Transceiver	Garmin	Test/Recert
03118-0300	MK-12D	NAV/COMM Radio (14V, No GS)	Narco	Repair
03118-0301	MK-12D	NAV/COMM Radio (14V, with GS)	Narco	Repair
03118-0302	MK-12D	NAV/COMM Radio (28V, No GS)	Narco	Repair
03118-0303	MK-12D	NAV/COMM Radio (28V, with GS)	Narco	Repair
03118-0316	MK-12D	NAV/COMM Radio (Cessna Version)	Narco	Repair
03118-300	MK-12D	NAV/COMM Radio (14V, No GS)	Narco	Repair
03118-301	MK-12D	NAV/COMM Radio (14V, with GS)	Narco	Repair
03118-302	MK-12D	NAV/COMM Radio (28V, No GS)	Narco	Repair
03118-303	MK-12D	NAV/COMM Radio (28V, with GS)	Narco	Repair
03118-316	MK-12D	NAV/COMM Radio (Cessna Version)	Narco	Repair
031216-1	TFM-530	VHF/VLO FM Transceiver	Technisonic	Repair
031216-1 (5V)	TFM-530	VHF/VLO FM Transceiver	Technisonic	Repair
031216-2	TFM-530	VHF/VLO FM Transceiver	Technisonic	Repair
031216-2 (5V)	TFM-530	VHF/VLO FM Transceiver	Technisonic	Repair
031216-3	TFM-530	VHF/VLO FM Transceiver	Technisonic	Repair
031216-3 (5V)	TFM-530	VHF/VLO FM Transceiver	Technisonic	Repair
031216-4	TFM-530	VHF/VLO FM Transceiver	Technisonic	Repair
031216-4 (5V)	TFM-530	VHF/VLO FM Transceiver	Technisonic	Repair
0376.299-921	JB3100-(1)	Junction Box	Becker	Repair
0387.843-921	AS3100-(12)	Audio Panel	Becker	Repair
0387.851-921	IC3100-(4)	Intercom Amplifier	Becker	Repair
0432.377-921	IC3100-(2)	Intercom Amplifier	Becker	Repair
0501.697-921	AS3100-(12)-12	Audio Panel	Becker	Repair
0511.129-915	ATC3401-110	Transponder	Becker	Repair
0511.137-915	ATC3401-010	Transponder	Becker	Repair
0511.145-915	ATC3401-111	Transponder	Becker	Repair
0511.153-915	ATC3401-011	Transponder	Becker	Repair
0511.986-910	AR3202-(2)-111	VHF Transceiver	Becker	Repair
0511.994-910	AR3202-(2)-011	VHF Transceiver	Becker	Repair
0514.187-910	AR3202-(1)-110	VHF Transceiver	Becker	Repair
0514.195-910	AR3202-(1)-010	VHF Transceiver	Becker	Repair
0515.337-910	AR3202-(1)-110CIG	VHF Transceiver	Becker	Repair
0515.663-921	AS3100-(12)-13	Audio Panel	Becker	Repair
0525.731-921	AS3100-(12N)-11	Audio Panel	Becker	Repair
0547.972-915	ATC4401-1	ATC Transponder	Becker	Repair

Part Number	Model	Description	Manufacturer	Capability
0547.980-915	ATC4401-1	ATC Transponder	Becker	Repair
0559.563-921	IC3100-(2)-01	Intercom Amplifier	Becker	Repair
0559.571-921	IC3100-(4)-01	Intercom Amplifier	Becker	Repair
056-0020-01	RCA60-02	Turn & Slip Indicator	RC Allen	Repair
056-0020-02	RCA60-03	Turn & Slip Indicator	RC Allen	Repair
056-0020-03	RCA60-04	Turn & Slip Indicator	RC Allen	Repair
056-0021-01	RCA60-01	Turn & Slip Indicator	RC Allen	Repair
056-0023-03	RCA56-5	Turn & Bank Indicator	RC Allen	Repair
056-0023-06	RCA56-8	Turn & Bank Indicator	RC Allen	Repair
056-0023-07	RCA56-9	Turn & Bank Indicator	RC Allen	Repair
056-0024-01	RCA56-11	Turn & Bank Indicator	RC Allen	Repair
056-0024-02	RCA56-3WL	Turn & Bank Indicator	RC Allen	Repair
056-0024-02	RCA56-3L	Turn & Bank Indicator	RC Allen	Repair
056-0024-02	RCA56-3BL	Turn & Bank Indicator	RC Allen	Repair
056-0024-03	RCA56-3W	Turn & Bank Indicator	RC Allen	Repair
056-0024-03	RCA56-3B	Turn & Bank Indicator	RC Allen	Repair
056-0024-03	RCA56-3	Turn & Bank Indicator	RC Allen	Repair
056-0024-04	RCA56-12	Turn & Bank Indicator	RC Allen	Repair
056-0024-05	RCA56-13BL	Turn & Bank Indicator	RC Allen	Repair
056-0024-06	RCA56-13B	Turn & Bank Indicator	RC Allen	Repair
060-00015-0000	KG102A	Directional Gyro	Bendix/King	Repair
060-00015-0001	KG102A	Directional Gyro	Bendix/King	Repair
060-00015-0002	KG102A	Directional Gyro	Bendix/King	Repair
060-00017-0000	KI256	Flight Command Indicator (0° Tilt)	Bendix/King	Repair
060-00017-0001	KI256	Flight Command Indicator (8° Tilt)	Bendix/King	Repair
060-0015-00	KG102A	Directional Gyro	Bendix/King	Repair
060-0015-01	KG102A	Directional Gyro	Bendix/King	Repair
060-0015-02	KG102A	Directional Gyro	Bendix/King	Repair
060-0017-00	KI256	Flight Command Indicator (0° Tilt)	Bendix/King	Repair
060-0017-01	KI256	Flight Command Indicator (8° Tilt)	Bendix/King	Repair
060-0020-01	KG258	Horizon Gyro	Bendix/King	Repair
060-0020-02	KG258	Horizon Gyro	Bendix/King	Repair
060-0020-03	KG258	Horizon Gyro	Bendix/King	Repair
060-0020-04	KG258	Horizon Gyro	Bendix/King	Repair
060-0020-05	KG258	Horizon Gyro	Bendix/King	Repair
060-0020-06	KG258	Horizon Gyro	Bendix/King	Repair
060-0020-07	KG258	Horizon Gyro	Bendix/King	Repair
060-0020-08	KG258	Horizon Gyro	Bendix/King	Repair
060-0020-09	KG258	Horizon Gyro	Bendix/King	Repair
060-0020-10	KG258	Horizon Gyro	Bendix/King	Repair
060-0020-11	KG258	Horizon Gyro	Bendix/King	Repair
060-0020-12	KG258	Horizon Gyro	Bendix/King	Repair
0601.349-921	AS3100-(12)-14	Audio Panel	Becker	Repair
0607.797-921	IC3100-(9)-01	Intercom Amplifier	Becker	Repair
0618.608-921	IC3100-(10)-01	Intercom Amplifier	Becker	Repair
063-01007-0000	KTR 993	HF Transceiver	Bendix/King	Repair
063-1007-00	KTR 993	HF Transceiver	Bendix/King	Repair
064-01015-0000	KTR953	Receiver/Exciter	Bendix/King	Repair
064-01015-0001	KTR953	Receiver/Exciter	Bendix/King	Repair
064-01015-0010	KTR953	Receiver/Exciter	Bendix/King	Repair
064-01015-0011	KTR953	Receiver/Exciter	Bendix/King	Repair
064-01015-0040	KTR953	Receiver/Exciter	Bendix/King	Repair
064-01015-0041	KTR953	Receiver/Exciter	Bendix/King	Repair
064-01015-0051	KTR953	Receiver/Exciter	Bendix/King	Repair
064-01015-0053	KTR953	Receiver/Exciter	Bendix/King	Repair
064-01016-0000	KCU951	HF Control Unit	Bendix/King	Repair
064-01016-0001	KCU951	HF Control Unit	Bendix/King	Repair
064-01016-0002	KCU951	HF Control Unit	Bendix/King	Repair
064-01016-0003	KCU951	HF Control Unit	Bendix/King	Repair
064-01016-0004	KCU951	HF Control Unit	Bendix/King	Repair
064-01017-0000	KAC952	Power Amplifier/Antenna Coupler	Bendix/King	Repair
064-01017-0001	KAC952	Power Amplifier/Antenna Coupler	Bendix/King	Repair
064-01017-0002	KAC952	Power Amplifier/Antenna Coupler	Bendix/King	Repair
064-01019-0000	KY196	VHF Comm Transceiver	Bendix/King	Repair
064-01019-0001	KY196E	VHF Comm Transceiver	Bendix/King	Repair
064-01019-0002	KY196	VHF Comm Transceiver	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
064-01019-0005	KY196	VHF Comm Transceiver	Bendix/King	Repair
064-01019-0006	KY196E	VHF Comm Transceiver	Bendix/King	Repair
064-01019-0007	KY196	VHF Comm Transceiver	Bendix/King	Repair
064-01019-0010	KY196	VHF Comm Transceiver	Bendix/King	Repair
064-01019-0011	KY196E	VHF Comm Transceiver	Bendix/King	Repair
064-01019-0012	KY196	VHF Comm Transceiver	Bendix/King	Repair
064-01019-0020	KY196	VHF Comm Transceiver	Bendix/King	Repair
064-01021-0000	KY197	VHF Comm Transceiver	Bendix/King	Repair
064-01021-0001	KY197E	VHF Comm Transceiver	Bendix/King	Repair
064-01021-0005	KY197	VHF Comm Transceiver	Bendix/King	Repair
064-01021-0006	KY197E	VHF Comm Transceiver	Bendix/King	Repair
064-01021-0010	KY197	VHF Comm Transceiver	Bendix/King	Repair
064-01021-0011	KY197E	VHF Comm Transceiver	Bendix/King	Repair
064-01021-0020	KY197	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0000	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0001	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0002	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0003	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0004	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0005	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0006	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0007	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0008	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0009	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0010	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0011	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0012	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0013	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0014	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01023-0015	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-01051-0070	KY97A	VHF Comm Transceiver	Bendix/King	Repair
064-01052-0070	KY96A	VHF Comm Transceiver	Bendix/King	Repair
064-01053-0030	KY197A	VHF Comm Transceiver	Bendix/King	Repair
064-01053-0031	KY197A	VHF Comm Transceiver	Bendix/King	Repair
064-01053-0032	KY197A	VHF Comm Transceiver	Bendix/King	Repair
064-01053-0060	KY197A	VHF Comm Transceiver (Silver Crown Plus)	Bendix/King	Repair
064-01054-0030	KY196A	VHF Comm Transceiver	Bendix/King	Repair
064-01054-0031	KY196A	VHF Comm Transceiver	Bendix/King	Repair
064-01054-0032	KY196A	VHF Comm Transceiver	Bendix/King	Repair
064-01054-0050	KY196A	VHF Comm Transceiver (CNI-5000)	Bendix/King	Repair
064-01054-0060	KY196A	VHF Comm Transceiver (Silver Crown Plus)	Bendix/King	Repair
064-1009-00	KTR905	VHF Comm Transceiver	Bendix/King	Repair
064-1009-01	KTR905	VHF Comm Transceiver	Bendix/King	Repair
064-1009-02	KTR905	VHF Comm Transceiver	Bendix/King	Repair
064-1009-03	KTR905	VHF Comm Transceiver	Bendix/King	Repair
064-1015-00	KTR953	Receiver/Exciter	Bendix/King	Repair
064-1015-01	KTR953	Receiver/Exciter	Bendix/King	Repair
064-1015-10	KTR953	Receiver/Exciter	Bendix/King	Repair
064-1015-11	KTR953	Receiver/Exciter	Bendix/King	Repair
064-1015-40	KTR953	Receiver/Exciter	Bendix/King	Repair
064-1015-41	KTR953	Receiver/Exciter	Bendix/King	Repair
064-1015-51	KTR953	Receiver/Exciter	Bendix/King	Repair
064-1015-53	KTR953	Receiver/Exciter	Bendix/King	Repair
064-1016-00	KCU951	HF Control Unit	Bendix/King	Repair
064-1016-01	KCU951	HF Control Unit	Bendix/King	Repair
064-1016-02	KCU951	HF Control Unit	Bendix/King	Repair
064-1016-03	KCU951	HF Control Unit	Bendix/King	Repair
064-1016-04	KCU951	HF Control Unit	Bendix/King	Repair
064-1017-00	KAC952	Power Amplifier/Antenna Coupler	Bendix/King	Repair
064-1017-01	KAC952	Power Amplifier/Antenna Coupler	Bendix/King	Repair
064-1017-02	KAC952	Power Amplifier/Antenna Coupler	Bendix/King	Repair
064-1019-00	KY196	VHF Comm Transceiver	Bendix/King	Repair
064-1019-01	KY196E	VHF Comm Transceiver	Bendix/King	Repair
064-1019-02	KY196	VHF Comm Transceiver	Bendix/King	Repair
064-1019-05	KY196	VHF Comm Transceiver	Bendix/King	Repair
064-1019-06	KY196E	VHF Comm Transceiver	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
064-1019-07	KY196	VHF Comm Transceiver	Bendix/King	Repair
064-1019-10	KY196	VHF Comm Transceiver	Bendix/King	Repair
064-1019-11	KY196E	VHF Comm Transceiver	Bendix/King	Repair
064-1019-12	KY196	VHF Comm Transceiver	Bendix/King	Repair
064-1019-20	KY196	VHF Comm Transceiver	Bendix/King	Repair
064-1020-00	KY92	VHF Comm Transceiver	Bendix/King	Repair
064-1020-01	KY92	VHF Comm Transceiver	Bendix/King	Repair
064-1020-03	KY92	VHF Comm Transceiver	Bendix/King	Repair
064-1020-04	KY92	VHF Comm Transceiver	Bendix/King	Repair
064-1021-00	KY197	VHF Comm Transceiver	Bendix/King	Repair
064-1021-01	KY197E	VHF Comm Transceiver	Bendix/King	Repair
064-1021-05	KY197	VHF Comm Transceiver	Bendix/King	Repair
064-1021-06	KY197E	VHF Comm Transceiver	Bendix/King	Repair
064-1021-10	KY197	VHF Comm Transceiver	Bendix/King	Repair
064-1021-11	KY197E	VHF Comm Transceiver	Bendix/King	Repair
064-1021-20	KY197	VHF Comm Transceiver	Bendix/King	Repair
064-1023-00	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1023-01	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1023-02	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1023-03	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1023-04	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1023-05	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1023-06	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1023-07	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1023-08	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1023-09	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1023-10	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1023-11	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1023-12	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1023-13	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1023-14	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1023-15	KTR908	VHF Comm Transceiver	Bendix/King	Repair
064-1051-10	KY97A	VHF Comm Transceiver	Bendix/King	Repair
064-1051-11	KY97A	VHF Comm Transceiver	Bendix/King	Repair
064-1051-30	KY97A	VHF Comm Transceiver	Bendix/King	Repair
064-1051-31	KY97A	VHF Comm Transceiver	Bendix/King	Repair
064-1051-50	KY97A	VHF Comm Transceiver	Bendix/King	Repair
064-1051-51	KY97A	VHF Comm Transceiver	Bendix/King	Repair
064-1051-60	KY97A	VHF Comm Transceiver	Bendix/King	Repair
064-1051-61	KY97A	VHF Comm Transceiver	Bendix/King	Repair
064-1051-70	KY97A	VHF Comm Transceiver	Bendix/King	Repair
064-1052-10	KY96A	VHF Comm Transceiver	Bendix/King	Repair
064-1052-11	KY96A	VHF Comm Transceiver	Bendix/King	Repair
064-1052-30	KY96A	VHF Comm Transceiver	Bendix/King	Repair
064-1052-31	KY96A	VHF Comm Transceiver	Bendix/King	Repair
064-1052-50	KY96A	VHF Comm Transceiver	Bendix/King	Repair
064-1052-51	KY96A	VHF Comm Transceiver	Bendix/King	Repair
064-1052-60	KY96A	VHF Comm Transceiver	Bendix/King	Repair
064-1052-61	KY96A	VHF Comm Transceiver	Bendix/King	Repair
064-1052-70	KY96A	VHF Comm Transceiver	Bendix/King	Repair
064-1053-30	KY197A	VHF Comm Transceiver	Bendix/King	Repair
064-1053-31	KY197A	VHF Comm Transceiver	Bendix/King	Repair
064-1053-32	KY197A	VHF Comm Transceiver	Bendix/King	Repair
064-1053-60	KY197A	VHF Comm Transceiver (Silver Crown Plus)	Bendix/King	Repair
064-1054-30	KY196A	VHF Comm Transceiver	Bendix/King	Repair
064-1054-31	KY196A	VHF Comm Transceiver	Bendix/King	Repair
064-1054-32	KY196A	VHF Comm Transceiver	Bendix/King	Repair
064-1054-50	KY196A	VHF Comm Transceiver (CNI-5000)	Bendix/King	Repair
064-1054-60	KY196A	VHF Comm Transceiver (Silver Crown Plus)	Bendix/King	Repair
065-00184-0100	KA285A	Remote Mode Annunciator	Bendix/King	Repair
065-0027-01	KS270	Pitch Servo	Bendix/King	Repair
065-0027-02	KS270	Pitch Servo	Bendix/King	Repair
065-0027-03	KS270	Pitch Servo	Bendix/King	Repair
065-0027-04	KS270	Pitch Servo	Bendix/King	Repair
065-0027-05	KS270	Pitch Servo	Bendix/King	Repair
065-0027-06	KS270	Pitch Servo	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
065-0028-00	KS271	Primary Servo	Bendix/King	Repair
065-0028-01	KS271	Primary Servo	Bendix/King	Repair
065-0028-02	KS271	Primary Servo	Bendix/King	Repair
065-0028-03	KS271	Primary Servo	Bendix/King	Repair
065-0028-04	KS271	Primary Servo	Bendix/King	Repair
065-0028-05	KS271	Primary Servo	Bendix/King	Repair
065-0029-01	KS272	Trim Servo	Bendix/King	Repair
065-0029-02	KS272	Trim Servo	Bendix/King	Repair
065-0029-03	KS272	Trim Servo	Bendix/King	Repair
065-0029-04	KS272	Trim Servo	Bendix/King	Repair
065-0029-05	KS272	Trim Servo	Bendix/King	Repair
065-0029-06	KS272	Trim Servo	Bendix/King	Repair
065-0029-07	KS272	Trim Servo	Bendix/King	Repair
065-0029-08	KS272	Trim Servo	Bendix/King	Repair
065-0029-09	KS272	Trim Servo	Bendix/King	Repair
065-0029-10	KS272	Trim Servo	Bendix/King	Repair
065-0029-11	KS272	Trim Servo	Bendix/King	Repair
065-0029-12	KS272	Trim Servo	Bendix/King	Repair
065-0029-13	KS272	Trim Servo	Bendix/King	Repair
065-0029-14	KS272	Trim Servo	Bendix/King	Repair
065-0029-15	KS272	Trim Servo	Bendix/King	Repair
065-0029-16	KS272	Trim Servo	Bendix/King	Repair
065-0029-17	KS272	Trim Servo	Bendix/King	Repair
065-0029-18	KS272	Trim Servo	Bendix/King	Repair
065-0029-19	KS272	Trim Servo	Bendix/King	Repair
065-0029-20	KS272	Trim Servo	Bendix/King	Repair
065-0029-21	KS272	Trim Servo	Bendix/King	Repair
065-0029-22	KS272	Trim Servo	Bendix/King	Repair
065-0029-23	KS272	Trim Servo	Bendix/King	Repair
065-0029-24	KS272	Trim Servo	Bendix/King	Repair
065-0029-25	KS272	Trim Servo	Bendix/King	Repair
065-0029-26	KS272	Trim Servo	Bendix/King	Repair
065-0029-27	KS272	Trim Servo	Bendix/King	Repair
065-0029-29	KS272	Trim Servo	Bendix/King	Repair
065-0029-30	KS272	Trim Servo	Bendix/King	Repair
065-0029-31	KS272	Trim Servo	Bendix/King	Repair
065-0029-32	KS272	Trim Servo	Bendix/King	Repair
065-0029-33	KS272	Trim Servo	Bendix/King	Repair
065-0029-34	KS272	Trim Servo	Bendix/King	Repair
065-0029-35	KS272	Trim Servo	Bendix/King	Repair
065-0029-36	KS272	Trim Servo	Bendix/King	Repair
065-0029-37	KS272	Trim Servo	Bendix/King	Repair
065-0029-38	KS272	Trim Servo	Bendix/King	Repair
065-0029-39	KS272	Trim Servo	Bendix/King	Repair
065-0029-40	KS272	Trim Servo	Bendix/King	Repair
065-0030-00	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-02	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-20	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-21	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-22	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-23	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-24	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-25	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-26	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-27	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-28	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-29	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-30	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-31	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-32	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-33	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-34	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-35	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-36	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-37	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-38	KM275	Servo Mount, Primary	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
065-0030-39	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-40	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-41	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0030-42	KM275	Servo Mount, Primary	Bendix/King	Repair
065-0031-00	KM276	Servo Mount, Trim	Bendix/King	Repair
065-0031-01	KM276	Servo Mount, Trim	Bendix/King	Repair
065-0031-02	KM276	Servo Mount, Trim	Bendix/King	Repair
065-0031-03	KM276	Servo Mount, Trim	Bendix/King	Repair
065-0031-04	KM276	Servo Mount, Trim	Bendix/King	Repair
065-0031-20	KM276	Servo Mount, Trim	Bendix/King	Repair
065-0031-21	KM276	Servo Mount, Trim	Bendix/King	Repair
065-0031-22	KM276	Servo Mount, Trim	Bendix/King	Repair
065-0031-23	KM276	Servo Mount, Trim	Bendix/King	Repair
065-0031-24	KM276	Servo Mount, Trim	Bendix/King	Repair
065-0032-00	KA285	Annunciator Panel	Bendix/King	Repair
065-0032-01	KA285	Annunciator Panel	Bendix/King	Repair
065-0033-00	KC290	Autopilot Mode Controller	Bendix/King	Repair
065-0033-01	KC290	Autopilot Mode Controller	Bendix/King	Repair
065-0033-02	KC290	Autopilot Mode Controller	Bendix/King	Repair
065-0034-00	KC295	Flight Computer	Bendix/King	Repair
065-0034-01	KC295	Flight Computer	Bendix/King	Repair
065-0034-02	KC295	Flight Computer	Bendix/King	Repair
065-0034-03	KC295	Flight Computer	Bendix/King	Repair
065-0034-04	KC295	Flight Computer	Bendix/King	Repair
065-0034-05	KC295	Flight Computer	Bendix/King	Repair
065-0034-06	KC295	Flight Computer	Bendix/King	Repair
065-0034-07	KC295	Flight Computer	Bendix/King	Repair
065-0034-08	KC295	Flight Computer	Bendix/King	Repair
065-0034-09	KC295	Flight Computer	Bendix/King	Repair
065-0034-10	KC295	Flight Computer	Bendix/King	Repair
065-0034-11	KC295	Flight Computer	Bendix/King	Repair
065-0034-12	KC295	Flight Computer	Bendix/King	Repair
065-0034-13	KC295	Flight Computer	Bendix/King	Repair
065-0034-14	KC295	Flight Computer	Bendix/King	Repair
065-0034-15	KC295	Flight Computer	Bendix/King	Repair
065-0034-16	KC295	Flight Computer	Bendix/King	Repair
065-0034-17	KC295	Flight Computer	Bendix/King	Repair
065-0035-00	KC291	Yaw Controller	Bendix/King	Repair
065-0035-01	KC291	Yaw Controller	Bendix/King	Repair
065-0036-00	KC296	Yaw Computer	Bendix/King	Repair
065-0036-01	KC296	Yaw Computer	Bendix/King	Repair
065-0037-00	KC292	Autopilot Mode Controller	Bendix/King	Repair
065-0037-01	KC292	Autopilot Mode Controller	Bendix/King	Repair
065-0041-00	KM277	Servo Mount, Pitch	Bendix/King	Repair
065-0041-01	KM277	Servo Mount, Pitch	Bendix/King	Repair
065-0041-02	KM277	Servo Mount, Pitch	Bendix/King	Repair
065-0046-00	KAS297	Altitude Selector	Bendix/King	Repair
065-0046-01	KAS297	Altitude Selector	Bendix/King	Repair
065-0046-02	KAS297	Altitude Selector	Bendix/King	Repair
065-0046-03	KAS297	Altitude Selector	Bendix/King	Repair
065-0046-04	KAS297	Altitude Selector	Bendix/King	Repair
065-0046-05	KAS297	Altitude Selector	Bendix/King	Repair
065-0053-00	KAS297A	Altitude Selector/Alerter	Bendix/King	Repair
065-0053-01	KAS297A	Altitude Selector/Alerter	Bendix/King	Repair
065-0053-02	KAS297A	Altitude Selector/Alerter	Bendix/King	Repair
065-0053-03	KAS297A	Altitude Selector/Alerter	Bendix/King	Repair
065-0053-04	KAS297A	Altitude Selector/Alerter	Bendix/King	Repair
065-0053-05	KAS297A	Altitude Selector/Alerter	Bendix/King	Repair
065-0053-06	KAS297A	Altitude Selector/Alerter	Bendix/King	Repair
065-0053-07	KAS297A	Altitude Selector/Alerter	Bendix/King	Repair
065-0053-08	KAS297A	Altitude Selector/Alerter	Bendix/King	Repair
065-0053-09	KAS297A	Altitude Selector/Alerter	Bendix/King	Repair
065-0058-00	KA185	Annunciator Panel	Bendix/King	Repair
065-0058-01	KA185	Annunciator Panel	Bendix/King	Repair
065-0059-01	KS270A	Pitch Servo	Bendix/King	Repair
065-0059-02	KS270A	Pitch Servo	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
065-0059-03	KS270A	Pitch Servo	Bendix/King	Repair
065-0059-04	KS270A	Pitch Servo	Bendix/King	Repair
065-0059-05	KS270A	Pitch Servo	Bendix/King	Repair
065-0059-06	KS270A	Pitch Servo	Bendix/King	Repair
065-0059-07	KS270A	Pitch Servo	Bendix/King	Repair
065-0059-08	KS270A	Pitch Servo	Bendix/King	Repair
065-0060-00	KS271A	Primary Servo	Bendix/King	Test/Recert
065-0060-01	KS271A	Primary Servo	Bendix/King	Test/Recert
065-0060-02	KS271A	Primary Servo	Bendix/King	Test/Recert
065-0060-03	KS271A	Primary Servo	Bendix/King	Test/Recert
065-0060-04	KS271A	Primary Servo	Bendix/King	Test/Recert
065-0060-05	KS271A	Primary Servo	Bendix/King	Test/Recert
065-0060-09	KS271A	Primary Servo	Bendix/King	Test/Recert
065-0060-60	KS271A	Primary Servo	Bendix/King	Test/Recert
065-0060-61	KS271A	Primary Servo	Bendix/King	Test/Recert
065-0061-01	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-02	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-03	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-04	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-05	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-06	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-07	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-08	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-09	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-10	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-11	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-12	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-13	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-14	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-15	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-16	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-17	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-18	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-19	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-20	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-21	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-22	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-23	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-24	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-25	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-26	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-27	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-29	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-30	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-31	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-32	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-33	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-34	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-35	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-36	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-37	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-38	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-39	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-40	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-41	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-42	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-43	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-50	KS272A	Trim Servo	Bendix/King	Test/Recert
065-0061-51	KS272A	Trim Servo	Bendix/King	Test/Recert
066-01021-0000	KR21	Marker Beacon Receiver	Bendix/King	Repair
066-01021-0001	KR21	Marker Beacon Receiver	Bendix/King	Repair
066-01044-0000	KMR675	Marker Beacon Receiver	Bendix/King	Repair
066-01044-0001	KMR675	Marker Beacon Receiver	Bendix/King	Repair
066-01055-0000	KMA24	Audio Panel/Marker Receiver	Bendix/King	Repair
066-01055-0001	KMA24	Audio Panel/Marker Receiver	Bendix/King	Repair
066-01055-0002	KMA24	Audio Panel/Marker Receiver	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
066-01055-0003	KMA24	Audio Panel/Marker Receiver	Bendix/King	Repair
066-01055-0050	KMA24H	Audio Panel	Bendix/King	Repair
066-01055-0051	KMA24H	Audio Panel	Bendix/King	Repair
066-01055-0052	KMA24H	Audio Panel	Bendix/King	Repair
066-01055-0053	KMA24H	Audio Panel	Bendix/King	Repair
066-01055-0054	KMA24H	Audio Panel	Bendix/King	Repair
066-01055-0065	KMA24H	Audio Panel	Bendix/King	Repair
066-01055-0066	KMA24H	Audio Panel	Bendix/King	Repair
066-01055-0067	KMA24H	Audio Panel	Bendix/King	Repair
066-01055-0068	KMA24H	Audio Panel	Bendix/King	Repair
066-01055-0070	KMA24H	Audio Panel	Bendix/King	Repair
066-01055-0071	KMA24H	Audio Panel	Bendix/King	Repair
066-01061-0001	KRA10	Radar Altimeter	Bendix/King	Repair
066-01061-0003	KRA10A	Radar Altimeter	Bendix/King	Repair
066-01062-0000	KT76A	Transponder (White Lighting)	Bendix/King	Repair
066-01062-0001	KT78A	Transponder	Bendix/King	Repair
066-01062-0002	KT76A	Transponder (Blue/White Lighting)	Bendix/King	Repair
066-01062-0010	KT76A	Transponder (Crown Version)	Bendix/King	Repair
066-01063-0000	KN75	Glideslop Receiver	Bendix/King	Repair
066-01064-0000	KN62	DME Transceiver	Bendix/King	Repair
066-01066-0000	KDM706	DME Transceiver	Bendix/King	Repair
066-01066-0001	KDM706	DME Transceiver	Bendix/King	Repair
066-01066-0002	KDM706	DME Transceiver	Bendix/King	Repair
066-01066-0041	KDM706	DME Transceiver	Bendix/King	Repair
066-01067-0000	KN53	VHF Nav Receiver w/ Glideslope	Bendix/King	Repair
066-01067-0001	KN53	VHF Nav Receiver w/o Glideslope	Bendix/King	Repair
066-01067-0002	KN53	VHF Nav Receiver w/ Glideslope	Bendix/King	Repair
066-01067-0003	KN53	VHF Nav Receiver w/o Glideslope	Bendix/King	Repair
066-01067-0004	KN53	VHF Nav Receiver w/ Glideslope (CNI-5000)	Bendix/King	Repair
066-01067-0005	KN53	VHF Nav Receiver w/o Glideslope (CNI-5000)	Bendix/King	Repair
066-01067-0010	KN53	VHF Nav Receiver w/ Glideslope (Silver Crown Plus)	Bendix/King	Repair
066-01068-0000	KN62A	DME Transceiver	Bendix/King	Repair
066-01068-0001	KN62A	DME Transceiver	Bendix/King	Repair
066-01068-0004	KN62A	DME Transceiver (Silver Crown Plus)	Bendix/King	Repair
066-01069-0000	KDI572	DME Indicator	Bendix/King	Repair
066-01069-0001	KDI572	DME Indicator	Bendix/King	Repair
066-01069-0002	KDI573	DME Slave Indicator	Bendix/King	Repair
066-01069-0003	KDI573	DME Slave Indicator	Bendix/King	Repair
066-01069-0004	KDI574	DME Indicator	Bendix/King	Repair
066-01069-0005	KDI574	DME Indicator	Bendix/King	Repair
066-01069-0007	KDI572	Bench Test Unit (Not for Aircraft Use)	Bendix/King	Repair
066-01069-0008	KDI572	DME Indicator	Bendix/King	Repair
066-01069-0009	KDI573	DME Slave Indicator	Bendix/King	Repair
066-01069-0010	KDI573	DME Slave Indicator	Bendix/King	Repair
066-01069-0011	KDI574	DME Indicator	Bendix/King	Repair
066-01069-0012	KDI574	DME Indicator	Bendix/King	Repair
066-01069-0013	KDI574	DME Indicator (Sierra Version)	Bendix/King	Repair
066-01069-0014	KDI574	DME Indicator	Bendix/King	Repair
066-01069-0015	KDI572	DME Indicator	Bendix/King	Repair
066-01070-0000	KN63	DME Transceiver	Bendix/King	Repair
066-01070-0001	KN63	DME Transceiver	Bendix/King	Repair
066-01071-0000	KXP756	Transponder	Bendix/King	Repair
066-01072-0000	KR87	ADF Receiver	Bendix/King	Repair
066-01072-0001	KR87	ADF Receiver	Bendix/King	Repair
066-01072-0002	KR87	ADF Receiver	Bendix/King	Repair
066-01072-0003	KR87	ADF Receiver	Bendix/King	Repair
066-01072-0004	KR87	ADF Receiver	Bendix/King	Repair
066-01072-0005	KR87	ADF Receiver	Bendix/King	Repair
066-01072-0006	KR87	ADF Receiver	Bendix/King	Repair
066-01072-0007	KR87	ADF Receiver	Bendix/King	Repair
066-01072-0014	KR87	ADF Receiver	Bendix/King	Repair
066-01072-0015	KR87	ADF Receiver	Bendix/King	Repair
066-01072-0017	KR87	ADF Receiver	Bendix/King	Repair
066-01077-0000	KDF806	ADF Receiver	Bendix/King	Repair
066-01077-0001	KDF806	ADF Receiver	Bendix/King	Repair
066-01088-0000	KN64	DME Transceiver	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
066-01088-0001	KN64	DME Transceiver (Silver Crown Plus)	Bendix/King	Repair
066-01141-0101	KT70	ATC Mode S Transponder	Bendix/King	Repair
066-01141-0201	KT70	ATC Mode S Transponder	Bendix/King	Repair
066-01141-1101	KT70	ATC Mode S Transponder	Bendix/King	Repair
066-01148-0101	KLN89B	GPS Receiver	Bendix/King	Limited Repair
066-01148-0102	KLN89B	GPS Receiver	Bendix/King	Limited Repair
066-01148-1111	KLN89	GPS Receiver	Bendix/King	Limited Repair
066-01148-1112	KLN89	GPS Receiver	Bendix/King	Limited Repair
066-01153-0101	KRA405B	Radar Altimeter	Bendix/King	Repair
066-01153-0202	KRA405B	Radar Altimeter	Bendix/King	Repair
066-01153-2001	KRA405B	Radar Altimeter	Bendix/King	Repair
066-01153-4001	KRA405B	Radar Altimeter	Bendix/King	Repair
066-01153-5001	KRA405B	Radar Altimeter	Bendix/King	Repair
066-01155-0101	KMA26	Audio Panel	Bendix/King	Repair
066-01155-0201	KMA26	Audio Panel	Bendix/King	Repair
066-01156-0101	KT76C	ATC Transponder	Bendix/King	Repair
066-01156-0201	KT76C	ATC Transponder	Bendix/King	Repair
066-01174-0101	KMD150	Multifunction Display	Bendix/King	Repair
066-01174-0201	KMD150	Multifunction Display	Bendix/King	Repair
066-01176-0101	KMA28	Audio Panel	Bendix/King	Test/Recert
066-03012-0000	KA35	Marker Light Assembly	Bendix/King	Repair
066-03012-0001	KA35A	Marker Light Assembly	Bendix/King	Repair
066-03031-0000	KNI415	Rad Alt Indicator	Honeywell	Repair
066-03031-0001	KNI415	Rad Alt Indicator	Honeywell	Repair
066-03031-0002	KNI415	Rad Alt Indicator	Honeywell	Repair
066-03031-0003	KNI415	Rad Alt Indicator	Honeywell	Repair
066-03034-0000	KI203	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-03034-0001	KI203	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-03034-0002	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0003	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0004	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0005	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0006	KI207	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0007	KI202	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-03034-0008	KI202	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-03034-0009	KI202	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-03034-0010	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0011	KI202	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-03034-0012	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0013	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0014	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0015	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0016	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0017	KI207	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0018	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0019	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0020	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0021	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0022	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0023	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0024	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03034-0025	KI207	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-03034-0026	KI202	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-03038-0000	KI229	Radio Magnetic Indicator	Bendix/King	Repair
066-03038-0001	KI229	Radio Magnetic Indicator	Bendix/King	Repair
066-03044-0000	KNI416	Rad Alt Indicator	Bendix/King	Repair
066-03044-0001	KNI416	Rad Alt Indicator	Bendix/King	Repair
066-03044-0002	KNI416	Rad Alt Indicator	Bendix/King	Repair
066-03044-0003	KNI416	Rad Alt Indicator	Bendix/King	Repair
066-03046-0000	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-03046-0001	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-03046-0002	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-03046-0003	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-03046-0004	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-03046-0005	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-03046-0006	KI525A	Horizontal Situation Indicator	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
066-03046-0007	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-03046-0008	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-03046-0010	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-03046-0011	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-03046-0012	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-03054-0000	KI250	Rad Alt Indicator	Bendix/King	Repair
066-03054-0001	KI250	Rad Alt Indicator	Bendix/King	Repair
066-03054-0003	KI250	Rad Alt Indicator	Bendix/King	Repair
066-03054-0004	KI250	Rad Alt Indicator	Bendix/King	Repair
066-03056-0000	KI208	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-03056-0001	KI209	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03056-0002	KI208	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-03056-0003	KI209	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-03059-0000	KI228	ADF Indicator	Bendix/King	Repair
066-03059-0001	KI228	ADF Indicator	Bendix/King	Repair
066-03060-0000	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-03060-0001	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-03060-0002	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-03060-0003	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-03060-0004	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-03060-0010	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-03060-0011	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-03060-0012	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-03060-0013	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-03062-0000	KEA346	Encoding Altimeter	Bendix/King	Repair
066-03062-0001	KEA346	Encoding Altimeter	Bendix/King	Repair
066-03062-0002	KEA346	Encoding Altimeter	Bendix/King	Repair
066-03062-0003	KEA346	Encoding Altimeter	Bendix/King	Repair
066-03062-0004	KEA346	Encoding Altimeter	Bendix/King	Repair
066-03062-0005	KEA346	Encoding Altimeter	Bendix/King	Repair
066-03062-0006	KEA346	Encoding Altimeter	Bendix/King	Repair
066-03062-0007	KEA346	Encoding Altimeter	Bendix/King	Repair
066-03062-0008	KEA346	Encoding Altimeter	Bendix/King	Repair
066-03062-0009	KEA346	Encoding Altimeter	Bendix/King	Repair
066-03062-0010	KEA346	Encoding Altimeter	Bendix/King	Repair
066-03062-0011	KEA346	Encoding Altimeter	Bendix/King	Repair
066-03062-0012	KEA346	Encoding Altimeter	Bendix/King	Repair
066-03063-0000	KI227	ADF Indicator	Bendix/King	Repair
066-03063-0001	KI227	ADF Indicator	Bendix/King	Repair
066-03064-0000	KEA129	Encoding Altimeter (-1k-20k ft, Dual Scale)	United Instruments	Repair
066-03064-0001	KEA129	Encoding Altimeter (-1k-20k ft, Dual Scale, Lighted)	United Instruments	Repair
066-03064-0002	KEA130	Encoding Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
066-03064-0003	KEA130	Encoding Altimeter (-1k-35k ft, Dual Scale, Lighted)	United Instruments	Repair
066-03064-0004	KEA130A	Encoding Altimeter (-1k-35k ft, Dual Scale, B/O)	United Instruments	Repair
066-03064-0005	KEA130A	Encoding Altimeter (-1k-35k ft, Dual Scale, Lighted, B/O)	United Instruments	Repair
066-04009-0000	KN72	VOR/LOC Converter	Bendix/King	Repair
066-04031-0101	KLN90	GPS Receiver	Bendix/King	Repair
066-04031-0111	KLN90A	GPS Receiver	Bendix/King	Repair
066-04031-0201	KLN90	GPS Receiver	Bendix/King	Repair
066-04031-0211	KLN90A	GPS Receiver	Bendix/King	Repair
066-04031-0301	KLN90	GPS Receiver	Bendix/King	Repair
066-04031-0311	KLN90A	GPS Receiver	Bendix/King	Repair
066-04031-0401	KLN90	GPS Receiver	Bendix/King	Repair
066-04031-0411	KLN90A	GPS Receiver	Bendix/King	Repair
066-04031-1121	KLN90B	GPS Receiver	Bendix/King	Repair
066-04031-1122	KLN90B	GPS Receiver	Bendix/King	Repair
066-04031-1221	KLN90B	GPS Receiver	Bendix/King	Repair
066-04031-1222	KLN90B	GPS Receiver	Bendix/King	Repair
066-04031-1321	KLN90B	GPS Receiver	Bendix/King	Repair
066-04031-1322	KLN90B	GPS Receiver	Bendix/King	Repair
066-04031-1421	KLN90B	GPS Receiver	Bendix/King	Repair
066-04031-1422	KLN90B	GPS Receiver	Bendix/King	Repair
066-04031-2121	KLN90B	GPS Receiver	Bendix/King	Repair
066-04031-2122	KLN90B	GPS Receiver	Bendix/King	Repair
066-04031-2221	KLN90B	GPS Receiver	Bendix/King	Repair
066-04031-2222	KLN90B	GPS Receiver	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
066-04031-2321	KLN90B	GPS Receiver	Bendix/King	Repair
066-04031-2322	KLN90B	GPS Receiver	Bendix/King	Repair
066-04031-2421	KLN90B	GPS Receiver	Bendix/King	Repair
066-04031-2422	KLN90B	GPS Receiver	Bendix/King	Repair
066-04034-0101	KLN900	GPS Receiver	Bendix/King	Repair
066-04034-0102	KLN900	GPS Receiver	Bendix/King	Repair
066-04034-0104	KLN900	GPS Receiver	Bendix/King	Repair
066-04034-0201	KLN900	GPS Receiver	Bendix/King	Repair
066-04034-0202	KLN900	GPS Receiver	Bendix/King	Repair
066-04034-0204	KLN900	GPS Receiver	Bendix/King	Repair
066-1008-00	KNR660	NAV Receiver (VOR/LOC/RMI)	Bendix/King	Repair
066-1010-00	KNR600	NAV Receiver (VOR/LOC)	Bendix/King	Repair
066-1021-00	KR21	Marker Beacon Receiver	Bendix/King	Repair
066-1021-01	KR21	Marker Beacon Receiver	Bendix/King	Repair
066-1023-00	KR85	ADF Receiver	King Radio	Repair
066-1024-03	KMA20	Audio Panel	Bendix/King	Repair
066-1024-04	KMA20	Audio Panel	Bendix/King	Repair
066-1024-05	KMA20	Audio Panel	Bendix/King	Repair
066-1024-06	KMA20	Audio Panel	Bendix/King	Repair
066-1024-07	KMA20	Audio Panel	Bendix/King	Repair
066-1024-08	KMA20	Audio Panel	Bendix/King	Repair
066-1024-09	KMA20	Audio Panel	Bendix/King	Repair
066-1024-10	KMA20	Audio Panel	Bendix/King	Repair
066-1024-11	KMA20	Audio Panel	Bendix/King	Repair
066-1024-12	KMA20	Audio Panel	Bendix/King	Repair
066-1024-13	KMA20	Audio Panel	Bendix/King	Repair
066-1024-14	KMA20	Audio Panel	Bendix/King	Repair
066-1024-15	KMA20	Audio Panel	Bendix/King	Repair
066-1024-16	KMA20	Audio Panel	Bendix/King	Repair
066-1026-00	KNR600A	NAV Receiver (VOR/LOC)	Bendix/King	Repair
066-1027-00	KNR660A	NAV Receiver (VOR/LOC/RMI)	Bendix/King	Repair
066-1029-00	KN65	DME Transceiver	Bendix/King	Repair
066-1029-01	KN65	DME Transceiver	Bendix/King	Repair
066-1029-02	KN65A	DME Transceiver	Bendix/King	Repair
066-1029-03	KN65A	DME Transceiver	Bendix/King	Repair
066-1033-00	KN73	Glideslope Receiver	Bendix/King	Repair
066-1034-00	KT76	Transponder (14V Lighting)	King Radio	Repair
066-1034-01	KT76	Transponder (28V Lighting)	King Radio	Repair
066-1034-02	KT78	Transponder (14V Lighting)	King Radio	Repair
066-1034-03	KT78	Transponder (28V Lighting)	King Radio	Repair
066-1034-04	C589520-0104	Transponder (KT78/Cessna 300, 14V Lighting, Grey)	King Radio	Repair
066-1034-05	C589520-0105	Transponder (KT78/Cessna 300, 28V Lighting, Grey)	King Radio	Repair
066-1034-06	C589520-0106	Transponder (KT78/Cessna 300, 28V Lighting, Black)	King Radio	Repair
066-1034-07	C589520-0101	Transponder (KT76/Cessna 300, 14V Lighting, Grey)	King Radio	Repair
066-1034-08	C589520-0102	Transponder (KT76/Cessna 300, 28V Lighting, Grey)	King Radio	Repair
066-1034-09	C589520-0103	Transponder (KT76/Cessna 300, 28V Lighting, Black)	King Radio	Repair
066-1034-10	KT78	Transponder (Crown Version, 14V Lighting)	King Radio	Repair
066-1034-11	KT78	Transponder (Crown Version, 28V Lighting)	King Radio	Repair
066-1034-12	C589520-0107	Transponder (KT76/Cessna 300, 14V Lighting, Black)	King Radio	Repair
066-1034-13	C589520-0108	Transponder (KT78/Cessna 300, 14V Lighting, Black)	King Radio	Repair
066-1037-00	KDM705	DME Transceiver	Bendix/King	Repair
066-1037-01	C582601-0301	DME Transceiver	Bendix/King	Repair
066-1037-02	KDM705	DME Transceiver	Bendix/King	Repair
066-1037-03	KDM705	DME Transceiver	Bendix/King	Repair
066-1037-04	KDM705A	DME Transceiver	Bendix/King	Repair
066-1037-05	KDM705A	DME Transceiver	Bendix/King	Repair
066-1037-06	KDM705	DME Transceiver	Bendix/King	Repair
066-1037-07	KDM705	DME Transceiver	Bendix/King	Repair
066-1037-08	KDM705A	DME Transceiver	Bendix/King	Repair
066-1037-09	KDM705A	DME Transceiver	Bendix/King	Repair
066-1038-00	KR86	ADF Receiver	Bendix/King	Repair
066-1038-10	KR86	ADF Receiver	Bendix/King	Repair
066-1041-00	KXP755	ATC Transponder	King Radio	Repair
066-1044-00	KMR675	Marker Beacon Receiver	Bendix/King	Repair
066-1044-01	KMR675	Marker Beacon Receiver	Bendix/King	Repair
066-1047-00	KDF805	ADF Receiver	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
066-1047-01	KDF805	ADF Receiver	Bendix/King	Repair
066-1048-00	KRA405	Radar Altimeter	Bendix/King	Repair
066-1048-02	KRA405	Radar Altimeter	Bendix/King	Repair
066-1053-00	KT79	Transponder	Bendix/King	Repair
066-1055-00	KMA24	Audio Panel/Marker Receiver	Bendix/King	Repair
066-1055-01	KMA24	Audio Panel/Marker Receiver	Bendix/King	Repair
066-1055-02	KMA24	Audio Panel/Marker Receiver	Bendix/King	Repair
066-1055-03	KMA24	Audio Panel/Marker Receiver	Bendix/King	Repair
066-1055-50	KMA24H	Audio Panel	Bendix/King	Repair
066-1055-51	KMA24H	Audio Panel	Bendix/King	Repair
066-1055-52	KMA24H	Audio Panel	Bendix/King	Repair
066-1055-53	KMA24H	Audio Panel	Bendix/King	Repair
066-1055-54	KMA24H	Audio Panel	Bendix/King	Repair
066-1055-65	KMA24H	Audio Panel	Bendix/King	Repair
066-1055-66	KMA24H	Audio Panel	Bendix/King	Repair
066-1055-67	KMA24H	Audio Panel	Bendix/King	Repair
066-1055-68	KMA24H	Audio Panel	Bendix/King	Repair
066-1055-70	KMA24H	Audio Panel	Bendix/King	Repair
066-1055-71	KMA24H	Audio Panel	Bendix/King	Repair
066-1061-01	KRA10	Radar Altimeter	Bendix/King	Repair
066-1061-03	KRA10A	Radar Altimeter	Bendix/King	Repair
066-1062-00	KT76A	Transponder (White Lighting)	Bendix/King	Repair
066-1062-01	KT78A	Transponder	Bendix/King	Repair
066-1062-02	KT76A	Transponder (Blue/White Lighting)	Bendix/King	Repair
066-1062-10	KT76A	Transponder (Crown Version)	Bendix/King	Repair
066-1063-00	KN75	Glideslop Receiver	Bendix/King	Repair
066-1064-00	KN62	DME Transceiver	Bendix/King	Repair
066-1066-00	KDM706	DME Transceiver	Bendix/King	Repair
066-1066-01	KDM706	DME Transceiver	Bendix/King	Repair
066-1066-02	KDM706	DME Transceiver	Bendix/King	Repair
066-1066-41	KDM706	DME Transceiver	Bendix/King	Repair
066-1067-00	KN53	VHF Nav Receiver w/ Glideslope	Bendix/King	Repair
066-1067-01	KN53	VHF Nav Receiver w/o Glideslope	Bendix/King	Repair
066-1067-02	KN53	VHF Nav Receiver w/ Glideslope	Bendix/King	Repair
066-1067-03	KN53	VHF Nav Receiver w/o Glideslope	Bendix/King	Repair
066-1067-04	KN53	VHF Nav Receiver w/ Glideslope (CNI-5000)	Bendix/King	Repair
066-1067-05	KN53	VHF Nav Receiver w/o Glideslope (CNI-5000)	Bendix/King	Repair
066-1067-10	KN53	VHF Nav Receiver w/ Glideslope (Silver Crown Plus)	Bendix/King	Repair
066-1068-00	KN62A	DME Transceiver	Bendix/King	Repair
066-1068-01	KN62A	DME Transceiver	Bendix/King	Repair
066-1068-04	KN62A	DME Transceiver (Silver Crown Plus)	Bendix/King	Repair
066-1069-00	KDI572	DME Indicator	Bendix/King	Repair
066-1069-01	KDI572	DME Indicator	Bendix/King	Repair
066-1069-02	KDI573	DME Slave Indicator	Bendix/King	Repair
066-1069-03	KDI573	DME Slave Indicator	Bendix/King	Repair
066-1069-04	KDI574	DME Indicator	Bendix/King	Repair
066-1069-05	KDI574	DME Indicator	Bendix/King	Repair
066-1069-07	KDI572	Bench Test Unit (Not for Aircraft Use)	Bendix/King	Repair
066-1069-08	KDI572	DME Indicator	Bendix/King	Repair
066-1069-09	KDI573	DME Slave Indicator	Bendix/King	Repair
066-1069-10	KDI573	DME Slave Indicator	Bendix/King	Repair
066-1069-11	KDI574	DME Indicator	Bendix/King	Repair
066-1069-12	KDI574	DME Indicator	Bendix/King	Repair
066-1069-13	KDI574	DME Indicator (Sierra Version)	Bendix/King	Repair
066-1069-14	KDI574	DME Indicator	Bendix/King	Repair
066-1069-15	KDI572	DME Indicator	Bendix/King	Repair
066-1070-00	KN63	DME Transceiver	Bendix/King	Repair
066-1070-01	KN63	DME Transceiver	Bendix/King	Repair
066-1071-00	KXP756	Transponder	Bendix/King	Repair
066-1072-00	KR87	ADF Receiver	Bendix/King	Repair
066-1072-01	KR87	ADF Receiver	Bendix/King	Repair
066-1072-02	KR87	ADF Receiver	Bendix/King	Repair
066-1072-03	KR87	ADF Receiver	Bendix/King	Repair
066-1072-04	KR87	ADF Receiver	Bendix/King	Repair
066-1072-05	KR87	ADF Receiver	Bendix/King	Repair
066-1072-06	KR87	ADF Receiver	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
066-1072-07	KR87	ADF Receiver	Bendix/King	Repair
066-1072-14	KR87	ADF Receiver	Bendix/King	Repair
066-1072-15	KR87	ADF Receiver	Bendix/King	Repair
066-1072-17	KR87	ADF Receiver	Bendix/King	Repair
066-1077-00	KDF806	ADF Receiver	Bendix/King	Repair
066-1077-01	KDF806	ADF Receiver	Bendix/King	Repair
066-1078-00	KNR634	NAV Receiver	Bendix/King	Repair
066-1078-01	KNR634	NAV Receiver	Bendix/King	Repair
066-1078-02	KNR634	NAV Receiver	Bendix/King	Repair
066-1078-03	KNR634	NAV Receiver	Bendix/King	Repair
066-1078-04	KNR634	NAV Receiver	Bendix/King	Repair
066-1078-05	KNR634	NAV Receiver	Bendix/King	Repair
066-1078-06	KNR634	NAV Receiver	Bendix/King	Repair
066-1078-07	KNR634	NAV Receiver	Bendix/King	Repair
066-1078-08	KNR634	NAV Receiver	Bendix/King	Repair
066-1078-10	KNR634A	NAV Receiver	Bendix/King	Repair
066-1078-11	KNR634A	NAV Receiver	Bendix/King	Repair
066-1078-12	KNR634A	NAV Receiver	Bendix/King	Repair
066-1078-13	KNR634A	NAV Receiver	Bendix/King	Repair
066-1078-14	KNR634A	NAV Receiver	Bendix/King	Repair
066-1078-15	KNR634A	NAV Receiver	Bendix/King	Repair
066-1078-16	KNR634A	NAV Receiver	Bendix/King	Repair
066-1078-17	KNR634A	NAV Receiver	Bendix/King	Repair
066-1088-00	KN64	DME Transceiver	Bendix/King	Repair
066-1088-01	KN64	DME Transceiver (Silver Crown Plus)	Bendix/King	Repair
066-3003-00	KDI570	DME Indicator	Bendix/King	Repair
066-3003-01	KDI570	DME Indicator	Bendix/King	Repair
066-3003-01	C582601-0201	DME Indicator	Bendix/King	Repair
066-3003-02	KDI570	DME Indicator	Bendix/King	Repair
066-3003-02	C582601-0204	DME Indicator	Bendix/King	Repair
066-3003-04	KDI570	DME Indicator	Bendix/King	Repair
066-3008-02	KI201C	Course Selection Indicator	Bendix/King	Repair
066-3012-00	KA35	Marker Light Assembly	Bendix/King	Repair
066-3012-01	KA35A	Marker Light Assembly	Bendix/King	Repair
066-3017-00	KI225	ADF Indicator	King Radio	Repair
066-3017-01	KI225	ADF Indicator	King Radio	Repair
066-3018-00	KI265	DME Indicator	Bendix/King	Repair
066-3025-00	KI213	Course Selection Indicator	Bendix/King	Repair
066-3025-01	KI214	Course Selection Indicator	Bendix/King	Repair
066-3031-00	KNI415	Rad Alt Indicator	Honeywell	Repair
066-3031-01	KNI415	Rad Alt Indicator	Honeywell	Repair
066-3031-02	KNI415	Rad Alt Indicator	Honeywell	Repair
066-3031-03	KNI415	Rad Alt Indicator	Honeywell	Repair
066-3032-00	KDI571	DME Indicator	Bendix/King	Repair
066-3032-01	KDI571	DME Indicator	Bendix/King	Repair
066-3032-02	KDI571	DME Indicator	Bendix/King	Repair
066-3032-03	KDI571	DME Indicator	Bendix/King	Repair
066-3032-04	KDI571	DME Indicator	Bendix/King	Repair
066-3032-05	KDI571	DME Indicator	Bendix/King	Repair
066-3032-06	KDI571	DME Indicator	Bendix/King	Repair
066-3032-07	KDI571	DME Indicator	Bendix/King	Repair
066-3032-08	KDI571	DME Indicator	Bendix/King	Repair
066-3032-09	KDI571	DME Indicator	Bendix/King	Repair
066-3032-10	KDI571	DME Indicator	Bendix/King	Repair
066-3032-11	KDI571	DME Indicator	Bendix/King	Repair
066-3032-12	KDI571	DME Indicator	Bendix/King	Repair
066-3032-13	KDI571	DME Indicator	Bendix/King	Repair
066-3032-14	KDI571	DME Indicator	Bendix/King	Repair
066-3032-15	KDI571	DME Indicator	Bendix/King	Repair
066-3032-16	KDI571	DME Indicator	Bendix/King	Repair
066-3032-17	KDI571	DME Indicator	Bendix/King	Repair
066-3032-18	KDI571	DME Indicator	Bendix/King	Repair
066-3032-19	KDI571	DME Indicator	Bendix/King	Repair
066-3032-20	KDI571	DME Indicator	Bendix/King	Repair
066-3032-21	KDI571	DME Indicator	Bendix/King	Repair
066-3034-00	KI203	Navigation Indicator (VOR/LOC)	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
066-3034-01	KI203	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-3034-02	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-03	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-04	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-05	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-06	KI207	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-07	KI202	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-3034-08	KI202	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-3034-09	KI202	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-3034-10	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-11	KI202	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-3034-12	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-13	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-14	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-15	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-16	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-17	KI207	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-18	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-19	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-20	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-21	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-22	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-23	KI204	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-24	KI206	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3034-25	KI207	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-3034-26	KI202	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-3038-00	KI229	Radio Magnetic Indicator	Bendix/King	Repair
066-3038-01	KI229	Radio Magnetic Indicator	Bendix/King	Repair
066-3044-00	KNI416	Rad Alt Indicator	Bendix/King	Repair
066-3044-01	KNI416	Rad Alt Indicator	Bendix/King	Repair
066-3044-02	KNI416	Rad Alt Indicator	Bendix/King	Repair
066-3044-03	KNI416	Rad Alt Indicator	Bendix/King	Repair
066-3046-00	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-3046-01	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-3046-02	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-3046-03	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-3046-04	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-3046-05	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-3046-06	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-3046-07	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-3046-08	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-3046-10	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-3046-11	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-3046-12	KI525A	Horizontal Situation Indicator	Bendix/King	Repair
066-3047-00	KI266	DME Indicator	Bendix/King	Repair
066-3052-00	KI267	DME/VOR Indicator	Bendix/King	Repair
066-3054-00	KI250	Rad Alt Indicator	Bendix/King	Repair
066-3054-01	KI250	Rad Alt Indicator	Bendix/King	Repair
066-3054-03	KI250	Rad Alt Indicator	Bendix/King	Repair
066-3054-04	KI250	Rad Alt Indicator	Bendix/King	Repair
066-3056-00	KI208	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-3056-01	KI209	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3056-02	KI208	Navigation Indicator (VOR/LOC)	Bendix/King	Repair
066-3056-03	KI209	Navigation Indicator (VOR/LOC/GS)	Bendix/King	Repair
066-3056-10	KI208A	Navigation Indicator (VOR/LOC/GPS)	Bendix/King	Repair
066-3056-11	KI209A	Navigation Indicator (VOR/LOC/GS/GPS)	Bendix/King	Repair
066-3059-00	KI228	ADF Indicator	Bendix/King	Repair
066-3059-01	KI228	ADF Indicator	Bendix/King	Repair
066-3060-00	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-3060-01	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-3060-02	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-3060-03	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-3060-04	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-3060-10	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-3060-11	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-3060-12	KNI582	Radio Magnetic Indicator	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
066-3060-13	KNI582	Radio Magnetic Indicator	Bendix/King	Repair
066-3062-00	KEA346	Encoding Altimeter	Bendix/King	Repair
066-3062-01	KEA346	Encoding Altimeter	Bendix/King	Repair
066-3062-02	KEA346	Encoding Altimeter	Bendix/King	Repair
066-3062-03	KEA346	Encoding Altimeter	Bendix/King	Repair
066-3062-04	KEA346	Encoding Altimeter	Bendix/King	Repair
066-3062-05	KEA346	Encoding Altimeter	Bendix/King	Repair
066-3062-06	KEA346	Encoding Altimeter	Bendix/King	Repair
066-3062-07	KEA346	Encoding Altimeter	Bendix/King	Repair
066-3062-08	KEA346	Encoding Altimeter	Bendix/King	Repair
066-3062-09	KEA346	Encoding Altimeter	Bendix/King	Repair
066-3062-10	KEA346	Encoding Altimeter	Bendix/King	Repair
066-3062-11	KEA346	Encoding Altimeter	Bendix/King	Repair
066-3062-12	KEA346	Encoding Altimeter	Bendix/King	Repair
066-3063-00	KI227	ADF Indicator	Bendix/King	Repair
066-3063-01	KI227	ADF Indicator	Bendix/King	Repair
066-3064-00	KEA129	Encoding Altimeter (-1k-20k ft, Dual Scale)	United Instruments	Repair
066-3064-01	KEA129	Encoding Altimeter (-1k-20k ft, Dual Scale, Lighted)	United Instruments	Repair
066-3064-02	KEA130	Encoding Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
066-3064-03	KEA130	Encoding Altimeter (-1k-35k ft, Dual Scale, Lighted)	United Instruments	Repair
066-3064-04	KEA130A	Encoding Altimeter (-1k-35k ft, Dual Scale, B/O)	United Instruments	Repair
066-3064-05	KEA130A	Encoding Altimeter (-1k-35k ft, Dual Scale, Lighted, B/O)	United Instruments	Repair
066-3114-00	IN812A	Radar Indicator	Bendix/King	Repair
066-3114-01	IN812A	Radar Indicator	Bendix/King	Repair
066-4004-00	KN77	VOR/LOC Converter	Bendix/King	Repair
066-4007-00	KNR630	NAV Receiver	King Radio	Repair
066-4007-01	KNR631	NAV Receiver	King Radio	Repair
066-4007-02	KNR632	NAV Receiver	King Radio	Repair
066-4007-03	KNR633	NAV Receiver	King Radio	Repair
066-4008-00	KNS80	Navigation System	Bendix/King	Repair
066-4008-01	KNS80	Navigation System	Bendix/King	Repair
066-4008-02	KNS80	Navigation System	Bendix/King	Repair
066-4008-03	KNS80	Navigation System	Bendix/King	Repair
066-4009-00	KN72	VOR/LOC Converter	Bendix/King	Repair
066-4010-00	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-01	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-02	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-03	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-04	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-10	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-11	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-12	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-13	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-14	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-15	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-16	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-17	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-18	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-19	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-20	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-21	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-30	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-31	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-32	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-33	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-34	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-35	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-36	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-37	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-38	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-39	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-40	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-60	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-61	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-62	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-63	KNS81	Navigation Computer	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
066-4010-64	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-65	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-66	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-67	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-69	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-70	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-71	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-80	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-81	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-82	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-83	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-84	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-85	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-86	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-87	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-88	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-89	KNS81	Navigation Computer	Bendix/King	Repair
066-4010-90	KNS81	Navigation Computer	Bendix/King	Repair
069-01024-0000	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0001	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0002	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0003	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0004	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0005	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0006	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0007	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0008	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0009	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0010	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0011	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0012	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0013	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0020	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0030	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0031	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0032	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0033	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0034	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0035	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0036	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0037	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0038	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0039	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0040	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0041	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0042	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01024-0043	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0000	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0001	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0002	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0003	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0004	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0005	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0006	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0007	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0020	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0021	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0022	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0023	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0024	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0025	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0026	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01025-0027	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-01028-0101	KX125	NAV/COMM Transceiver	Bendix/King	Repair
069-01028-1101	KX125	NAV/COMM Transceiver	Bendix/King	Repair
069-01029-0201	KLX135	VHF COMM/GPS Transceiver	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
069-01029-0703	KLX135A	VHF COMM/GPS Transceiver	Bendix/King	Repair
069-01032-0101	KX155A	NAV/COMM Transceiver	Bendix/King	Repair
069-01032-0201	KX155A	NAV/COMM Transceiver	Bendix/King	Repair
069-01033-0101	KX165A	NAV/COMM Transceiver	Bendix/King	Repair
069-01033-0201	KX165A	NAV/COMM Transceiver	Bendix/King	Repair
069-01034-0101	KLN94	GPS Receiver	Bendix/King	Repair
069-01034-0102	KLN94	GPS Receiver	Bendix/King	Repair
069-1010-03	KI212	Course Selection Indicator	Bendix/King	Repair
069-1010-04	KI211C	Course Selection Indicator	Bendix/King	Repair
069-1016-00	KX175	NAV/COMM Transceiver	King Radio	Repair
069-1017-00	KX170A	NAV/COMM Transceiver	King Radio	Repair
069-1018-00	KY195	COMM Transceiver	King Radio	Repair
069-1019-00	KX175B	NAV/COMM Transceiver	King Radio	Repair
069-1019-01	KX175BE	NAV/COMM Transceiver	King Radio	Repair
069-1019-05	KX175B	NAV/COMM Transceiver	King Radio	Repair
069-1020-00	KX170B	NAV/COMM Transceiver	King Radio	Repair
069-1020-01	KX170BE	NAV/COMM Transceiver	King Radio	Repair
069-1020-02	KX170B	NAV/COMM Transceiver	King Radio	Repair
069-1021-00	KY195B	COMM Transceiver	King Radio	Repair
069-1021-01	KY195BE	COMM Transceiver	King Radio	Repair
069-1021-04	KY195B	COMM Transceiver	King Radio	Repair
069-1024-00	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-01	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-02	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-03	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-04	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-05	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-06	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-07	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-08	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-09	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-10	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-11	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-12	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-13	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-20	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-30	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-31	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-32	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-33	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-34	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-35	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-36	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-37	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-38	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-39	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-40	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-41	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-42	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1024-43	KX155	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-00	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-01	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-02	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-03	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-04	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-05	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-06	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-07	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-20	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-21	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-22	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-23	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-24	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-25	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-26	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair
069-1025-27	KX165	VHF NAV/COMM Transceiver	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
071-01052-0000	KMT112	Flux Valve	Bendix/King	Test/Recert
071-01196-0000	KA44	ADF Antenna	Bendix/King	Repair
071-01216-0012	KFS564	NAV Control Unit	Bendix/King	Repair
071-01216-0013	KFS564	NAV Control Unit	Bendix/King	Repair
071-01216-0015	KFS564	NAV Control Unit	Bendix/King	Repair
071-01216-0016	KFS564	NAV Control Unit	Bendix/King	Repair
071-01216-0017	KFS564	NAV Control Unit	Bendix/King	Repair
071-01216-0018	KFS564	NAV Control Unit	Bendix/King	Repair
071-01216-0020	KFS564	NAV Control Unit	Bendix/King	Repair
071-01216-0021	KFS564	NAV Control Unit	Bendix/King	Repair
071-01216-0022	KFS564	NAV Control Unit	Bendix/King	Repair
071-01216-0023	KFS564	NAV Control Unit	Bendix/King	Repair
071-01216-0025	KFS564	NAV Control Unit	Bendix/King	Repair
071-01216-0026	KFS564	NAV Control Unit	Bendix/King	Repair
071-01216-0027	KFS564	NAV Control Unit	Bendix/King	Repair
071-01234-0000	KA44B	ADF Antenna (s/n: 24274 & Lower)	Bendix/King	Repair
071-01234-0000	KA44B	ADF Antenna (s/n: 24275 & Higher)	Bendix/King	Test/Recert
071-01234-0001	KA44B	ADF Antenna	Bendix/King	Test/Recert
071-01242-0000	KA51B	Slaving Accessory	Bendix/King	Repair
071-01242-0001	KA51B	Slaving Accessory	Bendix/King	Repair
071-01242-0002	KA51B	Slaving Accessory	Bendix/King	Repair
071-01242-0003	KA51B	Slaving Accessory	Bendix/King	Repair
071-01242-0004	KA51B	Slaving Accessory	Bendix/King	Repair
071-01242-0005	KA51B	Slaving Accessory	Bendix/King	Repair
071-01242-0006	KA51B	Slaving Accessory	Bendix/King	Repair
071-01242-0007	KA51B	Slaving Accessory	Bendix/King	Repair
071-01242-0008	KA51B	Slaving Accessory	Bendix/King	Repair
071-01242-0009	KA51B	Slaving Accessory	Bendix/King	Repair
071-01242-0010	KA51B	Slaving Accessory	Bendix/King	Repair
071-01242-0011	KA51B	Slaving Accessory	Bendix/King	Repair
071-01242-0013	KA51B	Slaving Accessory	Bendix/King	Repair
071-01242-0014	KA51B	Slaving Accessory	Bendix/King	Repair
071-01283-0012	KFS564A	NAV Control Unit	Bendix/King	Repair
071-01283-0013	KFS564A	NAV Control Unit	Bendix/King	Repair
071-01283-0015	KFS564A	NAV Control Unit	Bendix/King	Repair
071-01283-0016	KFS564A	NAV Control Unit	Bendix/King	Repair
071-01283-0017	KFS564A	NAV Control Unit	Bendix/King	Repair
071-01283-0018	KFS564A	NAV Control Unit	Bendix/King	Repair
071-01283-0020	KFS564A	NAV Control Unit	Bendix/King	Repair
071-01283-0021	KFS564A	NAV Control Unit	Bendix/King	Repair
071-01283-0022	KFS564A	NAV Control Unit	Bendix/King	Repair
071-01283-0023	KFS564A	NAV Control Unit	Bendix/King	Repair
071-01283-0025	KFS564A	NAV Control Unit	Bendix/King	Repair
071-01283-0026	KFS564A	NAV Control Unit	Bendix/King	Repair
071-01283-0027	KFS564A	NAV Control Unit	Bendix/King	Repair
071-01284-0004	KFS586A	ADF Control Unit	Bendix/King	Repair
071-01284-0005	KFS586A	ADF Control Unit	Bendix/King	Repair
071-01284-0006	KFS586A	ADF Control Unit	Bendix/King	Repair
071-01284-0007	KFS586A	ADF Control Unit	Bendix/King	Repair
071-01284-0008	KFS586A	ADF Control Unit	Bendix/King	Repair
071-01284-0009	KFS586A	ADF Control Unit	Bendix/King	Repair
071-01284-0010	KFS586A	ADF Control Unit	Bendix/King	Repair
071-01284-0011	KFS586A	ADF Control Unit	Bendix/King	Repair
071-01284-0012	KFS586A	ADF Control Unit	Bendix/King	Repair
071-01284-0013	KFS586A	ADF Control Unit	Bendix/King	Repair
071-01284-0014	KFS586A	ADF Control Unit	Bendix/King	Repair
071-01284-0015	KFS586A	ADF Control Unit	Bendix/King	Repair
071-01284-0016	KFS586A	ADF Control Unit	Bendix/King	Repair
071-01284-0017	KFS586A	ADF Control Unit	Bendix/King	Repair
071-01519-0101	ART2000	Weather Radar Transceiver	Bendix/King	Test/Recert
071-02009-0000	KA134	Audio Panel	Bendix/King	Repair
071-02009-0001	KA134	Audio Panel	Bendix/King	Repair
071-02009-0002	KA134	Audio Panel	Bendix/King	Repair
071-02009-0003	KA134	Audio Panel	Bendix/King	Repair
071-02009-0012	KA134	Audio Panel	Bendix/King	Repair
071-1012-12	KFS590B	VHF Comm Control	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
071-1012-13	KFS590B	VHF Comm Control	Bendix/King	Repair
071-1012-14	KFS590B	VHF Comm Control	Bendix/King	Repair
071-1012-15	KFS590B	VHF Comm Control	Bendix/King	Repair
071-1012-16	KFS590B	VHF Comm Control	Bendix/King	Repair
071-1012-17	KFS590B	VHF Comm Control	Bendix/King	Repair
071-1012-18	KFS590B	VHF Comm Control	Bendix/King	Repair
071-1012-19	KFS590B	VHF Comm Control	Bendix/King	Repair
071-1012-20	KFS590B	VHF Comm Control	Bendix/King	Repair
071-1012-21	KFS590B	VHF Comm Control	Bendix/King	Repair
071-1043-02	KFS570B	ATC Transponder Control	King Radio	Repair
071-1043-03	KFS570B	ATC Transponder Control	King Radio	Repair
071-1043-04	KFS570B	ATC Transponder Control	King Radio	Repair
071-1052-00	KMT112	Flux Valve	Bendix/King	Test/Recert
071-1053-01	KA51A	Slaving Accessory	Bendix/King	Repair
071-1053-02	KA51A	Slaving Accessory	Bendix/King	Repair
071-1053-03	KA51A	Slaving Accessory	Bendix/King	Repair
071-1053-04	KA51A	Slaving Accessory	Bendix/King	Repair
071-1053-05	KA51A	Slaving Accessory	Bendix/King	Repair
071-1053-06	KA51A	Slaving Accessory	Bendix/King	Repair
071-1053-07	KA51A	Slaving Accessory	Bendix/King	Repair
071-1053-08	KA51A	Slaving Accessory	Bendix/King	Repair
071-1053-09	KA51A	Slaving Accessory	Bendix/King	Repair
071-1066-00	KFS580B	ADF Control	Bendix/King	Repair
071-1066-01	KFS580B	ADF Control	Bendix/King	Repair
071-1066-02	KFS580B	ADF Control	Bendix/King	Repair
071-1066-03	KFS580B	ADF Control	Bendix/King	Repair
071-1066-04	KFS580B	ADF Control	Bendix/King	Repair
071-1076-00	KDA697	RMI Adapter	Bendix/King	Repair
071-1192-00	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-01	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-02	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-03	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-04	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-05	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-06	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-07	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-08	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-09	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-10	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-11	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-13	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-14	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-15	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-16	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-18	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-22	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1192-26	KFS576	ATC Transponder Control	Bendix/King	Repair
071-1196-00	KA44	ADF Antenna	Bendix/King	Repair
071-1210-04	KFS586	ADF Control Unit	Bendix/King	Repair
071-1210-05	KFS586	ADF Control Unit	Bendix/King	Repair
071-1210-06	KFS586	ADF Control Unit	Bendix/King	Repair
071-1210-07	KFS586	ADF Control Unit	Bendix/King	Repair
071-1210-08	KFS586	ADF Control Unit	Bendix/King	Repair
071-1210-09	KFS586	ADF Control Unit	Bendix/King	Repair
071-1210-10	KFS586	ADF Control Unit	Bendix/King	Repair
071-1210-11	KFS586	ADF Control Unit	Bendix/King	Repair
071-1210-12	KFS586	ADF Control Unit	Bendix/King	Repair
071-1210-13	KFS586	ADF Control Unit	Bendix/King	Repair
071-1210-14	KFS586	ADF Control Unit	Bendix/King	Repair
071-1210-15	KFS586	ADF Control Unit	Bendix/King	Repair
071-1210-16	KFS586	ADF Control Unit	Bendix/King	Repair
071-1210-17	KFS586	ADF Control Unit	Bendix/King	Repair
071-1215-24	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-25	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-26	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-27	KFS598	VHF Comm Control Unit	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
071-1215-29	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-30	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-31	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-32	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-34	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-35	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-36	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-37	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-38	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-39	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-40	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-41	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-42	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-43	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-44	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-45	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-54	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-55	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-56	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-57	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-59	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-60	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-61	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-62	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-64	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-65	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-66	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-67	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-70	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1215-71	KFS598	VHF Comm Control Unit	Bendix/King	Repair
071-1216-12	KFS564	NAV Control Unit	Bendix/King	Repair
071-1216-13	KFS564	NAV Control Unit	Bendix/King	Repair
071-1216-15	KFS564	NAV Control Unit	Bendix/King	Repair
071-1216-16	KFS564	NAV Control Unit	Bendix/King	Repair
071-1216-17	KFS564	NAV Control Unit	Bendix/King	Repair
071-1216-18	KFS564	NAV Control Unit	Bendix/King	Repair
071-1216-20	KFS564	NAV Control Unit	Bendix/King	Repair
071-1216-21	KFS564	NAV Control Unit	Bendix/King	Repair
071-1216-22	KFS564	NAV Control Unit	Bendix/King	Repair
071-1216-23	KFS564	NAV Control Unit	Bendix/King	Repair
071-1216-25	KFS564	NAV Control Unit	Bendix/King	Repair
071-1216-26	KFS564	NAV Control Unit	Bendix/King	Repair
071-1216-27	KFS564	NAV Control Unit	Bendix/King	Repair
071-1234-00	KA44B	ADF Antenna (s/n: 24274 & Lower)	Bendix/King	Repair
071-1234-00	KA44B	ADF Antenna (s/n: 24275 & Higher)	Bendix/King	Test/Recert
071-1234-01	KA44B	ADF Antenna	Bendix/King	Test/Recert
071-1242-00	KA51B	Slaving Accessory	Bendix/King	Repair
071-1242-01	KA51B	Slaving Accessory	Bendix/King	Repair
071-1242-02	KA51B	Slaving Accessory	Bendix/King	Repair
071-1242-03	KA51B	Slaving Accessory	Bendix/King	Repair
071-1242-04	KA51B	Slaving Accessory	Bendix/King	Repair
071-1242-05	KA51B	Slaving Accessory	Bendix/King	Repair
071-1242-06	KA51B	Slaving Accessory	Bendix/King	Repair
071-1242-07	KA51B	Slaving Accessory	Bendix/King	Repair
071-1242-08	KA51B	Slaving Accessory	Bendix/King	Repair
071-1242-09	KA51B	Slaving Accessory	Bendix/King	Repair
071-1242-10	KA51B	Slaving Accessory	Bendix/King	Repair
071-1242-11	KA51B	Slaving Accessory	Bendix/King	Repair
071-1242-13	KA51B	Slaving Accessory	Bendix/King	Repair
071-1242-14	KA51B	Slaving Accessory	Bendix/King	Repair
071-1268-00	KA594	HF Control Adapter	King Radio	Repair
071-1268-01	KA594	HF Control Adapter	King Radio	Repair
071-1274-00	KFS594	HF Control Unit	Bendix/King	Repair
071-1274-01	KFS594	HF Control Unit	Bendix/King	Repair
071-1274-02	KFS594	HF Control Unit	Bendix/King	Repair
071-1274-03	KFS594	HF Control Unit	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
071-1274-04	KFS594	HF Control Unit	Bendix/King	Repair
071-1274-05	KFS594	HF Control Unit	Bendix/King	Repair
071-1276-08	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-09	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-10	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-11	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-13	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-14	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-15	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-16	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-18	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-19	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-20	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-21	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-22	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-23	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-24	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-25	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1276-26	KFS576A	ATC Transponder Control	Bendix/King	Repair
071-1282-24	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-25	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-26	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-27	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-29	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-30	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-31	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-32	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-34	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-35	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-36	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-37	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-38	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-39	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-40	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-41	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-42	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-43	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-44	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-45	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-64	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-65	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-66	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-67	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-69	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-70	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-71	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-72	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-74	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-75	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-76	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-77	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-80	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1282-81	KFS598A	VHF Comm Control Unit	Bendix/King	Repair
071-1283-12	KFS564A	NAV Control Unit	Bendix/King	Repair
071-1283-13	KFS564A	NAV Control Unit	Bendix/King	Repair
071-1283-15	KFS564A	NAV Control Unit	Bendix/King	Repair
071-1283-16	KFS564A	NAV Control Unit	Bendix/King	Repair
071-1283-17	KFS564A	NAV Control Unit	Bendix/King	Repair
071-1283-18	KFS564A	NAV Control Unit	Bendix/King	Repair
071-1283-20	KFS564A	NAV Control Unit	Bendix/King	Repair
071-1283-21	KFS564A	NAV Control Unit	Bendix/King	Repair
071-1283-22	KFS564A	NAV Control Unit	Bendix/King	Repair
071-1283-23	KFS564A	NAV Control Unit	Bendix/King	Repair
071-1283-25	KFS564A	NAV Control Unit	Bendix/King	Repair
071-1283-26	KFS564A	NAV Control Unit	Bendix/King	Repair
071-1283-27	KFS564A	NAV Control Unit	Bendix/King	Repair

Part Number	Model	Description	Manufacturer	Capability
071-1284-04	KFS586A	ADF Control Unit	Bendix/King	Repair
071-1284-05	KFS586A	ADF Control Unit	Bendix/King	Repair
071-1284-06	KFS586A	ADF Control Unit	Bendix/King	Repair
071-1284-07	KFS586A	ADF Control Unit	Bendix/King	Repair
071-1284-08	KFS586A	ADF Control Unit	Bendix/King	Repair
071-1284-09	KFS586A	ADF Control Unit	Bendix/King	Repair
071-1284-10	KFS586A	ADF Control Unit	Bendix/King	Repair
071-1284-11	KFS586A	ADF Control Unit	Bendix/King	Repair
071-1284-12	KFS586A	ADF Control Unit	Bendix/King	Repair
071-1284-13	KFS586A	ADF Control Unit	Bendix/King	Repair
071-1284-14	KFS586A	ADF Control Unit	Bendix/King	Repair
071-1284-15	KFS586A	ADF Control Unit	Bendix/King	Repair
071-1284-16	KFS586A	ADF Control Unit	Bendix/King	Repair
071-1284-17	KFS586A	ADF Control Unit	Bendix/King	Repair
071-1378-00	RS811A	Radar Sensor	Bendix/King	Repair
071-2009-00	KA134	Audio Panel	Bendix/King	Repair
071-2009-01	KA134	Audio Panel	Bendix/King	Repair
071-2009-02	KA134	Audio Panel	Bendix/King	Repair
071-2009-03	KA134	Audio Panel	Bendix/King	Repair
071-2009-12	KA134	Audio Panel	Bendix/King	Repair
071-4027-00	KG257	Rate Gyro Mount w/o Gyro	Bendix/King	Repair
071-4027-01	KG257	Rate Gyro Mount w/ 14V Gyro	Bendix/King	Repair
071-4027-02	KG257	Rate Gyro Mount w/ 28V Gyro	Bendix/King	Repair
071-5038-00	KTS156	ADF Test Set	Bendix/King	Repair
0805.416-921	AS3100-(12A)	Audio Panel	Becker	Repair
081252-1-10	TDFM-136B	VHF FM Transceiver	Technisonic	Repair
081252-1-11	TDFM-136B	VHF FM Transceiver	Technisonic	Repair
081252-1-20	TDFM-136B	VHF FM Transceiver	Technisonic	Repair
081252-1-21	TDFM-136B	VHF FM Transceiver	Technisonic	Repair
081252-2-10	TDFM-136B	VHF FM Transceiver	Technisonic	Repair
081252-2-11	TDFM-136B	VHF FM Transceiver	Technisonic	Repair
081252-2-20	TDFM-136B	VHF FM Transceiver	Technisonic	Repair
081252-2-21	TDFM-136B	VHF FM Transceiver	Technisonic	Repair
081252-3-10	TDFM-136B	VHF FM Transceiver	Technisonic	Repair
081252-3-11	TDFM-136B	VHF FM Transceiver	Technisonic	Repair
081252-3-20	TDFM-136B	VHF FM Transceiver	Technisonic	Repair
081252-3-21	TDFM-136B	VHF FM Transceiver	Technisonic	Repair
0868.541-910	AR4201	VHF Transceiver	Becker	Repair
0874.361-921	AS3100-(12)-08	Audio Panel	Becker	Repair
0879.101-921	AS3100-(12N)-09	Audio Panel	Becker	Repair
0893.927-921	AS3100-(12)-11	Audio Panel	Becker	Repair
100-0002-01	RCA80B-2	Turn Rate Indicator	RC Allen	Repair
100-0027-01	RCA82A-1	Turn Rate Indicator	RC Allen	Repair
100-0027-02	RCA82A-2	Turn Rate Indicator	RC Allen	Repair
100-0027-05	RCA82A-4	Turn Rate Indicator	RC Allen	Repair
100-0030-01	RCA83A-1	Turn Rate Indicator	RC Allen	Repair
100-0030-02	RCA83A-2	Turn Rate Indicator	RC Allen	Repair
100-0030-05	RCA83A-11	Turn Rate Indicator	RC Allen	Repair
100-0037-01	RCA82A-11	Turn Rate Indicator	RC Allen	Repair
100-0037-02	RCA82A-11	Turn Rate Indicator	RC Allen	Repair
100-3010-000	-	RIPS,Type III NiCd	Radiant Power	Test/Recert
100-3010-001	-	RIPS,Type III NiCad,Enhanced BITE	Radiant Power	Test/Recert
10035-11244	212-070-238-5	Altimeter (-1k-35k ft, Lighted)	Aerosonic	Repair
10035-11244	212-070-238-005	Altimeter (-1k-35k ft, Lighted)	Aerosonic	Repair
10035-11424	212-070-238-7	Altimeter (-1k-35k ft, Dual Scale, Lighted)	Aerosonic	Repair
10035-11424	212-070-238-007	Altimeter (-1k-35k ft, Dual Scale, Lighted)	Aerosonic	Repair
10035-11892	-	Altimeter (-1k-35k ft)	Aerosonic	Repair
10035-2176	-	Altimeter (-1k-35k ft)	Aerosonic	Repair
10050-0106	-	Altimeter (-1k-50k ft)	Aerosonic	Repair
101-380030-11	RCA60-02	Turn & Slip Indicator	RC Allen	Repair
101-380030-9	RCA60-03	Turn & Slip Indicator	RC Allen	Repair
101-380037-1	4000B-28	Directional Gyro, Lighted	Beechcraft	Repair
101-380080-1	RCA22-19	Horizon Indicator	RC Allen	Repair
101-380080-3	RCA22-29	Horizon Indicator	RC Allen	Repair
101420-01205	-	Encoding Altimeter (-1k-20k ft, in.Hg)	Aerosonic	Repair
101420-01206	-	Encoding Altimeter (-1k-20k ft, mbar)	Aerosonic	Repair

Part Number	Model	Description	Manufacturer	Capability
101420-01223	-	Encoding Altimeter (-1k-20k ft, in.Hg)	Aerosonic	Repair
101420-01224	-	Encoding Altimeter (-1k-20k ft, mbar)	Aerosonic	Repair
101420-01249	-	Encoding Altimeter (-1k-20k ft, in.Hg)	Aerosonic	Repair
101420-01250	-	Encoding Altimeter (-1k-20k ft, mbar)	Aerosonic	Repair
101420-01255	-	Encoding Altimeter (-1k-20k ft, in.Hg)	Aerosonic	Repair
101420-01256	-	Encoding Altimeter (-1k-20k ft, mbar)	Aerosonic	Repair
101435-01211	-	Encoding Altimeter (-1k-35k ft, in.Hg)	Aerosonic	Repair
101435-01212	-	Encoding Altimeter (-1k-35k ft, mbar)	Aerosonic	Repair
101435-01229	-	Encoding Altimeter (-1k-35k ft, in.Hg)	Aerosonic	Repair
101435-01230	-	Encoding Altimeter (-1k-35k ft, mbar)	Aerosonic	Repair
101435-01261	-	Encoding Altimeter (-1k-35k ft, in.Hg)	Aerosonic	Repair
101435-01262	-	Encoding Altimeter (-1k-35k ft, mbar)	Aerosonic	Repair
101435-01267	-	Encoding Altimeter (-1k-35k ft, in.Hg)	Aerosonic	Repair
101435-01268	-	Encoding Altimeter (-1k-35k ft, mbar)	Aerosonic	Repair
101450-01217	-	Encoding Altimeter (-1k-50k ft, in.Hg)	Aerosonic	Repair
101450-01218	-	Encoding Altimeter (-1k-50k ft, mbar)	Aerosonic	Repair
101450-01235	-	Encoding Altimeter (-1k-50k ft, in.Hg)	Aerosonic	Repair
101450-01236	-	Encoding Altimeter (-1k-50k ft, mbar)	Aerosonic	Repair
101450-01273	-	Encoding Altimeter (-1k-50k ft, in.Hg)	Aerosonic	Repair
101450-01274	-	Encoding Altimeter (-1k-50k ft, mbar)	Aerosonic	Repair
101450-01279	-	Encoding Altimeter (-1k-50k ft, in.Hg)	Aerosonic	Repair
101450-01280	-	Encoding Altimeter (-1k-50k ft, mbar)	Aerosonic	Repair
101617-01339	-	Altimeter (-1k-17k ft, mbar)	Aerosonic	Repair
101617-01340	-	Altimeter (-1k-17k ft, in.Hg)	Aerosonic	Repair
101617-01349	-	Altimeter (-1k-17k ft, Dual Scale)	Aerosonic	Repair
101617-11372	-	Altimeter (-1k-17k ft, mbar, Lighted)	Aerosonic	Repair
101617-11373	-	Altimeter (-1k-17k ft, in.Hg, Lighted)	Aerosonic	Repair
101617-11374	-	Altimeter (-1k-17k ft, Dual Scale, Lighted)	Aerosonic	Repair
101627-01343	-	Altimeter (-1k-27k ft, mbar)	Aerosonic	Repair
101627-01344	-	Altimeter (-1k-27k ft, in.Hg)	Aerosonic	Repair
101627-01375	-	Altimeter (-1k-27k ft, Dual Scale)	Aerosonic	Repair
101627-11376	-	Altimeter (-1k-27k ft, mbar, Lighted)	Aerosonic	Repair
101627-11377	-	Altimeter (-1k-27k ft, in.Hg, Lighted)	Aerosonic	Repair
101627-11378	-	Altimeter (-1k-27k ft, Dual Scale, Lighted)	Aerosonic	Repair
101635-01358	-	Altimeter (-1k-35k ft, mbar)	Aerosonic	Repair
101635-01359	-	Altimeter (-1k-35k ft, in.Hg)	Aerosonic	Repair
101635-01379	-	Altimeter (-1k-35k ft, Dual Scale)	Aerosonic	Repair
101635-11380	-	Altimeter (-1k-35k ft, mbar, Lighted)	Aerosonic	Repair
101635-11381	-	Altimeter (-1k-35k ft, in.Hg, Lighted)	Aerosonic	Repair
101635-11382	-	Altimeter (-1k-35k ft, Dual Scale, Lighted)	Aerosonic	Repair
101635-11839	-	Altimeter (-1k-35k ft, Dual Scale, Lighted)	Aerosonic	Repair
101720-01354	-	Altimeter (-1k-20k ft, in.Hg)	Aerosonic	Repair
101720-01355	-	Altimeter (-1k-20k ft, mbar)	Aerosonic	Repair
101720-01362	58-380069-1	Altimeter (-1k-20k ft, in.Hg, Beechcraft)	Aerosonic	Repair
101720-01383	-	Altimeter (-1k-20k ft, Dual Scale)	Aerosonic	Repair
101720-01393	-	Altimeter (-1k-20k ft, in.Hg)	Aerosonic	Repair
101720-01459	-	Altimeter (-1k-20k ft, in.Hg)	Aerosonic	Repair
101720-01461	-	Altimeter (-1k-20k ft, Dual Scale)	Aerosonic	Repair
101720-01545	-	Altimeter (-1k-20k ft, in.Hg)	Aerosonic	Repair
101720-01546	-	Altimeter (-1k-20k ft, mbar)	Aerosonic	Repair
101720-01547	-	Altimeter (-1k-20k ft, mbar)	Aerosonic	Repair
101720-01562	58-380069-1	Altimeter (-1k-20k ft, in.Hg, Beechcraft)	Aerosonic	Repair
101720-01694	-	Altimeter (-1k-20k ft, in.Hg)	Aerosonic	Repair
101720-01999	-	Altimeter (-1k-20k ft, in.Hg)	Aerosonic	Repair
101720-11384	-	Altimeter (-1k-20k ft, in.Hg, Lighted)	Aerosonic	Repair
101720-11385	-	Altimeter (-1k-20k ft, mbar, Lighted)	Aerosonic	Repair
101720-11386	-	Altimeter (-1k-20k ft, Dual Scale, Lighted)	Aerosonic	Repair
101720-11564	58-380069-3	Altimeter (-1k-20k ft, in.Hg, Lighted, Beechcraft)	Aerosonic	Repair
101720-11810	-	Altimeter (-1k-20k ft, Dual Scale, Lighted)	Aerosonic	Repair
101730-01356	-	Altimeter (-1k-30k ft, in.Hg)	Aerosonic	Repair
101730-01357	-	Altimeter (-1k-30k ft, mbar)	Aerosonic	Repair
101730-01387	-	Altimeter (-1k-30k ft, Dual Scale)	Aerosonic	Repair
101730-01419	-	Altimeter (-1k-30k ft, Dual Scale)	Aerosonic	Repair
101730-11388	-	Altimeter (-1k-30k ft, in.Hg, Lighted)	Aerosonic	Repair
101730-11389	-	Altimeter (-1k-30k ft, mbar, Lighted)	Aerosonic	Repair
101730-11390	-	Altimeter (-1k-30k ft, Dual Scale, Lighted)	Aerosonic	Repair

Part Number	Model	Description	Manufacturer	Capability
101735-01455	-	Altimeter (-1k-35k ft, in.Hg)	Aerosonic	Repair
101735-01456	-	Altimeter (-1k-35k ft, mbar)	Aerosonic	Repair
101735-01495	-	Altimeter (-1k-35k ft, Dual Scale)	Aerosonic	Repair
101735-01500	-	Altimeter (-1k-35k ft, in.Hg)	Aerosonic	Repair
101735-01502	-	Altimeter (-1k-35k ft, in.Hg)	Aerosonic	Repair
101735-01563	58-380069-5	Altimeter (-1k-35k ft, in.Hg, Beechcraft)	Aerosonic	Repair
101735-01695	-	Altimeter (-1k-35k ft, in.Hg)	Aerosonic	Repair
101735-01723	-	Altimeter (-1k-35k ft, in.Hg)	Aerosonic	Repair
101735-01727	-	Altimeter (-1k-35k ft, mbar)	Aerosonic	Repair
101735-01803	58-380044-1	Altimeter (-1k-35k ft, Dual Scale, Beechcraft)	Aerosonic	Repair
101735-11565	58-380069-7	Altimeter (-1k-35k ft, in.Hg, Lighted, Beechcraft)	Aerosonic	Repair
101735-11726	-	Altimeter (-1k-35k ft, mbar, Lighted)	Aerosonic	Repair
101735-11728	-	Altimeter (-1k-35k ft, in.Hg, Lighted)	Aerosonic	Repair
101750-01710	-	Altimeter (-1k-50k ft, in.Hg)	Aerosonic	Repair
10189C01H00	C661063-0107	Airspeed Indicator	Ametek	Test/Recert
102-0011-01	RCA22-1	Horizon Indicator	RC Allen	Repair
102-0041-01	RCA22-2	Horizon Indicator	RC Allen	Repair
102-0041-02	RCA22-5	Horizon Indicator	RC Allen	Repair
102-0041-02	RCA22-10	Horizon Indicator	RC Allen	Repair
102-0041-03	RCA22-1	Horizon Indicator	RC Allen	Repair
102-0041-04	RCA22-8	Horizon Indicator	RC Allen	Repair
102-0041-04	RCA22-7	Horizon Indicator	RC Allen	Repair
102-0041-05	RCA22-18	Horizon Indicator	RC Allen	Repair
102-0041-06	RCA22-19	Horizon Indicator	RC Allen	Repair
102-0041-07	RCA22-20	Horizon Indicator	RC Allen	Repair
102-0041-08	RCA22-25	Horizon Indicator	RC Allen	Repair
102-0041-08S	RCA22-25S	Horizon Indicator	RC Allen	Repair
102-0041-09	RCA22-29	Horizon Indicator	RC Allen	Repair
102-0041-10	RCA22-30	Horizon Indicator	RC Allen	Repair
102-0041-11	RCA22-33	Horizon Indicator	RC Allen	Repair
102-0041-12	RCA22-36	Horizon Indicator	RC Allen	Repair
102-0041-12	RCA22-32	Horizon Indicator	RC Allen	Repair
102-0041-13	RCA22-34	Horizon Indicator	RC Allen	Repair
102-0041-14	RCA22-35	Horizon Indicator	RC Allen	Repair
102-0041-16	RCA22-37	Horizon Indicator	RC Allen	Repair
102-0041-29	RCA22-40	Horizon Indicator	RC Allen	Repair
102-0041-30	RCA22-41	Horizon Indicator	RC Allen	Repair
102-0041-33	RCA22-42	Horizon Indicator	RC Allen	Repair
102-0044-01	RCA22-3	Horizon Indicator	RC Allen	Repair
102-0045-01	RCA26BK-1	Attitude Indicator	RC Allen	Repair
102-0045-02	RCA26BK-1	Attitude Indicator	RC Allen	Repair
102-0047-01	RCA26CM-1	Attitude Indicator	RC Allen	Repair
102-0047-02	RCA26CM-3	Attitude Indicator	RC Allen	Repair
102-0047-03	RCA26CM-5	Attitude Indicator	RC Allen	Repair
102-0050-01	RCA26BK-8	Attitude Indicator	RC Allen	Repair
102-0050-02	RCA26BK-8	Attitude Indicator	RC Allen	Repair
102-0051-01	RCA26BK-2	Attitude Indicator	RC Allen	Repair
102-0051-02	RCA26BK-2	Attitude Indicator	RC Allen	Repair
102-0051-04	RCA26BK-20	Attitude Indicator	RC Allen	Repair
102-0052-01	RCA26C-5	Attitude Indicator	RC Allen	Repair
102-0052-02	RCA26C-5	Attitude Indicator	RC Allen	Repair
102-0053-01	RCA26AK-1	Attitude Indicator	RC Allen	Repair
102-0053-02	RCA26AK-1	Attitude Indicator	RC Allen	Repair
102-0053-03	RCA26AK-6	Attitude Indicator	RC Allen	Repair
102-0053-04	RCA26AK-6	Attitude Indicator	RC Allen	Repair
102-0054-01	RCA26BK-3	Attitude Indicator	RC Allen	Repair
102-0054-02	RCA26BK-3	Attitude Indicator	RC Allen	Repair
102-0054-03	RCA26BK-12	Attitude Indicator	RC Allen	Repair
102-0054-04	RCA26BK-12	Attitude Indicator	RC Allen	Repair
102-0054-05	RCA26BK-18	Attitude Indicator	RC Allen	Repair
102-0054-06	RCA26BK-31	Attitude Indicator	RC Allen	Repair
102-0054-07	RCA26BK-31	Attitude Indicator	RC Allen	Repair
102-0055-01	RCA26BK-4	Attitude Indicator	RC Allen	Repair
102-0055-02	RCA26BK-4	Attitude Indicator	RC Allen	Repair
102-0057-01	RCA26BK-6	Attitude Indicator	RC Allen	Repair
102-0057-02	RCA26BK-6	Attitude Indicator	RC Allen	Repair

Part Number	Model	Description	Manufacturer	Capability
102-0057-02	RCA26BK-16	Attitude Indicator	RC Allen	Repair
102-0059-01	RCA26BK-7	Attitude Indicator	RC Allen	Repair
102-0060-01	RCA26BK-9	Attitude Indicator	RC Allen	Repair
102-0060-02	RCA26BK-9	Attitude Indicator	RC Allen	Repair
102-0060-03	RCA26BK-29	Attitude Indicator	RC Allen	Repair
102-0060-04	RCA26BK-29	Attitude Indicator	RC Allen	Repair
102-0060-11	RCA26BK-34	Attitude Indicator	RC Allen	Repair
102-0060-12	RCA26BK-34	Attitude Indicator	RC Allen	Repair
102-0060-15	RCA26BK-36	Attitude Indicator	RC Allen	Repair
102-0060-16	RCA26BK-36	Attitude Indicator	RC Allen	Repair
102-0061-01	RCA26AK-2	Attitude Indicator	RC Allen	Repair
102-0061-02	RCA26AK-2	Attitude Indicator	RC Allen	Repair
102-0064-01	RCA26AK-4	Attitude Indicator	RC Allen	Repair
102-0064-02	RCA26AK-4	Attitude Indicator	RC Allen	Repair
102-0065-01	RCA26BK-10	Attitude Indicator	RC Allen	Repair
102-0066-01	RCA26AK-3	Attitude Indicator	RC Allen	Repair
102-0066-02	RCA26AK-3	Attitude Indicator	RC Allen	Repair
102-0067-02	RCA26CM-4	Attitude Indicator	RC Allen	Repair
102-0070-01	RCA26CM-2	Attitude Indicator	RC Allen	Repair
102-0070-02	RCA26CM-6	Attitude Indicator	RC Allen	Repair
102-0071-01	RCA22-6	Horizon Indicator	RC Allen	Repair
102-0071-02	RCA22-9	Horizon Indicator	RC Allen	Repair
102-0071-03	RCA22-11	Horizon Indicator	RC Allen	Repair
102-0071-04	RCA22-39	Horizon Indicator	RC Allen	Repair
102-0071-04	RCA22-38	Horizon Indicator	RC Allen	Repair
102-0071-04	RCA22-31	Horizon Indicator	RC Allen	Repair
102-0071-04	RCA22-24	Horizon Indicator	RC Allen	Repair
102-0072-01	RCA26C-7	Attitude Indicator	RC Allen	Repair
102-0072-02	RCA26C-7	Attitude Indicator	RC Allen	Repair
102-0074-01	RCA22-13	Horizon Indicator	RC Allen	Repair
102-0074-02	RCA22-14	Horizon Indicator	RC Allen	Repair
102-0074-03	RCA22-15	Horizon Indicator	RC Allen	Repair
102-0074-04	RCA22-17	Horizon Indicator	RC Allen	Repair
102-0075-01	RCA22-12	Horizon Indicator	RC Allen	Repair
102-0076-01	RCA26C-8	Attitude Indicator	RC Allen	Repair
102-0076-02	RCA26C-9	Attitude Indicator	RC Allen	Repair
102-0077-01	RCA26BK-18	Attitude Indicator	RC Allen	Repair
102-0078-01	RCA22-16	Horizon Indicator	RC Allen	Repair
102-0079-01	RCA26BK-21	Attitude Indicator	RC Allen	Repair
102-0080-01	RCA22-7F	Horizon Indicator	RC Allen	Repair
102-0080-05	RCA22-11F	Horizon Indicator	RC Allen	Repair
102-00801-05	RCA22-11F	Horizon Indicator	RC Allen	Repair
102200-11850	214-175-278-101	Altimeter (-1k-20k ft, Dual Scale, Lighted)	Aerosonic	Repair
102-380016-1	5000B-34	Attitude Gyro	Beechcraft	Repair
102-380016-3	5000B-35	Attitude Gyro, Lighted	Beechcraft	Repair
103-0009-01	RCA11D-2	Directional Gyro	RC Allen	Repair
103-0010-01	RCA11D-3	Directional Gyro	RC Allen	Repair
103-0011-01	RCA11D-4	Directional Gyro	RC Allen	Repair
103-0011-02	RCA11D-7	Directional Gyro	RC Allen	Repair
103-0012-01	RCA11D-5	Directional Gyro	RC Allen	Repair
103-0022-01	RCA15BK-1	Directional Gyro	RC Allen	Repair
103-0023-01	RCA15BK-2	Directional Gyro	RC Allen	Repair
103-0025-01	RCA15AK-1	Directional Gyro	RC Allen	Repair
103-0026-01	RCA15BK-4	Directional Gyro	RC Allen	Repair
103-0027-01	RCA15AK-2	Directional Gyro	RC Allen	Repair
103-0030-01	RCA11A-13	Directional Gyro	RC Allen	Repair
103-0030-02	RCA11A-16	Directional Gyro	RC Allen	Repair
103-0030-03	RCA11A-17	Directional Gyro	RC Allen	Repair
10420-11968E	-	Altimeter (-1k-20k ft, Dual Scale, Lighted)	Aerosonic	Limited Repair
10450-11110	C661072-0101	Altimeter (-1k-50k ft, in.Hg, Lighted)	Aerosonic	Repair
10450-11139	C661072-0102	Altimeter (-1k-50k ft, mbar, Lighted)	Aerosonic	Repair
10450-11525	-	Altimeter (-1k-50k ft, in.Hg, Lighted)	Aerosonic	Repair
10460-11110	C661072-0201	Altimeter (-1k-60k ft, in.Hg, Lighted)	Aerosonic	Repair
10460-11139	C661072-0202	Altimeter (-1k-60k ft, mbar, Lighted)	Aerosonic	Repair
105-389011-31	-	Engine Instrument Cluster	Beechcraft	Repair
105-389011-5	-	Engine Instrument Cluster	Beechcraft	Repair

Part Number	Model	Description	Manufacturer	Capability
1080.091-921	AS3100-(12)-07	Audio Panel	Becker	Repair
108-384003-23	-	Engine Instrument Cluster	Beechcraft	Repair
109-384007-1	5000B-30	Attitude Gyro, Lighted	Beechcraft	Repair
10962-2	S6155-61198-102	Frequency Sensor	Sikorsky	Repair
10962-3	S6155-61198-103	Frequency Sensor	Sikorsky	Repair
111302-5	-	Horizontal Situation Indicator	Astronautics	Repair
111303-4	-	Attitude Director Indicator	Astronautics	Repair
114-380010-1	RCA56-9	Turn & Bank Indicator	RC Allen	Repair
114-380011-3	RCA60-02	Turn & Slip Indicator	RC Allen	Repair
114-380014-1	4000B-27	Directional Gyro, Lighted	Beechcraft	Repair
114-380017-3	-	Pressure Indicator, Cabin Diff	Beechcraft	Repair
114-380017-5	-	Pressure Indicator, Cabin Diff	Beechcraft	Repair
114-380020-1	MD124-1	Cabin Air Temperature Indicator	Beechcraft	Repair
114-380049-11	MD95-11	Dual Prop Ammeter	Beechcraft	Repair
114-380057-1	RCA22-20	Horizon Indicator	RC Allen	Repair
114-380057-3	RCA22-30	Horizon Indicator	RC Allen	Repair
114-380057-5	RCA22-33	Horizon Indicator	RC Allen	Repair
117-3840281-1	RCA22-25	Horizon Indicator	RC Allen	Repair
12002-0105	C661011-0105	Altimeter (-1k-20k ft, in.Hg)	MacLeod	Repair
12002-0106	C661011-0106	Altimeter (-1k-20k ft, mbar)	MacLeod	Repair
12003M	-	Altimeter (-1k-20k ft, mbar)	MacLeod	Repair
12008-13	-	Altimeter (-1k-20k ft, mbar)	MacLeod	Repair
12008-9	-	Altimeter (-1k-20k ft, in.Hg)	MacLeod	Repair
12009-1000	-	Altimeter (-1k-20k ft, in.Hg)	MacLeod	Repair
12009-2000	-	Altimeter (-1k-20k ft, in.Hg)	MacLeod	Repair
120-12002-0105	-	Altimeter (-1k-20k ft, in.Hg)	MacLeod	Repair
120-12002-0106	-	Altimeter (-1k-20k ft, mbar)	MacLeod	Repair
120-12003	-	Altimeter (-1k-20k ft, in.Hg)	MacLeod	Repair
120-12003M	-	Altimeter (-1k-20k ft, mbar)	MacLeod	Repair
120-12008-13	-	Altimeter (-1k-20k ft, mbar)	MacLeod	Repair
120-12008-9	-	Altimeter (-1k-20k ft, in.Hg)	MacLeod	Repair
120-12009-1000	-	Altimeter (-1k-20k ft, in.Hg)	MacLeod	Repair
120-12009-2000	-	Altimeter (-1k-20k ft, in.Hg)	MacLeod	Repair
121672-01	7000B	Vertical Gyro	Lear Siegler	Repair
121672-01-15	7000B	Vertical Gyro	Lear Siegler	Repair
121672-01-16	7000B	Vertical Gyro	Lear Siegler	Repair
121672-01-17	7000B	Vertical Gyro	Lear Siegler	Repair
1229-1	-	Battery Temperature Indicator	Avtech	Repair
1229-1-1	-	Battery Temperature Indicator	Avtech	Repair
1234T100-3ATZ	1234T100	Turn & Slip Indicator, Lighted	Electric Gyro Corp	Repair
1234T100-3TZ	1234T100	Turn & Slip Indicator, Lighted	Electric Gyro Corp	Repair
1234T100-7ATZ	1234T100	Turn & Slip Indicator	Electric Gyro Corp	Repair
1234T100-7TZ	1234T100	Turn & Slip Indicator	Electric Gyro Corp	Repair
1234T100-7TZ6	1234T100	Turn & Slip Indicator	Electric Gyro Corp	Repair
1234T100-8ATZ	1234T100	Turn & Slip Indicator	Electric Gyro Corp	Repair
1234T100-9TZ	1234T100	Turn & Slip Indicator	Electric Gyro Corp	Repair
124.013-1	-	Dual Temp & Pressure Indicator	Kratos	Repair
124.013-3	-	Dual Temp & Pressure Indicator	Kratos	Repair
124.013-4	209-070-262-105	Dual Temp & Pressure Indicator	Kratos	Repair
124.014-111	212-070-116-11	Dual Temp & Pressure Indicator	Kratos	Repair
124.014-121	212-070-116-1	Dual Temp & Pressure Indicator	Kratos	Repair
124.014-13	212-070-116-13	Dual Temp & Pressure Indicator	Kratos	Repair
124.014-15	212-070-116-15	Dual Temp & Pressure Indicator	Kratos	Repair
124.014-17	212-070-116-17	Dual Temp & Pressure Indicator	Kratos	Repair
124.014-19	212-070-116-19	Dual Temp & Pressure Indicator	Kratos	Repair
124.014-23	212-070-116-23	Dual Temp & Pressure Indicator	Kratos	Repair
124.014-25	212-070-116-25	Dual Temp & Pressure Indicator	Kratos	Repair
124.040-1	209-070-263-3	Dual AC/DC Voltmeter	Kratos	Repair
124.040-1	209-070-263-003	Dual AC/DC Voltmeter	Kratos	Repair
124.041-1	212-075-036-101	Dual Temp & Pressure Indicator	Kratos	Repair
124.041-3	212-075-036-103	Dual Temp & Pressure Indicator	Kratos	Repair
124.044-2	-	Fuel Pressure Indicator	Kratos	Repair
124.044-3	214-075-253-1	Fuel Pressure Indicator	Kratos	Repair
124.067-2	212-075-420-3	ITT Indicator	Kratos	Repair
124.067-2	212-075-420-003	ITT Indicator	Kratos	Repair
124.115-1	-	Dual Temp & Pressure Indicator	Kratos	Repair

Part Number	Model	Description	Manufacturer	Capability
124.115-3	209-070-262-101	Dual Temp & Pressure Indicator	Kratos	Repair
124.115-5	209-070-262-103	Dual Temp & Pressure Indicator	Kratos	Repair
124.273-3	214-075-222-3	Dual Temp & Pressure Indicator	Kratos	Repair
124.273-5	214-075-222-5	Dual Temp & Pressure Indicator	Kratos	Repair
124.412-1	-	EGT Indicator	Kratos	Repair
124.444-0	-	TOT Indicator	Kratos	Repair
124.444-10	-	TOT Indicator	Kratos	Repair
124.444-12	-	TOT Indicator	Kratos	Repair
124.444-14	-	TOT Indicator	Kratos	Repair
124.444-16	-	TOT Indicator	Kratos	Repair
124.444-18	-	TOT Indicator	Kratos	Repair
124.444-2	-	TOT Indicator	Kratos	Repair
124.444-20	-	TOT Indicator	Kratos	Repair
124.444-4	-	TOT Indicator	Kratos	Repair
124.444-6	-	TOT Indicator	Kratos	Repair
124.444-8	-	TOT Indicator	Kratos	Repair
124.480-1	212-075-562-1	ITT Indicator	Kratos	Repair
124.480-1	212-075-562-001	ITT Indicator	Kratos	Repair
124.480-3	212-075-562-3	ITT Indicator	Kratos	Repair
124.480-3	212-075-562-003	ITT Indicator	Kratos	Repair
124.933A	209-070-264-1	Dual Ammeter	Kratos	Repair
124.933A	209-070-264-001	Dual Ammeter	Kratos	Repair
124.934A	209-070-263-1	Dual AC/DC Voltmeter	Kratos	Repair
124.934A	209-070-263-001	Dual AC/DC Voltmeter	Kratos	Repair
124623-01	7000E	Vertical Gyro, Type MD-1	Lear Siegler	Repair
124623-01-09	7000E	Vertical Gyro, Type MD-1	Lear Siegler	Repair
124623-01-10	7000E	Vertical Gyro, Type MD-1	Lear Siegler	Repair
124623-01-12	7000E	Vertical Gyro, Type MD-1	Lear Siegler	Repair
126-30-280	4000B-35	Directional Gyro	Slingsby Aviation	Repair
126-30-281	5000B-44	Attitude Gyro	Slingsby Aviation	Repair
1301-0001	-	Altimeter (-1k-35k ft, Lighted)	Aerosonic	Repair
1301-1001	212-070-238-3	Altimeter (-1k-35k ft, Lighted)	Aerosonic	Repair
1301-1001	212-070-238-003	Altimeter (-1k-35k ft, Lighted)	Aerosonic	Repair
1301-1001	10035-11326	Altimeter (-1k-35k ft, Lighted)	Aerosonic	Repair
1301-1002	-	Altimeter (-1k-35k ft, Lighted)	Aerosonic	Repair
1301-2001	212-070-238-1	Altimeter (-1k-35k ft, Lighted)	Aerosonic	Repair
1301-2001	212-070-238-001	Altimeter (-1k-35k ft, Lighted)	Aerosonic	Repair
13502-0201	-	Altimeter (-1k-35k ft, in.Hg)	MacLeod	Repair
13502-0202	-	Altimeter (-1k-35k ft, mbar)	MacLeod	Repair
13503M	-	Altimeter (-1k-35k ft, mbar)	MacLeod	Repair
13508-1	-	Altimeter (-1k-35k ft, in.Hg)	MacLeod	Repair
13508-5	-	Altimeter (-1k-35k ft, mbar)	MacLeod	Repair
135-13502-0201	-	Altimeter (-1k-35k ft, in.Hg)	MacLeod	Repair
135-13502-0202	-	Altimeter (-1k-35k ft, mbar)	MacLeod	Repair
135-13503	-	Altimeter (-1k-35k ft, in.Hg)	MacLeod	Repair
135-13503M	-	Altimeter (-1k-35k ft, mbar)	MacLeod	Repair
135-13508-1	-	Altimeter (-1k-35k ft, in.Hg)	MacLeod	Repair
135-13508-5	-	Altimeter (-1k-35k ft, mbar)	MacLeod	Repair
135-13522-1000	-	Altimeter (-1k-35k ft, in.Hg)	MacLeod	Repair
135-13522-1100	-	Altimeter (-1k-35k ft, mbar)	MacLeod	Repair
13522-1000	-	Altimeter (-1k-35k ft, in.Hg)	MacLeod	Repair
13522-1100	-	Altimeter (-1k-35k ft, mbar)	MacLeod	Repair
1372-1-101	209-075-326-101	RPM Limit Detector	Avtech	Repair
1372-1-5	209-075-326-5	RPM Limit Detector	Avtech	Repair
1372-1-5	209-075-326-005	RPM Limit Detector	Avtech	Repair
138740-15	-	Horizontal Situation Indicator	Astronautics	Repair
138740-17	-	Horizontal Situation Indicator	Astronautics	Repair
138740-19	-	Horizontal Situation Indicator	Astronautics	Repair
138740-23	-	Horizontal Situation Indicator	Astronautics	Repair
138740-25	-	Horizontal Situation Indicator	Astronautics	Repair
138740-9	-	Horizontal Situation Indicator	Astronautics	Repair
1394T100-10RA	1394T100 RA	Turn Coordinator, Lighted	Electric Gyro Corp	Repair
1394T100-10RB	1394T100 RB	Turn Coordinator, Lighted	Electric Gyro Corp	Repair
1394T100-10RZ	1394T100 RZ	Turn Coordinator, Lighted	Electric Gyro Corp	Repair
1394T100-11RZ	1394T100 RZ	Turn Coordinator, Lighted	Electric Gyro Corp	Repair
1394T100-12RA	1394T100 RA	Turn Coordinator, Lighted	Electric Gyro Corp	Repair

Part Number	Model	Description	Manufacturer	Capability
1394T100-12RB	1394T100 RB	Turn Coordinator, Lighted	Electric Gyro Corp	Repair
1394T100-12RZ	1394T100 RZ	Turn Coordinator	Electric Gyro Corp	Repair
1394T100-14RB	1394T100 RB	Turn Coordinator, Lighted	Electric Gyro Corp	Repair
1394T100-15RZ	1394T100 RZ	Turn Coordinator	Electric Gyro Corp	Repair
1394T100-19RZ	1394T100 RZ	Turn Coordinator, Lighted	Electric Gyro Corp	Repair
1394T100-20RZ	1394T100 RZ	Turn Coordinator	Electric Gyro Corp	Repair
1394T100-3(5)	-	Turn Coordinator	Electric Gyro Corp	Repair
1394T100-3A	1394T100 A	Turn Coordinator, Lighted	Electric Gyro Corp	Repair
1394T100-3AC	1394T100 A	Turn Coordinator, Lighted	Electric Gyro Corp	Repair
1394T100-3B	1394T100 B	Turn Coordinator, Lighted	Electric Gyro Corp	Repair
1394T100-3BC	1394T100 B	Turn Coordinator, Lighted	Electric Gyro Corp	Repair
1394T100-3Z	1394T100 Z	Turn Coordinator, Lighted	Electric Gyro Corp	Repair
1394T100-3ZB	1394T100 Z	Turn Coordinator, Lighted	Electric Gyro Corp	Repair
1394T100-7A	1394T100 A	Turn Coordinator	Electric Gyro Corp	Repair
1394T100-7B	1394T100 B	Turn Coordinator	Electric Gyro Corp	Repair
1394T100-7RB	1394T100 RB	Turn Coordinator	Electric Gyro Corp	Repair
1394T100-7RZ	1394T100 RZ	Turn Coordinator	Electric Gyro Corp	Repair
1394T100-7Z	1394T100 Z	Turn Coordinator	Electric Gyro Corp	Repair
1394T100-7ZP	1394T100 Z	Turn Coordinator	Electric Gyro Corp	Repair
1394T100-8RA	1394T100 RA	Turn Coordinator, Lighted	Electric Gyro Corp	Repair
1394T100-8RB	1394T100 RB	Turn Coordinator, Lighted	Electric Gyro Corp	Repair
1394T100-8RZ	1394T100 RZ	Turn Coordinator	Electric Gyro Corp	Repair
142640-01-01	4005AC	Attitude Indicator	Lear Siegler	Repair
145974-01-03	9000C	Vertical Gyro	Lear Siegler	Repair
145974-01-03	209-075-365-1	Vertical Gyro	Lear Siegler	Repair
145974-01-03	209-075-365-001	Vertical Gyro	Lear Siegler	Repair
148957-01-01	9000F	Vertical Gyro	Lear Siegler	Repair
15020-6501	-	Altimeter (-1k-20k ft)	Aerosonic	Test/Recert
152B2	-	Temperature Indicator	Lewis Engineering	Repair
152B3	-	Temperature Indicator	Lewis Engineering	Repair
152B4	-	Temperature Indicator	Lewis Engineering	Repair
152B5	-	Temperature Indicator	Lewis Engineering	Repair
152BL702	-	Temperature Indicator	Horizon	Repair
152BL702A	-	Temperature Indicator	Horizon	Repair
152BL702C	-	Temperature Indicator	Horizon	Repair
152BL702D	-	Temperature Indicator	Horizon	Repair
152BL702E	-	Temperature Indicator	Horizon	Repair
152BL703	-	Temperature Indicator	Horizon	Repair
152BL704	-	Temperature Indicator	Horizon	Repair
152BL706	-	Temperature Indicator	Horizon	Repair
152BL708	-	Temperature Indicator	Horizon	Repair
152BL708A	-	Temperature Indicator	Horizon	Repair
152BL708B	-	Temperature Indicator	Horizon	Repair
152BL708H	-	Temperature Indicator	Horizon	Repair
152BL709	-	Temperature Indicator	Horizon	Repair
152BL709A	-	Temperature Indicator	Horizon	Repair
152BL722	-	Temperature Indicator	Horizon	Repair
152BL801	-	Temperature Indicator	Horizon	Repair
152BL801A	-	Temperature Indicator	Horizon	Repair
152BL801B	-	Temperature Indicator	Horizon	Repair
152BL801C	-	Temperature Indicator	Horizon	Repair
152BL801D	-	Temperature Indicator	Horizon	Repair
152BL801E	-	Temperature Indicator	Horizon	Repair
152BL802A	-	Temperature Indicator	Horizon	Repair
152BL802B	-	Temperature Indicator	Horizon	Repair
152BL802C	-	Temperature Indicator	Horizon	Repair
152BL802D	-	Temperature Indicator	Horizon	Repair
152BL803	-	Temperature Indicator	Horizon	Repair
152BL803A	-	Temperature Indicator	Horizon	Repair
152BL803B	-	Temperature Indicator	Horizon	Repair
152BL803C	-	Temperature Indicator	Horizon	Repair
152HL2W3	206-070-267-11	Temperature Indicator	Lewis Engineering	Repair
152HL2W3	206-070-267-011	Temperature Indicator	Lewis Engineering	Repair
154993-1	-	Encoding Altimeter (-1k-20k ft, in.Hg)	Aero Mechanism	Repair
154993-1-LX	-	Encoding Altimeter (-1k-20k ft, in.Hg, Lighted)	Aero Mechanism	Repair
154993-2	-	Encoding Altimeter (-1k-35k ft, in.Hg)	Aero Mechanism	Repair

Part Number	Model	Description	Manufacturer	Capability
154993-2-LX	-	Encoding Altimeter (-1k-35k ft, in.Hg, Lighted)	Aero Mechanism	Repair
154993-3	-	Encoding Altimeter (-1k-30k ft, in.Hg)	Aero Mechanism	Repair
154993-3-LX	-	Encoding Altimeter (-1k-30k ft, in.Hg, Lighted)	Aero Mechanism	Repair
154993-4	-	Encoding Altimeter (-1k-20k ft, mbar)	Aero Mechanism	Repair
154993-4-LX	-	Encoding Altimeter (-1k-20k ft, mbar, Lighted)	Aero Mechanism	Repair
154993-5	-	Encoding Altimeter (-1k-35k ft, mbar)	Aero Mechanism	Repair
154993-5-LX	-	Encoding Altimeter (-1k-35k ft, mbar, Lighted)	Aero Mechanism	Repair
154993-6	-	Encoding Altimeter (-1k-30k ft, mbar)	Aero Mechanism	Repair
154993-6-LX	-	Encoding Altimeter (-1k-30k ft, mbar, Lighted)	Aero Mechanism	Repair
155456-2	-	Airspeed Indicator	Aero Mechanism	Repair
155456-8	-	Airspeed Indicator, Lighted	Aero Mechanism	Repair
155456-9	-	Airspeed Indicator, Lighted	Aero Mechanism	Repair
155750-1	-	Altimeter (-1k-20k ft, in.Hg, Lighted)	Aero Mechanism	Repair
155750-2	-	Altimeter (-1k-20k ft, in.Hg)	Aero Mechanism	Repair
161243-01-01	9000P	Vertical Gyro	Lear Siegler	Repair
162B11	-	Temperature Indicator	Lewis Engineering	Repair
162B2	-	Temperature Indicator	Lewis Engineering	Repair
162B2A	-	Temperature Indicator	Lewis Engineering	Repair
162B3	-	Temperature Indicator	Lewis Engineering	Repair
162B3F	412-375-007-107	Temperature Indicator	Lewis Engineering	Repair
162B4	-	Temperature Indicator	Lewis Engineering	Repair
163B2	-	Oil Temp Indicator	Lewis Engineering	Repair
163B2	-	Temperature Indicator	Lewis Engineering	Repair
163B2D	-	Oil Temp Indicator	Lewis Engineering	Repair
163B2D	-	Temperature Indicator	Lewis Engineering	Repair
163B4	-	Oil Temp Indicator	Lewis Engineering	Repair
163B4	-	Temperature Indicator	Lewis Engineering	Repair
1652-6AJ-B6-1	-	Vertical Velocity Indicator	Bendix	Repair
1719694-507	AP-5001	Antenna Pedestal	Honeywell	Repair
1719694-508	AP-5001	Antenna Pedestal	Honeywell	Repair
1719694-515	WA-700	Antenna Pedestal	Honeywell	Repair
1719694-516	WA-700	Antenna Pedestal	Honeywell	Repair
1719694-517	WA-700	Antenna Pedestal	Honeywell	Repair
1719726-506	RT-5001	Radar Receiver Transmitter	Honeywell	Repair
1719726-507	RT-5001	Radar Receiver Transmitter	Honeywell	Repair
1719726-511	RT-5001	Radar Receiver Transmitter	Honeywell	Repair
1777213-503	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-523	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-553	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-600	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-602	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-603	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-605	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-606	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-607	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-620	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-622	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-623	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-625	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-626	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-627	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-633	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-635	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-653	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-655	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-657	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-803	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-833	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777213-903	C-6	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777214-600	C-6A	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777214-602	C-6A	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777214-603	C-6A	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777214-605	C-6A	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777214-620	C-6A	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777214-622	C-6A	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777214-623	C-6A	Gyrosyn Compass Indicator, Lighted	Sperry	Repair

Part Number	Model	Description	Manufacturer	Capability
1777214-625	C-6A	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777214-633	C-6A	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777214-653	C-6A	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777214-655	C-6A	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1777214-823	C-6A	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1778686-603	C-6D	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1778686-605	C-6D	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1778686-623	C-6D	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1778686-625	C-6D	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1778686-653	C-6D	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1778686-655	C-6D	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1778686-823	C-6D	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1778686-825	C-6D	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1782993-603	C-6F	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1782993-605	C-6F	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1782993-623	C-6F	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1782993-625	C-6F	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1782993-635	C-6F	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1782993-653	C-6F	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1782993-655	C-6F	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1783755-603	C-6H	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1783755-605	C-6H	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1783755-613	C-6H	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1783755-615	C-6H	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1783755-623	C-6H	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1783755-625	C-6H	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784389-353	C-6J	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784389-603	C-6J	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784389-605	C-6J	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784389-613	C-6J	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784389-615	C-6J	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784389-623	C-6J	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784389-625	C-6J	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784389-653	C-6J	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784460-355	C-6E	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784460-525	C-6E	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784460-555	C-6E	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784460-653	C-6E	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784460-655	C-6E	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784460-656	C-6E	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784460-657	C-6E	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
1784775-142	HZ-6	Attitude Indicator	Sperry	Repair
1784775-143	HZ-6	Attitude Indicator	Sperry	Repair
1784775-242	HZ-6	Attitude Indicator	Sperry	Repair
1784775-243	HZ-6	Attitude Indicator	Sperry	Repair
1784775-342	HZ-6	Attitude Indicator	Sperry	Repair
1784775-343	HZ-6	Attitude Indicator	Sperry	Repair
1784775-442	HZ-6	Attitude Indicator	Sperry	Repair
1784775-443	HZ-6	Attitude Indicator	Sperry	Repair
1784775-444	HZ-6	Attitude Indicator	Sperry	Repair
18-1278	-	Dual Oil Pressure Indicator	Courter	Repair
18-1278-2	-	Dual Oil Pressure Indicator	Courter	Repair
18-1486	-	Dual Oil Pressure Indicator	Courter	Repair
18-1487	-	Dual Hydraulic Pressure Indicator	Courter	Repair
18-1530	-	Dual Oil Pressure Indicator	Courter	Repair
18-1838-15	212-070-160-15	Dual Torque Indicator	Courter	Test/Recert
18-1838-17	212-070-160-17	Dual Torque Indicator	Courter	Test/Recert
18-1838-22	212-070-160-107	Dual Torque Indicator	Courter	Test/Recert
18-1874	214-075-220-1	Course Indicator	Courter	Repair
18-1874	214-075-220-001	Course Indicator	Courter	Repair
18-380021-3	4000B-4	Directional Gyro	Beechcraft	Repair
1A250(1A)	-	Static Inverter, 250VA	Avionic Instruments	Repair
1A250(1B)	-	Static Inverter, 250VA	Avionic Instruments	Repair
1A250(1BF)	-	Static Inverter, 250VA	Avionic Instruments	Repair
1A250(1C)	-	Static Inverter, 250VA	Avionic Instruments	Repair
1A250(1D)	-	Static Inverter, 250VA	Avionic Instruments	Repair

Part Number	Model	Description	Manufacturer	Capability
1B495	FD01-0101-1	Flux Detector, Magnetic	Century Flight	Test/Recert
1B495-1	FD01-0101-1	Flux Detector, Magnetic	Century Flight	Test/Recert
1B495-3	FD01-0201-2	Flux Detector, Magnetic	Century Flight	Test/Recert
1B495-4	FD01-0301-1	Flux Detector, Magnetic	Century Flight	Test/Recert
1C714	-	Gyro Slaving Amplifier, Dual Channel	Century Flight	Repair
1D755	-	Gyro Slaving Amplifier w/ Bootstrap Synchro	Century Flight	Repair
1U149-001-1	5000B-5	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-001-2	5000B-25	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-001-3	5000B-28	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-001-4	5000B-30	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-001-5	5000B-35	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-001-6	5000B-41	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-002	5000F-5	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-002-1	5000F-7	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-002-2	5000F-10	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-002-3	5000F-11	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-002-6	5000F-17	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-003	5000E-2	Attitude Gyro	Sigma-Tek	Repair
1U149-003-1	5000E-2	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-003-2	5000E-2	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-003-3	5000E-2	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-004	5000E-3	Attitude Gyro	Sigma-Tek	Repair
1U149-004-1	5000E-3	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-005	5000B-11	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-006	5000E-7	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-006-1	5000E-10	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-006-8	5000E-22	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-007	5000E-6	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-007-1	5000E-11	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-007-9	5000E-23	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-010	5000E-13	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-010-1	5000B-37	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-010-2	5000B-39	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-010-3	5000B-49	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-010-4	5000B-54	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-010-5	5000B-64	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-010-6	5000B-66	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-010-7	5000B-70	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-011	5000B-27	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-012	5000B-40	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-012-1	5000B-47	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-012-2	5000B-52	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-012-4	5000B-55	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-013-1	5000B-45	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-013-3	5000B-53	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-014-12	5000B-73	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-014-13	5000B-74	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-014-5	5000B-58	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-015-11	5000B-72	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-015-15	5000B-75	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-015-9	5000B-67	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-016-7	5000B-62	Attitude Gyro	Sigma-Tek	Repair
1U149-016-8	5000B-63	Attitude Gyro	Sigma-Tek	Repair
1U149-017-10	5000B-68	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-018-14	5000E-24	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-018-16	5000E-25	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-018-17	5000E-26	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-018-18	5000E-27	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-019-19	5000B-76	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-021-1	5000M	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-021-9	5000M-16	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-022-2	5000M-5	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-023-3	5000M-6	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-024-4	5000M-7	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-025-5	5000M-8	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-026-6	5000M-9	Attitude Gyro, Lighted	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
1U149-027-7	5000M-14	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U149-028-8	5000M-15	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U150-001-1	4000B-7	Directional Gyro, Lighted	Edo-Aire	Repair
1U150-002	4000B-11	Directional Gyro, Lighted	Edo-Aire	Repair
1U150-003	4000C-1	Directional Gyro, Lighted	Edo-Aire	Repair
1U262-001-1	4000B	Directional Gyro	Sigma-Tek	Repair
1U262-001-10	4000B-9	Directional Gyro	Sigma-Tek	Repair
1U262-001-11	4000B-10	Directional Gyro	Sigma-Tek	Repair
1U262-001-13	4000B-12	Directional Gyro	Sigma-Tek	Repair
1U262-001-16	4000B-13	Directional Gyro	Sigma-Tek	Repair
1U262-001-18	4000B-15	Directional Gyro	Sigma-Tek	Repair
1U262-001-2	4000B-1	Directional Gyro	Sigma-Tek	Repair
1U262-001-21	4000B-16	Directional Gyro	Sigma-Tek	Repair
1U262-001-22	4000B-17	Directional Gyro	Sigma-Tek	Repair
1U262-001-24	4000B-18	Directional Gyro	Sigma-Tek	Repair
1U262-001-25	4000B-19	Directional Gyro	Sigma-Tek	Repair
1U262-001-27	4000B-20	Directional Gyro	Sigma-Tek	Repair
1U262-001-29	4000B-21	Directional Gyro	Sigma-Tek	Repair
1U262-001-3	4000B-2	Directional Gyro	Sigma-Tek	Repair
1U262-001-37	4000B-26	Directional Gyro	Sigma-Tek	Repair
1U262-001-39	4000B-30	Directional Gyro	Sigma-Tek	Repair
1U262-001-4	4000B-3	Directional Gyro	Sigma-Tek	Repair
1U262-001-5	4000B-4	Directional Gyro	Sigma-Tek	Repair
1U262-001-50	4000B-35	Directional Gyro	Sigma-Tek	Repair
1U262-001-52	4000B-37	Directional Gyro	Sigma-Tek	Repair
1U262-001-54	4000B-39	Directional Gyro	Sigma-Tek	Repair
1U262-001-57	4000B-42	Directional Gyro	Sigma-Tek	Repair
1U262-001-6	4000B-5	Directional Gyro	Sigma-Tek	Repair
1U262-001-60	4000B-44	Directional Gyro	Sigma-Tek	Repair
1U262-001-61	4000B-45	Directional Gyro	Sigma-Tek	Repair
1U262-001-7	4000B-6	Directional Gyro	Sigma-Tek	Repair
1U262-001-9	4000B-8	Directional Gyro	Sigma-Tek	Repair
1U262-002-12	4000B-11	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-002-17	4000B-14	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-002-32	4000B-22	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-002-42	4000B-31	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-002-44	4000B-33	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-002-51	4000B-36	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-002-53	4000B-38	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-002-55	4000B-40	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-002-58	4000B-43	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-002-67	4000B-46	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-002-69	4000B-48	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-002-8	4000B-7	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-003-14	4000C	Directional Gryo	Sigma-Tek	Repair
1U262-003-34	4000C-4	Directional Gryo	Sigma-Tek	Repair
1U262-003-48	4000C-12	Directional Gryo	Sigma-Tek	Repair
1U262-003-65	4000C-18	Directional Gryo	Sigma-Tek	Repair
1U262-004-15	4000C-1	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-004-35	4000C-7	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-004-49	4000C-13	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-004-66	4000C-19	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-004-68	4000C-22	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-005-19	4000D	Directional Gryo	Sigma-Tek	Repair
1U262-005-20	4000D-1	Directional Gryo	Sigma-Tek	Repair
1U262-005-26	4000D-2	Directional Gryo	Sigma-Tek	Repair
1U262-005-36	4000D-3	Directional Gryo	Sigma-Tek	Repair
1U262-005-43	4000D-5	Directional Gryo	Sigma-Tek	Repair
1U262-005-46	4000D-7	Directional Gryo	Sigma-Tek	Repair
1U262-006-28	4000E	Directional Gryo	Sigma-Tek	Repair
1U262-006-45	4000D-6	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-006-64	4000D-9	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-007-23	4000HR	Directional Gyro	Sigma-Tek	Repair
1U262-007-33	4000HR-1	Directional Gyro	Sigma-Tek	Repair
1U262-007-40	4000HR-2	Directional Gyro	Sigma-Tek	Repair
1U262-008-30	4000C-2	Directional Gryo	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
1U262-009-31	4000C-3	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-010-41	4000HR-3	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-010-59	4000HR-5	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-010-62	4000HR-6	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-010-63	4000HR-7	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-011-1	4000B-23	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-011-14	4000B-34	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-011-15	4000B-41	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-011-16	4000B-47	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-011-8	4000B-28	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-012-2	4000B-24	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-013-3	4000B-25	Directional Gyro	Sigma-Tek	Repair
1U262-014-11	4000C-9	Directional Gryo	Sigma-Tek	Repair
1U262-014-4	4000C-5	Directional Gyro	Sigma-Tek	Repair
1U262-015-12	4000C-10	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-015-13	4000C-11	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-015-17	4000C-20	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-015-5	4000C-6	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-017-7	4000B-27	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-018-10	4000D-4	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-019-9	4000B-32	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-031-1	4000H	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-032-2	4000H-1	Directional Gyro	Sigma-Tek	Repair
1U262-033-3	4000H-2	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-034-4	4000H-3	Directional Gryo	Sigma-Tek	Repair
1U262-035-7	4000H-6	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-036-8	4000H-7	Directional Gryo	Sigma-Tek	Repair
1U262-037-9	4000H-8	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-038-10	4000H-9	Directional Gryo	Sigma-Tek	Repair
1U262-041-1	4000C-16	Directional Gryo	Sigma-Tek	Repair
1U262-042-2	4000C-15	Directional Gyro, Lighted	Sigma-Tek	Repair
1U262-042-3	4000C-17	Directional Gyro, Lighted	Sigma-Tek	Repair
1U367-101-1	52D167	Attitude Gyro	Edo-Aire	Repair
1U367-102-2	52D167M	Attitude Gyro, Lighted	Edo-Aire	Repair
1U367-102-9	52D167-1M	Attitude Gyro, Lighted	Edo-Aire	Repair
1U367-103-3	52D166	Attitude Gyro	Edo-Aire	Repair
1U367-104-4	52D166M	Attitude Gyro, Lighted	Edo-Aire	Repair
1U367-105-5	101-384115-1	Attitude Gyro, Lighted	Edo-Aire	Repair
1U367-105-6	-	Attitude Gyro, Lighted	Edo-Aire	Repair
1U367-106-7	-	Attitude Gyro, Lighted	Edo-Aire	Repair
1U367-107-8	-	Attitude Gyro	Edo-Aire	Repair
1U367-201-1	52D266	Attitude Gyro	Sigma-Tek	Repair
1U367-202-2	52D266M	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-203-3	52D267	Attitude Gyro	Sigma-Tek	Repair
1U367-204-17	52D267N	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-204-4	52D267M	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-205-5	-	Attitude Gyro	Sigma-Tek	Repair
1U367-206-6	-	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-207-13	C661078-0101	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-207-15	-	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-207-16	-	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-207-7	-	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-207-8	101-380036-1	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-208-9	-	Attitude Gyro	Sigma-Tek	Repair
1U367-209-10	-	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-210-11	-	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-210-12	119-380005-1	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-211-1	52D266-1	Attitude Gyro	Sigma-Tek	Repair
1U367-212-2	52D266-1M	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-213-3	52D267-1	Attitude Gyro	Sigma-Tek	Repair
1U367-214-4	52D267-1M	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-221-1	51640-0000	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-221-3	51640-0010	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-222-2	51640-0008	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-222-4	51640-0018	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-231-1	117-384043-1	Attitude Gyro, Lighted	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
1U367-232-2	-	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-232-4	-	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-233-3	-	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-233-6	-	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-234-5	-	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-251-1	-	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-301-1	114-380013-1	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-302-2	114-380013-5	Attitude Gyro, Lighted	Sigma-Tek	Repair
1U367-303-3	-	Attitude Gyro, Lighted	Sigma-Tek	Repair
200-11DC(14)	-	Directional Gyro	AIM	Repair
200-11L	-	Directional Gyro	AIM	Repair
20018-11233	-	Airspeed Indicator, 0-180 Knots	Aerosonic	Repair
200-2	-	Directional Gyro	AIM	Repair
20020-11293	76450-00801-101	Airspeed Indicator, 0-200 Knots	Aerosonic	Repair
200-2BL	-	Directional Gyro	AIM	Repair
200-2ED	-	Directional Gyro	AIM	Repair
200-3	-	Directional Gyro	AIM	Repair
200-3DC(14)	-	Directional Gyro	AIM	Repair
200-3DC(28)	-	Directional Gyro	AIM	Repair
200-3E	-	Directional Gyro	AIM	Repair
200-3L	-	Directional Gyro	AIM	Repair
200-3M	-	Directional Gyro	AIM	Repair
200-4	-	Directional Gyro	AIM	Repair
200-5	52C72	Directional Gyro	AIM	Repair
200-5DBL	-	Directional Gyro	AIM	Repair
200-5G	-	Directional Gyro	AIM	Repair
200-5HBL	-	Directional Gyro	AIM	Repair
200-5HC	-	Directional Gyro	AIM	Repair
200-5J	-	Directional Gyro	AIM	Repair
200-5M	-	Directional Gyro	AIM	Repair
200-6BL	-	Directional Gyro	AIM	Repair
200-6DC(14)	-	Directional Gyro	AIM	Repair
200-6DC(28)	-	Directional Gyro	AIM	Repair
200-6E	-	Directional Gyro	AIM	Repair
200-7E	-	Directional Gyro	AIM	Repair
200-8	-	Directional Gyro	AIM	Repair
200-9BC	-	Directional Gyro	AIM	Repair
200-9BM	-	Directional Gyro	AIM	Repair
200-9C	-	Directional Gyro	AIM	Repair
200-9M	-	Directional Gyro	AIM	Repair
200-9ML	-	Directional Gyro	AIM	Repair
200-9X	-	Directional Gyro	AIM	Repair
200DCBL	-	Directional Gyro	AIM	Repair
200DCD(14)	-	Directional Gyro	AIM	Repair
200EDC	-	Directional Gyro	AIM	Repair
200ESB	-	Directional Gyro	AIM	Repair
201530-11373	130-380005-7	Airspeed Indicator	Aerosonic	Repair
20240-1188	C661063-0102	Airspeed Indicator	Aerosonic	Repair
20240-1189	C661063-0103	Airspeed Indicator	Aerosonic	Repair
20242005-104	-	Annunciator Meter	Bell Helicopter	Repair
203-021-003	76450-01078-103	Fuel Quantity Indicator	Gull	Repair
203-022-005	76450-01078-101	Dual Temp & Pressure Indicator	Gull	Repair
203-022-013	76450-00906-102	Dual Temp & Pressure Indicator	Gull	Repair
203-022-017	-	Dual Temp & Pressure Indicator	Gull	Repair
203-023-003	76450-01078-104	Dual Pressure Indicator	Gull	Repair
20321-001	76550-00915-108	Master Caution Panel	Korry	Repair
205-075-388-15	205-075-388-015	RPM Limit Detector	Bell Helicopter	Repair
206-075-545-1	206-075-545-001	RPM Sensor	Bell Helicopter	Test/Recert
206-075-606-103	RCA15BK-1	Directional Gyro	RC Allen	Repair
206-075-607-103	RCA26BK-12	Attitude Indicator	RC Allen	Repair
209-075-326-1	209-075-326-001	RPM Limit Detector	Bell Helicopter	Repair
212-073-927-1	212-073-927-001	Positioning Motor	Bell Helicopter	Repair
212-073-927-3	212-073-927-003	Servo Controller	Bell Helicopter	Repair
212-075-406-105	-	Engine Control Panel	Bell Helicopter	Repair
212-075-418-3	212-075-418-003	Actuator, Passenger Step	Bell Helicopter	Repair
212-077-163-1	212-077-163-001	Compass Control Panel	Bell Helicopter	Repair

Part Number	Model	Description	Manufacturer	Capability
212-077-164-1	212-077-164-001	Compass Control Panel	Bell Helicopter	Repair
214-074-300-107	-	AFCS Engage/Annunciator Panel	Bell Helicopter	Repair
214-075-150-1	214-075-150-001	Relay	Bell Helicopter	Test/Recert
214-175-107-101	-	Engine & Fuel Control Panel	Bell Helicopter	Repair
22-262-022	-	Indicator, Fuel Flow & Manifold Pressure	Sigma-Tek	Repair
22-262-022-1	C662001-0101	Indicator, Fuel Flow & Manifold Pressure	Sigma-Tek	Repair
22-262-022-2	C662001-0102	Indicator, Fuel Flow & Manifold Pressure	Sigma-Tek	Repair
22-262-022-3	C662001-0103	Indicator, Fuel Flow & Manifold Pressure	Sigma-Tek	Repair
22-262-022-4	C662001-0104	Indicator, Fuel Flow & Manifold Pressure	Sigma-Tek	Repair
22-280	-	Dual Tachometer	Sigma-Tek	Repair
22-280-015	-	Dual Tachometer	Sigma-Tek	Repair
22-280-015-2	-	Dual Tachometer	Sigma-Tek	Repair
22-280-015-3	-	Dual Tachometer	Sigma-Tek	Repair
22-280-015A	-	Dual Tachometer	Sigma-Tek	Repair
22-280-02	-	Dual Tachometer	Sigma-Tek	Repair
22-280-021	-	Dual Tachometer	Sigma-Tek	Repair
22-280-021-1	-	Dual Tachometer	Sigma-Tek	Repair
22-280-021-1A	-	Dual Tachometer	Sigma-Tek	Repair
22-280-021-2	-	Dual Tachometer	Sigma-Tek	Repair
22-280-021-3	-	Dual Tachometer	Sigma-Tek	Repair
22-280-021-4	-	Dual Tachometer	Sigma-Tek	Repair
22-280-021-5	-	Dual Tachometer	Sigma-Tek	Repair
22-280-021-6	-	Dual Tachometer	Sigma-Tek	Repair
22-280-021-6A	-	Dual Tachometer	Sigma-Tek	Repair
22-280-021-7	-	Dual Tachometer	Sigma-Tek	Repair
22-280-021-7A	-	Dual Tachometer	Sigma-Tek	Repair
22-280-021-8	-	Dual Tachometer	Sigma-Tek	Repair
22-280-021-8A	-	Dual Tachometer	Sigma-Tek	Repair
22-280-03	-	Dual Tachometer	Sigma-Tek	Repair
22-280-032	-	Dual Tachometer	Sigma-Tek	Repair
22-280-032-1	-	Dual Tachometer	Sigma-Tek	Repair
22-280-04	-	Dual Tachometer	Sigma-Tek	Repair
22-280-930	-	Dual Tachometer	Sigma-Tek	Repair
22-280-930-1	-	Dual Tachometer	Sigma-Tek	Repair
22-281	-	Dual Tachometer	Sigma-Tek	Repair
22-281-017	96-380014-3	Dual Tachometer	Sigma-Tek	Repair
22-281-017-1	96-380014-1	Dual Tachometer	Sigma-Tek	Repair
22-281-017-2	96-380014-5	Dual Tachometer	Sigma-Tek	Repair
22-281-017-3	96-380014-7	Dual Tachometer	Sigma-Tek	Repair
22-284	-	Dual Tachometer	Sigma-Tek	Repair
22-284-01	50-380010-9	Dual Tachometer	Sigma-Tek	Repair
22-284-010	-	Dual Tachometer	Sigma-Tek	Repair
22-284-011	50-380010-1	Dual Tachometer	Sigma-Tek	Repair
22-284-012	50-380010-7	Dual Tachometer	Sigma-Tek	Repair
22-284-013	50-380010-11	Dual Tachometer	Sigma-Tek	Repair
22-284-014	50-380010-13	Dual Tachometer	Sigma-Tek	Repair
22-284-015	50-380010-15	Dual Tachometer	Sigma-Tek	Repair
22-284-016	50-380010-17	Dual Tachometer	Sigma-Tek	Repair
22-284-017	-	Dual Tachometer	Sigma-Tek	Repair
22-284-02	-	Dual Tachometer	Sigma-Tek	Repair
22-284-020	-	Dual Tachometer	Sigma-Tek	Repair
22-284-020-1	-	Dual Tachometer	Sigma-Tek	Repair
22-284-021	50-380010-23	Dual Tachometer	Sigma-Tek	Repair
22-284-021-1	50-380010-25	Dual Tachometer	Sigma-Tek	Repair
22-284-023	CM3305-1	Dual Tachometer	Sigma-Tek	Repair
22-284-024	-	Dual Tachometer	Sigma-Tek	Repair
22-284-024-1	-	Dual Tachometer	Sigma-Tek	Repair
22-284-024-2	-	Dual Tachometer	Sigma-Tek	Repair
22-284-028	-	Dual Tachometer	Sigma-Tek	Repair
22-284-028-1	-	Dual Tachometer	Sigma-Tek	Repair
22-284-028-2	-	Dual Tachometer	Sigma-Tek	Repair
22-284-03	-	Dual Tachometer	Sigma-Tek	Repair
22-284-04	-	Dual Tachometer	Sigma-Tek	Repair
22-284-05	-	Dual Tachometer	Sigma-Tek	Repair
22-284-06	-	Dual Tachometer	Sigma-Tek	Repair
22-284-09	50-380010-21	Dual Tachometer	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
22-285	-	Dual Tachometer	Sigma-Tek	Repair
22-285-01	206-070-112-1	Dual Tachometer	Sigma-Tek	Repair
22-285-01	206-070-112-001	Dual Tachometer	Sigma-Tek	Repair
22-285-01-1	206-070-241-1	Dual Tachometer	Sigma-Tek	Repair
22-285-01-1	206-070-241-001	Dual Tachometer	Sigma-Tek	Repair
22-285-03	206-070-265-1	Dual Tachometer	Sigma-Tek	Repair
22-285-03	206-070-265-001	Dual Tachometer	Sigma-Tek	Repair
22-285-03-1	206-070-265-3	Dual Tachometer	Sigma-Tek	Repair
22-285-03-1	206-070-265-003	Dual Tachometer	Sigma-Tek	Repair
22-285-03-2	206-070-265-7	Dual Tachometer	Sigma-Tek	Repair
22-285-03-2	206-070-265-007	Dual Tachometer	Sigma-Tek	Repair
22-285-05	-	Dual Tachometer	Sigma-Tek	Repair
22-285-06	-	Dual Tachometer	Sigma-Tek	Repair
22-285-07	206-070-265-5	Dual Tachometer	Sigma-Tek	Repair
22-285-07	206-070-265-005	Dual Tachometer	Sigma-Tek	Repair
22-294-03	205-070-119-3	Indicator, Free Air Temperature	Weston Instruments	Repair
22-294-03	205-070-119-003	Indicator, Free Air Temperature	Weston Instruments	Repair
2231230-10-A-1	-	MFDAU	Teledyne	Limited Repair
22-374-01	-	Altimeter (-1k-20k ft, in.Hg)	Sigma-Tek	Repair
22-374-01-1	-	Altimeter (-1k-20k ft, mbar)	Sigma-Tek	Repair
22-374-A01	-	Altimeter (-1k-35k ft, in.Hg)	Sigma-Tek	Repair
22-374-A01-1	-	Altimeter (-1k-35k ft, mbar)	Sigma-Tek	Repair
22-374-A01-2	-	Altimeter (-1k-35k ft, in.Hg)	Sigma-Tek	Repair
22-374-A01-3	-	Altimeter (-1k-35k ft, mbar)	Sigma-Tek	Repair
22-374-A03	-	Altimeter (-1k-35k ft, in.Hg)	Sigma-Tek	Repair
22-374-A03-1	-	Altimeter (-1k-35k ft, mbar)	Sigma-Tek	Repair
22-374-A03-2	-	Altimeter (-1k-35k ft, in.Hg)	Sigma-Tek	Repair
22-374-A03-3	-	Altimeter (-1k-35k ft, mbar)	Sigma-Tek	Repair
22-374-A04	-	Altimeter (-1k-35k ft, Dual Scale)	Sigma-Tek	Repair
22-374-B01	-	Altimeter (-1k-20k ft, in.Hg)	Sigma-Tek	Repair
22-374-B01-1	-	Altimeter (-1k-20k ft, mbar)	Sigma-Tek	Repair
22-374-B01-2	-	Altimeter (-1k-20k ft, in.Hg)	Sigma-Tek	Repair
22-374-B01-3	-	Altimeter (-1k-20k ft, mbar)	Sigma-Tek	Repair
22-374-B01-4	-	Altimeter (-1k-20k ft, in.Hg, Lighted)	Sigma-Tek	Repair
22-374-B04	-	Altimeter (-1k-20k ft, Dual Scale)	Sigma-Tek	Repair
22-696-01	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-013	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-014	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-015	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-016	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-017	35-380036-5	Airspeed Indicator	Sigma-Tek	Repair
22-696-017	35-380036-1	Airspeed Indicator	Sigma-Tek	Repair
22-696-017-1	35-380036-7	Airspeed Indicator	Sigma-Tek	Repair
22-696-017-2	35-380036-9	Airspeed Indicator	Sigma-Tek	Repair
22-696-017-3	35-380036-11	Airspeed Indicator	Sigma-Tek	Repair
22-696-017-4	35-380036-13	Airspeed Indicator	Sigma-Tek	Repair
22-696-017-5	35-380036-15	Airspeed Indicator	Sigma-Tek	Repair
22-696-017-6	35-380036-17	Airspeed Indicator	Sigma-Tek	Repair
22-696-018	35-380036-3	Airspeed Indicator	Sigma-Tek	Repair
22-696-02	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-021	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-035	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-036	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-037	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-039	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-04	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-040	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-041	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-042	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-043	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-044	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-045	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-046	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-047	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-048	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-049	-	Airspeed Indicator	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
22-696-05	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-050	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-051	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-052	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-053	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-054	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-055	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-056	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-059	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-06	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-061	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-062	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-065	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-067	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-068	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-069	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-070	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-071	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-072	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-073	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-074	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-075	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-075-1	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-075-2	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-075-3	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-077	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-077-1	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-078	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-079	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-080	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-081	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-083	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-083-1	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-083-2	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-084	169-380009	Airspeed Indicator	Sigma-Tek	Repair
22-696-084-1	169-380009-3	Airspeed Indicator	Sigma-Tek	Repair
22-696-084-2	169-380009-7	Airspeed Indicator	Sigma-Tek	Repair
22-696-084-3	169-380009-9	Airspeed Indicator	Sigma-Tek	Repair
22-696-084-4	169-380009-5	Airspeed Indicator	Sigma-Tek	Repair
22-696-086	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-086-1	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-086-2	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-086-3	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-086-4	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-087	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-087-1	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-088	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-089	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-091	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-092	-	Airspeed Indicator	Sigma-Tek	Repair
22-696-093	-	Airspeed Indicator	Sigma-Tek	Repair
22-993-02-1A	S1392-N2	Vertical Speed Indicator (0-2000ft/min)	Garwin	Repair
23-400-01	4000C	Directional Gryo	Edo-Aire	Repair
23-401-01	4000B-3	Directional Gyro	Weston	Repair
23-401-02	4000B	Directional Gyro	Weston	Repair
23-401-02-1	4000B-1	Directional Gyro	Weston	Repair
23-401-02-2	4000B-2	Directional Gyro	Weston	Repair
23-401-02-3	4000B-4	Directional Gyro	Weston	Repair
23-401-02-4	4000B-5	Directional Gyro	Weston	Repair
23-401-02-5	4000B-6	Directional Gyro	Weston	Repair
23-401-02-6	4000B-8	Directional Gyro	Weston	Repair
23-401-02-7	4000B-9	Directional Gyro	Weston	Repair
23-401-02-8	4000B-10	Directional Gyro	Weston	Repair
23-501-010	5000F-1	Attitude Gyro	Sigma-Tek	Repair
23-501-013	5000B-3	Attitude Gyro	Sigma-Tek	Repair
23-501-014	5000F-2	Attitude Gyro	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
23-501-015	5000F-3	Attitude Gyro	Sigma-Tek	Repair
23-501-016	5000B-10	Attitude Gyro	Sigma-Tek	Repair
23-501-016-1	5000B-33	Attitude Gyro	Sigma-Tek	Repair
23-501-016-2	5000B-34	Attitude Gyro	Sigma-Tek	Repair
23-501-017	5000F-6	Attitude Gyro	Sigma-Tek	Repair
23-501-017-1	5000F-9	Attitude Gyro	Sigma-Tek	Repair
23-501-017-2	5000F-14	Attitude Gyro	Sigma-Tek	Repair
23-501-018	5000B-12	Attitude Gyro	Sigma-Tek	Repair
23-501-018-1	5000B-13	Attitude Gyro	Sigma-Tek	Repair
23-501-018-2	5000B-22	Attitude Gyro	Sigma-Tek	Repair
23-501-019	5000F-8	Attitude Gyro	Sigma-Tek	Repair
23-501-019-1	5000F-12	Attitude Gyro	Sigma-Tek	Repair
23-501-02	5000D	Attitude Gyro	Sigma-Tek	Repair
23-501-020	5000F-13	Attitude Gyro	Sigma-Tek	Repair
23-501-021	5000B-31	Attitude Gyro	Sigma-Tek	Repair
23-501-03	5000B	Attitude Gyro	Sigma-Tek	Repair
23-501-03-1	5000B-8	Attitude Gyro	Sigma-Tek	Repair
23-501-031-1	5000B-38	Attitude Gyro	Sigma-Tek	Repair
23-501-03-2	5000B-15	Attitude Gyro	Sigma-Tek	Repair
23-501-032-2	5000B-43	Attitude Gyro	Sigma-Tek	Repair
23-501-032-3	5000B-50	Attitude Gyro	Sigma-Tek	Repair
23-501-033-3	5000B-46	Attitude Gyro	Sigma-Tek	Repair
23-501-034-4	5000B-51	Attitude Gyro	Sigma-Tek	Repair
23-501-035-5	5000M-1	Attitude Gyro	Sigma-Tek	Repair
23-501-036-6	5000M-2	Attitude Gyro	Sigma-Tek	Repair
23-501-037-7	5000M-3	Attitude Gyro	Sigma-Tek	Repair
23-501-038-8	5000M-4	Attitude Gyro	Sigma-Tek	Repair
23-501-039-9	5000M-10	Attitude Gyro	Sigma-Tek	Repair
23-501-04	5000E	Attitude Gyro	Sigma-Tek	Repair
23-501-040-10	5000M-11	Attitude Gyro	Sigma-Tek	Repair
23-501-04-1	5000E-4	Attitude Gyro	Sigma-Tek	Repair
23-501-041-1	5000B-60	Attitude Gyro	Sigma-Tek	Repair
23-501-04-2	5000E-8	Attitude Gyro	Sigma-Tek	Repair
23-501-042-2	5000B-61	Attitude Gyro	Sigma-Tek	Repair
23-501-04-24	5000E-20	Attitude Gyro	Sigma-Tek	Repair
23-501-043-3	5000M-12	Attitude Gyro	Sigma-Tek	Repair
23-501-044-4	5000M-13	Attitude Gyro	Sigma-Tek	Repair
23-501-05	5000E-1	Attitude Gyro	Sigma-Tek	Repair
23-501-05-1	5000E-5	Attitude Gyro	Sigma-Tek	Repair
23-501-05-2	5000E-9	Attitude Gyro	Sigma-Tek	Repair
23-501-05-25	5000E-21	Attitude Gyro	Sigma-Tek	Repair
23-501-06	5000B-4	Attitude Gyro	Sigma-Tek	Repair
23-501-06-1	5000B-2	Attitude Gyro	Sigma-Tek	Repair
23-501-06-10	5000B-21	Attitude Gyro	Sigma-Tek	Repair
23-501-06-12	5000B-24	Attitude Gyro	Sigma-Tek	Repair
23-501-06-13	5000B-26	Attitude Gyro	Sigma-Tek	Repair
23-501-06-14	5000B-29	Attitude Gyro	Sigma-Tek	Repair
23-501-06-15	5000B-32	Attitude Gyro	Sigma-Tek	Repair
23-501-06-16	5000B-36	Attitude Gyro	Sigma-Tek	Repair
23-501-06-17	5000B-42	Attitude Gyro	Sigma-Tek	Repair
23-501-06-18	5000B-44	Attitude Gyro	Sigma-Tek	Repair
23-501-06-19	5000B-48	Attitude Gyro	Sigma-Tek	Repair
23-501-06-2	5000B-7	Attitude Gyro	Sigma-Tek	Repair
23-501-06-20	5000B-57	Attitude Gyro	Sigma-Tek	Repair
23-501-06-21	5000B-65	Attitude Gyro	Sigma-Tek	Repair
23-501-06-22	5000B-69	Attitude Gyro	Sigma-Tek	Repair
23-501-06-23	5000B-71	Attitude Gyro	Sigma-Tek	Repair
23-501-06-3	5000B-9	Attitude Gyro	Sigma-Tek	Repair
23-501-06-4	5000B-14	Attitude Gyro	Sigma-Tek	Repair
23-501-06-6	5000B-17	Attitude Gyro	Sigma-Tek	Repair
23-501-06-7	5000B-18	Attitude Gyro	Sigma-Tek	Repair
23-501-06-8	5000B-19	Attitude Gyro	Sigma-Tek	Repair
23-501-06-9	5000B-20	Attitude Gyro	Sigma-Tek	Repair
23-501-07	5000B-1	Attitude Gyro	Sigma-Tek	Repair
23-501-08	5000D-1	Attitude Gyro	Sigma-Tek	Repair
23-501-09	5000F	Attitude Gyro	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
24668-003	4300-2XX	Attitude Indicator	Cirrus	Repair
2503148-2	AN-140	Annunciator	Sperry	Repair
251-ES	-	Attitude Gyro	AIM	Repair
2587193-1	C-14	Gyro Compass	Sperry	Repair
2587193-143	C-14A	Gyro Compass	Sperry	Repair
2587193-2	C-14	Gyro Compass	Sperry	Repair
2587193-21	C-14	Gyro Compass	Sperry	Repair
2587193-22	C-14	Gyro Compass	Sperry	Repair
2587193-23	C-14	Gyro Compass	Sperry	Repair
2587193-24	C-14	Gyro Compass	Sperry	Repair
2587193-25	C-14	Gyro Compass	Sperry	Repair
2587193-26	C-14	Gyro Compass	Sperry	Repair
2587193-3	C-14	Gyro Compass	Sperry	Repair
2587193-33	C-14	Gyro Compass	Sperry	Repair
2587193-36	C-14	Gyro Compass	Sperry	Repair
2587193-4	C-14	Gyro Compass	Sperry	Repair
2587193-41	C-14A	Gyro Compass	Sperry	Repair
2587193-42	C-14A	Gyro Compass	Sperry	Repair
2587193-43	C-14A	Gyro Compass	Sperry	Repair
2587193-44	C-14A	Gyro Compass	Sperry	Repair
2587193-45	C-14A	Gyro Compass	Sperry	Repair
2587193-46	C-14A	Gyro Compass	Sperry	Repair
2587193-47	C-14A	Gyro Compass	Sperry	Repair
2587193-5	C-14	Gyro Compass	Sperry	Repair
2587193-6	C-14	Gyro Compass	Sperry	Repair
2587193-7	C-14	Gyro Compass	Sperry	Repair
2587317-355	C-6L	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
2587317-653	C-6L	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
2587317-655	C-6L	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
2587317-656	C-6L	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
2587317-657	C-6L	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
2587317-658	C-6L	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
2588282-653	C-6M	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
2588282-655	C-6M	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
2588282-656	C-6M	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
2588282-657	C-6M	Gyrosyn Compass Indicator, Lighted	Sperry	Repair
2593379-001	DRC-1	Dual Remote Compensator	Honeywell	Repair
2593379-001	CS-412	Dual Remote Compensator	Honeywell	Repair
2593379-002	DRC-1	Dual Remote Compensator	Honeywell	Repair
2593379-002	CS-412	Dual Remote Compensator	Honeywell	Repair
2593379-1	DRC-1	Dual Remote Compensator	Honeywell	Repair
2593379-1	CS-412	Dual Remote Compensator	Honeywell	Repair
2593379-2	DRC-1	Dual Remote Compensator	Honeywell	Repair
2593379-2	CS-412	Dual Remote Compensator	Honeywell	Repair
2593691-901	VG-401	Attitude Reference	Sperry	Repair
2593996-333	TARSYN-333	3-Axis Reference Gyro	Honeywell	Repair
2593996-444	TARSYN-444	3-Axis Reference Gyro	Honeywell	Repair
2593996-555	TARSYN-555	3-Axis Reference Gyro	Honeywell	Repair
266-E5542-00	-	Underwater Acoustic Beacon	L3Harris	Test/Recert
270-2436-010	613L-3	Transponder Control	Collins	Repair
270-2436-020	613L-3	Transponder Control	Collins	Repair
270-2436-030	613L-3	Transponder Control	Collins	Repair
270-2436-040	613L-3	Transponder Control	Collins	Repair
270-2436-050	613L-3	Transponder Control	Collins	Repair
270-2436-060	613L-3	Transponder Control	Collins	Repair
270-2436-070	613L-3	Transponder Control	Collins	Repair
270-2436-080	613L-3	Transponder Control	Collins	Repair
270-2436-090	613L-3	Transponder Control	Collins	Repair
270-2436-100	613L-3	Transponder Control	Collins	Repair
300(Beech)	-	Attitude Gyro	AIM	Repair
300(Cessna)	-	Attitude Gyro	AIM	Repair
3000-0104	C668516-0104	Cabin Alt/Diff Pressure Indicator	United Instruments	Repair
300-1	-	Attitude Gyro	AIM	Repair
300-1(8° Tilt)	-	Attitude Gyro	AIM	Repair
300-1(Cessna)	-	Attitude Gyro	AIM	Repair
300-19A	-	Attitude Gyro	AIM	Repair

Part Number	Model	Description	Manufacturer	Capability
300-19B	-	Attitude Gyro	AIM	Repair
300-1BCF	-	Attitude Gyro	AIM	Repair
300-1BL	-	Attitude Gyro	AIM	Repair
300-1CF(8°)(Cessna)	-	Attitude Gyro	AIM	Repair
300-1CF(Cessna)	-	Attitude Gyro	AIM	Repair
300-1CFL(8°)(Cessna)	-	Attitude Gyro	AIM	Repair
300-1E	-	Attitude Gyro	AIM	Repair
300-2	-	Attitude Gyro	AIM	Repair
300-2CF	-	Attitude Gyro	AIM	Repair
300-2CF(8°)	-	Attitude Gyro	AIM	Repair
300-2CFC	-	Attitude Gyro	AIM	Repair
300-2CFC(8°)	-	Attitude Gyro	AIM	Repair
300-2CFL	-	Attitude Gyro	AIM	Repair
300-2CFML	-	Attitude Gyro	AIM	Repair
300-2R	-	Attitude Gyro	AIM	Repair
300-3	-	Attitude Gyro	AIM	Repair
300-3CF	-	Attitude Gyro	AIM	Repair
300-3CF(8°)	-	Attitude Gyro	AIM	Repair
300-3CF(8°)(Cessna)	-	Attitude Gyro	AIM	Repair
300-3CF(Cessna)	-	Attitude Gyro	AIM	Repair
300-3CFG	-	Attitude Gyro	AIM	Repair
300-3CFL	-	Attitude Gyro	AIM	Repair
300-3CFL(8°)	-	Attitude Gyro	AIM	Repair
300-3CFM	-	Attitude Gyro	AIM	Repair
300-4	-	Attitude Gyro	AIM	Repair
300-5	-	Attitude Gyro	AIM	Repair
300-6	-	Attitude Gyro	AIM	Repair
300-7DC(14)	-	Attitude Gyro	AIM	Repair
300-7DC(28)	-	Attitude Gyro	AIM	Repair
300-9DC	-	Attitude Gyro	AIM	Repair
30230-1174	114-380035-1	Vertical Speed Indicator, Instantaneous	Aerosonic	Repair
30-231-3	-	Smoke Detector	Kidde	Repair
30-231-9	-	Smoke Detector	Kidde	Repair
30-231R-7B	-	Smoke Detector	Kidde	Repair
303-006-003	76450-01078-106	Dual Torque Indicator	Gull	Repair
30-303A	-	Control Amplifier, Fire Detection System	Pyrotector	Repair
303088-003	4000D-2	Directional Gryo	Astronautics	Repair
303089-002	4000E	Directional Gryo	Astronautics	Repair
30-326ET-1	-	Control Amplifier, Fire Detection System	Pyrotector	Test/Recert
305394-2-1	-	Switch, Speed	Garrett / AiResearch	Test/Recert
305394-2-2	-	Switch, Speed	Garrett / AiResearch	Test/Recert
305394-2-3	-	Switch, Speed	Garrett / AiResearch	Test/Recert
3057-3-131	-	Torque Indicator	Labem	Repair
3057-3-132	-	Torque Indicator	Labem	Repair
3057-3-133	-	Torque Indicator	Labem	Repair
3057-3-134	-	Torque Indicator	Labem	Repair
3057-3-135	-	Torque Indicator	ECET	Repair
3057-3-136	-	Torque Indicator	ECET	Repair
3057-3-136-1	-	Torque Indicator	ECET	Repair
3057-3-136-3	-	Torque Indicator	ECET	Repair
3057-3-136-4	-	Torque Indicator	ECET	Repair
3057-3-136-5	-	Torque Indicator	ECET	Repair
3057-3-136-6	-	Torque Indicator	ECET	Repair
3057-3-137	-	Torque Indicator	ECET	Repair
310-007-003	76450-00902-103	Dual Torque Indicator	Gull	Repair
31100C	C661075-0106	Directional Gyro	Aeritalia	Repair
32005-007	-	Tachometer Generator	AAE	Test/Recert
32005-008	-	Tachometer Generator	AAE	Test/Recert
32005-023	-	Tachometer Generator	AAE	Test/Recert
32005-025	-	Tachometer Generator	AAE	Test/Recert
32005-026	-	Tachometer Generator	AAE	Test/Recert
32005-030	-	Tachometer Generator	AAE	Test/Recert
32005-034	-	Tachometer Generator	AAE	Test/Recert
32005-037	-	Tachometer Generator	AAE	Test/Recert
33776-44019-042	-	Caution/Advisory Panel	Sikorsky	Repair
33776-44127-041	-	Stick Trim Panel	Sikorsky	Repair

Part Number	Model	Description	Manufacturer	Capability
33776-44127-044	-	Stick Trim Panel	Sikorsky	Repair
33776-44261-050	-	Compass Control Panel	Sikorsky	Repair
33776-44289-041	-	Master Caution/Advisory Panel	Sikorsky	Repair
33776-44289-042	-	Master Caution/Advisory Panel	Sikorsky	Repair
33776-44290-041	-	Master Warning Panel	Sikorsky	Repair
33776-46306-041	-	Avionics Switching Unit	Sikorsky	Repair
33776-46320-041	-	EGPWS Switching Unit	Sikorsky	Repair
35000-5	-	Control Unit, Fire & Overheat Detection System	Fenwal	Test/Recert
3571251-9111	-	MGT Indicator	Bendix Avionics	Repair
3571251-9119	-	MGT Indicator	Bendix Avionics	Repair
3571251-9121	-	MGT Indicator	Bendix Avionics	Repair
3571251-9131	212-075-067-105	ITT Indicator	Bendix Avionics	Repair
3571262-5101	-	Tachometer Indicator	Bendix Avionics	Repair
3571262-5108	212-075-037-101	Tachometer Indicator	Bendix Avionics	Repair
3571262-5109	-	Tachometer Indicator	Bendix Avionics	Repair
3571320-0001	-	Synchro Indicator	Bendix Aviation	Repair
3571320-0002	-	Synchro Indicator	Bendix Aviation	Repair
3571320-0003	-	Synchro Indicator	Bendix Aviation	Repair
3571320-0005	-	Synchro Indicator	Bendix Aviation	Repair
3571320-0006	-	Synchro Indicator	Bendix Aviation	Repair
3571320-0007	-	Synchro Indicator	Bendix Aviation	Repair
3571320-0008	-	Synchro Indicator	Bendix Aviation	Repair
3571320-0010	-	Synchro Indicator	Bendix Aviation	Repair
3571320-0016	-	Synchro Indicator	Bendix Aviation	Repair
3571320-0018	-	Synchro Indicator	Bendix Aviation	Repair
3571320-0019	-	Synchro Indicator	Bendix Aviation	Repair
3571320-0030	-	Synchro Indicator	Bendix Aviation	Repair
3571320-0035	-	Synchro Indicator	Bendix Aviation	Repair
3713527-507	DI-5001	Digital Radar Indicator	Honeywell	Repair
3713527-508	DI-5001	Digital Radar Indicator	Honeywell	Repair
3714925-501	RTA-1003	Receiver Transmitter Antenna	Honeywell	Repair
3714925-502	RTA-1003	Receiver Transmitter Antenna	Honeywell	Repair
3716302-501	DI-5001	Digital Radar Indicator	Honeywell	Repair
3716302-502	DI-5001	Digital Radar Indicator	Honeywell	Repair
37500-000	-	Altimeter (-1k-20k ft, mbar)	Badin-Crouzet	Repair
37500-001	-	Altimeter (-1k-20k ft, mbar, Lighted)	Badin-Crouzet	Repair
37500-002	-	Altimeter (-1k-20k ft, mbar, Lighted)	Badin-Crouzet	Repair
37500-080	-	Altimeter (-1k-20k ft, mbar)	Badin-Crouzet	Repair
37500-084	-	Altimeter (-1k-20k ft, mbar, Lighted)	Badin-Crouzet	Repair
37500-0840	-	Altimeter (-1k-20k ft, mbar, Lighted)	Badin-Crouzet	Repair
37500-0841	-	Altimeter (-1k-20k ft, mbar, Lighted)	Badin-Crouzet	Repair
37500-0847	-	Altimeter (-1k-20k ft, mbar, Lighted)	Badin-Crouzet	Repair
37500-0848	-	Altimeter (-1k-20k ft, mbar, Lighted)	Badin-Crouzet	Repair
37500-220	-	Altimeter (-1k-20k ft, in.Hg)	Badin-Crouzet	Repair
37500-224	-	Altimeter (-1k-20k ft, in.Hg, Lighted)	Badin-Crouzet	Repair
37500-2241	-	Altimeter (-1k-20k ft, in.Hg, Lighted)	Badin-Crouzet	Repair
37500-280	-	Altimeter (-1k-20k ft, mbar)	Badin-Crouzet	Repair
37500-284	-	Altimeter (-1k-20k ft, mbar, Lighted)	Badin-Crouzet	Repair
37500-5847	-	Altimeter (-1k-20k ft, mbar, Lighted)	Badin-Crouzet	Repair
37500-AB-M	-	Altimeter (-1k-20k ft, mbar)	Badin-Crouzet	Repair
37500-AD-M	-	Altimeter (-1k-20k ft, mbar, Lighted)	Badin-Crouzet	Repair
376.299-921	JB3100-(1)	Junction Box	Becker	Repair
38210-000	-	Indicator, Rate of Climb	Badin-Crouzet	Repair
38210-010	-	Indicator, Rate of Climb	Badin-Crouzet	Repair
38210-300	-	Indicator, Rate of Climb	Badin-Crouzet	Repair
38210-380	-	Indicator, Rate of Climb	Badin-Crouzet	Repair
38210-390	-	Indicator, Rate of Climb	Badin-Crouzet	Repair
38210-397	-	Indicator, Rate of Climb	Badin-Crouzet	Repair
38210-480	-	Indicator, Rate of Climb	Badin-Crouzet	Repair
38210-490	-	Indicator, Rate of Climb	Badin-Crouzet	Repair
38210-AC-M	-	Indicator, Rate of Climb	Badin-Crouzet	Repair
38399-330	-	Airspeed Indicator (0-200 mp/h)	Sextant	Repair
38399-330-02	-	Airspeed Indicator (0-200 mp/h)	Sextant	Repair
38399-480	-	Airspeed Indicator (0-320 km/h)	Sextant	Repair
38399-480-02	-	Airspeed Indicator (0-320 km/h)	Sextant	Repair
38399-490	-	Airspeed Indicaotr (0-180 knots)	Sextant	Repair

Part Number	Model	Description	Manufacturer	Capability
38399-490-02	-	Airspeed Indicaotr (0-180 knots)	Sextant	Repair
38399-AB-M	-	Airspeed Indicaotr (0-180 knots)	Sextant	Repair
38399-AC-M	-	Airspeed Indicaotr (0-180 knots)	Sextant	Repair
38399-AD-M	-	Airspeed Indicaotr (0-180 knots, Lighted)	Sextant	Repair
387.843-921	AS3100-(12)	Audio Panel	Becker	Repair
387.851-921	IC3100-(4)	Intercom Amplifier	Becker	Repair
393004-01409	205-061-633-7	Fuel Quantity Indicator	Simmonds Precision	Repair
393004-01409	205-061-633-007	Fuel Quantity Indicator	Simmonds Precision	Repair
393004-01491	204-062-610-3	Fuel Quantity Indicator	Simmonds Precision	Repair
393004-01491	204-062-610-003	Fuel Quantity Indicator	Simmonds Precision	Repair
393004-01539	-	Fuel Quantity Indicator	Simmonds Precision	Repair
393004-01685	-	Fuel Quantity Indicator	Simmonds Precision	Repair
393004-01699	204-061-606-3	Fuel Quantity Indicator	Simmonds Precision	Repair
393004-01699	204-061-606-003	Fuel Quantity Indicator	Simmonds Precision	Repair
393004-01862	-	Fuel Quantity Indicator	Simmonds Precision	Repair
393004-01884	-	Fuel Quantity Indicator	Simmonds Precision	Repair
393004-01970	204-060-683-5	Fuel Quantity Indicator	Simmonds Precision	Repair
393004-01970	204-060-683-005	Fuel Quantity Indicator	Simmonds Precision	Repair
393004-10827	-	Fuel Quantity Indicator	Simmonds Precision	Repair
393008-036	446001239	Fuel Quantity Indicator	Simmonds Precision	Repair
393008-037	446001240-00	Fuel Quantity Indicator	Simmonds Precision	Repair
393008-040	446001265	Fuel Quantity Indicator	Simmonds Precision	Repair
393008-042	-	Fuel Quantity Indicator	Simmonds Precision	Repair
393008-046	446003587-00	Fuel Quantity Indicator	Simmonds Precision	Repair
393008-047	446003533-00	Fuel Quantity Indicator	Simmonds Precision	Repair
393008-056	-	Fuel Quantity Indicator	Simmonds Precision	Repair
393008-064	-	Fuel Quantity Indicator	Simmonds Precision	Repair
393008-074	212-899-245-1	Fuel Quantity Indicator	Simmonds Precision	Repair
393008-074	212-899-245-001	Fuel Quantity Indicator	Simmonds Precision	Repair
393008-077	214-066-030-5	Fuel Quantity Indicator	Simmonds Precision	Repair
393008-077	214-066-030-005	Fuel Quantity Indicator	Simmonds Precision	Repair
393008-078	214-066-030-7	Fuel Quantity Indicator	Simmonds Precision	Repair
393008-078	214-066-030-007	Fuel Quantity Indicator	Simmonds Precision	Repair
393008-082	446001265	Fuel Quantity Indicator	Simmonds Precision	Repair
393085-43708	-	Fuel Quantity Indicator	Simmonds Precision	Repair
3935-1	-	Turn & Slip Indicator	General Design	Repair
3935-2	-	Turn & Slip Indicator	General Design	Repair
3A42.32.15M.28.3.AB	-	Altimeter (2", -1k-15k meters, mbar, 28V Light)	Thommen	Repair
3A43.32.20F.28.1.CL	-	Altimeter (2", -1k-20k ft, Dual Scale, 28V Light)	Thommen	Repair
3A43.32.20F.28.4.CG	-	Altimeter (2", -1k-20k ft, Dual Scale, 28V Light)	Thommen	Repair
3A43.32.20F.28.4.EE	-	Altimeter (2", -1k-20k ft, Dual Scale, 28V Light)	Thommen	Repair
3A43.32.50F.05.1.AB	-	Altimeter (2", -1k-50k ft, mbar, 5V Light)	Thommen	Repair
3A43.32.50F.05.1.AU	-	Altimeter (2", -1k-50k ft, mbar, 5V Light)	Thommen	Repair
3A43.32.50F.05.1.EG	-	Altimeter (2", -1k-50k ft, in.Hg, 5V Light)	Thommen	Repair
3A43.42.35F.05.1.AB	-	Altimeter (2", -1k-35k ft, mbar, 5V Light)	Thommen	Repair
3A43.42.50F.05.1.DE	-	Altimeter (2", -1k-50k ft, Dual Scale, 5V Light)	Thommen	Repair
3A43.42.50F.05.1.EG	-	Altimeter (2", -1k-50k ft, in.Hg, 5V Light)	Thommen	Repair
3A43.42.50F.05.1.FT	-	Altimeter (2", -1k-50k ft, in.Hg, 5V Light)	Thommen	Repair
3A43.52.50F.05.1.CB	-	Altimeter (2", -1k-50k ft, Dual Scale, 5V Light)	Thommen	Repair
3A43.52.50F.05.4.FG	-	Altimeter (2", -1k-50k ft, Dual Scale, 5V Light)	Thommen	Repair
4000-10	-	ELT, Pointer Sentry	Pointer	Test/Recert
4000-11	-	ELT, Pointer Sentry	Pointer	Test/Recert
4000172-8501	IN-831A	Horizontal Situation Indicator	Bendix Avionics	Repair
4000172-8502	IN-831A	Horizontal Situation Indicator	Bendix Avionics	Repair
4000172-8503	IN-831A	Horizontal Situation Indicator	Bendix Avionics	Repair
4000172-8504	IN-831A	Horizontal Situation Indicator	Bendix Avionics	Repair
4000172-8505	IN-831A	Horizontal Situation Indicator	Bendix Avionics	Repair
4000172-8511	IN-831A	Horizontal Situation Indicator	Bendix Avionics	Repair
4000172-8512	IN-831A	Horizontal Situation Indicator	Bendix Avionics	Repair
4000172-8513	IN-831A	Horizontal Situation Indicator	Bendix Avionics	Repair
4000184-8501	DH-841A	Flight Director Horizon	Bendix Avionics	Repair
4000184-8501	300-7CF	Flight Director Horizon	AIM	Repair
4000184-8502	DH-841A	Flight Director Horizon	Bendix Avionics	Repair
4000184-8502	300-7CF(8°)	Flight Director Horizon	AIM	Repair
4000184-8503	DH-841A	Flight Director Horizon	Bendix Avionics	Repair
4000184-8503	300-7CF	Flight Director Horizon	AIM	Repair

Part Number	Model	Description	Manufacturer	Capability
4000184-8504	DH-841A	Flight Director Horizon	Bendix Avionics	Repair
4000184-8504	300-7CF(8°)	Flight Director Horizon	AIM	Repair
4000191-8502	-	Flux Valve	Bendix/King	Test/Recert
4000503-0201	IN-1202A	Radar Indicator	Bendix Avionics	Repair
4000503-0202	IN-1202A	Radar Indicator	Bendix Avionics	Repair
4000503-0203	IN-1202A	Radar Indicator	Bendix Avionics	Repair
4000503-0204	IN-1202A	Radar Indicator	Bendix Avionics	Repair
4000503-0205	IN-1202A	Radar Indicator	Bendix Avionics	Repair
4000503-0241	IN-1202A	Radar Indicator	Bendix Avionics	Repair
4000503-0242	IN-1202A	Radar Indicator	Bendix Avionics	Repair
4000503-0251	IN-1202A	Radar Indicator	Bendix Avionics	Repair
4000503-0252	IN-1202A	Radar Indicator	Bendix Avionics	Repair
4000503-0253	IN-1202A	Radar Indicator	Bendix Avionics	Repair
4000504-0301	DA-1203A	Drive Assembly, Radar Antenna	Bendix Avionics	Repair
4000504-0302	DA-1203A	Drive Assembly, Radar Antenna	Bendix Avionics	Repair
4000504-0303	DA-1203A	Drive Assembly, Radar Antenna	Bendix Avionics	Repair
4000763-3101	RT-131A	Radar Transceiver	Bendix Avionics	Repair
4000764-3201	IN-132A	Radar Indicator	Bendix Avionics	Repair
4000764-3202	IN-132A	Radar Indicator	Bendix Avionics	Repair
4000764-3203	IN-132A	Radar Indicator	Bendix Avionics	Repair
4000764-3204	IN-132A	Radar Indicator	Bendix Avionics	Repair
4000790-4401	DA-144A	Antenna Drive Unit	Bendix/King	Repair
4000790-4402	DA-144A	Antenna Drive Unit	Bendix/King	Repair
4000790-4403	DA-144A	Antenna Drive Unit	Bendix/King	Repair
4000790-4404	DA-144A	Antenna Drive Unit	Bendix/King	Repair
4000790-4405	DA-144A	Antenna Drive Unit	Bendix/King	Repair
4000790-4406	DA-144A	Antenna Drive Unit	Bendix/King	Repair
4000790-4407	DA-144A	Antenna Drive Unit	Bendix/King	Repair
4000831-0101	RT-1401A	Radar Transceiver	Bendix Avionics	Repair
4000831-0102	RT-1401B	Radar Transceiver	Bendix Avionics	Repair
4000831-0103	RT-1401B	Radar Transceiver	Bendix Avionics	Repair
4000831-0104	RT-1401B	Radar Transceiver	Bendix Avionics	Repair
4000831-0105	RT-1401B	Radar Transceiver	Bendix Avionics	Repair
4000831-0106	RT-1401B	Radar Transceiver	Bendix Avionics	Repair
4000831-0112	RT-1401B	Radar Transceiver	Bendix Avionics	Repair
4000833-0201	IN-1402A	Radar Indicator	Bendix Avionics	Repair
4000833-0202	IN-1402A	Radar Indicator	Bendix Avionics	Repair
4000833-0207	IN-1402B	Radar Indicator	Bendix Avionics	Repair
4000833-0208	IN-1402B	Radar Indicator	Bendix Avionics	Repair
4000965-0201	IN-1302A	Radar Indicator	Bendix Avionics	Repair
4000965-0202	IN-1302A	Radar Indicator	Bendix Avionics	Repair
4000965-0203	IN-1302A	Radar Indicator	Bendix Avionics	Repair
4000965-0204	IN-1302A	Radar Indicator	Bendix Avionics	Repair
4000965-0206	IN-1302A	Radar Indicator	Bendix Avionics	Repair
4000965-0207	IN-1302A	Radar Indicator	Bendix Avionics	Repair
4000965-0208	IN-1302A	Radar Indicator	Bendix Avionics	Repair
4001018-6101	ART-161A	Radar Antenna/RT	Bendix Avionics	Repair
4001018-6102	ART-161A	Radar Antenna/RT	Bendix Avionics	Repair
4001018-6103	ART-161A	Radar Antenna/RT	Bendix Avionics	Repair
4001018-6104	ART-161A	Radar Antenna/RT	Bendix Avionics	Repair
4001018-6105	ART-161A	Radar Antenna/RT	Bendix Avionics	Repair
4001018-6106	ART-161A	Radar Antenna/RT	Bendix Avionics	Repair
4001018-6107	ART-161A	Radar Antenna/RT	Bendix Avionics	Repair
4001018-6108	ART-161A	Radar Antenna/RT	Bendix Avionics	Repair
4001670-2501	IN-2025A	Radar Indicator	Bendix Avionics	Repair
4001670-2502	IN-2025A	Radar Indicator	Bendix Avionics	Repair
4001670-2503	IN-2025A	Radar Indicator	Bendix Avionics	Repair
4001670-2504	IN-2025A	Radar Indicator	Bendix Avionics	Repair
4001670-2511	IN-2025B	Radar Indicator	Bendix Avionics	Repair
4001670-2512	IN-2025B	Radar Indicator	Bendix Avionics	Repair
4001670-2513	IN-2025B	Radar Indicator	Bendix Avionics	Repair
4001670-2514	IN-2025B	Radar Indicator	Bendix Avionics	Repair
4001670-2515	IN-2025B	Radar Indicator	Bendix Avionics	Repair
4001670-2516	IN-2025B	Radar Indicator	Bendix Avionics	Repair
4001808-901	VG-14	Vertical Gyro	Sperry	Repair
4001846-3201	IN-232A	Radar Indicator	Bendix Avionics	Repair

Part Number	Model	Description	Manufacturer	Capability
4001921-5101	RT-1151A	Radar Transceiver	Bendix Avionics	Repair
4001922-5201	IN-1152A	Radar Indicator	Bendix Avionics	Repair
4001922-5202	IN-1152A	Radar Indicator	Bendix Avionics	Repair
4001922-5203	IN-1152A	Radar Indicator	Bendix Avionics	Repair
4001922-5204	IN-1152A	Radar Indicator	Bendix Avionics	Repair
4003-01	5000E-24	Attitude Gyro, Lighted	Chelton	Repair
4003-02	5000E-26	Attitude Gyro, Lighted	Chelton	Repair
4003-03	5000E-27	Attitude Gyro, Lighted	Chelton	Repair
4003-04	5000E-25	Attitude Gyro, Lighted	Chelton	Repair
4004437-901	RT-220	Radio Altimeter R/T	Sperry	Repair
4004437-902	RT-221	Radio Altimeter R/T	Sperry	Repair
4004437-903	RT-220H	Radio Altimeter R/T	Sperry	Repair
4006-01	4000C-22	Directional Gyro, Lighted	Chelton	Repair
4012384-902	VS-444	Vertical Speed Indicator	Sperry	Repair
4012395-905	MS-701	Mode Selector Controller	Sperry	Repair
4014267-901	RA-215	Radio Altimeter Indicator	Sperry	Repair
4014267-902	RA-235	Radio Altimeter Indicator	Sperry	Repair
4014267-903	RA-215	Radio Altimeter Indicator	Sperry	Repair
4018368-901	MS-500	Mode Selector	Sperry	Repair
4018368-902	MS-500	Mode Selector	Sperry	Repair
4018368-903	MS-500	Mode Selector	Sperry	Repair
4018368-904	MS-500	Mode Selector	Sperry	Repair
4018368-905	MS-500	Mode Selector	Sperry	Repair
4018368-906	MS-500	Mode Selector	Sperry	Repair
4018368-907	MS-500	Mode Selector	Sperry	Repair
4018368-908	MS-500	Mode Selector	Sperry	Repair
4018368-910	MS-500	Mode Selector	Sperry	Repair
4018368-912	MS-500	Mode Selector	Sperry	Repair
4018368-913	MS-500	Mode Selector	Sperry	Repair
4018368-914	MS-500	Mode Selector	Sperry	Repair
4018368-915	MS-500	Mode Selector	Sperry	Repair
4018368-916	MS-500	Mode Selector	Sperry	Repair
4018368-917	MS-500	Mode Selector	Sperry	Repair
4018368-918	MS-500	Mode Selector	Sperry	Repair
4018368-919	MS-500	Mode Selector	Sperry	Repair
4018368-920	MS-500	Mode Selector	Sperry	Repair
4018368-921	MS-500	Mode Selector	Sperry	Repair
4018368-922	MS-500	Mode Selector	Sperry	Repair
4018368-923	MS-500	Mode Selector	Sperry	Repair
4018368-924	MS-500	Mode Selector	Sperry	Repair
4018368-925	MS-500	Mode Selector	Sperry	Repair
4018639-901	PC-500	Autopilot Controller	Sperry	Repair
4018639-902	PC-500	Autopilot Controller	Sperry	Repair
4018639-903	PC-500	Autopilot Controller	Sperry	Repair
4018639-904	PC-500	Autopilot Controller	Sperry	Repair
4018639-905	PC-500	Autopilot Controller	Sperry	Repair
4018639-906	PC-500	Autopilot Controller	Sperry	Repair
4018639-907	PC-500	Autopilot Controller	Sperry	Repair
4018639-908	PC-500	Autopilot Controller	Sperry	Repair
4018639-909	PC-500	Autopilot Controller	Sperry	Repair
4018639-910	PC-500	Autopilot Controller	Sperry	Repair
4018639-911	PC-500	Autopilot Controller	Sperry	Repair
4018639-912	PC-500	Autopilot Controller	Sperry	Repair
4018639-913	PC-500	Autopilot Controller	Sperry	Repair
4018639-914	PC-500	Autopilot Controller	Sperry	Repair
4018639-919	PC-500	Autopilot Controller	Sperry	Repair
4018639-920	PC-500	Autopilot Controller	Sperry	Repair
4018639-923	PC-500	Autopilot Controller	Sperry	Repair
4018639-924	PC-500	Autopilot Controller	Sperry	Repair
4018639-925	PC-500	Autopilot Controller	Sperry	Repair
4018639-926	PC-500	Autopilot Controller	Sperry	Repair
4018639-927	PC-500	Autopilot Controller	Sperry	Repair
4018639-928	PC-500	Autopilot Controller	Sperry	Repair
4018639-929	PC-500	Autopilot Controller	Sperry	Repair
4018639-930	PC-500	Autopilot Controller	Sperry	Repair
4018639-931	PC-500	Autopilot Controller	Sperry	Repair

Part Number	Model	Description	Manufacturer	Capability
4018639-932	PC-500	Autopilot Controller	Sperry	Repair
4018639-933	PC-500	Autopilot Controller	Sperry	Repair
4020550-901	AD-300D	Attitude Director Indicator	Sperry	Repair
4020550-903	AD-300D	Attitude Director Indicator	Sperry	Repair
4020550-904	AD-300H	Attitude Director Indicator	Sperry	Repair
4020577-3	C-14D	Gyro Compass	Sperry	Repair
4020577-6	C-14D	Gyro Compass	Sperry	Repair
4020577-8	C-14D	Gyro Compass	Sperry	Repair
40760-0105	4000D	Directional Gryo	ARC	Repair
40760-0114	4000D-1	Directional Gryo	ARC	Repair
412-077-050-101	-	AHRS Control Panel Assembly	Bell Helicopter	Repair
41420-0014	RT-359A	Transponder	ARC	Repair
41420-0028	RT-359A	Transponder	ARC	Repair
41420-1114	RT-359A	Transponder	ARC	Repair
41420-1128	RT-359A	Transponder	ARC	Repair
4200-10	4200-1X	Attitude Gyro, Lighted (2")	Mid-Continent	Repair
4200-11	4200-1X	Attitude Gyro, Lighted (2")	Mid-Continent	Repair
42540-2114	EA-401A	Encoding Altimeter	ARC	Repair
42540-2128	EA-401A	Encoding Altimeter	ARC	Repair
42540-2214	EA-401A	Encoding Altimeter	ARC	Repair
42540-2228	EA-401A	Encoding Altimeter	ARC	Repair
42540-3114	EA-401A	Encoding Altimeter	ARC	Repair
42540-3128	EA-401A	Encoding Altimeter	ARC	Repair
42540-3214	EA-401A	Encoding Altimeter	ARC	Repair
42540-3228	EA-401A	Encoding Altimeter	ARC	Repair
42540-4114	EA-401A	Encoding Altimeter	ARC	Repair
42540-4128	EA-401A	Encoding Altimeter	ARC	Repair
42540-4214	EA-401A	Encoding Altimeter	ARC	Repair
42540-4228	EA-401A	Encoding Altimeter	ARC	Repair
42540-5114	EA-401A	Encoding Altimeter	ARC	Repair
42540-5128	EA-401A	Encoding Altimeter	ARC	Repair
42540-5214	EA-401A	Encoding Altimeter	ARC	Repair
42540-5228	EA-401A	Encoding Altimeter	ARC	Repair
42540-6114	EA-401A	Encoding Altimeter	ARC	Repair
42540-6128	EA-401A	Encoding Altimeter	ARC	Repair
42540-6214	EA-401A	Encoding Altimeter	ARC	Repair
42540-6228	EA-401A	Encoding Altimeter	ARC	Repair
42540-7114	EA-401A	Encoding Altimeter	ARC	Repair
42540-7128	EA-401A	Encoding Altimeter	ARC	Repair
42540-7214	EA-401A	Encoding Altimeter	ARC	Repair
42540-7228	EA-401A	Encoding Altimeter	ARC	Repair
4300-202	4300-2XX	Attitude Indicator	Mid-Continent	Repair
4300-203	4300-2XX	Attitude Indicator	Mid-Continent	Repair
4300-204	4300-2XX	Attitude Indicator	Mid-Continent	Repair
4300-205	4300-2XX	Attitude Indicator w/ Battery	Mid-Continent	Repair
4300-206	4300-2XX	Attitude Indicator	Mid-Continent	Repair
4300-207	4300-2XX	Attitude Indicator	Mid-Continent	Repair
4300-208	4300-2XX	Attitude Indicator	Mid-Continent	Repair
4300-213	4300-2XX	Attitude Indicator	Mid-Continent	Repair
4300-215	4300-2XX	Attitude Indicator w/ Battery	Mid-Continent	Repair
4300-311	4300-3XX	Attitude Indicator	Mid-Continent	Repair
4300-312	4300-3XX	Attitude Indicator	Mid-Continent	Repair
4300-313	4300-3XX	Attitude Indicator	Mid-Continent	Repair
4300-314	4300-3XX	Attitude Indicator	Mid-Continent	Repair
4300-331	4300-3XX	Attitude Indicator	Mid-Continent	Repair
4300-332	4300-3XX	Attitude Indicator	Mid-Continent	Repair
4300-333	4300-3XX	Attitude Indicator	Mid-Continent	Repair
4300-334	4300-3XX	Attitude Indicator	Mid-Continent	Repair
4300-411	4300-4XX	Attitude Indicator w/ Battery	Mid-Continent	Repair
4300-412	4300-4XX	Attitude Indicator w/ Battery	Mid-Continent	Repair
4300-413	4300-4XX	Attitude Indicator w/ Battery	Mid-Continent	Repair
4300-414	4300-4XX	Attitude Indicator w/ Battery	Mid-Continent	Repair
4300-431	4300-4XX	Attitude Indicator w/ Battery	Mid-Continent	Repair
4300-432	4300-4XX	Attitude Indicator w/ Battery	Mid-Continent	Repair
4300-433	4300-4XX	Attitude Indicator w/ Battery	Mid-Continent	Repair
4300-434	4300-4XX	Attitude Indicator w/ Battery	Mid-Continent	Repair

Part Number	Model	Description	Manufacturer	Capability
4300-511	4300-5XX	Attitude Indicator	Mid-Continent	Repair
4300-512	4300-5XX	Attitude Indicator	Mid-Continent	Repair
4300-513	4300-5XX	Attitude Indicator	Mid-Continent	Repair
4300-514	4300-5XX	Attitude Indicator	Mid-Continent	Repair
4300-531	4300-5XX	Attitude Indicator	Mid-Continent	Repair
4300-532	4300-5XX	Attitude Indicator	Mid-Continent	Repair
4300-533	4300-5XX	Attitude Indicator	Mid-Continent	Repair
4300-534	4300-5XX	Attitude Indicator	Mid-Continent	Repair
4300-611	4300-6XX	Attitude Indicator w/ Battery	Mid-Continent	Repair
4300-613	4300-6XX	Attitude Indicator w/ Battery	Mid-Continent	Repair
430-6040-201	SL40	VHF COMM Transceiver	Garmin	Limited Repair
430-6040-202	SL40	VHF COMM Transceiver	Garmin	Limited Repair
430-6040-203	SL40	VHF COMM Transceiver	Garmin	Limited Repair
430-6040-300	SL30	VHF NAV/COMM Transceiver	Garmin	Limited Repair
430-6040-301	SL30	VHF NAV/COMM Transceiver	Garmin	Limited Repair
430-6040-302	SL30	VHF NAV/COMM Transceiver	Garmin	Limited Repair
430-6040-303	SL30	VHF NAV/COMM Transceiver	Garmin	Limited Repair
4308-1002	369A4522	Torque Indicator	INSCO	Repair
4308-1003	369A4512	Torque Indicator	INSCO	Repair
4308-1004	369A4512B	Torque Indicator	INSCO	Repair
4308-1006	369A4526	Torque Indicator	INSCO	Repair
4308-1009	206-070-268-11	Torque Indicator	INSCO	Repair
4308-1009	206-070-268-011	Torque Indicator	INSCO	Repair
4308-1014	-	Torque Indicator	INSCO	Repair
4308-1020	369H4526-3	Torque Indicator	INSCO	Repair
4308-1024	369H6418	Torque Indicator	INSCO	Repair
4308-1025	22-111-02	Torque Indicator	INSCO	Repair
4308-1026	-	Torque Indicator	INSCO	Repair
4308-1033	369H4526-5	Torque Indicator	INSCO	Repair
4308-1046	369H4526-7	Torque Indicator	INSCO	Repair
4308-1050	-	Torque Indicator	INSCO	Repair
4308-1052	-	Torque Indicator	INSCO	Repair
4308-3001	206-070-268-1	Torque Indicator	INSCO	Repair
4308-3001	206-070-268-001	Torque Indicator	INSCO	Repair
4308-3008	206-070-268-9	Torque Indicator	INSCO	Repair
4308-3008	206-070-268-009	Torque Indicator	INSCO	Repair
4308-3018	206-075-185-1	Torque Indicator	INSCO	Repair
4308-3018	206-075-185-001	Torque Indicator	INSCO	Repair
4308-3021	206-075-185-3	Torque Indicator	INSCO	Repair
4308-3021	206-075-185-003	Torque Indicator	INSCO	Repair
4308-3022	206-070-268-13	Torque Indicator	INSCO	Repair
4308-3022	206-070-268-013	Torque Indicator	INSCO	Repair
4308-3051	206-075-185-101	Torque Indicator	INSCO	Repair
4308-3055	206-075-185-103	Torque Indicator	INSCO	Repair
4308-3058	206-075-185-105	Torque Indicator	INSCO	Repair
4310-3005	214-075-239-11	Engine Torquemeter	INSCO	Repair
4310-3005	214-075-239-011	Engine Torquemeter	INSCO	Repair
432.377-921	IC3100-(2)	Intercom Amplifier	Becker	Repair
43300-6128	EA-801A	Encoding Altimeter	ARC	Repair
43300-61288	EA-801A	Encoding Altimeter	Sperry	Repair
43300-6228	EA-801A	Encoding Altimeter	ARC	Repair
43300-62288	EA-801A	Encoding Altimeter	Sperry	Repair
43-638-02	-	Helipilot Control	Associated Air	Repair
43-638-02A	-	Helipilot Control	Associated Air	Repair
449-1	-	Power Supply	Astronics	Repair
449-2	-	Power Supply	Astronics	Repair
449-3	-	Power Supply	Astronics	Repair
449-4	-	Power Supply	Astronics	Repair
45-0013-3	-	Landing Light, Retractable	Grimes	Repair
45-0013-7	-	Landing Light, Retractable	Grimes	Repair
45-0122-1	-	Light Assembly, Search & Landing	Grimes	Repair
45-0182-1	-	Searchlight, Controllable	Grimes	Repair
45-0182-1M	-	Searchlight, Controllable	Grimes	Repair
45-0182-3	-	Searchlight, Controllable	Grimes	Repair
45-0182-3M	-	Searchlight, Controllable	Grimes	Repair
45-0182-5	-	Searchlight, Controllable	Grimes	Repair

Part Number	Model	Description	Manufacturer	Capability
45-0182-5M	-	Searchlight, Controllable	Grimes	Repair
45-0182-7	-	Searchlight, Controllable	Grimes	Repair
45-0182-7M	-	Searchlight, Controllable	Grimes	Repair
45-0182-9	-	Searchlight, Controllable	Grimes	Repair
45-0182-9M	-	Searchlight, Controllable	Grimes	Repair
453-0150	ELT 110-4	ELT	Artex	Test/Recert
453-0150-01	ELT 100HM	ELT	Artex	Test/Recert
453-0150-02	ELT 110-6	ELT	Artex	Test/Recert
453-0190	ELT-200	ELT	Artex	Test/Recert
453-0204	ELT-200HM	ELT	Artex	Test/Recert
453-0421-( )	110-406 NAV	ELT	Artex	Test/Recert
453-0422-( )	110-406HM NAV	ELT	Artex	Test/Recert
453-5000-( )	C406-2	ELT	Artex	Test/Recert
453-5001-( )	C406-2HM	ELT	Artex	Test/Recert
453-5002-( )	C406-1	ELT	Artex	Test/Recert
453-5003-( )	C406-1HM	ELT	Artex	Test/Recert
453-5004	B406-4	ELT	Artex	Test/Recert
453-5012-( )	G406-4	ELT	Artex	Test/Recert
453-5060	C406-N	ELT	Artex	Test/Recert
453-5061	C406-N HM	ELT	Artex	Test/Recert
453-6603	ME406	ELT	Artex	Test/Recert
453-6604	ME406HM	ELT	Artex	Test/Recert
453-6611	ME406P	ELT	Artex	Test/Recert
45568-001	76550-00915-111	Master Warning Panel	Korry	Repair
46660-1000	RT-385A	Transceiver	ARC Radio	Repair
46660-1100	RT-385A	Transceiver	ARC Radio	Repair
500-(12)EBB	-	Attitude Gyro	AIM	Repair
500CF	-	Attitude Gyro	AIM	Repair
500CFL	-	Attitude Gyro	AIM	Repair
500DC(HUGHES)	-	Attitude Gyro	AIM	Repair
500DCFBL	-	Attitude Gyro	AIM	Repair
500E	-	Attitude Gyro	AIM	Repair
500E-8°	-	Attitude Gyro	AIM	Repair
500EB	-	Attitude Gyro	AIM	Repair
500ECFLA8	-	Attitude Gyro	AIM	Repair
500ECFLK	-	Attitude Gyro	AIM	Repair
500EDC	-	Attitude Gyro	AIM	Repair
500EL(S)	-	Attitude Gyro	AIM	Repair
501.697-921	AS3100-(12)-12	Audio Panel	Becker	Repair
501-1075-01	PS-823A	Emergency Power Supply	JET	Repair
501-1075-02	PS-823B	Emergency Power Supply	JET	Repair
501-1075-03	PS-823C	Emergency Power Supply	JET	Repair
501-1075-04	PS-823D	Emergency Power Supply	JET	Repair
501-1075-05	PS-823A/T	Emergency Power Supply	JET	Repair
501-1075-06	PS-823B/T	Emergency Power Supply	JET	Repair
501-1075-07	PS-823C/T	Emergency Power Supply	JET	Repair
501-1075-08	PS-823D/T	Emergency Power Supply	JET	Repair
501-1075-09	PS-823E	Emergency Power Supply	JET	Repair
501-1075-10	PS-823F	Emergency Power Supply	JET	Repair
501-1075-11	PS-823G	Emergency Power Supply	JET	Repair
501-1075-12	PS-823H	Emergency Power Supply	JET	Repair
501-1075-13	PS-823E/T	Emergency Power Supply	JET	Repair
501-1075-14	PS-823F/T	Emergency Power Supply	JET	Repair
501-1075-15	PS-823G/T	Emergency Power Supply	JET	Repair
501-1075-16	PS-823H/T	Emergency Power Supply	JET	Repair
501-1228-01	PS-835A	Emergency Power Supply	JET	Repair
501-1228-02	PS-835B	Emergency Power Supply	JET	Repair
501-1228-03	PS-835C	Emergency Power Supply	JET	Repair
501-1228-04	PS-835D	Emergency Power Supply	JET	Repair
501-1228-05	PS-835E	Emergency Power Supply	JET	Repair
501-1228-06	PS-835F	Emergency Power Supply	JET	Repair
501-1228-07	PS-835G	Emergency Power Supply	JET	Repair
501-1318-01	SC-841A	Static Converter	JET	Repair
501-1712-01	PS-855A	Emergency Power Supply	JET	Repair
501-1712-02	PS-855B	Emergency Power Supply	JET	Repair
501-1712-03	PS-855C	Emergency Power Supply	JET	Repair

Part Number	Model	Description	Manufacturer	Capability
501-1712-04	PS-855D	Emergency Power Supply	JET	Repair
501-1719-01	PS-850A	Emergency Power Supply	JET	Repair
501-1719-02	PS-850B	Emergency Power Supply	JET	Repair
5018-111-00-10	-	Engine Shutdown Detector	Brion Leroux	Repair
5021-1024	-	TOT Indicator	INSCO	Repair
5021-1028	-	TOT Indicator	INSCO	Repair
5021-3001	206-075-190-1	TOT Indicator	INSCO	Repair
5021-3001	206-075-190-001	TOT Indicator	INSCO	Repair
5021-3002	206-075-190-3	TOT Indicator	INSCO	Repair
5021-3002	206-075-190-003	TOT Indicator	INSCO	Repair
5021-3009	-	TOT Indicator	INSCO	Repair
5021-3030	206-075-190-7	TOT Indicator	INSCO	Repair
5021-3030	206-075-190-007	TOT Indicator	INSCO	Repair
5021-3039	-	TOT Indicator	INSCO	Repair
5021-3048	-	TOT Indicator	INSCO	Repair
502B28	-	Temperature Indicator	Lewis Engineering	Repair
502B29	-	Temperature Indicator	Lewis Engineering	Repair
50-324417-17	5000B-31	Attitude Gyro	Beechcraft	Repair
5035P2B-P158	-	Encoding Altimeter (-1k-20k ft, Dual Scale, B/O)	United Instruments	Repair
5035P2B-P158 P.158	-	Encoding Altimeter (-1k-20k ft, Dual Scale, B/O)	United Instruments	Repair
5035P2-P25	-	Encoding Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5035P2-P25 P.25	-	Encoding Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5035P2-P25 P.91	-	Encoding Altimeter (-1k-20k ft, in.Hg, Lighted)	United Instruments	Repair
5035P2-P25 P.95	-	Encoding Altimeter (-1k-20k ft, in.Hg, 28V Light)	United Instruments	Repair
5035P2-P26	-	Encoding Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5035P2-P26 P.26	-	Encoding Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5035P2-P26 P.96	-	Encoding Altimeter (-1k-20k ft, in.Hg, Lighted)	United Instruments	Repair
5035P2-P27	-	Encoding Altimeter (-1k-20k ft, mbar)	United Instruments	Repair
5035P2-P27 P.101	-	Encoding Altimeter (-1k-20k ft, mbar, Lighted)	United Instruments	Repair
5035P2-P27 P.27	-	Encoding Altimeter (-1k-20k ft, mbar)	United Instruments	Repair
5035P2-P30	-	Encoding Altimeter (-1k-20k ft, mbar)	United Instruments	Repair
5035P2-P30 P.111	-	Encoding Altimeter (-1k-20k ft, mbar, Lighted)	United Instruments	Repair
5035P2-P30 P.30	-	Encoding Altimeter (-1k-20k ft, mbar)	United Instruments	Repair
5035P2-P39	-	Encoding Altimeter (-1k-20k ft, Dual Scale)	United Instruments	Repair
5035P2-P39 P.144	-	Encoding Altimeter (-1k-20k ft, Dual, Lighted)	United Instruments	Repair
5035P2-P39 P.39	-	Encoding Altimeter (-1k-20k ft, Dual Scale)	United Instruments	Repair
5035P2-P42	-	Encoding Altimeter (-1k-20k ft, Dual Scale)	United Instruments	Repair
5035P2-P42 P.140	-	Encoding Altimeter (-1k-20k ft, Dual, Lighted)	United Instruments	Repair
5035P2-P42 P.143	-	Encoding Altimeter (-1k-20k ft, Dual Scale, 28V Light)	United Instruments	Repair
5035P2-P42 P.42	-	Encoding Altimeter (-1k-20k ft, Dual Scale)	United Instruments	Repair
5035P2-P43	066-3064-00	Encoding Altimeter (-1k-20k ft, Dual Scale)	United Instruments	Repair
5035P2-P43 P.43	066-3064-00	Encoding Altimeter (-1k-20k ft, Dual Scale)	United Instruments	Repair
5035P2-P44	066-3064-01	Encoding Altimeter (-1k-20k ft, Dual Scale, Lighted)	United Instruments	Repair
5035P2-P44 P.44	066-3064-01	Encoding Altimeter (-1k-20k ft, Dual Scale, Lighted)	United Instruments	Repair
5035P3-P33	-	Encoding Altimeter (-1k-30k ft, in.Hg)	United Instruments	Repair
5035P3-P33 P.116	-	Encoding Altimeter (-1k-30k ft, in.Hg, Lighted)	United Instruments	Repair
5035P3-P33 P.33	-	Encoding Altimeter (-1k-30k ft, in.Hg)	United Instruments	Repair
5035P3-P34	-	Encoding Altimeter (-1k-30k ft, mbar)	United Instruments	Repair
5035P3-P34 P.121	-	Encoding Altimeter (-1k-30k ft, mbar, Lighted)	United Instruments	Repair
5035P3-P34 P.34	-	Encoding Altimeter (-1k-30k ft, mbar)	United Instruments	Repair
5035P4-P37	-	Encoding Altimeter (-1k-25k ft, in.Hg)	United Instruments	Repair
5035P4-P37 P.126	-	Encoding Altimeter (-1k-25k ft, in.Hg, Lighted)	United Instruments	Repair
5035P4-P37 P.37	-	Encoding Altimeter (-1k-25k ft, in.Hg)	United Instruments	Repair
5035P4-P38	-	Encoding Altimeter (-1k-25k ft, mbar)	United Instruments	Repair
5035P4-P38 P.131	-	Encoding Altimeter (-1k-25k ft, mbar, Lighted)	United Instruments	Repair
5035P4-P38 P.38	-	Encoding Altimeter (-1k-25k ft, mbar)	United Instruments	Repair
5035PB-P159	-	Encoding Altimeter (-1k-35k ft, Dual Scale, B/O)	United Instruments	Repair
5035PB-P159 P.159	-	Encoding Altimeter (-1k-35k ft, Dual Scale, B/O)	United Instruments	Repair
5035P-P22	-	Encoding Altimeter (-1k-35k ft, in.Hg)	United Instruments	Repair
5035P-P22 P.22	-	Encoding Altimeter (-1k-35k ft, in.Hg)	United Instruments	Repair
5035P-P22 P.76	-	Encoding Altimeter (-1k-35k ft, in.Hg Lighted)	United Instruments	Repair
5035P-P23	-	Encoding Altimeter (-1k-35k ft, in.Hg)	United Instruments	Repair
5035P-P23 P.23	-	Encoding Altimeter (-1k-35k ft, in.Hg)	United Instruments	Repair
5035P-P23 P.81	-	Encoding Altimeter (-1k-35k ft, in.Hg, Lighted)	United Instruments	Repair
5035P-P24	-	Encoding Altimeter (-1k-35k ft, mbar)	United Instruments	Repair
5035P-P24 P.24	-	Encoding Altimeter (-1k-35k ft, mbar)	United Instruments	Repair

Part Number	Model	Description	Manufacturer	Capability
5035P-P24 P.86	-	Encoding Altimeter (-1k-35k ft, mbar, Lighted)	United Instruments	Repair
5035P-P28	-	Encoding Altimeter (-1k-35k ft, mbar)	United Instruments	Repair
5035P-P28 P.106	-	Encoding Altimeter (-1k-35k ft, mbar, Lighted)	United Instruments	Repair
5035P-P28 P.28	-	Encoding Altimeter (-1k-35k ft, mbar)	United Instruments	Repair
5035P-P40	-	Encoding Altimeter (-1k-35k ft, Dual Scale, Piper)	United Instruments	Repair
5035P-P41	-	Encoding Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
5035P-P41 P.136	-	Encoding Altimeter (-1k-35k ft, Dual, Lighted)	United Instruments	Repair
5035P-P41 P.41	-	Encoding Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
5035P-P45	066-3064-02	Encoding Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
5035P-P45 P.45	066-3064-02	Encoding Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
5035P-P46	066-3064-03	Encoding Altimeter (-1k-35k ft, Dual Scale, Lighted)	United Instruments	Repair
5035P-P46 P.46	066-3064-03	Encoding Altimeter (-1k-35k ft, Dual Scale, Lighted)	United Instruments	Repair
5035P-P50	-	Encoding Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
5035P-P50 P.149	-	Encoding Altimeter (-1k-35k ft, Dual, Lighted)	United Instruments	Repair
5035P-P50 P.150	-	Encoding Altimeter (-1k-35k ft, Dual Scale, 5V Light)	United Instruments	Repair
5035P-P50 P.50	-	Encoding Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
50-384203	5000B-10	Attitude Gyro	Beechcraft	Repair
50-384203-3	5000B-33	Attitude Gyro	Beechcraft	Repair
50-384205	4000B-10	Directional Gyro	Beechcraft	Repair
504-0001-902	251CF(8°)	Attitude Gyro	AIM	Repair
504-0001-902	251CF	Attitude Gyro	AIM	Repair
504-0001-907	700-2CF	Attitude Gyro	AIM	Repair
504-0001-908	700-3CFK	Attitude Gyro	AIM	Repair
504-0001-908	700-3CF	Attitude Gyro	AIM	Repair
504-0001-911	300-7CF(8°)	Attitude Gyro	AIM	Repair
504-0001-911	300-7CF	Attitude Gyro	AIM	Repair
504-0001-912	700-5CF (MOD 2)	Attitude Gyro	AIM	Repair
504-0001-912	700-5CF (MOD 1)	Attitude Gyro	AIM	Repair
504-0001-912	700-5CF	Attitude Gyro	AIM	Repair
504-0001-916	300-2CFM(8°)	Attitude Gyro	AIM	Repair
504-0001-916	300-2CFM	Attitude Gyro	AIM	Repair
504-0001-918	300-9A(8°)	Attitude Gyro	AIM	Repair
504-0001-918	300-9A	Attitude Gyro	AIM	Repair
504-0001-918	300-9(8°)	Attitude Gyro	AIM	Repair
504-0001-918	300-9	Attitude Gyro	AIM	Repair
504-0001-920	300-11AX	Attitude Gyro	AIM	Repair
504-0001-920	300-11AL	Attitude Gyro	AIM	Repair
504-0001-920	300-11A	Attitude Gyro	AIM	Repair
504-0001-921	300-16A(8°)	Attitude Gyro	AIM	Repair
504-0001-921	300-16A	Attitude Gyro	AIM	Repair
504-0001-922	300-9C(8°)	Attitude Gyro	AIM	Repair
504-0001-922	300-9C	Attitude Gyro	AIM	Repair
504-0001-922	300-9B(8°)	Attitude Gyro	AIM	Repair
504-0001-922	300-9B	Attitude Gyro	AIM	Repair
504-0001-925	300-17A	Attitude Gyro	AIM	Repair
504-0001-926	300-23A	Attitude Gyro	AIM	Repair
504-0001-927	300-23B	Attitude Gyro	AIM	Repair
504-0001-928	300-23C	Attitude Gyro	AIM	Repair
504-0002-902	500ECFK	Attitude Gyro	AIM	Repair
504-0002-902	500ECF	Attitude Gyro	AIM	Repair
504-0002-906	500ED	Attitude Gyro	AIM	Repair
504-0002-912	500ECFA	Attitude Gyro	AIM	Repair
504-0002-913	500ECFL	Attitude Gyro	AIM	Repair
504-0002-916	500E-2B(8°)	Attitude Gyro	AIM	Repair
504-0002-916	500E-2B	Attitude Gyro	AIM	Repair
504-0002-918	500ECFB	Attitude Gyro	AIM	Repair
504-0002-919	500ECFBK	Attitude Gyro	AIM	Repair
504-0002-920	500E-2C8	Attitude Gyro	AIM	Repair
504-0002-920	500E-2C5	Attitude Gyro	AIM	Repair
504-0002-920	500E-2C16	Attitude Gyro	AIM	Repair
504-0002-920	500E-2C	Attitude Gyro	AIM	Repair
504-0002-921	500E-2D8	Attitude Gyro	AIM	Repair
504-0002-921	500E-2D5	Attitude Gyro	AIM	Repair
504-0002-921	500E-2D	Attitude Gyro	AIM	Repair
504-0002-922	500E-2E8	Attitude Gyro	AIM	Repair
504-0002-922	500E-2E5	Attitude Gyro	AIM	Repair

Part Number	Model	Description	Manufacturer	Capability
504-0002-922	500E-2E	Attitude Gyro	AIM	Repair
504-0002-923	500E-3A8	Attitude Gyro	AIM	Repair
504-0002-923	500E-3A5	Attitude Gyro	AIM	Repair
504-0002-923	500E-3A	Attitude Gyro	AIM	Repair
504-0002-924	500E-2F8	Attitude Gyro	AIM	Repair
504-0002-924	500E-2F5	Attitude Gyro	AIM	Repair
504-0002-924	500E-2F	Attitude Gyro	AIM	Repair
504-0002-925	500E-3B8	Attitude Gyro	AIM	Repair
504-0002-925	500E-3B5	Attitude Gyro	AIM	Repair
504-0002-925	500E-3B	Attitude Gyro	AIM	Repair
504-0002-926	500E-4A8	Attitude Gyro	AIM	Repair
504-0002-926	500E-4A5	Attitude Gyro	AIM	Repair
504-0002-926	500E-4A	Attitude Gyro	AIM	Repair
504-0002-928	500E-3C8	Attitude Gyro	AIM	Repair
504-0002-928	500E-3C5	Attitude Gyro	AIM	Repair
504-0002-928	500E-3C	Attitude Gyro	AIM	Repair
504-0002-929	500E-5A8	Attitude Gyro	AIM	Repair
504-0002-929	500E-5A5	Attitude Gyro	AIM	Repair
504-0002-929	500E-5A	Attitude Gyro	AIM	Repair
504-0002-930	500E-5B8	Attitude Gyro	AIM	Repair
504-0002-930	500E-5B5	Attitude Gyro	AIM	Repair
504-0002-930	500E-5B	Attitude Gyro	AIM	Repair
504-0002-931	500E-6A8	Attitude Gyro	AIM	Repair
504-0002-931	500E-6A5	Attitude Gyro	AIM	Repair
504-0002-931	500E-6A	Attitude Gyro	AIM	Repair
504-0002-932	500E-6B8	Attitude Gyro	AIM	Repair
504-0002-932	500E-6B5	Attitude Gyro	AIM	Repair
504-0002-932	500E-6B	Attitude Gyro	AIM	Repair
504-0003-904	500-1A6	Attitude Gyro	AIM	Repair
504-0005-901	251ECFBK	Attitude Gyro	AIM	Repair
504-0005-901	251ECFB(8°)K	Attitude Gyro	AIM	Repair
504-0005-901	251ECFB(8°)	Attitude Gyro	AIM	Repair
504-0005-901	251ECFB	Attitude Gyro	AIM	Repair
504-0005-905	300-16B(8°)	Attitude Gyro	AIM	Repair
504-0005-905	300-16B	Attitude Gyro	AIM	Repair
504-0005-906	300-11BX	Attitude Gyro	AIM	Repair
504-0005-906	300-11B(8°)	Attitude Gyro	AIM	Repair
504-0005-906	300-11B	Attitude Gyro	AIM	Repair
504-0005-907	300-24B(8°)	Attitude Gyro	AIM	Repair
504-0005-907	300-24B	Attitude Gyro	AIM	Repair
504-0005-908	300-24A(8°)	Attitude Gyro	AIM	Repair
504-0005-908	300-24A	Attitude Gyro	AIM	Repair
504-0006-903	700-4CF(6°)	Attitude Gyro	AIM	Repair
504-0006-903	700-4CF	Attitude Gyro	AIM	Repair
504-0006-906	300-3BCF	Attitude Gyro	AIM	Repair
504-0006-908	300-BCFL	Attitude Gyro	AIM	Repair
504-0006-909	300-3J8	Attitude Gyro	AIM	Repair
504-0006-910	C661076-0103	Attitude Gyro	AIM	Repair
504-0006-910	300-3CFC	Attitude Gyro	AIM	Repair
504-0006-912	300-10	Attitude Gyro	AIM	Repair
504-0006-913	300-14L	Attitude Gyro	AIM	Repair
504-0006-914	300-14(8°)	Attitude Gyro	AIM	Repair
504-0006-914	300-14	Attitude Gyro	AIM	Repair
504-0006-915	300-BCF-3	Attitude Gyro	AIM	Repair
504-0006-916	300-20HDL	Attitude Gyro	AIM	Repair
504-0006-917	300-20HD(8°)	Attitude Gyro	AIM	Repair
504-0006-917	300-20HD	Attitude Gyro	AIM	Repair
504-0006-918	300-50	Attitude Gyro	AIM	Repair
504-0006-919	300-50L	Attitude Gyro	AIM	Repair
504-0006-920	300-15	Attitude Gyro	AIM	Repair
504-0006-921	300-15	Attitude Gyro	AIM	Repair
504-0006-922	300-15B	Attitude Gyro	AIM	Repair
504-0006-928	300-14LK	Attitude Gyro	AIM	Repair
504-0006-929	300-14K	Attitude Gyro	AIM	Repair
504-0007-905	300-1CF	Attitude Gyro	AIM	Repair
504-0010-901	500DC(14)	Attitude Gyro	AIM	Repair

Part Number	Model	Description	Manufacturer	Capability
504-0010-902	500DC(28)	Attitude Gyro	AIM	Repair
504-0010-903	500DCF(14)	Attitude Gyro	AIM	Repair
504-0010-904	500DCFL(8°)	Attitude Gyro	AIM	Repair
504-0010-904	500DCFL	Attitude Gyro	AIM	Repair
504-0010-905	500DCF(14)P6	Attitude Gyro	AIM	Repair
504-0010-905	500DCF(14)P	Attitude Gyro	AIM	Repair
504-0010-906	500DCF(28)P6	Attitude Gyro	AIM	Repair
504-0010-906	500DCF(28)P	Attitude Gyro	AIM	Repair
504-0010-907	500DC(BELL)(5)	Attitude Gyro	AIM	Repair
504-0010-907	500DC(BELL)	Attitude Gyro	AIM	Repair
504-0010-909	500DCF(28)	Attitude Gyro	AIM	Repair
504-0010-910	500DCFM(28) MOD 3	Attitude Gyro	AIM	Repair
504-0010-910	500DCFM(28) MOD 2	Attitude Gyro	AIM	Repair
504-0010-910	500DCFM(28) MOD 1	Attitude Gyro	AIM	Repair
504-0010-912	500DCD(28) MOD 5	Attitude Gyro	AIM	Repair
504-0010-912	500DCD(28)	Attitude Gyro	AIM	Repair
504-0010-912	500DCD(14) MOD 5	Attitude Gyro	AIM	Repair
504-0010-912	500DCD(14)	Attitude Gyro	AIM	Repair
504-0010-913	500DCA(BELL)(5)	Attitude Gyro	AIM	Repair
504-0010-913	500DCA(BELL)	Attitude Gyro	AIM	Repair
504-0010-914	500DCFML8	Attitude Gyro	AIM	Repair
504-0010-915	500DCFL(14)	Attitude Gyro	AIM	Repair
504-0010-916	500DC(28)S	Attitude Gyro	AIM	Repair
504-0010-918	500DC1A8	Attitude Gyro	AIM	Repair
504-0010-918	500DC1A5	Attitude Gyro	AIM	Repair
504-0010-918	500DC1A	Attitude Gyro	AIM	Repair
504-0010-919	500D-3A(28)	Attitude Gyro	AIM	Repair
504-0010-920	500D-3A(14)	Attitude Gyro	AIM	Repair
504-0011-902	300-1ED	Attitude Gyro	AIM	Repair
504-0011-903	300-1ECF(8°)	Attitude Gyro	AIM	Repair
504-0011-903	300-1ECF	Attitude Gyro	AIM	Repair
504-0014-901	700-3ECF	Attitude Gyro	AIM	Repair
504-0014-902	700-3ECF(4°)	Attitude Gyro	AIM	Repair
504-0014-903	700-23ECF	Attitude Gyro	AIM	Repair
504-0016-901	251CFL	Attitude Gyro	AIM	Repair
504-0016-902	300-17B(8°)	Attitude Gyro	AIM	Repair
504-0016-902	300-17B	Attitude Gyro	AIM	Repair
504-0016-903	300-18A	Attitude Gyro	AIM	Repair
504-0016-904	300-18B	Attitude Gyro	AIM	Repair
504-0016-905	300-18C	Attitude Gyro	AIM	Repair
504-0016-906	251CFLB	Attitude Gyro	AIM	Repair
504-0016-907	300-26	Attitude Gyro	AIM	Repair
504-0016-908	300-26L	Attitude Gyro	AIM	Repair
504-0016-909	300-26K	Attitude Gyro	AIM	Repair
504-0016-910	300-26LK	Attitude Gyro	AIM	Repair
504-0017-901	510-1A	Attitude Gyro	AIM	Repair
504-0017-903	510-3A	Attitude Gyro	AIM	Repair
504-0017-905	510-5A	Attitude Gyro	AIM	Repair
504-0017-907	510-7A	Attitude Gyro	AIM	Repair
504-0017-908	510-1B	Attitude Gyro	AIM	Repair
504-0017-909	510-8A	Attitude Gyro	AIM	Repair
504-0017-910	510-10A/B	Attitude Gyro	AIM	Repair
504-0017-911	510-10C	Attitude Gyro	AIM	Repair
504-0017-912	510-7C	Attitude Gyro	AIM	Repair
504-0017-913	510-17A	Attitude Gyro	AIM	Repair
504-0017-914	510-17B	Attitude Gyro	AIM	Repair
504-0017-916	510-8B	Attitude Gyro	AIM	Repair
504-0017-917	510-8C	Attitude Gyro	AIM	Repair
504-0017-918	510-1F	Attitude Gyro	AIM	Repair
504-0017-921	510-8D	Attitude Gyro	AIM	Repair
504-0017-922	510-8E	Attitude Gyro	AIM	Repair
504-0017-923	510-8F	Attitude Gyro	AIM	Repair
504-0017-924	510-8G	Attitude Gyro	AIM	Repair
504-0017-925	510-8H	Attitude Gyro	AIM	Repair
504-0017-926	510-1G	Attitude Gyro	AIM	Repair
504-0017-928	510-1J17	Attitude Gyro	AIM	Repair

Part Number	Model	Description	Manufacturer	Capability
504-0017-930	510-1K	Attitude Gyro	AIM	Repair
504-0017-931	510-1M	Attitude Gyro	AIM	Repair
504-0017-932	510-1N	Attitude Gyro	AIM	Repair
504-0017-933	510-1P	Attitude Gyro	AIM	Repair
504-0017-934	510-1R	Attitude Gyro	AIM	Repair
504-0019-902	500E-7A8	Attitude Gyro	AIM	Repair
504-0019-902	500E-7A5	Attitude Gyro	AIM	Repair
504-0019-902	500E-7A	Attitude Gyro	AIM	Repair
504-0019-903	500ECFLAK	Attitude Gyro	AIM	Repair
504-0019-904	500E-4B	Attitude Gyro	AIM	Repair
504-0019-905	500ECFC	Attitude Gyro	AIM	Repair
504-0019-906	500E-2N	Attitude Gyro	AIM	Repair
504-0019-907	500ECFBL	Attitude Gyro	AIM	Repair
504-0019-908	500E-4C10	Attitude Gyro	AIM	Repair
504-0021-901	500ECFK-2	Attitude Gyro	AIM	Repair
504-0021-901	500ECF-2	Attitude Gyro	AIM	Repair
504-0021-902	500ECFA-2	Attitude Gyro	AIM	Repair
504-0021-903	500ECFL-2	Attitude Gyro	AIM	Repair
504-0021-904	500ECFB-2	Attitude Gyro	AIM	Repair
504-0021-905	500ECFBK-2	Attitude Gyro	AIM	Repair
504-0021-906	500ECFLK-2	Attitude Gyro	AIM	Repair
504-0021-907	500ECFBL-2	Attitude Gyro	AIM	Repair
504-0021-908	500ECFL-2A	Attitude Gyro	AIM	Repair
504-0022-901	251ECFR8	Attitude Gyro	AIM	Repair
504-0022-901	251ECFR	Attitude Gyro	AIM	Repair
504-0022-902	251ECFRB	Attitude Gyro	AIM	Repair
504-0022-903	251ECFRBK	Attitude Gyro	AIM	Repair
504-0022-904	251ECFRA	Attitude Gyro	AIM	Repair
504-0023-901	251CFR(8°)	Attitude Gyro	AIM	Repair
504-0023-901	251CFR	Attitude Gyro	AIM	Repair
504-0024-901	510-21A/AH	Attitude Gyro	AIM	Repair
504-0024-902	510-21B/BH	Attitude Gyro	AIM	Repair
504-0024-903	510-21C/CH	Attitude Gyro	AIM	Repair
504-0024-904	510-21D/DH	Attitude Gyro	AIM	Repair
504-0024-905	510-21E/EH	Attitude Gyro	AIM	Repair
504-0024-906	510-21F	Attitude Gyro	AIM	Repair
504-0024-907	510-21G	Attitude Gyro	AIM	Repair
504-0028-901	510-22A/AH	Attitude Gyro	AIM	Repair
504-0028-902	510-22B/BH	Attitude Gyro	AIM	Repair
504-0028-903	510-22C/CH	Attitude Gyro	AIM	Repair
504-0028-904	510-22D/DH	Attitude Gyro	AIM	Repair
504-0028-905	510-22E/EH	Attitude Gyro	AIM	Repair
504-0028-906	510-22F/FH	Attitude Gyro	AIM	Repair
504-0028-907	510-22G/GH	Attitude Gyro	AIM	Repair
504-0028-908	510-22H/HH	Attitude Gyro	AIM	Repair
504-0028-909	510-22J	Attitude Gyro	AIM	Repair
504-0028-910	510-22K	Attitude Gyro	AIM	Repair
504-0028-911	510-22LH	Attitude Gyro	AIM	Repair
504-0028-912	510-22M	Attitude Gyro	AIM	Repair
504-0028-913	510-22N	Attitude Gyro	AIM	Repair
504-0028-914	510-22P	Attitude Gyro	AIM	Repair
504-0029-901	700-6CF	Attitude Gyro	AIM	Repair
504-0029-902	700-6CFL	Attitude Gyro	AIM	Repair
504-0029-903	700-7CF	Attitude Gyro	AIM	Repair
504-0029-904	700-7CFL	Attitude Gyro	AIM	Repair
504-0029-905	700-7ECF	Attitude Gyro	AIM	Repair
504-0029-906	700-ECFL	Attitude Gyro	AIM	Repair
504-0030-909	510-24J/JH	Attitude Gyro	AIM	Repair
504-0030-910	510-24K/KH	Attitude Gyro	AIM	Repair
504-0030-911	510-24L/LH	Attitude Gyro	AIM	Repair
504-0030-912	510-24M/MH	Attitude Gyro	AIM	Repair
504-0030-913	510-24N	Attitude Gyro	AIM	Repair
504-0030-914	510-24P	Attitude Gyro	AIM	Repair
504-0030-915	510-24R	Attitude Gyro	AIM	Repair
504-0030-916	510-24S	Attitude Gyro	AIM	Repair
504-0030-918	510-24V	Attitude Gyro	AIM	Repair

Part Number	Model	Description	Manufacturer	Capability
504-0030-919	510-24W	Attitude Gyro	AIM	Repair
504-0030-920	510-24L2	Attitude Gyro	AIM	Repair
504-0031-901	510-25A	Attitude Gyro	AIM	Repair
504-0031-902	510-27A	Attitude Gyro	AIM	Repair
504-0031-903	510-27B	Attitude Gyro	AIM	Repair
504-0031-904	510-27C	Attitude Gyro	AIM	Repair
504-0031-906	510-27E	Attitude Gyro	AIM	Repair
504-0031-907	510-27F	Attitude Gyro	AIM	Repair
504-0031-908	510-27G	Attitude Gyro	AIM	Repair
504-0031-909	510-27H	Attitude Gyro	AIM	Repair
504-0031-910	510-27J	Attitude Gyro	AIM	Repair
504-0031-911	510-27K	Attitude Gyro	AIM	Repair
504-0031-912	510-27L	Attitude Gyro	AIM	Repair
504-0031-913	510-27M	Attitude Gyro	AIM	Repair
504-0031-914	510-27N	Attitude Gyro	AIM	Repair
504-0031-915	510-27P	Attitude Gyro	AIM	Repair
504-0031-916	510-27R	Attitude Gyro	AIM	Repair
504-0031-917	510-27T	Attitude Gyro	AIM	Repair
504-0032-902	505-2B	Attitude Gyro	AIM	Repair
504-0032-904	505-2A	Attitude Gyro	AIM	Repair
504-0032-906	505-2C	Attitude Gyro	AIM	Repair
504-0032-911	505-2BK	Attitude Gyro	AIM	Repair
504-0032-912	505-2BS	Attitude Gyro	AIM	Repair
504-0032-916	505-2BG	Attitude Gyro	AIM	Repair
504-0032-917	505-2BKS	Attitude Gyro	AIM	Repair
504-0033-901	305-1A	Attitude Gyro	AIM	Repair
504-0033-902	305-1AL	Attitude Gyro	AIM	Repair
504-0033-903	305-1B	Attitude Gyro	AIM	Repair
504-0033-904	305-1BL	Attitude Gyro	AIM	Repair
504-0033-905	305-1C	Attitude Gyro	AIM	Repair
504-0033-906	305-1CL	Attitude Gyro	AIM	Repair
504-0033-907	305-2A	Attitude Gyro	AIM	Repair
504-0033-908	305-2AL	Attitude Gyro	AIM	Repair
504-0033-909	305-2B	Attitude Gyro	AIM	Repair
504-0033-910	305-2BL	Attitude Gyro	AIM	Repair
504-0033-911	305-2C	Attitude Gyro	AIM	Repair
504-0033-912	305-2CL	Attitude Gyro	AIM	Repair
504-0033-913	C661051-0201	Attitude Gyro	AIM	Repair
504-0033-913	305-2BC	Attitude Gyro	AIM	Repair
504-0033-921	305-1A	Attitude Gyro	AIM	Repair
504-0033-922	305-1AL	Attitude Gyro	AIM	Repair
504-0033-923	305-1B	Attitude Gyro	AIM	Repair
504-0033-924	305-1BL	Attitude Gyro	AIM	Repair
504-0033-925	305-1C	Attitude Gyro	AIM	Repair
504-0033-926	305-1CL	Attitude Gyro	AIM	Repair
504-0033-927	305-2A	Attitude Gyro	AIM	Repair
504-0033-928	305-2AL	Attitude Gyro	AIM	Repair
504-0033-929	305-2B	Attitude Gyro	AIM	Repair
504-0033-930	305-2BL	Attitude Gyro	AIM	Repair
504-0033-931	305-2C	Attitude Gyro	AIM	Repair
504-0033-932	305-2CL	Attitude Gyro	AIM	Repair
504-0033-933	C661051-0201	Attitude Gyro	AIM	Repair
504-0033-933	305-2BC	Attitude Gyro	AIM	Repair
504-0033-934	305-2BLS	Attitude Gyro	AIM	Repair
504-0033-943	305-1D	Attitude Gyro	AIM	Repair
504-0033-944	305-1BS	Attitude Gyro	AIM	Repair
504-0035-901	520-1A	Attitude Gyro	AIM	Repair
504-0035-902	520-1AG	Attitude Gyro	AIM	Repair
504-0035-903	520-1B	Attitude Gyro	AIM	Repair
504-0035-904	520-1BG	Attitude Gyro	AIM	Repair
504-0035-905	520-2A	Attitude Gyro	AIM	Repair
504-0035-906	520-2AG	Attitude Gyro	AIM	Repair
504-0035-907	520-2B	Attitude Gyro	AIM	Repair
504-0035-908	520-2BG	Attitude Gyro	AIM	Repair
504-0035-909	520-3A	Attitude Gyro	AIM	Repair
504-0035-910	520-3AG	Attitude Gyro	AIM	Repair

Part Number	Model	Description	Manufacturer	Capability
504-0035-911	520-3B	Attitude Gyro	AIM	Repair
504-0035-912	520-3BG	Attitude Gyro	AIM	Repair
504-0035-913	520-4A	Attitude Gyro	AIM	Repair
504-0035-914	520-4AG	Attitude Gyro	AIM	Repair
504-0035-915	520-4B	Attitude Gyro	AIM	Repair
504-0035-916	520-4BG	Attitude Gyro	AIM	Repair
504-0035-917	520-5B	Attitude Gyro	AIM	Repair
504-0035-918	520-6B	Attitude Gyro	AIM	Repair
504-0035-921	520-9B	Attitude Gyro	AIM	Repair
504-0035-922	520-10B	Attitude Gyro	AIM	Repair
504-0035-923	520-11B	Attitude Gyro	AIM	Repair
504-0035-924	520-12B	Attitude Gyro	AIM	Repair
504-0035-925	520-15B	Attitude Gyro	AIM	Repair
504-0035-926	520-16B	Attitude Gyro	AIM	Repair
504-0037-901	510-29A/AH	Attitude Gyro	AIM	Repair
504-0037-902	510-29B/BH	Attitude Gyro	AIM	Repair
504-0037-903	510-29C/CH	Attitude Gyro	AIM	Repair
504-0037-904	510-29D/DH	Attitude Gyro	AIM	Repair
504-0037-905	510-29E	Attitude Gyro	AIM	Repair
504-0038-902	510-30B	Attitude Gyro	AIM	Repair
504-0038-903	510-30BK	Attitude Gyro	AIM	Repair
504-0038-904	510-30BW	Attitude Gyro	AIM	Repair
504-0038-905	510-30BKW	Attitude Gyro	AIM	Repair
504-0038-906	510-30C	Attitude Gyro	AIM	Repair
504-0038-907	510-30D	Attitude Gyro	AIM	Repair
504-0038-908	510-30DK	Attitude Gyro	AIM	Repair
504-0038-909	510-30DW	Attitude Gyro	AIM	Repair
504-0038-910	510-30DKW	Attitude Gyro	AIM	Repair
504-0038-911	510-30E	Attitude Gyro	AIM	Repair
504-0038-913	510-30G	Attitude Gyro	AIM	Repair
504-0038-914	510-30H	Attitude Gyro	AIM	Repair
504-0041-901	510-31A	Attitude Gyro	AIM	Repair
504-0041-902	510-31B	Attitude Gyro	AIM	Repair
504-0042-901	510-32A	Attitude Gyro	AIM	Repair
504-0042-902	510-32AK	Attitude Gyro	AIM	Repair
504-0042-903	510-32B	Attitude Gyro	AIM	Repair
504-0042-904	510-32BK	Attitude Gyro	AIM	Repair
504-0042-905	510-32C	Attitude Gyro	AIM	Repair
504-0043-901	510-33A	Attitude Gyro	AIM	Repair
504-0044-901	510-34A	Attitude Gyro	AIM	Repair
504-0045-901	510-35A	Attitude Gyro	AIM	Repair
504-0045-902	510-35B	Attitude Gyro	AIM	Repair
504-0045-903	510-35C	Attitude Gyro	AIM	Repair
504-0045-904	510-35D	Attitude Gyro	AIM	Repair
504-0046-901	510-36A	Attitude Gyro	AIM	Repair
504-0048-901	510-37A	Attitude Gyro	AIM	Repair
504-0048-902	510-37B	Attitude Gyro	AIM	Repair
504-0048-903	510-37C	Attitude Gyro	AIM	Repair
504-0051-901	510-39A	Attitude Gyro	AIM	Repair
504-0052-901	510-40A	Attitude Gyro	AIM	Repair
504-0053-901	510-41A	Attitude Gyro	AIM	Repair
504-0057-901	510-44A	Attitude Gyro	AIM	Repair
504-0110-901	1100-14(0)	Attitude Gyro	AIM	Repair
504-0110-902	1100-14(11)	Attitude Gyro	AIM	Repair
504-0110-903	1100-14L(11D)	Attitude Gyro	AIM	Repair
504-0110-904	1100-14L(0D)	Attitude Gyro	AIM	Repair
504-0110-905	1100-14S(11)	Attitude Gyro	AIM	Repair
504-0110-906	1100-14(5)DIA	Attitude Gyro	AIM	Repair
504-0110-907	1100-14(5)	Attitude Gyro	AIM	Repair
504-0110-908	1100-14(8)	Attitude Gyro	AIM	Repair
504-0110-909	1100-14(12)	Attitude Gyro	AIM	Repair
504-0110-910	1100-14(14)	Attitude Gyro	AIM	Repair
504-0110-911	1100-14L(5D)	Attitude Gyro	AIM	Repair
504-0110-912	1100-14L(8D)	Attitude Gyro	AIM	Repair
504-0110-913	1100-14L(12D)	Attitude Gyro	AIM	Repair
504-0110-914	1100-14L(14D)	Attitude Gyro	AIM	Repair

Part Number	Model	Description	Manufacturer	Capability
504-0110-915	1100-14LS(0D)	Attitude Gyro	AIM	Repair
504-0110-916	1100-14LS(5D)	Attitude Gyro	AIM	Repair
504-0110-917	1100-14LS(8D)	Attitude Gyro	AIM	Repair
504-0110-918	1100-14LS(12D)	Attitude Gyro	AIM	Repair
504-0110-919	1100-14LS(14D)	Attitude Gyro	AIM	Repair
504-0110-920	1100-14S(0)	Attitude Gyro	AIM	Repair
504-0110-921	1100-14S(5)	Attitude Gyro	AIM	Repair
504-0110-922	1100-14S(8)	Attitude Gyro	AIM	Repair
504-0110-923	1100-14S(12)	Attitude Gyro	AIM	Repair
504-0110-924	1100-14S(14)	Attitude Gyro	AIM	Repair
504-0110-926	1100-14LK(0D)	Attitude Gyro	AIM	Repair
504-0110-927	1100-14LK(-2D)	Attitude Gyro	AIM	Repair
504-0111-901	1100-28LSK(0F)	Attitude Gyro	AIM	Repair
504-0111-902	1100-28(11)	Attitude Gyro	AIM	Repair
504-0111-903	1100-28L(20B)	Attitude Gyro	AIM	Repair
504-0111-904	1100-28(0)	Attitude Gyro	AIM	Repair
504-0111-905	1100-28L(0F)	Attitude Gyro	AIM	Repair
504-0111-906	1100-28(0)CES	Attitude Gyro	AIM	Repair
504-0111-907	1100-28LS(8F)	Attitude Gyro	AIM	Repair
504-0111-908	1100-28(5)	Attitude Gyro	AIM	Repair
504-0111-909	1100-28(8)	Attitude Gyro	AIM	Repair
504-0111-910	1100-28(12)	Attitude Gyro	AIM	Repair
504-0111-911	1100-28(14)	Attitude Gyro	AIM	Repair
504-0111-912	1100-28L(5F)	Attitude Gyro	AIM	Repair
504-0111-913	1100-28L(7F)	Attitude Gyro	AIM	Repair
504-0111-914	1100-28L(8F)	Attitude Gyro	AIM	Repair
504-0111-915	1100-28L(12F)	Attitude Gyro	AIM	Repair
504-0111-916	1100-28L(14F)	Attitude Gyro	AIM	Repair
504-0111-917	1100-28LS(0F)	Attitude Gyro	AIM	Repair
504-0111-918	1100-28LS(5F)	Attitude Gyro	AIM	Repair
504-0111-919	1100-28LS(12F)	Attitude Gyro	AIM	Repair
504-0111-920	1100-28LS(14F)	Attitude Gyro	AIM	Repair
504-0111-921	1100-28S(0)	Attitude Gyro	AIM	Repair
504-0111-922	1100-28S(5)	Attitude Gyro	AIM	Repair
504-0111-923	1100-28S(8)	Attitude Gyro	AIM	Repair
504-0111-924	1100-28S(12)	Attitude Gyro	AIM	Repair
504-0111-925	1100-28S(14)	Attitude Gyro	AIM	Repair
504-0111-926	1100-28LK(5F)	Attitude Gyro	AIM	Repair
504-0111-927	1100-28S(11)	Attitude Gyro	AIM	Repair
504-0111-928	1100-28LS(7F)	Attitude Gyro	AIM	Repair
504-0111-929	1100-28L(15F)	Attitude Gyro	AIM	Repair
504-0111-930	1100-28LS(15F)	Attitude Gyro	AIM	Repair
504-0111-931	1100-28L(11F)	Attitude Gyro	AIM	Repair
504-0111-932	1100-28LS(11F)	Attitude Gyro	AIM	Repair
504-0111-933	1100-28L(15B)	Attitude Gyro	AIM	Repair
504-0111-934	1100-28L(10F)	Attitude Gyro	AIM	Repair
504-0111-935	1100-28LS(16F)	Attitude Gyro	AIM	Repair
504-0111-936	1100-28L(0F)DIA	Attitude Gyro	AIM	Repair
504-0111-937	1100-28L(6F)	Attitude Gyro	AIM	Repair
504-0111-938	1100-28LK(0F)DIA	Attitude Gyro	AIM	Repair
504-0111-939	1100-28LK(8E)	Attitude Gyro	AIM	Repair
504-0111-940	1100-28LS(4F)	Attitude Gyro	AIM	Repair
504-0111-941	1100-28LK(-2F)	Attitude Gyro	AIM	Repair
504-0111-942	1100-28LS(14E)	Attitude Gyro	AIM	Repair
504-0111-943	1100-28LS(11B)	Attitude Gyro	AIM	Repair
504-0111-944	1100-28K(10)	Attitude Gyro	AIM	Repair
505-0001-910	200-6	Directional Gyro	AIM	Repair
505-0001-917	200H	Directional Gyro	AIM	Repair
505-0001-917	200-5H	Directional Gyro	AIM	Repair
505-0001-920	200-10	Directional Gyro	AIM	Repair
505-0001-921	200-11	Directional Gyro	AIM	Repair
505-0001-925	200-5C	Directional Gyro	AIM	Repair
505-0001-928	200-9C3	Directional Gyro	AIM	Repair
505-0001-929	200-14	Directional Gyro	AIM	Repair
505-0001-931	200-11AL	Directional Gyro	AIM	Repair
505-0001-932	200-11CL	Directional Gyro	AIM	Repair

Part Number	Model	Description	Manufacturer	Capability
505-0001-937	200-19	Directional Gyro	AIM	Repair
505-0001-938	200-19L	Directional Gyro	AIM	Repair
505-0001-939	200HL	Directional Gyro	AIM	Repair
505-0002-902	200E	Directional Gyro	AIM	Repair
505-0002-903	200DC(14)	Directional Gyro	AIM	Repair
505-0002-904	200DC(28)	Directional Gyro	AIM	Repair
505-0002-906	200DC(14)	Directional Gyro	AIM	Repair
505-0002-907	200DC(28)	Directional Gyro	AIM	Repair
505-0002-910	200ED	Directional Gyro	AIM	Repair
505-0002-915	200-10DC(28)	Directional Gyro	AIM	Repair
505-0002-916	200-10DC(14)	Directional Gyro	AIM	Repair
505-0002-917	200DCD(28)	Directional Gyro	AIM	Repair
505-0002-918	200EB	Directional Gyro	AIM	Repair
505-0002-919	200E-2	Directional Gyro	AIM	Repair
505-0002-920	200ED-2	Directional Gyro	AIM	Repair
505-0002-921	200-11DC(28)	Directional Gyro	AIM	Repair
505-0002-922	200-8DCL	Directional Gyro	AIM	Repair
505-0008-901	200-5BL	Directional Gyro	AIM	Repair
505-0008-902	200-5L	Directional Gyro	AIM	Repair
505-0008-907	200-10BL	Directional Gyro	AIM	Repair
505-0010-901	200DC(BELL)	Directional Gyro	AIM	Repair
505-0010-902	200DCL(28)	Directional Gyro	AIM	Repair
505-0010-903	200EL	Directional Gyro	AIM	Repair
505-0010-904	200DCFM(28)	Directional Gyro	AIM	Repair
505-0010-905	200DCJ	Directional Gyro	AIM	Repair
505-0010-906	200DCA(BELL)	Directional Gyro	AIM	Repair
505-0010-907	200EBL	Directional Gyro	AIM	Repair
505-0010-908	200DCL(Lear)	Directional Gyro	AIM	Repair
505-0010-909	200DC1A	Directional Gyro	AIM	Repair
505-0010-910	200DC2A(BELL)	Directional Gyro	AIM	Repair
505-0010-911	200DC3A	Directional Gyro	AIM	Repair
505-0010-912	200DCL(14)	Directional Gyro	AIM	Repair
505-0013-903	200-12A(14)	Directional Gyro	AIM	Repair
505-0013-904	200-12A(28)	Directional Gyro	AIM	Repair
505-0014-901	200-13	Directional Gyro	AIM	Repair
505-0014-902	200-13A	Directional Gyro	AIM	Repair
505-0017-901	200-9M3	Directional Gyro	AIM	Repair
505-0017-904	200-5A2	Directional Gyro	AIM	Repair
505-0030-905	200-22DCA14	Directional Gyro	AIM	Repair
505-0030-906	200-22DCA28	Directional Gyro	AIM	Repair
505-0030-907	200-22DCB14	Directional Gyro	AIM	Repair
505-0030-908	200-22DCB28	Directional Gyro	AIM	Repair
505-0031-901	205-1A	Directional Gyro	AIM	Repair
505-0031-902	205-1AL	Directional Gyro	AIM	Repair
505-0031-903	205-1B	Directional Gyro	AIM	Repair
505-0031-904	206-075-606-107	Directional Gyro	AIM	Repair
505-0031-904	205-1BL	Directional Gyro	AIM	Repair
505-0031-905	205-1C	Directional Gyro	AIM	Repair
505-0031-906	205-1CL	Directional Gyro	AIM	Repair
505-0031-907	205-2A	Directional Gyro	AIM	Repair
505-0031-908	205-2AL	Directional Gyro	AIM	Repair
505-0031-909	205-2B	Directional Gyro	AIM	Repair
505-0031-910	205-2BL	Directional Gyro	AIM	Repair
505-0031-911	205-2C	Directional Gyro	AIM	Repair
505-0031-912	205-2CL	Directional Gyro	AIM	Repair
505-0031-916	205-1BC	Directional Gyro	AIM	Repair
505-0031-926	205-6BL	Directional Gyro	AIM	Repair
505-0031-927	205-1D	Directional Gyro	AIM	Repair
505-0031-928	205-1BLF	Directional Gyro	AIM	Repair
505-0031-929	205-1BF	Directional Gyro	AIM	Repair
505-0031-930	205-7BL	Directional Gyro	AIM	Repair
505-0031-930	206-075-606-109	Directional Gyro	AIM	Repair
505-0031-931	205-1BLD	Directional Gyro	AIM	Repair
505-0031-933	205-1BLR	Directional Gyro	AIM	Repair
511.129-915	ATC3401-110	Transponder	Becker	Repair
511.137-915	ATC3401-010	Transponder	Becker	Repair

Part Number	Model	Description	Manufacturer	Capability
511.145-915	ATC3401-111	Transponder	Becker	Repair
511.153-915	ATC3401-011	Transponder	Becker	Repair
511.986-910	AR3202-(2)-111	VHF Transceiver	Becker	Repair
511.994-910	AR3202-(2)-011	VHF Transceiver	Becker	Repair
514.187-910	AR3202-(1)-110	VHF Transceiver	Becker	Repair
514.195-910	AR3202-(1)-010	VHF Transceiver	Becker	Repair
515.337-910	AR3202-(1)-110CIG	VHF Transceiver	Becker	Repair
515.663-921	AS3100-(12)-13	Audio Panel	Becker	Repair
51509-001	-	Voltage Regulator	TRW	Repair
51509-001R	-	Voltage Regulator	TRW	Repair
51509-002	-	Voltage Regulator	TRW	Repair
51509-002A	-	Voltage Regulator	TRW	Repair
51509-002B	-	Voltage Regulator	TRW	Repair
51509-002R	-	Voltage Regulator	TRW	Repair
5205160-001	CDI-5160L-0	Course Selector Indicator	Aeronetics	Repair
5205160-002	CDI-5160L-E	Course Selector Indicator	Aeronetics	Repair
5205160-003	CDI-5160L-EO	Course Selector Indicator	Aeronetics	Repair
5205160-004	CDI-5160L-O/W	Course Selector Indicator	Aeronetics	Repair
5205160-005	CDI-5160L-EO/5	Course Selector Indicator	Aeronetics	Repair
5205160-006	CDI-5160L-EO/B	Course Selector Indicator	Aeronetics	Repair
5205160-006	214-075-231-5	Course Selector Indicator	Aeronetics	Repair
5205160-006	214-075-231-005	Course Selector Indicator	Aeronetics	Repair
5205160-007	CDI-5160-E	Course Selector Indicator	Aeronetics	Repair
5205160-008	CDI-5160-O	Course Selector Indicator	Aeronetics	Repair
5205160-009	CDI-5160-EO	Course Selector Indicator	Aeronetics	Repair
5205160-010	CDI-5160L-EO/S	Course Selector Indicator	Aeronetics	Repair
5205160-011	CDI-5160L-EO/R	Course Selector Indicator	Aeronetics	Repair
5205160-011	214-075-231-1	Course Selector Indicator	Aeronetics	Repair
5205160-011	214-075-231-001	Course Selector Indicator	Aeronetics	Repair
5205160-012	CDI-5160L-E/S	Course Selector Indicator	Aeronetics	Repair
522-2447-505	313N-2	NAV/COMM Control	Collins	Repair
522-2447-515	313N-2	NAV/COMM Control	Collins	Repair
522-2447-552	313N-2	NAV/COMM Control	Collins	Repair
522-2447-556	313N-2D	NAV/COMM Control	Collins	Repair
522-2447-557	313N-2D	NAV/COMM Control	Collins	Repair
522-2447-560	313N-2D	NAV/COMM Control	Collins	Repair
522-2447-562	313N-2	NAV/COMM Control	Collins	Repair
522-2447-563	313N-2D	NAV/COMM Control	Collins	Repair
522-2447-564	313N-2D	NAV/COMM Control	Collins	Repair
522-2447-570	313N-2D	NAV/COMM Control	Collins	Repair
522-2447-571	313N-2D	NAV/COMM Control	Collins	Repair
522-2447-574	313N-2	NAV/COMM Control	Collins	Repair
522-2449-000	313N-4	NAV Control	Collins	Repair
522-2449-001	313N-4	NAV Control	Collins	Repair
522-2449-002	313N-4	NAV Control	Collins	Repair
522-2599-000	313N-5	COMM Control	Collins	Repair
522-2599-001	313N-5	COMM Control	Collins	Repair
522-2599-002	313N-5	COMM Control	Collins	Repair
522-2599-003	313N-5	COMM Control	Collins	Repair
522-2599-004	313N-5	COMM Control	Collins	Repair
522-2599-500	313N-5	COMM Control	Collins	Repair
522-2599-501	313N-5	COMM Control	Collins	Repair
522-2599-502	313N-5	COMM Control	Collins	Repair
522-2599-503	313N-5	COMM Control	Collins	Repair
522-2599-504	313N-5	COMM Control	Collins	Repair
522-2638-000	331A-3G	Course Indicator	Collins	Repair
522-2638-001	331A-3G	Course Indicator	Collins	Repair
522-2638-002	331A-3G	Course Indicator	Collins	Repair
522-2638-003	331A-3G	Course Indicator	Collins	Repair
522-2638-005	331A-3G	Course Indicator	Collins	Repair
522-2638-006	331A-3G	Course Indicator	Collins	Repair
522-2638-007	331A-3G	Course Indicator	Collins	Repair
522-2638-008	331A-3G	Course Indicator	Collins	Repair
522-2638-009	331A-3G	Course Indicator	Collins	Repair
522-2638-010	331A-3G	Course Indicator	Collins	Repair
522-2643-00	323A-3G	Flux Detector	Collins	Test/Recert

Part Number	Model	Description	Manufacturer	Capability
522-2643-000	323A-3G	Flux Detector	Collins	Test/Recert
522-2644-00	328A-3G	Slaving Accessory	Collins	Repair
522-2644-000	328A-3G	Slaving Accessory	Collins	Repair
522-2644-011	328A-3G	Slaving Accessory	Collins	Repair
522-2644-013	328A-3G	Slaving Accessory	Collins	Repair
522-2645-00	332E-3G	Directional Gyro	Collins	Repair
522-2645-000	332E-3G	Directional Gyro	Collins	Repair
522-2866-000	356C-4	Isolation Amplifier	Collins	Repair
522-2867-000	356F-3	Speaker Amplifier	Collins	Repair
522-2899-000	387C-4	Audio Control Panel	Collins	Repair
522-2899-012	387C-4	Audio Control Panel	Collins	Repair
522-3082-00	331A-3F	Course Indicator	Collins	Repair
522-3082-000	331A-3F	Course Indicator	Collins	Repair
522-3082-001	331A-3F	Course Indicator	Collins	Repair
522-3082-002	331A-3F	Course Indicator	Collins	Repair
522-3241-00	332E-4	Directional Gyro	Collins	Repair
522-3241-000	332E-4	Directional Gyro	Collins	Repair
522-3613-000	313N-4A	NAV Control	Collins	Repair
522-3613-001	313N-4A	NAV Control	Collins	Repair
522-3613-002	313N-4A	NAV Control	Collins	Repair
522-3614-000	313N-4B	NAV Control	Collins	Repair
522-3614-001	313N-4B	NAV Control	Collins	Repair
522-3614-003	313N-4B	NAV Control	Collins	Repair
522-3614-004	313N-4B	NAV Control	Collins	Repair
522-3614-200	313N-4B	NAV Control	Collins	Repair
522-3614-203	313N-4B	NAV Control	Collins	Repair
522-3614-205	313N-4B	NAV Control	Collins	Repair
522-3614-206	313N-4B	NAV Control	Collins	Repair
522-3614-300	313N-4BA	NAV Control	Collins	Repair
522-3614-500	313N-4B	NAV Control	Collins	Repair
522-3614-503	313N-4B	NAV Control	Collins	Repair
522-3614-506	313N-4B	NAV Control	Collins	Repair
522-3615-001	313N-4C	NAV Control	Collins	Repair
522-3615-002	313N-4C	NAV Control	Collins	Repair
522-3615-003	313N-4C	NAV Control	Collins	Repair
522-3615-005	313N-4C	NAV Control	Collins	Repair
522-3615-201	313N-4C	NAV Control	Collins	Repair
522-3615-202	313N-4C	NAV Control	Collins	Repair
522-3615-205	313N-4C	NAV Control	Collins	Repair
522-3616-000	313N-4D	NAV Control	Collins	Repair
522-3616-001	313N-4D	NAV Control	Collins	Repair
522-3616-200	313N-4D	NAV Control	Collins	Repair
522-3616-201	313N-4D	NAV Control	Collins	Repair
522-3616-202	313N-4D	NAV Control	Collins	Repair
522-3616-203	313N-4D	NAV Control	Collins	Repair
522-3616-204	313N-4D	NAV Control	Collins	Repair
522-3616-501	313N-4D	NAV Control	Collins	Repair
522-3616-502	313N-4D	NAV Control	Collins	Repair
522-3616-503	313N-4D	NAV Control	Collins	Repair
522-3616-504	313N-4D	NAV Control	Collins	Repair
522-3617-000	313N-5A	COMM Control	Collins	Repair
522-3617-001	313N-5A	COMM Control	Collins	Repair
522-3617-002	313N-5A	COMM Control	Collins	Repair
522-3617-003	313N-5A	COMM Control	Collins	Repair
522-3617-500	313N-5A	COMM Control	Collins	Repair
522-3617-503	313N-5A	COMM Control	Collins	Repair
522-3985-001	332D-11	Vertical Gyro	Collins	Repair
522-4945-001	323A-2G	Flux Detector	Collins	Test/Recert
5237 A.901	-	Altimeter (2", -1k-20k ft, in.Hg, LH Knob, Unlit)	United Instruments	Test/Recert
5237 A.902	-	Altimeter (2", -1k-20k ft, in.Hg, LH Knob, Lit)	United Instruments	Test/Recert
5237A A.905	-	Altimeter (2", -1k-35k ft, in.Hg, LH Knob, Unlit)	United Instruments	Test/Recert
5237A A.906	-	Altimeter (2", -1k-35k ft, in.Hg, LH Knob, Lit)	United Instruments	Test/Recert
5237AM A.907	-	Altimeter (2", -1k-35k ft, mbar, LH Knob, Unlit)	United Instruments	Test/Recert
5237AM A.908	-	Altimeter (2", -1k-35k ft, mbar, LH Knob, Lit)	United Instruments	Test/Recert
5237AMR A.918	-	Altimeter (2", -1k-35k ft, in.Hg, RH Knob, Lit)	United Instruments	Test/Recert
5237AR A.916	-	Altimeter (2", -1k-35k ft, in.Hg, RH Knob, Unlit)	United Instruments	Test/Recert

Part Number	Model	Description	Manufacturer	Capability
5237M A.903	-	Altimeter (2", -1k-20k ft, mbar, LH Knob, Unlit)	United Instruments	Test/Recert
5237M A.904	-	Altimeter (2", -1k-20k ft, mbar, LH Knob, Lit)	United Instruments	Test/Recert
5237MR A.914	-	Altimeter (2", -1k-20k ft, mbar, RH Knob, Lit)	United Instruments	Test/Recert
5237R A.912	-	Altimeter (2", -1k-20k ft, mbar, RH Knob, Unlit)	United Instruments	Test/Recert
525.731-921	AS3100-(12N)-11	Audio Panel	Becker	Repair
52C73	5000B-2	Attitude Gyro	Century Flight	Repair
52D136-0010	NSD-360	Navigational Situation Display	Century Flight	Repair
52D136-0020	NSD-360	Navigational Situation Display	Century Flight	Repair
52D136-0110	NSD-360	Navigational Situation Display	Century Flight	Repair
52D136-0120	NSD-360	Navigational Situation Display	Century Flight	Repair
52D136-0210	NSD-360	Navigational Situation Display	Century Flight	Repair
52D136-0220	NSD-360	Navigational Situation Display	Century Flight	Repair
52D136-1020	NSD-360	Navigational Situation Display	Century Flight	Repair
52D136-1120	NSD-360	Navigational Situation Display	Century Flight	Repair
52D136-1220	NSD-360	Navigational Situation Display	Century Flight	Repair
52D136-1333	NSD-360A	Navigational Situation Display	Century Flight	Repair
52D137-1020	NSD-360	Navigational Situation Display	Century Flight	Repair
52D137-1120	NSD-360	Navigational Situation Display	Century Flight	Repair
52D137-1220	NSD-360	Navigational Situation Display	Century Flight	Repair
52D137-1332	NSD-360A	Navigational Situation Display	Century Flight	Repair
52D137-1333	NSD-360A	Navigational Situation Display	Century Flight	Repair
52D137-2331	NSD-360A	Navigational Situation Display	Century Flight	Repair
52D137-2334	NSD-360A	Navigational Situation Display	Century Flight	Repair
52D154	4000C-2	Directional Gryo	Century Flight	Repair
52D154M	4000C-3	Directional Gyro, Lighted	Century Flight	Repair
52D189	NSD-1000	Navigational Situation Display	Century Flight	Repair
52D189-1	NSD-1000	Navigational Situation Display	Century Flight	Repair
52D254	4000C-5	Directional Gyro	Century Flight	Repair
52D254M	4000C-6	Directional Gyro, Lighted	Century Flight	Repair
52D54	4000C	Directional Gryo	Century Flight	Repair
52D54-2	4000C-4	Directional Gryo	Century Flight	Repair
52D54-2M	4000C-7	Directional Gyro, Lighted	Century Flight	Repair
52D54M	4000C-1	Directional Gyro, Lighted	Century Flight	Repair
547.972-915	ATC4401-1	ATC Transponder	Becker	Repair
547.980-915	ATC4401-1	ATC Transponder	Becker	Repair
557-4011-902	IVA557	RMI Indicator	Aerospatiale	Repair
557-4021-902	IVA557	RMI Indicator	Aerospatiale	Repair
557-4031-001	IVA557	RMI Indicator	Aerospatiale	Repair
557-4031-621	IVA557	RMI Indicator	Aerospatiale	Repair
557-4051-202	IVA557	RMI Indicator	Aerospatiale	Repair
557-4101-212	IVA557	RMI Indicator	Aerospatiale	Repair
557-4111-202	IVA557	RMI Indicator	Aerospatiale	Repair
557-4131-002	IVA557	RMI Indicator	Aerospatiale	Repair
557-4131-902	IVA557	RMI Indicator	Aerospatiale	Repair
557-4161-202	IVA557	RMI Indicator	Aerospatiale	Repair
557-4231-201	IVA557	RMI Indicator	Aerospatiale	Repair
559.563-921	IC3100-(2)-01	Intercom Amplifier	Becker	Repair
559.571-921	IC3100-(4)-01	Intercom Amplifier	Becker	Repair
563-193	114-380049-3	Dual Prop Amp Indicator	Hickok	Repair
563-267	114-380049-5	Dual Prop Amp Indicator	Hickok	Repair
563-305	114-380049-7	Dual Prop Amp Indicator	Hickok	Repair
5633-710-80-11	-	NG Indicator	Sextant	Repair
5633-711-80-10	-	NG Indicator	Sextant	Repair
5633-712-20-11	-	NG Indicator	Sextant	Repair
5637-560-00-10	704A47-632-065	T4 Indicator	Sextant	Repair
570-074-080-3	570-074-080-003	Transducer	Bell Helicopter	Test & Recert
570-074-150-3	570-074-150-003	Sensor Amplifier Assembly - SCAS	Bell Helicopter	Repair
570-074-150-5	570-074-150-005	Sensor Amplifier Assembly - SCAS	Bell Helicopter	Repair
570-074-251-1	570-074-251-001	Signal Amplifier Unit - Pitch	Bell Helicopter	Repair
570-074-252-1	570-074-252-001	S.A.U.- ROLL	Bell Helicopter	Repair
570-074-252-5	570-074-252-005	S.A.U.- YAW	Bell Helicopter	Repair
5707-3002	206-075-189-1	Fuel Quantity Indicator	INSCO	Repair
5707-3002	206-075-189-001	Fuel Quantity Indicator	INSCO	Repair
5707-3007	206-075-189-3	Fuel Quantity Indicator	INSCO	Repair
5707-3007	206-075-189-003	Fuel Quantity Indicator	INSCO	Repair
5707-3012	206-063-656-3	Fuel Quantity Indicator	INSCO	Repair

Part Number	Model	Description	Manufacturer	Capability
5707-3012	206-063-656-003	Fuel Quantity Indicator	INSCO	Repair
5707-3013	-	Fuel Quantity Indicator	INSCO	Repair
5707-3025	-	Fuel Quantity Indicator	INSCO	Repair
5707-3027	206-075-740-107	Fuel Quantity Indicator	INSCO	Repair
571-29020-012	29020-012	Pneumatic Altimeter (-1k-35k ft, in.Hg, Lighted)	IDC	Repair
571-29020-214	29020-214	Pneumatic Altimeter (-1k-20k ft, mbar, Lighted)	IDC	Repair
571-29020-412	29020-412	Pneumatic Altimeter (-1k-35k ft, in.Hg, Lighted)	IDC	Repair
574-074-100-5	574-074-100-005	Synchro Control Unit Assembly	Bell Helicopter	Repair
574-074-101-15	574-074-101-015	S.C.M. - PITCH	Bell Helicopter	Repair
574-074-101-17	574-074-101-017	Synchro Control Module - Roll	Bell Helicopter	Repair
574-074-101-19	574-074-101-019	Synchro Control Module - Yaw	Bell Helicopter	Repair
574-074-140-1	574-074-140-001	AFCS/SCAS Control Panel	Bell Helicopter	Repair
574-074-140-3	574-074-140-003	AFCS/SCAS Control Panel	Bell Helicopter	Repair
574-074-140-5	574-074-140-005	AFCS/SCAS Control Panel	Bell Helicopter	Repair
574-074-140-701	-	AFCS/SCAS Control Panel	Bell Helicopter	Repair
574-074-150-1	574-074-150-001	AFCS Trim Control Panel	Bell Helicopter	Repair
574-074-150-3	574-074-150-003	AFCS Trim Control Panel	Bell Helicopter	Repair
574-074-295-3	574-074-295-003	AFCS Control Panel	Bell Helicopter	Repair
5813-700-00-10	-	Tachometer (NTL-NR)	Sextant	Repair
5813-700-00-11	-	Tachometer (NTL-NR)	Sextant	Repair
5813-700-00-12	-	Tachometer (NTL-NR)	Sextant	Repair
5813-701-00-00	-	Tachometer (NTL-NR)	Sextant	Repair
58-380013-3	5000B-5	Attitude Gyro, Lighted	Beechcraft	Repair
58-380014-3	4000B-7	Directional Gyro, Lighted	Beechcraft	Repair
58-380094-9	1394T100 Z	Turn Coordinator, Lighted	Beechcraft	Repair
5932-0105	C661011-0105	Altimeter, Pressure	United Instruments	Repair
5932A	-	Altimeter, Pressure	United Instruments	Repair
5932A-0201	C661011-0201	Altimeter, Pressure	United Instruments	Repair
5932AP	-	Altimeter, Pressure	United Instruments	Repair
5932-BH01	-	Altimeter, Pressure	United Instruments	Repair
5932-BH5	-	Altimeter, Pressure	United Instruments	Repair
5932P	-	Altimeter, Pressure	United Instruments	Repair
5934 A.68	LA-71-11	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5934 A.91	206-070-263-7	Altimeter (-1k-20k ft, mbar, Lighted)	United Instruments	Repair
5934 A.91	206-070-263-007	Altimeter (-1k-20k ft, mbar, Lighted)	United Instruments	Repair
5934-1	-	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5934-1 A.66	58-380069-1	Altimeter (-1k-20k ft, in.Hg, Beechcraft)	United Instruments	Repair
5934-1 A.91	206-070-263-5	Altimeter (-1k-20k ft, in.Hg, 5V Lighting)	United Instruments	Repair
5934-1 A.91	206-070-263-005	Altimeter (-1k-20k ft, in.Hg, 5V Lighting)	United Instruments	Repair
5934-3	-	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5934-3 A.154	-	Altimeter (-1k-20k ft, in.Hg, Lighted)	United Instruments	Repair
5934-3 A.67	58-380069-3	Altimeter (-1k-20k ft, in.Hg, Lighted, Beechcraft)	United Instruments	Repair
5934-3 A.68	-	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5934-3D A.137	-	Altimeter (-1k-20k ft, in.Hg, Close Tolerance)	United Instruments	Repair
5934-3D A.227	-	Altimeter (-1k-20k ft, in.Hg, Lighted, C/T)	United Instruments	Repair
5934A	-	Altimeter (-1k-35k ft, in.Hg)	United Instruments	Repair
5934A A.69	C661014-0101	Altimeter (-1k-35k ft, in.Hg, Cessna)	United Instruments	Repair
5934A-1	-	Altimeter (-1k-35k ft, in.Hg)	United Instruments	Repair
5934A-1 A.106	58-380069-5	Altimeter (-1k-35k ft, in.Hg, Beechcraft)	United Instruments	Repair
5934A-1 A.107	58-380069-7	Altimeter (-1k-35k ft, in.Hg, Lighted, Beechcraft)	United Instruments	Repair
5934A-3	-	Altimeter (-1k-35k ft, in.Hg)	United Instruments	Repair
5934A-3 A.150	-	Altimeter (-1k-35k ft, in.Hg, Lighted)	United Instruments	Repair
5934A-3 A.61	-	Altimeter (-1k-35k ft, in.Hg)	United Instruments	Repair
5934A-3D A.138	-	Altimeter (-1k-35k ft, in.Hg, Close Tolerance)	United Instruments	Repair
5934A-3D A.231	-	Altimeter (-1k-35k ft, in.Hg, Lighted, C/T)	United Instruments	Repair
5934-A67	-	Altimeter (-1k-20k ft, in.Hg, Lighted)	United Instruments	Repair
5934-A74	-	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5934AD-1	-	Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
5934AD-3	-	Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
5934AD-3 A.131	-	Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
5934AD-3 A.254	-	Altimeter (-1k-35k ft, Dual Scale, Lighted)	United Instruments	Repair
5934AD-3D A.143	-	Altimeter (-1k-35k ft, Dual Scale, Close Tolerance)	United Instruments	Repair
5934AD-3D A.272	-	Altimeter (-1k-35k ft, Dual Scale, Lighted, C/T)	United Instruments	Repair
5934AM	-	Altimeter (-1k-35k ft, mbar)	United Instruments	Repair
5934AM-1	-	Altimeter (-1k-35k ft, mbar)	United Instruments	Repair
5934AM-3	-	Altimeter (-1k-35k ft, mbar)	United Instruments	Repair

Part Number	Model	Description	Manufacturer	Capability
5934AM-3 A.204	-	Altimeter (-1k-35k ft, mbar, Lighted)	United Instruments	Repair
5934AM-3 A.85	-	Altimeter (-1k-35k ft, mbar)	United Instruments	Repair
5934AM-3D A.140	-	Altimeter (-1k-35k ft, mbar, Close Tolerance)	United Instruments	Repair
5934AM-3D A.241	-	Altimeter (-1k-35k ft, mbar, Lighted, C/T)	United Instruments	Repair
5934D-1	-	Altimeter (-1k-20k ft, Dual Scale)	United Instruments	Repair
5934D-3	-	Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
5934D-3 A.129	-	Altimeter (-1k-20k ft, Dual Scale)	United Instruments	Repair
5934D-3 A.159	-	Altimeter (-1k-20k ft, Dual Scale, 5V Lighting)	United Instruments	Repair
5934D-3 A.246	-	Altimeter (-1k-20k ft, Dual Scale, Lighted)	United Instruments	Repair
5934D-3D A.141	-	Altimeter (-1k-20k ft, Dual Scale, Close Tolerance)	United Instruments	Repair
5934D-3D A.262	-	Altimeter (-1k-20k ft, Dual Scale, Lighted, C/T)	United Instruments	Repair
5934M	-	Altimeter (-1k-20k ft, mbar)	United Instruments	Repair
5934M-1	-	Altimeter (-1k-20k ft, mbar)	United Instruments	Repair
5934M-3	-	Altimeter (-1k-20k ft, mbar)	United Instruments	Repair
5934M-3 A.189	-	Altimeter (-1k-20k ft, mbar, Lighted)	United Instruments	Repair
5934M-3 A.73	-	Altimeter (-1k-20k ft, mbar)	United Instruments	Repair
5934M-3D A.139	-	Altimeter (-1k-20k ft, mbar, Close Tolerance)	United Instruments	Repair
5934M-3D A.236	-	Altimeter (-1k-20k ft, mbar, Lighted, C/T)	United Instruments	Repair
5934P	-	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5934P A.63	LA-72-11	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5934P-1	-	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5934P-1 A.163	-	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5934P-1 A.56	C661071-0101	Altimeter (-1k-20k ft, in.Hg, Cessna)	United Instruments	Repair
5934P-1 A.63	-	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5934P-1 A.83	-	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5934P-3	-	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5934P-3 A.163	-	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5934P-3 A.194	-	Altimeter (-1k-20k ft, in.Hg, Lighted)	United Instruments	Repair
5934P-3 A.197	-	Altimeter (-1k-20k ft, in.Hg, 14V Lighting)	United Instruments	Repair
5934P-3 A.441	-	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5934P-3 A.617	S3328-1	Altimeter (-1k-20k ft, in.Hg, 28V, Cessna)	United Instruments	Repair
5934P-3 A.83	-	Altimeter (-1k-20k ft, in.Hg)	United Instruments	Repair
5934PA	-	Altimeter (-1k-35k ft, in.Hg)	United Instruments	Repair
5934PA-1	-	Altimeter (-1k-35k ft, in.Hg)	United Instruments	Repair
5934PA-1 A.58	C661071-0201	Altimeter (-1k-35k ft, in.Hg, Cessna)	United Instruments	Repair
5934PA-1 A.69	C661014-0101	Altimeter (-1k-35k ft, in.Hg, Cessna)	United Instruments	Repair
5934PA-1 A.86	-	Altimeter (-1k-35k ft, in.Hg)	United Instruments	Repair
5934PA-3	-	Altimeter (-1k-35k ft, in.Hg)	United Instruments	Repair
5934PA-3 A.122	-	Altimeter (-1k-35k ft, in.Hg, Lighted)	United Instruments	Repair
5934PA-3 A.86	-	Altimeter (-1k-35k ft, in.Hg)	United Instruments	Repair
5934PA-3D A.127	-	Altimeter (-1k-35k ft, in.Hg, Close Tolerance)	United Instruments	Repair
5934PA-3D A.217	-	Altimeter (-1k-35k ft, in.Hg, Lighted, C/T)	United Instruments	Repair
5934PA-3L	-	Altimeter (-1k-35k ft, in.Hg, Lighted)	United Instruments	Repair
5934P-A56	C661071-0101	Altimeter (-1k-20k ft, in.Hg, Cessna)	United Instruments	Repair
5934PA-A58	C661071-0201	Altimeter (-1k-35k ft, in.Hg, Cessna)	United Instruments	Repair
5934PA-A76	-	Altimeter (-1k-35k ft, in.Hg)	United Instruments	Repair
5934PAD-1	-	Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
5934PAD-3	-	Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
5934PAD-3 A.132	-	Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
5934PAD-3 A.135	-	Altimeter (-1k-35k ft, Dual Scale)	United Instruments	Repair
5934PAD-3 A.259	-	Altimeter (-1k-35k ft, Dual Scale, Lighted)	United Instruments	Repair
5934PAD-3D A.144	-	Altimeter (-1k-35k ft, Dual Scale, Close Tolerance)	United Instruments	Repair
5934PAD-3D A.277	-	Altimeter (-1k-35k ft, Dual Scale, Lighted, C/T)	United Instruments	Repair
5934PAD-3D A.657	S3828-1	Altimeter (-1k-35k ft, Dual Scale, C/T, Cessna)	United Instruments	Repair
5934PAD-3L	-	Altimeter (-1k-35k ft, Dual Scale, Lighted)	United Instruments	Repair
5934PAM	-	Altimeter (-1k-35k ft, mbar)	United Instruments	Repair
5934PAM-1	-	Altimeter (-1k-35k ft, mbar)	United Instruments	Repair
5934PAM-3	-	Altimeter (-1k-35k ft, mbar)	United Instruments	Repair
5934PAM-3 A.124	-	Altimeter (-1k-35k ft, mbar, Lighted)	United Instruments	Repair
5934PAM-3 A.87	-	Altimeter (-1k-35k ft, mbar)	United Instruments	Repair
5934PAM-3D A.128	-	Altimeter (-1k-35k ft, mbar, Close Tolerance)	United Instruments	Repair
5934PAM-3D A.222	-	Altimeter (-1k-35k ft, mbar, Lighted, C/T)	United Instruments	Repair
5934PAM-3L	-	Altimeter (-1k-35k ft, mbar, Lighted)	United Instruments	Repair
5934PD-1	-	Altimeter (-1k-20k ft, Dual Scale)	United Instruments	Repair
5934PD-1 A.134	-	Altimeter (-1k-20k ft, Dual Scale)	United Instruments	Repair
5934PD-3	-	Altimeter (-1k-20k ft, Dual Scale)	United Instruments	Repair

Part Number	Model	Description	Manufacturer	Capability
5934PD-3 A.130	-	Altimeter (-1k-20k ft, Dual Scale)	United Instruments	Repair
5934PD-3 A.134	-	Altimeter (-1k-20k ft, Dual Scale)	United Instruments	Repair
5934PD-3 A.250	-	Altimeter (-1k-20k ft, Dual Scale, Lighted)	United Instruments	Repair
5934PD-3 A.251	-	Altimeter (-1k-20k ft, Dual Scale, 5V Lighting)	United Instruments	Repair
5934PD-3 A.253	-	Altimeter (-1k-20k ft, Dual Scale, 28V Lighting)	United Instruments	Repair
5934PD-3 A.624	-	Altimeter (-1k-25k ft, Dual Scale, Lighted)	United Instruments	Repair
5934PD-3 A.656	S3827-1	Altimeter (-1k-20k ft, Dual Scale, 28V Lighting, Cessna)	United Instruments	Repair
5934PD-3 A.669	-	Altimeter (-1k-25k ft, Dual Scale)	United Instruments	Repair
5934PD-3D A.142	-	Altimeter (-1k-20k ft, Dual Scale, Close Tolerance)	United Instruments	Repair
5934PD-3D A.267	-	Altimeter (-1k-20k ft, Dual Scale, Lighted, C/T)	United Instruments	Repair
5934PM	-	Altimeter (-1k-20k ft, mbar)	United Instruments	Repair
5934PM-1	-	Altimeter (-1k-20k ft, mbar)	United Instruments	Repair
5934PM-1 A.57	C661071-0102	Altimeter (-1k-20k ft, mbar, Cessna)	United Instruments	Repair
5934PM-1 A.84	-	Altimeter (-1k-20k ft, mbar)	United Instruments	Repair
5934PM-3	-	Altimeter (-1k-20k ft, mbar)	United Instruments	Repair
5934PM-3 A.199	-	Altimeter (-1k-20k ft, mbar, Lighted)	United Instruments	Repair
5934PM-3 A.84	-	Altimeter (-1k-20k ft, mbar)	United Instruments	Repair
600-009-900	TC100(12)	Turn Coordinator	Brittain Industries	Repair
600-009-930	TC100(12)	Turn Coordinator	Brittain Industries	Repair
601.349-921	AS3100-(12)-14	Audio Panel	Becker	Repair
601-009-950	TC100(24)	Turn Coordinator	Brittain Industries	Repair
601-009-980	TC100(24)	Turn Coordinator	Brittain Industries	Repair
601285-01	704.A.47.270.101	Quadruple Gauge Cluster	Jaeger	Repair
601285-02	-	Quadruple Gauge Cluster	Jaeger	Repair
60-1321-1	-	Power Supply, Emergency Exit Light	Grimes	Repair
60-1321-5	-	Power Supply, Emergency Exit Light	Grimes	Repair
60-1321-7	-	Power Supply, Emergency Exit Light	Grimes	Repair
60-3274-1	-	Power Supply, Strobe Light	Grimes	Repair
60-3274-3	-	Power Supply, Strobe Light	Grimes	Repair
60-3274-4	-	Power Supply, Strobe Light	Grimes	Repair
60-3274-5	-	Power Supply, Strobe Light	Grimes	Repair
607.797-921	IC3100-(9)-01	Intercom Amplifier	Becker	Repair
6080 H.38	C662037-0106	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6080-H38	C662037-0106	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6111 D.16	-	Manifold Pressure Indicator, Single	United Instruments	Repair
6111 D.17	-	Manifold Pressure Indicator, Single	United Instruments	Repair
6111 D.91	-	Manifold Pressure Indicator, Single	United Instruments	Repair
6111 D.96	-	Manifold Pressure Indicator, Single	United Instruments	Repair
6112 D.15	-	Manifold Pressure Indicator, Single	United Instruments	Repair
6121 E.57	-	Manifold Pressure Indicator, Dual	United Instruments	Repair
6121 E.58	-	Manifold Pressure Indicator, Dual	United Instruments	Repair
6121 E.94	-	Manifold Pressure Indicator, Dual	United Instruments	Repair
6121A	-	Manifold Pressure Indicator, Dual	United Instruments	Repair
6121A E.100	-	Manifold Pressure Indicator, Dual	United Instruments	Repair
6121A E.101	-	Manifold Pressure Indicator, Dual	United Instruments	Repair
6122 E.56	-	Manifold Pressure Indicator, Dual	United Instruments	Repair
61476-402-1	-	Tachometer Indicator	Sextant	Repair
61476-403-1	-	Tachometer Indicator	Sextant	Repair
618.608-921	IC3100-(10)-01	Intercom Amplifier	Becker	Repair
6211 F.12	-	Fuel Pressure Indicator, Single	United Instruments	Repair
6211 F.13	-	Fuel Pressure Indicator, Single	United Instruments	Repair
6211 F.16	-	Fuel Pressure Indicator, Single	United Instruments	Repair
6211 F.2	C662010-0101	Fuel Pressure Indicator, Single	United Instruments	Repair
6211 F.3	C662010-0102	Fuel Pressure Indicator, Single	United Instruments	Repair
6211 F.4	C662010-0103	Fuel Pressure Indicator, Single	United Instruments	Repair
6211 F.9	-	Fuel Pressure Indicator, Single	United Instruments	Repair
6212 F.7	-	Fuel Pressure Indicator, Single	United Instruments	Repair
6213 F.10	-	Fuel Pressure Indicator, Single	United Instruments	Repair
6213 F.11	-	Fuel Pressure Indicator, Single	United Instruments	Repair
6213 F.14	-	Fuel Pressure Indicator, Single	United Instruments	Repair
6213 F.15	-	Fuel Pressure Indicator, Single	United Instruments	Repair
622-0555-001	332C-10	Radio Magnetic Indicator	Collins	Repair
622-0555-002	332C-10	Radio Magnetic Indicator	Collins	Repair
622-0555-003	332C-10	Radio Magnetic Indicator	Collins	Repair
622-0555-004	332C-10	Radio Magnetic Indicator	Collins	Repair
622-0555-005	332C-10	Radio Magnetic Indicator	Collins	Repair

Part Number	Model	Description	Manufacturer	Capability
622-0555-006	332C-10	Radio Magnetic Indicator	Collins	Repair
622-0555-007	332C-10	Radio Magnetic Indicator	Collins	Repair
622-0555-008	332C-10	Radio Magnetic Indicator	Collins	Repair
622-0555-010	332C-10	Radio Magnetic Indicator	Collins	Repair
622-0555-011	332C-10	Radio Magnetic Indicator	Collins	Repair
622-0876-001	VIR-30A	NAV Receiver	Collins	Repair
622-0876-002	VIR-30A	NAV Receiver	Collins	Repair
622-0876-003	VIR-30A	NAV Receiver	Collins	Repair
622-0876-004	VIR-30A	NAV Receiver	Collins	Repair
622-0876-011	VIR-30A	NAV Receiver	Collins	Repair
622-0876-012	VIR-30A	NAV Receiver	Collins	Repair
622-0876-013	VIR-30A	NAV Receiver	Collins	Repair
622-0876-014	VIR-30A	NAV Receiver	Collins	Repair
622-0876-201	VIR-30A	NAV Receiver	Collins	Repair
622-0876-202	VIR-30A	NAV Receiver	Collins	Repair
622-0876-203	VIR-30A	NAV Receiver	Collins	Repair
622-0876-204	VIR-30A	NAV Receiver	Collins	Repair
622-0876-211	VIR-30A	NAV Receiver	Collins	Repair
622-0876-212	VIR-30A	NAV Receiver	Collins	Repair
622-0876-213	VIR-30A	NAV Receiver	Collins	Repair
622-0876-214	VIR-30A	NAV Receiver	Collins	Repair
622-0877-001	VIR-30M	NAV Receiver	Collins	Repair
622-0877-002	VIR-30M	NAV Receiver	Collins	Repair
622-0877-003	VIR-30M	NAV Receiver	Collins	Repair
622-0877-004	VIR-30M	NAV Receiver	Collins	Repair
622-0877-201	VIR-30M	NAV Receiver	Collins	Repair
622-0877-202	VIR-30M	NAV Receiver	Collins	Repair
622-0877-203	VIR-30M	NAV Receiver	Collins	Repair
622-0877-204	VIR-30M	NAV Receiver	Collins	Repair
6221 G.107	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.11	S-1513-2	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.110	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.112	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.14	C662020-0101	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.15	C662020-0102	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.16	C662020-0103	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.17	C662020-0104	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.18	C662020-0105	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.21	96-384069-1	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.26	C662040-0101	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.27	C662040-0102	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.28	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.29	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.30	C662020-0106	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.32	C662040-0103	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.37	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.38	C662020-0107	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.39	C662020-0108	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.41	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.43	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.44	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.45	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.54	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.55	C662020-0109	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.56	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.57	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.58	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.60	C662020-0110	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.65	C662020-0111	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.66	96-384069-3	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.67	96-380015-5	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.68	96-380015-7	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.69	C662020-0112	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.70	C662020-0113	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.71	C662020-0114	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.72	C662020-0115	Fuel Pressure Indicator, Dual	United Instruments	Repair

Part Number	Model	Description	Manufacturer	Capability
6221 G.73	C662040-0104	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.74	C662020-0116	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.75	C662040-0106	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.77	C662020-0118	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.78	C662020-0119	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.81	C662020-0201	Fuel Pressure Indicator, Dual	United Instruments	Repair
6221 G.85	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
622-1204-001	339H-4	Radio Altimeter Indicator	Collins	Repair
622-1204-002	339H-4	Radio Altimeter Indicator	Collins	Repair
622-1204-003	339H-4	Radio Altimeter Indicator	Collins	Repair
622-1204-004	339H-4	Radio Altimeter Indicator	Collins	Repair
622-1204-005	339H-4	Radio Altimeter Indicator	Collins	Repair
622-1204-006	339H-4	Radio Altimeter Indicator	Collins	Repair
622-1204-007	339H-4	Radio Altimeter Indicator	Collins	Repair
622-1204-008	339H-4	Radio Altimeter Indicator	Collins	Repair
622-1204-010	339H-4	Radio Altimeter Indicator	Collins	Repair
622-1205-001	339H-4A	Radio Altimeter Indicator	Collins	Repair
622-1205-002	339H-4A	Radio Altimeter Indicator	Collins	Repair
622-1205-003	339H-4A	Radio Altimeter Indicator	Collins	Repair
622-1205-004	339H-4A	Radio Altimeter Indicator	Collins	Repair
622-1205-005	339H-4A	Radio Altimeter Indicator	Collins	Repair
622-1205-006	339H-4A	Radio Altimeter Indicator	Collins	Repair
622-1233-001	DME-40	DME Transceiver	Collins	Repair
622-1233-003	DME-40	DME Transceiver	Collins	Repair
622-1234-002	339F-12	DME Indicator	Collins	Repair
622-1234-003	339F-12	DME Indicator	Collins	Repair
622-1234-004	339F-12	DME Indicator	Collins	Repair
622-1234-005	339F-12	DME Indicator	Collins	Repair
622-1234-007	339F-12	DME Indicator	Collins	Repair
622-1234-012	339F-12	DME Indicator	Collins	Repair
622-1234-013	339F-12	DME Indicator	Collins	Repair
622-1234-016	339F-12	DME Indicator	Collins	Repair
622-1234-017	339F-12	DME Indicator	Collins	Repair
622-1234-113	339F-12	DME Indicator	Collins	Repair
622-1234-207	339F-12	DME Indicator	Collins	Repair
622-1234-313	339F-12	DME Indicator	Collins	Repair
622-1270-001	TDR-90	Transponder	Collins	Repair
622-1334-001	VHF-20B	VHF Transceiver	Collins	Repair
622-1334-002	VHF-20B	VHF Transceiver	Collins	Repair
622-1879-001	VHF-20A	VHF Transceiver	Collins	Repair
622-1879-002	VHF-20A	VHF Transceiver	Collins	Repair
6222 G.10	C662007-0401N	Fuel Pressure Indicator, Dual	United Instruments	Repair
6222 G.13	CM2642-L4	Fuel Pressure Indicator, Dual	United Instruments	Repair
6222 G.19	C662007-0501	Fuel Pressure Indicator, Dual	United Instruments	Repair
6222 G.20	C662007-0502	Fuel Pressure Indicator, Dual	United Instruments	Repair
6222 G.23	C662007-0301	Fuel Pressure Indicator, Dual	United Instruments	Repair
6222 G.25	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6222 G.3	C662007-0402N	Fuel Pressure Indicator, Dual	United Instruments	Repair
6222 G.36	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6222 G.4	CM2642-L5N	Fuel Pressure Indicator, Dual	United Instruments	Repair
6222 G.40	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6222 G.59	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6222 G.87	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6222 G.9	CM2642-L6N	Fuel Pressure Indicator, Dual	United Instruments	Repair
622-2012-011	339F-12A	DME Indicator	Collins	Repair
622-2012-012	339F-12A	DME Indicator	Collins	Repair
622-2012-013	339F-12A	DME Indicator	Collins	Repair
622-2012-014	339F-12A	DME Indicator	Collins	Repair
622-2012-201	339F-12A	DME Indicator	Collins	Repair
622-2078-001	VHF-251	COMM Transceiver	Collins	Repair
622-2080-001	VIR-351	NAV Receiver	Collins	Repair
622-2080-011	VIR-351	NAV Receiver	Collins	Repair
622-2082-001	IND-350	NAV Indicator	Collins	Repair
622-2082-002	IND-350	NAV Indicator	Collins	Repair
622-2082-003	IND-350	NAV Indicator	Collins	Repair
622-2083-001	IND-351	NAV Indicator	Collins	Repair

Part Number	Model	Description	Manufacturer	Capability
622-2083-002	IND-351	NAV Indicator	Collins	Repair
622-2083-003	IND-351	NAV Indicator	Collins	Repair
622-2084-001	GLS-350	Glideslope Receiver	Collins	Repair
622-2085-001	MKR-350	Marker Receiver	Collins	Repair
622-2087-001	AMR-350	Audio/Marker Panel	Collins	Repair
622-2087-006	AMR-350	Audio/Marker Panel	Collins	Repair
622-2087-011	AMR-350	Audio/Marker Panel	Collins	Repair
622-2087-016	AMR-350	Audio/Marker Panel	Collins	Repair
622-2087-017	AMR-350	Audio/Marker Panel	Collins	Repair
622-2087-018	AMR-350	Audio/Marker Panel	Collins	Repair
622-2087-023	AMR-350	Audio/Marker Panel	Collins	Repair
622-2087-028	AMR-350	Audio/Marker Panel	Collins	Repair
622-2088-001	AUD-250	Audio Panel	Collins	Repair
622-2088-011	AUD-250	Audio Panel	Collins	Repair
622-2088-016	AUD-250	Audio Panel	Collins	Repair
622-2088-017	AUD-250	Audio Panel	Collins	Repair
622-2092-001	TDR-950	Transponder	Collins	Repair
622-2175-001	339F-12B	DME Indicator	Collins	Repair
622-2175-002	339F-12B	DME Indicator	Collins	Repair
622-2175-003	339F-12B	DME Indicator	Collins	Repair
622-2175-004	339F-12B	DME Indicator	Collins	Repair
622-2175-201	339F-12B	DME Indicator	Collins	Repair
622-2176-001	339F-12C	DME Indicator	Collins	Repair
622-2176-002	339F-12C	DME Indicator	Collins	Repair
622-2176-201	339F-12C	DME Indicator	Collins	Repair
622-2177-001	339F-12D	DME Indicator	Collins	Repair
622-2362-001	ADF-60A	ADF Receiver	Collins	Repair
622-2363-001	ANT-60A	ADF Antenna	Collins	Limited Repair
622-2363-002	ANT-60A	ADF Antenna	Collins	Limited Repair
622-2425-001	IND-351C	NAV Indicator	Collins	Repair
622-2425-002	IND-351C	NAV Indicator	Collins	Repair
622-2462-001	AMR-350H	Audio/Marker Panel	Collins	Repair
622-2462-011	AMR-350H	Audio/Marker Panel	Collins	Repair
622-2462-016	AMR-350H	Audio/Marker Panel	Collins	Repair
622-2462-017	AMR-350H	Audio/Marker Panel	Collins	Repair
622-2462-018	AMR-350H	Audio/Marker Panel	Collins	Repair
622-2463-001	AUD-250H	Audio Panel	Collins	Repair
622-2463-011	AUD-250H	Audio Panel	Collins	Repair
622-2463-016	AUD-250H	Audio Panel	Collins	Repair
622-2463-017	AUD-250H	Audio Panel	Collins	Repair
622-2494-001	ANT-212	Weather Radar Antenna	Collins	Repair
622-2494-002	ANT-212	Weather Radar Antenna	Collins	Repair
622-2495-001	ANT-210	Weather Radar Antenna	Collins	Repair
622-2495-002	ANT-210	Weather Radar Antenna	Collins	Repair
622-2501-001	ANT-312	Weather Radar Antenna	Collins	Repair
622-2502-001	ANT-310	Weather Radar Antenna	Collins	Repair
622-2504-001	ANT-318	Weather Radar Antenna	Collins	Repair
622-2506-001	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-002	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-003	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-004	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-005	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-006	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-007	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-008	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-009	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-010	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-011	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-012	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-013	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-014	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-015	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-101	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-102	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-103	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-104	RMI-36	Radio Magnetic Indicator	Collins	Repair

Part Number	Model	Description	Manufacturer	Capability
622-2506-105	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-106	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-107	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-108	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-109	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-110	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2506-111	RMI-36	Radio Magnetic Indicator	Collins	Repair
622-2855-001	ALT-55B	Rad Alt Transceiver	Collins	Repair
622-2855-002	ALT-55B	Rad Alt Transceiver	Collins	Repair
622-2855-011	ALT-55B	Rad Alt Transceiver	Collins	Repair
622-2855-012	ALT-55B	Rad Alt Transceiver	Collins	Repair
622-2873-001	ADF-60B	ADF Receiver	Collins	Repair
622-2882-001	TCR-200	HF Transceiver	Collins	Repair
622-2882-002	TCR-200	HF Transceiver	Collins	Repair
622-2883-001	PWR-200	Power Amplifier	Collins	Repair
622-2884-001	AAC-200	HF Antenna Coupler	Collins	Repair
622-2884-003	AAC-200	HF Antenna Coupler	Collins	Repair
622-2884-004	AAC-200	HF Antenna Coupler	Collins	Repair
622-2884-005	AAC-200	HF Antenna Coupler	Collins	Repair
622-2885-001	CTL-200	HF Control Unit	Collins	Repair
622-2885-002	CTL-200	HF Control Unit	Collins	Repair
622-2885-003	CTL-200	HF Control Unit	Collins	Repair
622-2885-004	CTL-200	HF Control Unit	Collins	Repair
622-2885-005	CTL-200	HF Control Unit	Collins	Repair
622-2885-006	CTL-200	HF Control Unit	Collins	Repair
622-2885-011	CTL-200	HF Control Unit	Collins	Repair
622-2885-012	CTL-200	HF Control Unit	Collins	Repair
622-2885-013	CTL-200	HF Control Unit	Collins	Repair
622-2885-014	CTL-200	HF Control Unit	Collins	Repair
622-2885-015	CTL-200	HF Control Unit	Collins	Repair
622-2885-016	CTL-200	HF Control Unit	Collins	Repair
622-2937-001	ALI-55	Rad Alt Indicator	Collins	Repair
622-2937-002	ALI-55	Rad Alt Indicator	Collins	Repair
622-2937-003	ALI-55	Rad Alt Indicator	Collins	Repair
622-2937-004	ALI-55	Rad Alt Indicator	Collins	Repair
622-2937-005	ALI-55	Rad Alt Indicator	Collins	Repair
622-2937-008	ALI-55	Rad Alt Indicator	Collins	Repair
622-2937-009	ALI-55	Rad Alt Indicator	Collins	Repair
622-2938-001	ALI-55A	Rad Alt Indicator	Collins	Repair
622-2938-002	ALI-55A	Rad Alt Indicator	Collins	Repair
622-2938-003	ALI-55A	Rad Alt Indicator	Collins	Repair
622-2938-004	ALI-55A	Rad Alt Indicator	Collins	Repair
6223 G.34	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6223 G.35	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6223 G.42	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6223 G.46	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6223 G.47	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6223 G.48	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6223 G.49	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
622-3001-001	339F-12E	DME Indicator	Collins	Repair
622-3004-001	TDR-950L	Transponder	Collins	Repair
622-3101-001	AUD-251H	Audio Panel	Collins	Repair
622-3101-006	AUD-251H	Audio Panel	Collins	Repair
622-3101-011	AUD-251H	Audio Panel	Collins	Repair
622-3101-016	AUD-251H	Audio Panel	Collins	Repair
622-3101-021	AUD-251H	Audio Panel	Collins	Repair
622-3102-001	MKL-351	Remote Marker Lights	Collins	Repair
622-3201-001	ALT-50A	Radio Altimeter Transceiver	Collins	Repair
622-3201-002	ALT-50A	Radio Altimeter Transceiver	Collins	Repair
622-3201-011	ALT-50A	Radio Altimeter Transceiver	Collins	Repair
622-3201-012	ALT-50A	Radio Altimeter Transceiver	Collins	Repair
622-3307-001	VHF-251S	COMM Transceiver	Collins	Repair
622-3363-001	VHF-251E	COMM Transceiver	Collins	Repair
622-3366-001	GLS-350E	Glideslope Receiver	Collins	Repair
622-3670-001	TCR-451	DME Transceiver	Collins	Repair
622-3671-001	IND-450	DME Indicator	Collins	Repair

Part Number	Model	Description	Manufacturer	Capability
622-3672-001	IND-451	DME Indicator	Collins	Repair
622-3702-001	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3702-002	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3702-003	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3702-004	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3702-005	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3702-006	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3702-007	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3702-008	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3702-009	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3702-010	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3702-011	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3702-012	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3702-013	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3702-014	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3702-015	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3702-016	BDI-36	Bearing Distance Indicator	Collins	Repair
622-3710-001	ANT-60B	ADF Antenna	Collins	Limited Repair
622-3881-001	IND-40C	DME Indicator	Collins	Repair
622-3881-002	IND-40C	DME Indicator	Collins	Repair
622-3915-001	IND-40	DME Indicator	Collins	Repair
622-3915-002	IND-40	DME Indicator	Collins	Repair
622-3916-001	IND-40A	DME Indicator	Collins	Repair
622-3916-002	IND-40A	DME Indicator	Collins	Repair
622-3917-001	IND-40B	DME Indicator	Collins	Repair
622-3917-002	IND-40B	DME Indicator	Collins	Repair
622-3918-001	IND-41	DME Indicator	Collins	Repair
622-3918-002	IND-41	DME Indicator	Collins	Repair
622-3919-001	IND-41A	DME Indicator	Collins	Repair
622-3919-002	IND-41A	DME Indicator	Collins	Repair
622-3920-001	IND-41B	DME Indicator	Collins	Repair
622-3920-002	IND-41B	DME Indicator	Collins	Repair
622-3921-001	IND-41C	DME Indicator	Collins	Repair
622-3921-002	IND-41C	DME Indicator	Collins	Repair
6224 G.109	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
6224 G.61	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
622-4020-001	ANT-212D	Weather Radar Antenna	Collins	Repair
622-4021-001	WXT-200A	Weather Radar Receiver-Transmitter	Collins	Repair
622-4022-001	WXT-250A	Weather Radar Receiver-Transmitter	Collins	Repair
622-4160-001	DRI-55	Rad Alt Indicator	Collins	Repair
622-4160-002	DRI-55	Rad Alt Indicator	Collins	Repair
622-4160-003	DRI-55	Rad Alt Indicator	Collins	Repair
622-4160-004	DRI-55	Rad Alt Indicator	Collins	Repair
622-4160-005	DRI-55	Rad Alt Indicator	Collins	Repair
622-4160-006	DRI-55	Rad Alt Indicator	Collins	Repair
622-4160-007	DRI-55	Rad Alt Indicator	Collins	Repair
622-4160-008	DRI-55	Rad Alt Indicator	Collins	Repair
622-4160-011	DRI-55	Rad Alt Indicator	Collins	Repair
622-4160-012	DRI-55	Rad Alt Indicator	Collins	Repair
622-4160-013	DRI-55	Rad Alt Indicator	Collins	Repair
622-4160-014	DRI-55	Rad Alt Indicator	Collins	Repair
622-4160-015	DRI-55	Rad Alt Indicator	Collins	Repair
622-4160-016	DRI-55	Rad Alt Indicator	Collins	Repair
622-4160-017	DRI-55	Rad Alt Indicator	Collins	Repair
622-4160-018	DRI-55	Rad Alt Indicator	Collins	Repair
622-4331-001	IND-300	Weather Radar Indicator	Collins	Repair
622-4331-002	IND-300	Weather Radar Indicator	Collins	Repair
622-4331-003	IND-300	Weather Radar Indicator	Collins	Repair
622-4424-001	332D-11V	Vertical Gyro	Collins	Repair
622-4471-001	CTL-201	HF Control Unit	Collins	Repair
622-4471-002	CTL-201	HF Control Unit	Collins	Repair
622-4471-003	CTL-201	HF Control Unit	Collins	Repair
622-4471-004	CTL-201	HF Control Unit	Collins	Repair
622-4471-005	CTL-201	HF Control Unit	Collins	Repair
622-4471-006	CTL-201	HF Control Unit	Collins	Repair
622-4471-007	CTL-201	HF Control Unit	Collins	Repair

Part Number	Model	Description	Manufacturer	Capability
622-4471-008	CTL-201	HF Control Unit	Collins	Repair
622-4471-009	CTL-201	HF Control Unit	Collins	Repair
622-4471-010	CTL-201	HF Control Unit	Collins	Repair
622-4471-011	CTL-201	HF Control Unit	Collins	Repair
622-4471-012	CTL-201	HF Control Unit	Collins	Repair
622-4471-013	CTL-201	HF Control Unit	Collins	Repair
622-4471-014	CTL-201	HF Control Unit	Collins	Repair
622-4471-015	CTL-201	HF Control Unit	Collins	Repair
622-4471-016	CTL-201	HF Control Unit	Collins	Repair
622-4471-017	CTL-201	HF Control Unit	Collins	Repair
622-4471-018	CTL-201	HF Control Unit	Collins	Repair
622-4471-019	CTL-201	HF Control Unit	Collins	Repair
622-4471-020	CTL-201	HF Control Unit	Collins	Repair
622-4477-001	IND-350A	NAV Indicator	Collins	Repair
622-4478-001	IND-351A	NAV Indicator	Collins	Repair
622-4479-001	IND-351D	NAV Indicator	Collins	Repair
622-4488-001	332D-11B	Vertical Gyro	Collins	Repair
622-4490-001	CTL-201A	HF Control Unit	Collins	Repair
622-4490-002	CTL-201A	HF Control Unit	Collins	Repair
622-4490-003	CTL-201A	HF Control Unit	Collins	Repair
622-4490-004	CTL-201A	HF Control Unit	Collins	Repair
622-4490-005	CTL-201A	HF Control Unit	Collins	Repair
622-4490-006	CTL-201A	HF Control Unit	Collins	Repair
622-4490-007	CTL-201A	HF Control Unit	Collins	Repair
622-4490-008	CTL-201A	HF Control Unit	Collins	Repair
622-4490-009	CTL-201A	HF Control Unit	Collins	Repair
622-4490-010	CTL-201A	HF Control Unit	Collins	Repair
622-4490-011	CTL-201A	HF Control Unit	Collins	Repair
622-4490-012	CTL-201A	HF Control Unit	Collins	Repair
622-4490-013	CTL-201A	HF Control Unit	Collins	Repair
622-4490-014	CTL-201A	HF Control Unit	Collins	Repair
622-4490-015	CTL-201A	HF Control Unit	Collins	Repair
622-4490-016	CTL-201A	HF Control Unit	Collins	Repair
622-4490-017	CTL-201A	HF Control Unit	Collins	Repair
622-4490-018	CTL-201A	HF Control Unit	Collins	Repair
622-4490-019	CTL-201A	HF Control Unit	Collins	Repair
622-4490-020	CTL-201A	HF Control Unit	Collins	Repair
622-4523-001	CTL-20	VHF COMM Control	Collins	Repair
622-4523-002	CTL-20	VHF COMM Control	Collins	Repair
622-4523-003	CTL-20	VHF COMM Control	Collins	Repair
622-4523-004	CTL-20	VHF COMM Control	Collins	Repair
622-4523-005	CTL-20	VHF COMM Control	Collins	Repair
622-4523-006	CTL-20	VHF COMM Control	Collins	Repair
622-4523-007	CTL-20	VHF COMM Control	Collins	Repair
622-4523-008	CTL-20	VHF COMM Control	Collins	Repair
622-4523-009	CTL-20	VHF COMM Control	Collins	Repair
622-4523-010	CTL-20	VHF COMM Control	Collins	Repair
622-4523-011	CTL-20	VHF COMM Control	Collins	Repair
622-4523-012	CTL-20	VHF COMM Control	Collins	Repair
622-4523-013	CTL-20	VHF COMM Control	Collins	Repair
622-4523-014	CTL-20	VHF COMM Control	Collins	Repair
622-4523-015	CTL-20	VHF COMM Control	Collins	Repair
622-4523-016	CTL-20	VHF COMM Control	Collins	Repair
622-4523-017	CTL-20	VHF COMM Control	Collins	Repair
622-4523-018	CTL-20	VHF COMM Control	Collins	Repair
622-4523-201	CTL-20	VHF COMM Control	Collins	Repair
622-4523-202	CTL-20	VHF COMM Control	Collins	Repair
622-4523-203	CTL-20	VHF COMM Control	Collins	Repair
622-4523-204	CTL-20	VHF COMM Control	Collins	Repair
622-4523-205	CTL-20	VHF COMM Control	Collins	Repair
622-4523-206	CTL-20	VHF COMM Control	Collins	Repair
622-4523-207	CTL-20	VHF COMM Control	Collins	Repair
622-4523-208	CTL-20	VHF COMM Control	Collins	Repair
622-4523-209	CTL-20	VHF COMM Control	Collins	Repair
622-4523-210	CTL-20	VHF COMM Control	Collins	Repair
622-4523-211	CTL-20	VHF COMM Control	Collins	Repair

Part Number	Model	Description	Manufacturer	Capability
622-4523-212	CTL-20	VHF COMM Control	Collins	Repair
622-4523-213	CTL-20	VHF COMM Control	Collins	Repair
622-4523-214	CTL-20	VHF COMM Control	Collins	Repair
622-4523-215	CTL-20	VHF COMM Control	Collins	Repair
622-4523-216	CTL-20	VHF COMM Control	Collins	Repair
622-4523-217	CTL-20	VHF COMM Control	Collins	Repair
622-4523-218	CTL-20	VHF COMM Control	Collins	Repair
622-4523-801	CTL-20	VHF COMM Control	Collins	Repair
622-4523-802	CTL-20	VHF COMM Control	Collins	Repair
622-4523-803	CTL-20	VHF COMM Control	Collins	Repair
622-4523-804	CTL-20	VHF COMM Control	Collins	Repair
622-4524-041	CTL-30	NAV Control	Collins	Repair
622-4524-042	CTL-30	NAV Control	Collins	Repair
622-4524-043	CTL-30	NAV Control	Collins	Repair
622-4524-044	CTL-30	NAV Control	Collins	Repair
622-4524-049	CTL-30	NAV Control	Collins	Repair
622-4524-050	CTL-30	NAV Control	Collins	Repair
622-4524-051	CTL-30	NAV Control	Collins	Repair
622-4524-052	CTL-30	NAV Control	Collins	Repair
622-4524-053	CTL-30	NAV Control	Collins	Repair
622-4524-054	CTL-30	NAV Control	Collins	Repair
622-4524-055	CTL-30	NAV Control	Collins	Repair
622-4524-056	CTL-30	NAV Control	Collins	Repair
622-4524-057	CTL-30	NAV Control	Collins	Repair
622-4524-058	CTL-30	NAV Control	Collins	Repair
622-4524-059	CTL-30	NAV Control	Collins	Repair
622-4524-060	CTL-30	NAV Control	Collins	Repair
622-4524-061	CTL-30	NAV Control	Collins	Repair
622-4524-062	CTL-30	NAV Control	Collins	Repair
622-4524-063	CTL-30	NAV Control	Collins	Repair
622-4524-064	CTL-30	NAV Control	Collins	Repair
622-4524-065	CTL-30	NAV Control	Collins	Repair
622-4524-066	CTL-30	NAV Control	Collins	Repair
622-4524-067	CTL-30	NAV Control	Collins	Repair
622-4524-068	CTL-30	NAV Control	Collins	Repair
622-4524-073	CTL-30	NAV Control	Collins	Repair
622-4524-074	CTL-30	NAV Control	Collins	Repair
622-4524-075	CTL-30	NAV Control	Collins	Repair
622-4524-076	CTL-30	NAV Control	Collins	Repair
622-4524-077	CTL-30	NAV Control	Collins	Repair
622-4524-078	CTL-30	NAV Control	Collins	Repair
622-4524-079	CTL-30	NAV Control	Collins	Repair
622-4524-080	CTL-30	NAV Control	Collins	Repair
622-4524-085	CTL-30	NAV Control	Collins	Repair
622-4524-086	CTL-30	NAV Control	Collins	Repair
622-4524-087	CTL-30	NAV Control	Collins	Repair
622-4524-088	CTL-30	NAV Control	Collins	Repair
622-4524-097	CTL-30	NAV Control	Collins	Repair
622-4524-098	CTL-30	NAV Control	Collins	Repair
622-4524-099	CTL-30	NAV Control	Collins	Repair
622-4524-100	CTL-30	NAV Control	Collins	Repair
622-4524-101	CTL-30	NAV Control	Collins	Repair
622-4524-102	CTL-30	NAV Control	Collins	Repair
622-4524-103	CTL-30	NAV Control	Collins	Repair
622-4524-104	CTL-30	NAV Control	Collins	Repair
622-4524-105	CTL-30	NAV Control	Collins	Repair
622-4524-106	CTL-30	NAV Control	Collins	Repair
622-4524-107	CTL-30	NAV Control	Collins	Repair
622-4524-108	CTL-30	NAV Control	Collins	Repair
622-4524-109	CTL-30	NAV Control	Collins	Repair
622-4524-110	CTL-30	NAV Control	Collins	Repair
622-4524-111	CTL-30	NAV Control	Collins	Repair
622-4524-112	CTL-30	NAV Control	Collins	Repair
622-4524-277	CTL-30	NAV Control	Collins	Repair
622-4524-278	CTL-30	NAV Control	Collins	Repair
622-4524-279	CTL-30	NAV Control	Collins	Repair

Part Number	Model	Description	Manufacturer	Capability
622-4524-811	CTL-30	NAV Control	Collins	Repair
622-4524-813	CTL-30	NAV Control	Collins	Repair
622-4524-814	CTL-30	NAV Control	Collins	Repair
622-4524-815	CTL-30	NAV Control	Collins	Repair
622-4524-816	CTL-30	NAV Control	Collins	Repair
622-4524-817	CTL-30	NAV Control	Collins	Repair
622-4524-819	CTL-30	NAV Control	Collins	Repair
622-4524-820	CTL-30	NAV Control	Collins	Repair
622-4524-822	CTL-30	NAV Control	Collins	Repair
622-4524-825	CTL-30	NAV Control	Collins	Repair
622-4524-826	CTL-30	NAV Control	Collins	Repair
622-4524-827	CTL-30	NAV Control	Collins	Repair
622-4524-828	CTL-30	NAV Control	Collins	Repair
622-4526-001	CTL-60	ADF Control	Collins	Repair
622-4526-002	CTL-60	ADF Control	Collins	Repair
622-4526-003	CTL-60	ADF Control	Collins	Repair
622-4526-004	CTL-60	ADF Control	Collins	Repair
622-4526-005	CTL-60	ADF Control	Collins	Repair
622-4526-006	CTL-60	ADF Control	Collins	Repair
622-4526-007	CTL-60	ADF Control	Collins	Repair
622-4526-008	CTL-60	ADF Control	Collins	Repair
622-4526-009	CTL-60	ADF Control	Collins	Repair
622-4526-010	CTL-60	ADF Control	Collins	Repair
622-4526-011	CTL-60	ADF Control	Collins	Repair
622-4526-012	CTL-60	ADF Control	Collins	Repair
622-4526-013	CTL-60	ADF Control	Collins	Repair
622-4526-014	CTL-60	ADF Control	Collins	Repair
622-4526-015	CTL-60	ADF Control	Collins	Repair
622-4526-016	CTL-60	ADF Control	Collins	Repair
622-4526-017	CTL-60	ADF Control	Collins	Repair
622-4526-018	CTL-60	ADF Control	Collins	Repair
622-4526-019	CTL-60	ADF Control	Collins	Repair
622-4526-020	CTL-60	ADF Control	Collins	Repair
622-4526-021	CTL-60	ADF Control	Collins	Repair
622-4526-022	CTL-60	ADF Control	Collins	Repair
622-4526-023	CTL-60	ADF Control	Collins	Repair
622-4526-024	CTL-60	ADF Control	Collins	Repair
622-4526-025	CTL-60	ADF Control	Collins	Repair
622-4526-026	CTL-60	ADF Control	Collins	Repair
622-4526-027	CTL-60	ADF Control	Collins	Repair
622-4526-028	CTL-60	ADF Control	Collins	Repair
622-4526-029	CTL-60	ADF Control	Collins	Repair
622-4526-030	CTL-60	ADF Control	Collins	Repair
622-4526-031	CTL-60	ADF Control	Collins	Repair
622-4526-032	CTL-60	ADF Control	Collins	Repair
622-4526-033	CTL-60	ADF Control	Collins	Repair
622-4526-034	CTL-60	ADF Control	Collins	Repair
622-4526-801	CTL-60	ADF Control	Collins	Repair
622-4526-802	CTL-60	ADF Control	Collins	Repair
622-4526-803	CTL-60	ADF Control	Collins	Repair
622-4526-804	CTL-60	ADF Control	Collins	Repair
622-4526-805	CTL-60	ADF Control	Collins	Repair
622-4526-806	CTL-60	ADF Control	Collins	Repair
622-4526-807	CTL-60	ADF Control	Collins	Repair
622-4526-808	CTL-60	ADF Control	Collins	Repair
622-4527-001	CTL-90	Transponder Control	Collins	Repair
622-4527-002	CTL-90	Transponder Control	Collins	Repair
622-4527-003	CTL-90	Transponder Control	Collins	Repair
622-4527-004	CTL-90	Transponder Control	Collins	Repair
622-4527-005	CTL-90	Transponder Control	Collins	Repair
622-4527-006	CTL-90	Transponder Control	Collins	Repair
622-4527-007	CTL-90	Transponder Control	Collins	Repair
622-4527-008	CTL-90	Transponder Control	Collins	Repair
622-4527-009	CTL-90	Transponder Control	Collins	Repair
622-4527-010	CTL-90	Transponder Control	Collins	Repair
622-4527-011	CTL-90	Transponder Control	Collins	Repair

Part Number	Model	Description	Manufacturer	Capability
622-4527-012	CTL-90	Transponder Control	Collins	Repair
622-4527-013	CTL-90	Transponder Control	Collins	Repair
622-4527-014	CTL-90	Transponder Control	Collins	Repair
622-4527-015	CTL-90	Transponder Control	Collins	Repair
622-4527-016	CTL-90	Transponder Control	Collins	Repair
622-4527-017	CTL-90	Transponder Control	Collins	Repair
622-4527-018	CTL-90	Transponder Control	Collins	Repair
622-4527-019	CTL-90	Transponder Control	Collins	Repair
622-4527-020	CTL-90	Transponder Control	Collins	Repair
622-4527-021	CTL-90	Transponder Control	Collins	Repair
622-4527-801	CTL-90	Transponder Control	Collins	Repair
622-4527-802	CTL-90	Transponder Control	Collins	Repair
622-4527-803	CTL-90	Transponder Control	Collins	Repair
622-4527-804	CTL-90	Transponder Control	Collins	Repair
622-4545-001	CTL-220	HF Control Unit	Collins	Repair
622-4545-002	CTL-220	HF Control Unit	Collins	Repair
622-4545-003	CTL-220	HF Control Unit	Collins	Repair
622-4545-004	CTL-220	HF Control Unit	Collins	Repair
622-4545-005	CTL-220	HF Control Unit	Collins	Repair
622-4545-006	CTL-220	HF Control Unit	Collins	Repair
622-4545-011	CTL-220	HF Control Unit	Collins	Repair
622-4545-012	CTL-220	HF Control Unit	Collins	Repair
622-4545-013	CTL-220	HF Control Unit	Collins	Repair
622-4545-014	CTL-220	HF Control Unit	Collins	Repair
622-4545-015	CTL-220	HF Control Unit	Collins	Repair
622-4545-016	CTL-220	HF Control Unit	Collins	Repair
622-4545-021	CTL-220	HF Control Unit	Collins	Repair
622-4545-022	CTL-220	HF Control Unit	Collins	Repair
622-4545-023	CTL-220	HF Control Unit	Collins	Repair
622-4545-024	CTL-220	HF Control Unit	Collins	Repair
622-4545-025	CTL-220	HF Control Unit	Collins	Repair
622-4545-026	CTL-220	HF Control Unit	Collins	Repair
622-4545-031	CTL-220	HF Control Unit	Collins	Repair
622-4545-032	CTL-220	HF Control Unit	Collins	Repair
622-4545-033	CTL-220	HF Control Unit	Collins	Repair
622-4545-034	CTL-220	HF Control Unit	Collins	Repair
622-4545-035	CTL-220	HF Control Unit	Collins	Repair
622-4545-036	CTL-220	HF Control Unit	Collins	Repair
622-4565-001	332D-11T	Vertical Gyro	Collins	Repair
622-4565-002	332D-11T	Vertical Gyro	Collins	Repair
6225 G.62	-	Fuel Pressure Indicator, Dual	United Instruments	Repair
622-5337-001	TCR-220	HF Transceiver	Collins	Repair
622-5337-002	TCR-220	HF Transceiver	Collins	Repair
622-5367-001	ALI-55B	Rad Alt Indicator	Collins	Repair
622-5588-001	IND-450C	DME Indicator	Collins	Repair
622-5940-001	IND-220	Weather Radar Indicator	Collins	Repair
622-5940-008	IND-220	Weather Radar Indicator	Collins	Repair
622-5941-001	IND-270	Weather Radar Indicator	Collins	Repair
622-5941-002	IND-270	Weather Radar Indicator	Collins	Repair
622-6135-001	CCU-65	Compensator Unit	Collins	Repair
622-6135-002	CCU-65	Compensator Unit	Collins	Repair
622-6135-003	CCU-65	Compensator Unit	Collins	Repair
622-6135-004	CCU-65	Compensator Unit	Collins	Repair
622-6135-005	CCU-65	Compensator Unit	Collins	Repair
622-6135-011	CCU-65	Compensator Unit	Collins	Repair
622-6135-012	CCU-65	Compensator Unit	Collins	Repair
622-6135-013	CCU-65	Compensator Unit	Collins	Repair
622-6135-014	CCU-65	Compensator Unit	Collins	Repair
622-6135-015	CCU-65	Compensator Unit	Collins	Repair
622-6136-001	DGS-65	Directional Gyro	Collins	Repair
622-6136-002	DGS-65	Directional Gyro	Collins	Repair
622-6137-001	VIR-32	Navigation Receiver	Collins	Repair
622-6137-201	VIR-32	Navigation Receiver	Collins	Repair
622-6152-001	VHF-22A	VHF Comm Transceiver	Collins	Repair
622-6152-002	VHF-22A	VHF Comm Transceiver	Collins	Repair
622-6152-011	VHF-22A	VHF Comm Transceiver	Collins	Repair

Part Number	Model	Description	Manufacturer	Capability
622-6152-012	VHF-22A	VHF Comm Transceiver	Collins	Repair
622-6152-021	VHF-22A	VHF Comm Transceiver	Collins	Repair
622-6152-022	VHF-22A	VHF Comm Transceiver	Collins	Repair
622-6152-023	VHF-22A	VHF Comm Transceiver	Collins	Repair
622-6152-031	VHF-22A	VHF Comm Transceiver	Collins	Repair
622-6152-032	VHF-22A	VHF Comm Transceiver	Collins	Repair
622-6152-033	VHF-22A	VHF Comm Transceiver	Collins	Repair
622-6153-001	VHF-22B	VHF Comm Transceiver	Collins	Repair
622-6153-002	VHF-22B	VHF Comm Transceiver	Collins	Repair
622-6153-021	VHF-22B	VHF Comm Transceiver	Collins	Repair
622-6153-022	VHF-22B	VHF Comm Transceiver	Collins	Repair
622-6153-023	VHF-22B	VHF Comm Transceiver	Collins	Repair
622-6174-001	RCP-65	Remote Compensator Unit	Collins	Repair
622-6263-001	DME-42	DME Transceiver	Collins	Repair
622-6263-002	DME-42	DME Transceiver	Collins	Repair
622-6263-003	DME-42	DME Transceiver	Collins	Repair
622-6334-001	CTL-30R	NAV Control	Collins	Repair
622-6334-002	CTL-30R	NAV Control	Collins	Repair
622-6334-003	CTL-30R	NAV Control	Collins	Repair
622-6334-004	CTL-30R	NAV Control	Collins	Repair
622-6334-801	CTL-30R	NAV Control	Collins	Repair
622-6334-802	CTL-30R	NAV Control	Collins	Repair
622-6389-001	VHF-21A	VHF Comm Transceiver	Collins	Repair
622-6389-002	VHF-21A	VHF Comm Transceiver	Collins	Repair
622-6389-011	VHF-21A	VHF Comm Transceiver	Collins	Repair
622-6389-012	VHF-21A	VHF Comm Transceiver	Collins	Repair
622-6390-001	VHF-21B	VHF Comm Transceiver	Collins	Repair
622-6390-002	VHF-21B	VHF Comm Transceiver	Collins	Repair
622-6470-001	AAC-200P	HF Antenna Coupler	Collins	Repair
622-6470-002	AAC-200P	HF Antenna Coupler	Collins	Repair
622-6471-001	AAC-220P	HF Antenna Coupler	Collins	Repair
622-6471-002	AAC-220P	HF Antenna Coupler	Collins	Repair
622-6513-001	ANT-312A	Weather Radar Antenna	Collins	Repair
622-6520-001	CTL-22	VHF COMM Control	Collins	Repair
622-6520-002	CTL-22	VHF COMM Control	Collins	Repair
622-6520-003	CTL-22	VHF COMM Control	Collins	Repair
622-6520-004	CTL-22	VHF COMM Control	Collins	Repair
622-6520-005	CTL-22	VHF COMM Control	Collins	Repair
622-6520-006	CTL-22	VHF COMM Control	Collins	Repair
622-6520-007	CTL-22	VHF COMM Control	Collins	Repair
622-6520-008	CTL-22	VHF COMM Control	Collins	Repair
622-6520-009	CTL-22	VHF COMM Control	Collins	Repair
622-6520-010	CTL-22	VHF COMM Control	Collins	Repair
622-6520-011	CTL-22	VHF COMM Control	Collins	Repair
622-6520-012	CTL-22	VHF COMM Control	Collins	Repair
622-6520-013	CTL-22	VHF COMM Control	Collins	Repair
622-6520-014	CTL-22	VHF COMM Control	Collins	Repair
622-6520-015	CTL-22	VHF COMM Control	Collins	Repair
622-6520-016	CTL-22	VHF COMM Control	Collins	Repair
622-6520-801	CTL-22	VHF COMM Control	Collins	Repair
622-6520-802	CTL-22	VHF COMM Control	Collins	Repair
622-6521-001	CTL-32	NAV Control	Collins	Repair
622-6521-002	CTL-32	NAV Control	Collins	Repair
622-6521-003	CTL-32	NAV Control	Collins	Repair
622-6521-004	CTL-32	NAV Control	Collins	Repair
622-6521-005	CTL-32	NAV Control	Collins	Repair
622-6521-006	CTL-32	NAV Control	Collins	Repair
622-6521-007	CTL-32	NAV Control	Collins	Repair
622-6521-008	CTL-32	NAV Control	Collins	Repair
622-6521-009	CTL-32	NAV Control	Collins	Repair
622-6521-010	CTL-32	NAV Control	Collins	Repair
622-6521-011	CTL-32	NAV Control	Collins	Repair
622-6521-012	CTL-32	NAV Control	Collins	Repair
622-6521-013	CTL-32	NAV Control	Collins	Repair
622-6521-014	CTL-32	NAV Control	Collins	Repair
622-6521-015	CTL-32	NAV Control	Collins	Repair

Part Number	Model	Description	Manufacturer	Capability
622-6521-016	CTL-32	NAV Control	Collins	Repair
622-6521-025	CTL-32	NAV Control	Collins	Repair
622-6521-026	CTL-32	NAV Control	Collins	Repair
622-6521-027	CTL-32	NAV Control	Collins	Repair
622-6521-028	CTL-32	NAV Control	Collins	Repair
622-6521-029	CTL-32	NAV Control	Collins	Repair
622-6521-030	CTL-32	NAV Control	Collins	Repair
622-6521-031	CTL-32	NAV Control	Collins	Repair
622-6521-032	CTL-32	NAV Control	Collins	Repair
622-6521-801	CTL-32	NAV Control	Collins	Repair
622-6521-802	CTL-32	NAV Control	Collins	Repair
622-6521-803	CTL-32	NAV Control	Collins	Repair
622-6521-804	CTL-32	NAV Control	Collins	Repair
622-6522-001	CTL-62	ADF Control	Collins	Repair
622-6522-002	CTL-62	ADF Control	Collins	Repair
622-6522-003	CTL-62	ADF Control	Collins	Repair
622-6522-004	CTL-62	ADF Control	Collins	Repair
622-6522-005	CTL-62	ADF Control	Collins	Repair
622-6522-006	CTL-62	ADF Control	Collins	Repair
622-6522-007	CTL-62	ADF Control	Collins	Repair
622-6522-008	CTL-62	ADF Control	Collins	Repair
622-6522-009	CTL-62	ADF Control	Collins	Repair
622-6522-010	CTL-62	ADF Control	Collins	Repair
622-6522-011	CTL-62	ADF Control	Collins	Repair
622-6522-012	CTL-62	ADF Control	Collins	Repair
622-6522-013	CTL-62	ADF Control	Collins	Repair
622-6522-014	CTL-62	ADF Control	Collins	Repair
622-6522-015	CTL-62	ADF Control	Collins	Repair
622-6522-016	CTL-62	ADF Control	Collins	Repair
622-6522-017	CTL-62	ADF Control	Collins	Repair
622-6522-018	CTL-62	ADF Control	Collins	Repair
622-6522-019	CTL-62	ADF Control	Collins	Repair
622-6522-020	CTL-62	ADF Control	Collins	Repair
622-6522-021	CTL-62	ADF Control	Collins	Repair
622-6522-022	CTL-62	ADF Control	Collins	Repair
622-6522-023	CTL-62	ADF Control	Collins	Repair
622-6522-024	CTL-62	ADF Control	Collins	Repair
622-6522-025	CTL-62	ADF Control	Collins	Repair
622-6522-026	CTL-62	ADF Control	Collins	Repair
622-6522-027	CTL-62	ADF Control	Collins	Repair
622-6522-028	CTL-62	ADF Control	Collins	Repair
622-6522-029	CTL-62	ADF Control	Collins	Repair
622-6522-030	CTL-62	ADF Control	Collins	Repair
622-6522-031	CTL-62	ADF Control	Collins	Repair
622-6522-032	CTL-62	ADF Control	Collins	Repair
622-6522-801	CTL-62	ADF Control	Collins	Repair
622-6522-802	CTL-62	ADF Control	Collins	Repair
622-6522-803	CTL-62	ADF Control	Collins	Repair
622-6522-804	CTL-62	ADF Control	Collins	Repair
622-6523-001	CTL-92	Transponder Control	Collins	Repair
622-6523-002	CTL-92	Transponder Control	Collins	Repair
622-6523-003	CTL-92	Transponder Control	Collins	Repair
622-6523-004	CTL-92	Transponder Control	Collins	Repair
622-6523-005	CTL-92	Transponder Control	Collins	Repair
622-6523-006	CTL-92	Transponder Control	Collins	Repair
622-6523-007	CTL-92	Transponder Control	Collins	Repair
622-6523-008	CTL-92	Transponder Control	Collins	Repair
622-6523-009	CTL-92	Transponder Control	Collins	Repair
622-6523-010	CTL-92	Transponder Control	Collins	Repair
622-6523-011	CTL-92	Transponder Control	Collins	Repair
622-6523-012	CTL-92	Transponder Control	Collins	Repair
622-6523-013	CTL-92	Transponder Control	Collins	Repair
622-6523-014	CTL-92	Transponder Control	Collins	Repair
622-6523-015	CTL-92	Transponder Control	Collins	Repair
622-6523-016	CTL-92	Transponder Control	Collins	Repair
622-6523-201	CTL-92	Transponder Control	Collins	Repair

Part Number	Model	Description	Manufacturer	Capability
622-6523-202	CTL-92	Transponder Control	Collins	Repair
622-6523-203	CTL-92	Transponder Control	Collins	Repair
622-6523-204	CTL-92	Transponder Control	Collins	Repair
622-6523-205	CTL-92	Transponder Control	Collins	Repair
622-6523-206	CTL-92	Transponder Control	Collins	Repair
622-6523-207	CTL-92	Transponder Control	Collins	Repair
622-6523-208	CTL-92	Transponder Control	Collins	Repair
622-6523-209	CTL-92	Transponder Control	Collins	Repair
622-6523-210	CTL-92	Transponder Control	Collins	Repair
622-6523-211	CTL-92	Transponder Control	Collins	Repair
622-6523-212	CTL-92	Transponder Control	Collins	Repair
622-6523-213	CTL-92	Transponder Control	Collins	Repair
622-6523-214	CTL-92	Transponder Control	Collins	Repair
622-6523-215	CTL-92	Transponder Control	Collins	Repair
622-6523-216	CTL-92	Transponder Control	Collins	Repair
622-6523-305	CTL-92	Transponder Control	Collins	Repair
622-6523-306	CTL-92	Transponder Control	Collins	Repair
622-6523-307	CTL-92	Transponder Control	Collins	Repair
622-6523-308	CTL-92	Transponder Control	Collins	Repair
622-6523-313	CTL-92	Transponder Control	Collins	Repair
622-6523-314	CTL-92	Transponder Control	Collins	Repair
622-6523-315	CTL-92	Transponder Control	Collins	Repair
622-6523-316	CTL-92	Transponder Control	Collins	Repair
622-6523-801	CTL-92	Transponder Control	Collins	Repair
622-6523-802	CTL-92	Transponder Control	Collins	Repair
622-6524-001	IND-42A	DME Indicator	Collins	Repair
622-6524-002	IND-42A	DME Indicator	Collins	Repair
622-6524-003	IND-42A	DME Indicator	Collins	Repair
622-6524-004	IND-42A	DME Indicator	Collins	Repair
622-6557-001	TCR-230	HF Transceiver	Collins	Repair
622-6557-002	TCR-230	HF Transceiver	Collins	Repair
622-6557-003	TCR-230	HF Transceiver	Collins	Repair
622-6557-011	TCR-230	HF Transceiver	Collins	Repair
622-6557-012	TCR-230	HF Transceiver	Collins	Repair
622-6557-013	TCR-230	HF Transceiver	Collins	Repair
622-6590-001	CAD-62	Control Adapter	Collins	Repair
622-6590-002	CAD-62	Control Adapter	Collins	Repair
622-6614-001	CTL-230	HF Control	Collins	Repair
622-6614-002	CTL-230	HF Control	Collins	Repair
622-6614-003	CTL-230	HF Control	Collins	Repair
622-6614-004	CTL-230	HF Control	Collins	Repair
622-6614-005	CTL-230	HF Control	Collins	Repair
622-6614-006	CTL-230	HF Control	Collins	Repair
622-6614-007	CTL-230	HF Control	Collins	Repair
622-6614-008	CTL-230	HF Control	Collins	Repair
622-6614-021	CTL-230	HF Control	Collins	Repair
622-6614-022	CTL-230	HF Control	Collins	Repair
622-6614-023	CTL-230	HF Control	Collins	Repair
622-6614-024	CTL-230	HF Control	Collins	Repair
622-6614-025	CTL-230	HF Control	Collins	Repair
622-6614-026	CTL-230	HF Control	Collins	Repair
622-6614-027	CTL-230	HF Control	Collins	Repair
622-6614-028	CTL-230	HF Control	Collins	Repair
622-6633-001	ANT-318A	Weather Radar Antenna	Collins	Repair
622-6667-001	PWR-230	HF Power Amplifier	Collins	Repair
622-6668-001	AAC-220	HF Antenna Coupler	Collins	Repair
622-6668-002	AAC-220	HF Antenna Coupler	Collins	Repair
622-7318-001	IND-42C	DME Indicator	Collins	Repair
622-7318-002	IND-42C	DME Indicator	Collins	Repair
622-7318-003	IND-42C	DME Indicator	Collins	Repair
622-7318-004	IND-42C	DME Indicator	Collins	Repair
622-7382-001	ADF-462	ADF Receiver	Collins	Repair
622-7382-101	ADF-462	ADF Receiver	Collins	Repair
622-7382-111	ADF-462	ADF Receiver	Collins	Repair
622-7444-001	ANT-310A	Weather Radar Antenna	Collins	Repair
622-7667-001	DDA-42	Distance Data Adapter	Collins	Repair

Part Number	Model	Description	Manufacturer	Capability
622-8332-001	CAD-31	Control Adapter	Collins	Repair
622-8332-002	CAD-31	Control Adapter	Collins	Repair
622-8737-001	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-002	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-003	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-004	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-005	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-006	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-007	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-008	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-009	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-010	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-011	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-012	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-013	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-014	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-015	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-016	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-801	CTL-22A	VHF COMM Control	Collins	Repair
622-8737-802	CTL-22A	VHF COMM Control	Collins	Repair
622-8738-001	CTL-32A	NAV Control	Collins	Repair
622-8738-002	CTL-32A	NAV Control	Collins	Repair
622-8738-003	CTL-32A	NAV Control	Collins	Repair
622-8738-004	CTL-32A	NAV Control	Collins	Repair
622-8738-005	CTL-32A	NAV Control	Collins	Repair
622-8738-006	CTL-32A	NAV Control	Collins	Repair
622-8738-007	CTL-32A	NAV Control	Collins	Repair
622-8738-008	CTL-32A	NAV Control	Collins	Repair
622-8738-009	CTL-32A	NAV Control	Collins	Repair
622-8738-010	CTL-32A	NAV Control	Collins	Repair
622-8738-011	CTL-32A	NAV Control	Collins	Repair
622-8738-012	CTL-32A	NAV Control	Collins	Repair
622-8738-013	CTL-32A	NAV Control	Collins	Repair
622-8738-014	CTL-32A	NAV Control	Collins	Repair
622-8738-015	CTL-32A	NAV Control	Collins	Repair
622-8738-016	CTL-32A	NAV Control	Collins	Repair
622-8738-025	CTL-32A	NAV Control	Collins	Repair
622-8738-026	CTL-32A	NAV Control	Collins	Repair
622-8738-027	CTL-32A	NAV Control	Collins	Repair
622-8738-028	CTL-32A	NAV Control	Collins	Repair
622-8738-029	CTL-32A	NAV Control	Collins	Repair
622-8738-030	CTL-32A	NAV Control	Collins	Repair
622-8738-031	CTL-32A	NAV Control	Collins	Repair
622-8738-032	CTL-32A	NAV Control	Collins	Repair
622-8738-801	CTL-32A	NAV Control	Collins	Repair
622-8738-802	CTL-32A	NAV Control	Collins	Repair
622-8738-803	CTL-32A	NAV Control	Collins	Repair
622-8738-804	CTL-32A	NAV Control	Collins	Repair
622-8739-001	CTL-62A	ADF Control	Collins	Repair
622-8739-002	CTL-62A	ADF Control	Collins	Repair
622-8739-003	CTL-62A	ADF Control	Collins	Repair
622-8739-004	CTL-62A	ADF Control	Collins	Repair
622-8739-005	CTL-62A	ADF Control	Collins	Repair
622-8739-006	CTL-62A	ADF Control	Collins	Repair
622-8739-007	CTL-62A	ADF Control	Collins	Repair
622-8739-008	CTL-62A	ADF Control	Collins	Repair
622-8739-009	CTL-62A	ADF Control	Collins	Repair
622-8739-010	CTL-62A	ADF Control	Collins	Repair
622-8739-011	CTL-62A	ADF Control	Collins	Repair
622-8739-012	CTL-62A	ADF Control	Collins	Repair
622-8739-013	CTL-62A	ADF Control	Collins	Repair
622-8739-014	CTL-62A	ADF Control	Collins	Repair
622-8739-015	CTL-62A	ADF Control	Collins	Repair
622-8739-016	CTL-62A	ADF Control	Collins	Repair
622-8739-017	CTL-62A	ADF Control	Collins	Repair
622-8739-018	CTL-62A	ADF Control	Collins	Repair

Part Number	Model	Description	Manufacturer	Capability
622-8739-019	CTL-62A	ADF Control	Collins	Repair
622-8739-020	CTL-62A	ADF Control	Collins	Repair
622-8739-021	CTL-62A	ADF Control	Collins	Repair
622-8739-022	CTL-62A	ADF Control	Collins	Repair
622-8739-023	CTL-62A	ADF Control	Collins	Repair
622-8739-024	CTL-62A	ADF Control	Collins	Repair
622-8739-025	CTL-62A	ADF Control	Collins	Repair
622-8739-026	CTL-62A	ADF Control	Collins	Repair
622-8739-027	CTL-62A	ADF Control	Collins	Repair
622-8739-028	CTL-62A	ADF Control	Collins	Repair
622-8739-029	CTL-62A	ADF Control	Collins	Repair
622-8739-030	CTL-62A	ADF Control	Collins	Repair
622-8739-031	CTL-62A	ADF Control	Collins	Repair
622-8739-032	CTL-62A	ADF Control	Collins	Repair
622-8739-801	CTL-62A	ADF Control	Collins	Repair
622-8739-802	CTL-62A	ADF Control	Collins	Repair
622-8739-803	CTL-62A	ADF Control	Collins	Repair
622-8739-804	CTL-62A	ADF Control	Collins	Repair
622-8740-001	CTL-92A	Transponder Control	Collins	Repair
622-8740-002	CTL-92A	Transponder Control	Collins	Repair
622-8740-003	CTL-92A	Transponder Control	Collins	Repair
622-8740-004	CTL-92A	Transponder Control	Collins	Repair
622-8740-005	CTL-92A	Transponder Control	Collins	Repair
622-8740-006	CTL-92A	Transponder Control	Collins	Repair
622-8740-007	CTL-92A	Transponder Control	Collins	Repair
622-8740-008	CTL-92A	Transponder Control	Collins	Repair
622-8740-009	CTL-92A	Transponder Control	Collins	Repair
622-8740-010	CTL-92A	Transponder Control	Collins	Repair
622-8740-011	CTL-92A	Transponder Control	Collins	Repair
622-8740-012	CTL-92A	Transponder Control	Collins	Repair
622-8740-013	CTL-92A	Transponder Control	Collins	Repair
622-8740-014	CTL-92A	Transponder Control	Collins	Repair
622-8740-015	CTL-92A	Transponder Control	Collins	Repair
622-8740-016	CTL-92A	Transponder Control	Collins	Repair
622-8740-201	CTL-92A	Transponder Control	Collins	Repair
622-8740-202	CTL-92A	Transponder Control	Collins	Repair
622-8740-203	CTL-92A	Transponder Control	Collins	Repair
622-8740-204	CTL-92A	Transponder Control	Collins	Repair
622-8740-205	CTL-92A	Transponder Control	Collins	Repair
622-8740-206	CTL-92A	Transponder Control	Collins	Repair
622-8740-207	CTL-92A	Transponder Control	Collins	Repair
622-8740-208	CTL-92A	Transponder Control	Collins	Repair
622-8740-209	CTL-92A	Transponder Control	Collins	Repair
622-8740-210	CTL-92A	Transponder Control	Collins	Repair
622-8740-211	CTL-92A	Transponder Control	Collins	Repair
622-8740-212	CTL-92A	Transponder Control	Collins	Repair
622-8740-213	CTL-92A	Transponder Control	Collins	Repair
622-8740-214	CTL-92A	Transponder Control	Collins	Repair
622-8740-215	CTL-92A	Transponder Control	Collins	Repair
622-8740-216	CTL-92A	Transponder Control	Collins	Repair
622-8740-801	CTL-92A	Transponder Control	Collins	Repair
622-8740-802	CTL-92A	Transponder Control	Collins	Repair
622-9976-001	IND-42M	DME Indicator	Collins	Repair
622-9976-002	IND-42M	DME Indicator	Collins	Repair
622-9976-003	IND-42M	DME Indicator	Collins	Repair
622-9976-004	IND-42M	DME Indicator	Collins	Repair
6300-A11B-15-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-A15D-27-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-A1B-95-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-A1B-99-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-A25B-55-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-A25D-19-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-A27C-155-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-A2B-1-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-A2G-20-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-A50B-14-B1	-	Synchro Indicator	Bendix Aviation	Repair

Part Number	Model	Description	Manufacturer	Capability
6300-A50B-7-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-A9B-6-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-A9D-1-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-A9D-6-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B16B-1-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B17A-14-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B17A-19-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B17B-100-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B23A-14-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B25A-12-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B25A-19-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B3A-14-A4	-	Synchro Indicator	Bendix Aviation	Repair
6300-B3A-14-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B3A-15-A4	-	Synchro Indicator	Bendix Aviation	Repair
6300-B3A-15-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B3B-95-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B4E-2-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B4J-1-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B5A-14-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B5A-15-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B7B-1-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-B7C-100-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C14A-141-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C16A-6-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C17A-52-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C1B-19-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C22A-175-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C24A-20-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C30B-121-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C31B-200-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C36A-203-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C38A-155-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C38B-155-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C3A-107-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C3A-108-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C42A-201-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C45A-101-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C49A-155-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C7A-29-B1	-	Synchro Indicator	Bendix Aviation	Repair
6300-C8A-6-B1	-	Synchro Indicator	Bendix Aviation	Repair
6311 H.125	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6311 H.138	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6311 H.207	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6311 H.209	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6311 H.88	36-380053-1	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6311 H.89	36-380053-3	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6311 H.92	36-380053-5	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6311 H.93	36-380053-7	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6311A	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6311A H.107	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6311A H.108	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6311A H.146	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6312 H.122	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6312 H.123	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6313 H.179	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6313 H.215	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6313 H.76	169-380035	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6313 H.77	169-380035-1	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6313 H.78	169-380035-3	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6314 H.100	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6314 H.64	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6315 H.66	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.1	33-380006-5	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.10	35-380054-1	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.106	C662037-0206	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.109	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair

Part Number	Model	Description	Manufacturer	Capability
6331 H.110	C662037-0207	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.12	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.121	C662037-0209	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.126	C662037L0210	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.127	C662037-0210	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.128	C662037L0201	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.129	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.13	C662001-0205	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.131	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.132	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.139	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.140	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.145	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.154	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.156	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.160	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.164	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.165	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.169	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.17	C662001-0206	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.171	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.172	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.173	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.174	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.175	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.176	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.177	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.178	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.182	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.183	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.184	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.185	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.186	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.187	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.197	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.2	35-380054-3	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.202	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.205	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.211	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.212	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.213	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.214	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.217	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.218	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.22	C662001-0301	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.27	33-380016-1	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.28	33-380016-3	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.3	35-380054-5	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.30	33-380017-1	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.31	33-380017-3	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.32	36-380006-1	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.33	36-380006-3	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.34	C662037-0102	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.35	C662037-0103	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.36	C662037-0104	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.37	C662037-0105	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.39	C662037-0201	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.40	C662037-0202	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.41	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.42	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.43	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.46	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.47	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.49	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.5	C662001-0202	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.50	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair

Part Number	Model	Description	Manufacturer	Capability
6331 H.51	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.52	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.53	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.55	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.56	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.58	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.6	C662001-0203	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.63	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.65	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.67	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.7	C662001-0204	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.70	C662037-0108	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.72	C662037-0107	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.73	C662037-0203	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.75	35-380054-7	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.79	C662037-0109	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.8	33-380006-3	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.80	C662037-0204	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.81	C662037-0205	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.83	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.86	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.87	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.9	33-380006	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.90	C662037-0110	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.95	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6331 H.98	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6332 H.150	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6332 H.23	C662001-0302	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6332 H.57	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.102	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.103	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.137	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.151	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.161	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.162	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.167	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.168	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.192	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.24	C662001-0207	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.38	C662037-0106	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.54	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.59	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.74	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.82	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6333 H.91	-	Manifold/Fuel Pressure Indicator	United Instruments	Repair
6405-14	-	Turn Coordinator	S-TEC	Repair
6405-14-5L	-	Turn Coordinator	S-TEC	Repair
6405-14L	-	Turn Coordinator	S-TEC	Repair
6405-28	-	Turn Coordinator	S-TEC	Repair
6405-28-5L	-	Turn Coordinator	S-TEC	Repair
6405-28L	-	Turn Coordinator	S-TEC	Repair
6405-8-14-5L	-	Turn Coordinator	S-TEC	Repair
6405-8-14L	-	Turn Coordinator	S-TEC	Repair
6405-8-28-5L	-	Turn Coordinator	S-TEC	Repair
6405-8-28L	-	Turn Coordinator	S-TEC	Repair
6406-1	4000D-9	Directional Gyro, Lighted	S-TEC	Repair
6407-14	-	Turn Coordinator	S-TEC	Repair
6407-14L	-	Turn Coordinator	S-TEC	Repair
6407-28	-	Turn Coordinator	S-TEC	Repair
6407-28L	-	Turn Coordinator	S-TEC	Repair
6407-8-14L	-	Turn Coordinator	S-TEC	Repair
6407-8-28L	-	Turn Coordinator	S-TEC	Repair
64818-000-1	-	Oil Temp Indicator	Sextant	Test/Recert
64818-001-1	-	Oil Pressure Indicator	Sextant	Test/Recert
64818-010-1	-	Oil Pressure Indicator	Sextant	Test/Recert
64818-012-1	-	Oil Temp Indicator	Sextant	Test/Recert

Part Number	Model	Description	Manufacturer	Capability
64818-013-1	-	Oil Pressure Indicator	Sextant	Test/Recert
64818-015-1	-	Oil Temp Indicator	Sextant	Test/Recert
64818-018-1	-	Oil Pressure Indicator	Sextant	Test/Recert
64818-020-1	-	Oil Temp Indicator	Sextant	Test/Recert
64818-300-1	-	Fuel Pressure Indicator	Sextant	Test/Recert
64818-303-1	-	Fuel Pressure Indicator	Sextant	Test/Recert
64818-307-1	-	Fuel Pressure Indicator	Sextant	Test/Recert
6501-1001	206-070-266-5	Single Tachometer	INSCO	Repair
6501-1001	206-070-266-005	Single Tachometer	INSCO	Repair
6501-1005	206-070-243-1	Single Tachometer	INSCO	Repair
6501-1005	206-070-243-001	Single Tachometer	INSCO	Repair
6501-1006	369A4516	Single Tachometer	INSCO	Repair
6501-1010	-	Single Tachometer	INSCO	Repair
6501-1011	206-070-243-3	Single Tachometer	INSCO	Repair
6501-1011	206-070-243-003	Single Tachometer	INSCO	Repair
6501-1014	-	Single Tachometer	INSCO	Repair
6501-1016	850275-507	Single Tachometer	INSCO	Repair
6501-1029	104-384010-3	Single Tachometer	INSCO	Repair
6501-1030	104-384011-3	Single Tachometer	INSCO	Repair
6501-1035	-	Single Tachometer	INSCO	Repair
6501-1036	369A4516-3	Single Tachometer	INSCO	Repair
6501-1039	035A-986418-4	Single Tachometer	INSCO	Repair
6501-1040	369A4516-7	Single Tachometer	INSCO	Repair
6501-1044	-	Single Tachometer	INSCO	Repair
6501-1046	50-380035-5	Single Tachometer	INSCO	Repair
6501-1047	50-380034-3	Single Tachometer	INSCO	Repair
6501-1051	-	Single Tachometer	INSCO	Repair
6501-1055	-	Single Tachometer	INSCO	Repair
6501-1056	-	Single Tachometer	INSCO	Repair
6501-1058	850275-509	Single Tachometer	INSCO	Repair
6501-1068	105-956851	Single Tachometer	INSCO	Repair
6501-2004	206-070-266-3	Single Tachometer	INSCO	Repair
6501-2004	206-070-266-003	Single Tachometer	INSCO	Repair
6501-3003	206-070-266-1	Single Tachometer	INSCO	Repair
6501-3003	206-070-266-001	Single Tachometer	INSCO	Repair
6501-3007	206-070-266-7	Single Tachometer	INSCO	Repair
6501-3007	206-070-266-007	Single Tachometer	INSCO	Repair
6501-3008	206-070-266-9	Single Tachometer	INSCO	Repair
6501-3008	206-070-266-009	Single Tachometer	INSCO	Repair
6501-3017	109-0729-08	Single Tachometer	INSCO	Repair
6501-3034	109-0729-08-3	Single Tachometer	INSCO	Repair
6501-3037	-	Single Tachometer	INSCO	Repair
6501-3054	-	Single Tachometer	INSCO	Repair
6501-3061	-	Single Tachometer	INSCO	Repair
6501-3062	-	Single Tachometer	INSCO	Repair
65-0151-5	-	Indicator Light, Landing Gear Up	Grimes	Repair
6502-1001	206-070-265-5	Dual Tachometer	INSCO	Repair
6502-1001	206-070-265-005	Dual Tachometer	INSCO	Repair
6502-1002	204-072-129-1	Dual Tachometer	INSCO	Repair
6502-1002	204-072-129-001	Dual Tachometer	INSCO	Repair
6502-1006	206-070-241-1	Dual Tachometer	INSCO	Repair
6502-1006	206-070-241-001	Dual Tachometer	INSCO	Repair
6502-1007	-	Dual Tachometer	INSCO	Repair
6502-1008	204-072-129-3	Dual Tachometer	INSCO	Repair
6502-1008	204-072-129-003	Dual Tachometer	INSCO	Repair
6502-1009	369H4516	Dual Tachometer	INSCO	Repair
6502-1011	47-711-021-1	Dual Tachometer	INSCO	Repair
6502-1013	369H-4518	Dual Tachometer	INSCO	Repair
6502-1014	206-070-265-9	Dual Tachometer	INSCO	Repair
6502-1014	206-070-265-009	Dual Tachometer	INSCO	Repair
6502-1019	369H4518-3	Dual Tachometer	INSCO	Repair
6502-1024	369H4518-3	Dual Tachometer	INSCO	Repair
6502-1032	850083-507	Dual Tachometer	INSCO	Repair
6502-1033	369H4518-7	Dual Tachometer	INSCO	Repair
6502-1034	369D24518	Dual Tachometer	INSCO	Repair
6502-1038	369H4518-9	Dual Tachometer	INSCO	Repair

Part Number	Model	Description	Manufacturer	Capability
6502-2004	206-070-265-3	Dual Tachometer	INSCO	Repair
6502-2004	206-070-265-003	Dual Tachometer	INSCO	Repair
6502-3003	206-070-265-1	Dual Tachometer	INSCO	Repair
6502-3003	206-070-265-001	Dual Tachometer	INSCO	Repair
6502-3010	206-070-265-7	Dual Tachometer	INSCO	Repair
6502-3010	206-070-265-007	Dual Tachometer	INSCO	Repair
6502-3020	-	Dual Tachometer	INSCO	Repair
6502-3031	206-070-265-11	Dual Tachometer	INSCO	Repair
6502-3031	206-070-265-011	Dual Tachometer	INSCO	Repair
6502-3045	-	Dual Tachometer	INSCO	Repair
6502-3046	206-070-265-101	Dual Tachometer	INSCO	Repair
65-0647-1	209-075-325-9	Indicator Light, Master Caution	Grimes	Repair
65-0647-1	209-075-325-009	Indicator Light, Master Caution	Grimes	Repair
65-0648-1	209-075-325-11	Indicator Light, RPM Warning	Grimes	Repair
65-0648-1	209-075-325-011	Indicator Light, RPM Warning	Grimes	Repair
651-001-500	4000D-3	Directional Gryo	Brittain	Repair
7000299-901	PC-702	Helipilot Controller	Honeywell	Repair
7000299-902	PC-702	Helipilot Controller	Honeywell	Repair
7000299-903	PC-702	Helipilot Controller	Honeywell	Repair
7000299-904	PC-702	Helipilot Controller	Honeywell	Repair
7000299-905	PC-702	Helipilot Controller	Honeywell	Repair
7000299-906	PC-700	Helipilot Controller	Honeywell	Repair
7000299-907	PC-700	Helipilot Controller	Honeywell	Repair
7000299-908	PC-700	Helipilot Controller	Honeywell	Repair
7000299-909	PC-700	Helipilot Controller	Honeywell	Repair
7000299-910	PC-700	Helipilot Controller	Honeywell	Repair
7000299-911	PC-700	Helipilot Controller	Honeywell	Repair
7000299-912	PC-700	Helipilot Controller	Honeywell	Repair
7000299-913	PC-700	Helipilot Controller	Honeywell	Repair
7000605-901	MS-700	Mode Selector, Flight Director	Honeywell	Repair
7000605-902	MS-700	Mode Selector, Flight Director	Honeywell	Repair
7000605-906	MS-700	Mode Selector, Flight Director	Honeywell	Repair
7000605-907	MS-700	Mode Selector, Flight Director	Honeywell	Repair
7000605-909	MS-700	Mode Selector, Flight Director	Honeywell	Repair
7000622-901	VG-14A	Vertical Gyro	Honeywell	Repair
7000622-902	VG-14A	Vertical Gyro	Honeywell	Repair
7000836-901	AD-500A	Attitude Director Indicator	Honeywell	Repair
7000836-902	AD-500A	Attitude Director Indicator	Honeywell	Repair
7000836-903	AD-500B	Attitude Director Indicator	Honeywell	Repair
7000836-904	AD-500B	Attitude Director Indicator	Honeywell	Repair
7000836-905	AD-500C	Attitude Director Indicator	Honeywell	Repair
7000836-906	AD-500C	Attitude Director Indicator	Honeywell	Repair
7000836-907	AD-500D	Attitude Director Indicator	Honeywell	Repair
7000836-908	AD-500D	Attitude Director Indicator	Honeywell	Repair
7000836-909	AD-500A	Attitude Director Indicator	Honeywell	Repair
7000836-910	AD-500A	Attitude Director Indicator	Honeywell	Repair
7000836-911	AD-500B	Attitude Director Indicator	Honeywell	Repair
7000836-912	AD-500B	Attitude Director Indicator	Honeywell	Repair
7000836-913	AD-500C	Attitude Director Indicator	Honeywell	Repair
7000836-914	AD-500C	Attitude Director Indicator	Honeywell	Repair
7000836-915	AR-500	Attitude Reference Indicator	Honeywell	Repair
7000836-916	AR-500	Attitude Reference Indicator	Honeywell	Repair
7000836-917	AD-500A	Attitude Director Indicator	Honeywell	Repair
7000836-918	AD-500A	Attitude Director Indicator	Honeywell	Repair
7000836-919	AD-500C	Attitude Director Indicator	Honeywell	Repair
7000836-920	AD-500C	Attitude Director Indicator	Honeywell	Repair
7000836-921	AD-500C	Attitude Director Indicator	Honeywell	Repair
7000836-922	AD-500C	Attitude Director Indicator	Honeywell	Repair
7000836-923	AD-500A	Attitude Director Indicator	Honeywell	Repair
7000836-924	AD-500A	Attitude Director Indicator	Honeywell	Repair
7000836-925	AD-500D	Attitude Director Indicator	Honeywell	Repair
7000836-926	AD-500D	Attitude Director Indicator	Honeywell	Repair
7000836-927	AR-500	Attitude Reference Indicator	Honeywell	Repair
7000836-928	AR-500	Attitude Reference Indicator	Honeywell	Repair
7000836-932	AD-500A	Attitude Director Indicator	Honeywell	Repair
7000839-901	RA-315	Radio Altimeter Indicator	Sperry	Repair

Part Number	Model	Description	Manufacturer	Capability
7000839-902	RA-315	Radio Altimeter Indicator	Sperry	Repair
7000839-903	RA-315	Radio Altimeter Indicator	Sperry	Repair
7000839-904	RA-335	Radio Altimeter Indicator	Sperry	Repair
7000839-905	RA-335	Radio Altimeter Indicator	Sperry	Repair
7000839-906	RA-315	Radio Altimeter Indicator	Sperry	Repair
7000839-922	RA-315	Radio Altimeter Indicator	Sperry	Repair
7000839-923	RA-335	Radio Altimeter Indicator	Sperry	Repair
7000C.186	S3327-1	Vertical Speed Indicator (0-2000ft/min)	United Instruments	Repair
7000C.192	-	Vertical Speed Indicator (0-10m/sec)	United Instruments	Repair
7000C.193	-	Vertical Speed Indicator (0-10m/sec)	United Instruments	Repair
7000C.2	-	Vertical Speed Indicator (0-2000ft/min)	United Instruments	Repair
7000C.26	-	Vertical Speed Indicator (0-2000ft/min)	United Instruments	Repair
7000C.31	-	Vertical Speed Indicator (0-2000ft/min)	United Instruments	Repair
7000C.32	C661080-0101	Vertical Speed Indicator (0-2000ft/min)	United Instruments	Repair
7000C.86	-	Vertical Speed Indicator (0-2000ft/min)	United Instruments	Repair
7000C.91	-	Vertical Speed Indicator (0-2000ft/min)	United Instruments	Repair
7000-C92N2	S1392-N2	Vertical Speed Indicator (0-2000ft/min)	United Instruments	Repair
7001182-901	AD-550A	Attitude Director Indicator	Honeywell	Repair
7001182-902	AD-550A	Attitude Director Indicator	Honeywell	Repair
7001182-903	AD-550B	Attitude Director Indicator	Honeywell	Repair
7001182-904	AD-550B	Attitude Director Indicator	Honeywell	Repair
7001182-905	AD-550C	Attitude Director Indicator	Honeywell	Repair
7001182-906	AD-550C	Attitude Director Indicator	Honeywell	Repair
7001182-907	AD-550H	Attitude Director Indicator	Honeywell	Repair
7001182-909	AD-550A	Attitude Director Indicator	Honeywell	Repair
7001182-910	AD-550A	Attitude Director Indicator	Honeywell	Repair
7001182-911	AD-550B	Attitude Director Indicator	Honeywell	Repair
7001182-912	AD-550B	Attitude Director Indicator	Honeywell	Repair
7001182-913	AD-550C	Attitude Director Indicator	Honeywell	Repair
7001182-914	AD-550C	Attitude Director Indicator	Honeywell	Repair
7001182-915	AD-550H	Attitude Director Indicator	Honeywell	Repair
7001182-916	AD-550C	Attitude Director Indicator	Honeywell	Repair
7001182-917	AD-550C	Attitude Director Indicator	Honeywell	Repair
7001182-918	AD-550C	Attitude Director Indicator	Honeywell	Repair
7001182-919	AD-550C	Attitude Director Indicator	Honeywell	Repair
7001433-901	VA-100	Voice Advisory System	Honeywell	Repair
7001433-902	VA-100	Voice Advisory System	Honeywell	Repair
7001433-903	VA-100	Voice Advisory System	Honeywell	Repair
7001433-904	VA-100	Voice Advisory System	Honeywell	Repair
70-0158-1	76550-01008-101	Dimmer Control	Grimes	Repair
70-0158-3	76550-01008-102	Dimmer Control	Grimes	Repair
70-0158-5	76550-01008-103	Dimmer Control	Grimes	Repair
7001840-901	RT-300	Radio Altimeter R/T	Sperry	Test/Recert
7001840-902	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-903	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-904	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-905	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-906	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-911	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-912	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-913	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-914	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-915	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-916	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-917	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-918	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-922	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-924	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-926	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-928	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-931	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-932	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-934	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-936	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-937	RT-300	Radio Altimeter R/T	Sperry	Repair
7001840-938	RT-300	Radio Altimeter R/T	Sperry	Repair

Part Number	Model	Description	Manufacturer	Capability
700-2	-	Attitude Gyro	AIM	Repair
7002353-901	AZ-649	Air Data Sensor	Honeywell	Test/Recert
7002353-902	AZ-649	Air Data Sensor	Honeywell	Test/Recert
7002353-911	AZ-649	Air Data Sensor	Honeywell	Test/Recert
7002353-912	AZ-649	Air Data Sensor	Honeywell	Test/Recert
7002353-913	AZ-649	Air Data Sensor	Honeywell	Test/Recert
7002412-901	AL-200	Altitude Preselect Controller	Honeywell	Repair
7002412-902	AL-200	Altitude Preselect Controller	Honeywell	Repair
7002412-903	AL-300	Altitude Preselect Controller	Honeywell	Repair
7002412-904	AL-300	Altitude Preselect Controller	Honeywell	Repair
7002412-906	AL-300	Altitude Preselect Controller	Honeywell	Repair
700-2BCFL	-	Attitude Gyro	AIM	Repair
700-3	-	Attitude Gyro	AIM	Repair
700-3CFL	-	Attitude Gyro	AIM	Repair
7007700-705	WI-700	Weather Radar Indicator	Honeywell	Repair
7007700-706	WI-700	Weather Radar Indicator	Honeywell	Repair
70256N01D01	AM-250	Barometric Altimeter	Honeywell	Test/Recert
70256N02D02	AM-250	Barometric Altimeter	Honeywell	Test/Recert
7030B C.73	-	Vertical Speed Indicator (0-3000ft/min)	United Instruments	Repair
7030C.189	-	Vertical Speed Indicator (0-3000ft/min)	United Instruments	Repair
7030C.194	-	Vertical Speed Indicator (0-15m/sec)	United Instruments	Repair
7030C.195	-	Vertical Speed Indicator (0-15m/sec)	United Instruments	Repair
7030C.27	-	Vertical Speed Indicator (0-3000ft/min)	United Instruments	Repair
7030C.29	C661035-0101	Vertical Speed Indicator (0-3000ft/min)	United Instruments	Repair
7030C.3	-	Vertical Speed Indicator (0-3000ft/min)	United Instruments	Repair
7030C.94	-	Vertical Speed Indicator (0-3000ft/min)	United Instruments	Repair
7030C.99	-	Vertical Speed Indicator (0-3000ft/min)	United Instruments	Repair
7040-B4	-	Vertical Speed Indicator (0-4000ft/min)	United Instruments	Repair
7040C.104	-	Vertical Speed Indicator (0-4000ft/min)	United Instruments	Repair
7040C.109	-	Vertical Speed Indicator (0-4000ft/min)	United Instruments	Repair
7040C.11	-	Vertical Speed Indicator (0-4000ft/min)	United Instruments	Repair
7040C.18	58-380018-1	Vertical Speed Indicator (0-4000ft/min)	United Instruments	Repair
7040C.196	-	Vertical Speed Indicator (0-20m/sec)	United Instruments	Repair
7040C.197	-	Vertical Speed Indicator (0-20m/sec)	United Instruments	Repair
7040C.28	-	Vertical Speed Indicator (0-4000ft/min)	United Instruments	Repair
7040C.4	-	Vertical Speed Indicator (0-4000ft/min)	United Instruments	Repair
7060C.114	-	Vertical Speed Indicator (0-6000ft/min)	United Instruments	Repair
7060C.198	-	Indicator, Vertical Speed (0-30m/sec)	United Instruments	Repair
7060C.199	-	Indicator, Vertical Speed (0-30m/sec, Lighted)	United Instruments	Repair
7060C.20	-	Vertical Speed Indicator (0-6000ft/min)	United Instruments	Repair
7060C.46	-	Vertical Speed Indicator (0-6000ft/min)	United Instruments	Repair
709001-102	76450-01005-102	Landing Gear Control	Eaton	Repair
709001-6	76450-01005-101	Landing Gear Control	Eaton	Repair
7120C.119	-	Instant Vertical Speed Indicator (0-2000ft/min)	United Instruments	Repair
7120C.40	-	Instant Vertical Speed Indicator (0-2000ft/min)	United Instruments	Repair
7125-1	214-075-244-1	Rate Gyro Transmitter	General Design	Repair
7125-1	214-075-244-001	Rate Gyro Transmitter	General Design	Repair
7125-2	214-075-244-1	Rate Gyro Transmitter	General Design	Repair
7125-2	214-075-244-001	Rate Gyro Transmitter	General Design	Repair
7130B C.71	-	Instant Vertical Speed Indicator (0-3000ft/min)	United Instruments	Repair
7130C.41	-	Instant Vertical Speed Indicator (0-3000ft/min)	United Instruments	Repair
7130C.44	100-384054-1	Instant Vertical Speed Indicator (0-3000ft/min)	United Instruments	Repair
7130C.47	-	Instant Vertical Speed Indicator (0-3000ft/min)	United Instruments	Repair
7130C.82	-	Instant Vertical Speed Indicator (0-3000ft/min)	United Instruments	Repair
7140C.125	-	Instant Vertical Speed Indicator (0-4000ft/min)	United Instruments	Repair
7140C.42	-	Instant Vertical Speed Indicator (0-4000ft/min)	United Instruments	Repair
7160C.130	-	Instant Vertical Speed Indicator (0-6000ft/min)	United Instruments	Repair
7160C.43	-	Instant Vertical Speed Indicator (0-6000ft/min)	United Instruments	Repair
748-934-2	-	Fuel Quantity Indicator	Intertechnique	Repair
749-416	-	Fuel Quantity Indicator	Intertechnique	Repair
75-0074-209	-	Advisory Panel, No.1 Auxiliary	Grimes	Repair
75-0286-1	-	Caution Panel	Grimes	Repair
75-0286-11	-	Caution Panel	Grimes	Repair
75-0286-13	-	Caution Panel	Grimes	Repair
75-0286-3	-	Caution Panel	Grimes	Repair
75-0286-5	-	Caution Panel	Grimes	Repair

Part Number	Model	Description	Manufacturer	Capability
75-0286-7	-	Caution Panel	Grimes	Repair
75-0286-9	-	Caution Panel	Grimes	Repair
761240-1	76900-01803-101	AFCS Control Panel	Hamilton Standard	Repair
761272-3	76900-01804-103	AFCS Indicator Panel	Hamilton Standard	Repair
761272-4	76900-01804-104	AFCS Indicator Panel	Hamilton Standard	Repair
761282-1	76900-01806-102	AFCS Yaw Switch	Hamilton Standard	Repair
76450-01010-043	-	Compass Control Panel	Sikorsky	Repair
76450-01010-044	-	Compass Control Panel	Sikorsky	Repair
76450-22032-044	-	Dimming Control Panel Assembly	Sikorsky	Repair
764685-1	76900-01805-101	Airspeed Switch (40 knots)	Hamilton Standard	Repair
764685-2	76900-01805-102	Airspeed Switch (60 knots)	Hamilton Standard	Repair
76550-00703-041	-	Caution/Advisory Panel	Sikorsky	Repair
76550-02005-101	-	Searchlight, Controllable	Grimes	Repair
76550-02005-102	-	Searchlight, Controllable	Grimes	Repair
76550-02005-103	-	Searchlight, Controllable	Grimes	Repair
76550-02005-104	-	Searchlight, Controllable	Grimes	Repair
76550-02500-046	-	EEC Panel	Sikorsky	Repair
76550-02500-048	-	EEC Panel	Sikorsky	Repair
777-1493-001	614L-11	ADF Control Unit	Collins	Repair
777-1493-002	614L-11	ADF Control Unit	Collins	Repair
777-1493-003	614L-11	ADF Control Unit	Collins	Repair
777-1493-004	614L-11	ADF Control Unit	Collins	Repair
777-1493-005	614L-11	ADF Control Unit	Collins	Repair
777-1493-006	614L-11	ADF Control Unit	Collins	Repair
777-1493-007	614L-11	ADF Control Unit	Collins	Repair
777-1493-008	614L-11	ADF Control Unit	Collins	Repair
777-1493-009	614L-11	ADF Control Unit	Collins	Repair
777-1493-010	614L-11	ADF Control Unit	Collins	Repair
787-6366-001	614L-12	ADF Control Unit	Collins	Repair
787-6366-002	614L-12	ADF Control Unit	Collins	Repair
787-6366-003	614L-12	ADF Control Unit	Collins	Repair
787-6366-004	614L-12	ADF Control Unit	Collins	Repair
787-6366-005	614L-12	ADF Control Unit	Collins	Repair
787-6366-006	614L-12	ADF Control Unit	Collins	Repair
787-6366-007	614L-12	ADF Control Unit	Collins	Repair
787-6366-008	614L-12	ADF Control Unit	Collins	Repair
787-6366-009	614L-12	ADF Control Unit	Collins	Repair
787-6366-010	614L-12	ADF Control Unit	Collins	Repair
787-6366-011	614L-12	ADF Control Unit	Collins	Repair
787-6366-012	614L-12	ADF Control Unit	Collins	Repair
787-6366-013	614L-12	ADF Control Unit	Collins	Repair
787-6366-014	614L-12	ADF Control Unit	Collins	Repair
787-6366-015	614L-12	ADF Control Unit	Collins	Repair
787-6366-016	614L-12	ADF Control Unit	Collins	Repair
787-6366-017	614L-12	ADF Control Unit	Collins	Repair
787-6366-018	614L-12	ADF Control Unit	Collins	Repair
787-6385-002	331A-6P	Course Indicator	Collins	Repair
792-6275-001	614L-13	ADF Control Unit	Collins	Repair
792-6275-002	614L-13	ADF Control Unit	Collins	Repair
792-6275-003	614L-13	ADF Control Unit	Collins	Repair
792-6275-004	614L-13	ADF Control Unit	Collins	Repair
792-6275-005	614L-13	ADF Control Unit	Collins	Repair
792-6275-006	614L-13	ADF Control Unit	Collins	Repair
792-6275-007	614L-13	ADF Control Unit	Collins	Repair
792-6275-008	614L-13	ADF Control Unit	Collins	Repair
792-6657-001	VHF-20	VHF Transceiver	Collins	Repair
792-6657-003	VHF-20	VHF Transceiver	Collins	Repair
792-6657-004	VHF-20	VHF Transceiver	Collins	Repair
792-6694-001	332D-11A	Vertical Gyro	Collins	Repair
792-6694-002	332D-11A	Vertical Gyro	Collins	Repair
792-6694-004	332D-11A	Vertical Gyro	Collins	Repair
8.043.003	-	Directional Gyro	Aeritalia	Repair
8.043.008.1	-	Directional Gyro	Aeritalia	Repair
8.048.003	-	Horizon Gyro	Aeritalia	Repair
8.048.008.1	-	Horizon Gyro	Aeritalia	Repair
8.048.008.1.01	36100C	Horizon Gyro	Aeritalia	Repair

Part Number	Model	Description	Manufacturer	Capability
8.048.008.1.01	C661076-0105	Horizon Gyro	Aeritalia	Repair
8.148.014	C661076-0105	Gyro Horizon	Aeritalia	Repair
8.148.014	36101C	Gyro Horizon	Aeritalia	Repair
8.148.015	99002-8	Gyro Horizon	Aeritalia	Repair
8.148.015	36101P	Gyro Horizon	Aeritalia	Repair
8.148.016	36101C	Gyro Horizon	Aeritalia	Repair
8.148.017	36101W	Gyro Horizon	Aeritalia	Repair
8.148.019	36101E	Gyro Horizon	Aeritalia	Repair
8.148.036	36101E	Gyro Horizon	Aeritalia	Repair
8.148.051	36101B	Gyro Horizon	Aeritalia	Repair
8.148.056	36101D	Gyro Horizon	Aeritalia	Repair
8000 B.1	-	Airspeed Indicator	United Instruments	Repair
8000 B.11	-	Airspeed Indicator	United Instruments	Repair
8000 B.111	206-070-264-7	Airspeed Indicator	United Instruments	Repair
8000 B.111	206-070-264-007	Airspeed Indicator	United Instruments	Repair
8000 B.12	206-070-264-5	Airspeed Indicator	United Instruments	Repair
8000 B.12	206-070-264-005	Airspeed Indicator	United Instruments	Repair
8000 B.13	-	Airspeed Indicator	United Instruments	Repair
8000 B.156	-	Airspeed Indicator	United Instruments	Repair
8000 B.166	-	Airspeed Indicator	United Instruments	Repair
8000 B.225	-	Airspeed Indicator	United Instruments	Repair
8000 B.234	-	Airspeed Indicator	United Instruments	Repair
8000 B.336	206-075-725-1	Airspeed Indicator	United Instruments	Repair
8000 B.336	206-075-725-001	Airspeed Indicator	United Instruments	Repair
8000 B.4	206-070-264-1	Airspeed Indicator	United Instruments	Repair
8000 B.4	206-070-264-001	Airspeed Indicator	United Instruments	Repair
8000 B.445	-	Airspeed Indicator	United Instruments	Repair
8000 B.446	-	Airspeed Indicator	United Instruments	Repair
8000 B.461	-	Airspeed Indicator	United Instruments	Repair
8000 B.463	-	Airspeed Indicator	United Instruments	Repair
8000 B.464	-	Airspeed Indicator	United Instruments	Repair
8000 B.747	-	Airspeed Indicator	United Instruments	Repair
8000 B.751	206-075-725-103	Airspeed Indicator	United Instruments	Repair
8000 B.758	-	Airspeed Indicator	United Instruments	Repair
8000 B.780	-	Airspeed Indicator	United Instruments	Repair
8000 B.825	206-075-725-109	Airspeed Indicator	United Instruments	Repair
8000 B.827	-	Airspeed Indicator	United Instruments	Repair
8000 B.828	-	Airspeed Indicator	United Instruments	Repair
8000 B.860	-	Airspeed Indicator	United Instruments	Repair
8000 B.861	-	Airspeed Indicator	United Instruments	Repair
8000 B.865	-	Airspeed Indicator	United Instruments	Repair
8000 B.876	-	Airspeed Indicator	United Instruments	Repair
8000 BH1	206-070-264-1	Airspeed Indicator	United Instruments	Repair
8000 BH1	206-070-264-001	Airspeed Indicator	United Instruments	Repair
8000 BH3	206-070-264-3	Airspeed Indicator	United Instruments	Repair
8000 BH3	206-070-264-003	Airspeed Indicator	United Instruments	Repair
8000 BH5	206-070-264-5	Airspeed Indicator	United Instruments	Repair
8000 BH5	206-070-264-005	Airspeed Indicator	United Instruments	Repair
8000 BH7	-	Airspeed Indicator	United Instruments	Repair
80-0092-3	-	Caution Panel	Grimes	Repair
80-0092-301	-	Caution Panel, No.2 Auxiliary	Grimes	Repair
80-0092-7	S6155-61279-001	Caution Panel	Grimes	Repair
80-0093-1	S6155-61579-001	Caution Panel	Grimes	Repair
80-0093-5	S6155-61579-002	Caution Panel	Grimes	Repair
8000T B.111	206-070-264-7	Airspeed Indicator	United Instruments	Repair
8000T B.111	206-070-264-007	Airspeed Indicator	United Instruments	Repair
8000T B.12	206-070-264-5	Airspeed Indicator	United Instruments	Repair
8000T B.12	206-070-264-005	Airspeed Indicator	United Instruments	Repair
80-0132-11	S6157-62561-7	Caution Panel	Grimes	Repair
80-0132-9	S6157-62561-5	Caution Panel	Grimes	Repair
80-0203-15	209-075-325-109	Annunciator Panel	Grimes	Repair
80-0203-17	209-075-325-111	Annunciator Panel	Grimes	Repair
80-0203-3	209-075-325-27	Annunciator Panel	Grimes	Repair
80-0203-3	209-075-325-027	Annunciator Panel	Grimes	Repair
80-0203-5	209-075-325-33	Annunciator Panel	Grimes	Repair
80-0203-5	209-075-325-033	Annunciator Panel	Grimes	Repair

Part Number	Model	Description	Manufacturer	Capability
80-0203-9	209-075-325-45	Annunciator Panel	Grimes	Repair
80-0203-9	209-075-325-045	Annunciator Panel	Grimes	Repair
80-0295-15	214-075-100-15	Annunciator Panel	Grimes	Repair
80-0295-15	214-075-100-015	Annunciator Panel	Grimes	Repair
80-0331-1	61550-61353-101	Master Caution Panel	Grimes	Repair
80-0331-3	61550-61353-102	Master Caution Panel	Grimes	Repair
8025 B.167	-	Airspeed Indicator	United Instruments	Repair
8025 B.447	-	Airspeed Indicator	United Instruments	Repair
8025 B.465	-	Airspeed Indicator	United Instruments	Repair
8025 B.477	-	Airspeed Indicator	United Instruments	Repair
8025 B.488	-	Airspeed Indicator	United Instruments	Repair
8025 B.7	-	Airspeed Indicator	United Instruments	Repair
8025 B.778	-	Airspeed Indicator	United Instruments	Repair
8025 B.845	-	Airspeed Indicator	United Instruments	Repair
8030 B.10	-	Airspeed Indicator	United Instruments	Repair
8030 B.168	-	Airspeed Indicator	United Instruments	Repair
8030 B.357	-	Airspeed Indicator	United Instruments	Repair
8030 B.358	-	Airspeed Indicator	United Instruments	Repair
8030 B.448	-	Airspeed Indicator	United Instruments	Repair
8030 B.466	-	Airspeed Indicator	United Instruments	Repair
8030 B.553	-	Airspeed Indicator	United Instruments	Repair
8033-100095	RE-800	HF Receiver/Exciter	Sunair Electronics	Repair
8033-2000	SCU-80	HF Control Unit	Sunair Electronics	Repair
8033-200090	SCU-80	HF Control Unit	Sunair Electronics	Repair
8033-3000	ACU-810	HF Amplifier/Coupler	Sunair Electronics	Repair
8033-300094	ACU-810	HF Amplifier/Coupler	Sunair Electronics	Repair
8040 B.480	-	Airspeed Indicator	United Instruments	Repair
8040 B.489	-	Airspeed Indicator	United Instruments	Repair
8040B	-	Encoding Altimeter (-1k-20k ft, in.Hg)	Aero Mechanism	Repair
8040B-LR	-	Encoding Altimeter (-1k-20k ft, in.Hg, Lighted)	Aero Mechanism	Repair
8040B-LW	-	Encoding Altimeter (-1k-20k ft, in.Hg, Lighted)	Aero Mechanism	Repair
8040B-LX	-	Encoding Altimeter (-1k-20k ft, in.Hg, Lighted)	Aero Mechanism	Repair
8040B-MB	-	Encoding Altimeter (-1k-20k ft, mbar)	Aero Mechanism	Repair
8040B-MB-LR	-	Encoding Altimeter (-1k-20k ft, mbar, Lighted)	Aero Mechanism	Repair
8040B-MB-LW	-	Encoding Altimeter (-1k-20k ft, mbar, Lighted)	Aero Mechanism	Repair
8040B-MB-LX	-	Encoding Altimeter (-1k-20k ft, mbar, Lighted)	Aero Mechanism	Repair
8047/10	-	Altimeter (-1k-50k ft, in.Hg, Lighted)	Horizon	Repair
8047/10B	-	Altimeter (-1k-50k ft, in.Hg, Lighted)	Horizon	Repair
8047/10DH	-	Altimeter (-1k-50k ft, in.Hg, Lighted)	Horizon	Repair
8047/10NVG	-	Altimeter (-1k-50k ft, in.Hg, Lighted)	Horizon	Repair
8047/10NVG-5V	-	Altimeter (-1k-50k ft, in.Hg, Lighted)	Horizon	Repair
8047/20	-	Altimeter (-1k-50k ft, mbar, Lighted)	Horizon	Repair
8047/20A	-	Altimeter (-1k-80k ft, mbar, Lighted)	Horizon	Repair
8047/20B	-	Altimeter (-1k-50k ft, mbar, Lighted)	Horizon	Repair
8047/20DH	-	Altimeter (-1k-50k ft, mbar, Lighted)	Horizon	Repair
8048/1	-	Altimeter (-1k-15k ft, mbar, Lighted)	Horizon	Repair
805.416-921	AS3100-(12A)	Audio Panel	Becker	Repair
8095536-8101	RS811A	Radar Sensor	Bendix	Repair
8095537-8101	IN812A	Radar Indicator (Black Bezel, 5/14/28V Lighting)	Bendix	Repair
8095537-8102	IN812A	Radar Indicator (Gray Bezel, 5/14/28V Lighting)	Bendix	Repair
8099-300092	ACU-810A	HF Amplifier/Coupler	Sunair Electronics	Repair
8100 B.154	-	Airspeed Indicator, True	United Instruments	Repair
8100 B.155	-	Airspeed Indicator, True	United Instruments	Repair
8100 B.261	-	Airspeed Indicator, True	United Instruments	Repair
8100 B.265	-	Airspeed Indicator, True	United Instruments	Repair
8100 B.321	-	Airspeed Indicator, True	United Instruments	Repair
8100 B.339	-	Airspeed Indicator, True	United Instruments	Repair
8100 B.371	-	Airspeed Indicator, True	United Instruments	Repair
8100 B.95	-	Airspeed Indicator, True	United Instruments	Repair
8107-140-00-10	-	Engine Shutdown Detector	Brion Leroux	Repair
8125 B.178	-	Airspeed Indicator, True	United Instruments	Repair
8125 B.229	-	Airspeed Indicator, True	United Instruments	Repair
8125 B.267	-	Airspeed Indicator, True	United Instruments	Repair
8125 B.283	-	Airspeed Indicator, True	United Instruments	Repair
8125 B.341	-	Airspeed Indicator, True	United Instruments	Repair
8125 B.350	-	Airspeed Indicator, True	United Instruments	Repair

Part Number	Model	Description	Manufacturer	Capability
8125 B.354	-	Airspeed Indicator, True	United Instruments	Repair
8125 B.408	-	Airspeed Indicator, True	United Instruments	Repair
8125 B.452	-	Airspeed Indicator, True	United Instruments	Repair
8125 B.535	-	Airspeed Indicator, True	United Instruments	Repair
8125 B.614	-	Airspeed Indicator (0-210 Knots)	United Instruments	Repair
8125 B.97	-	Airspeed Indicator, True	United Instruments	Repair
8130 B.185	-	Airspeed Indicator, True	United Instruments	Repair
8130 B.192	-	Airspeed Indicator, True	United Instruments	Repair
8130 B.249	-	Airspeed Indicator, True	United Instruments	Repair
8130 B.311	-	Airspeed Indicator, True	United Instruments	Repair
8130 B.388	-	Airspeed Indicator, True	United Instruments	Repair
8130 B.429	-	Airspeed Indicator, True	United Instruments	Repair
8130 B.492	-	Airspeed Indicator, True	United Instruments	Repair
8140 B.457	-	Airspeed Indicator, True	United Instruments	Repair
8140 B.851	-	Airspeed Indicator, True	United Instruments	Repair
8140B-20	-	Encoding Altimeter (-1k-20k ft, in.Hg)	Aero Mechanism	Repair
8140B-20LR	-	Encoding Altimeter (-1k-20k ft, in.Hg, Lighted)	Aero Mechanism	Repair
8140B-20LW	-	Encoding Altimeter (-1k-20k ft, in.Hg, Lighted)	Aero Mechanism	Repair
8140B-20LX	-	Encoding Altimeter (-1k-20k ft, in.Hg, Lighted)	Aero Mechanism	Repair
8140B-20MB	-	Encoding Altimeter (-1k-20k ft, mbar)	Aero Mechanism	Repair
8140B-20MB-LR	-	Encoding Altimeter (-1k-20k ft, mbar, Lighted)	Aero Mechanism	Repair
8140B-20MB-LW	-	Encoding Altimeter (-1k-20k ft, mbar, Lighted)	Aero Mechanism	Repair
8140B-20MB-LX	-	Encoding Altimeter (-1k-20k ft, mbar, Lighted)	Aero Mechanism	Repair
8140B-30	-	Encoding Altimeter (-1k-30k ft, in.Hg)	Aero Mechanism	Repair
8140B-30LR	-	Encoding Altimeter (-1k-30k ft, in.Hg, Lighted)	Aero Mechanism	Repair
8140B-30LW	-	Encoding Altimeter (-1k-30k ft, in.Hg, Lighted)	Aero Mechanism	Repair
8140B-30LX	-	Encoding Altimeter (-1k-30k ft, in.Hg, Lighted)	Aero Mechanism	Repair
8140B-30MB	-	Encoding Altimeter (-1k-30k ft, mbar)	Aero Mechanism	Repair
8140B-30MB-LR	-	Encoding Altimeter (-1k-30k ft, mbar, Lighted)	Aero Mechanism	Repair
8140B-30MB-LW	-	Encoding Altimeter (-1k-30k ft, mbar, Lighted)	Aero Mechanism	Repair
8140B-30MB-LX	-	Encoding Altimeter (-1k-30k ft, mbar, Lighted)	Aero Mechanism	Repair
8140B-35	-	Encoding Altimeter (-1k-35k ft, in.Hg)	Aero Mechanism	Repair
8140B-35LR	-	Encoding Altimeter (-1k-35k ft, in.Hg, Lighted)	Aero Mechanism	Repair
8140B-35LW	-	Encoding Altimeter (-1k-35k ft, in.Hg, Lighted)	Aero Mechanism	Repair
8140B-35LX	-	Encoding Altimeter (-1k-35k ft, in.Hg, Lighted)	Aero Mechanism	Repair
8140B-35MB	-	Encoding Altimeter (-1k-35k ft, mbar)	Aero Mechanism	Repair
8140B-35MB-LR	-	Encoding Altimeter (-1k-35k ft, mbar, Lighted)	Aero Mechanism	Repair
8140B-35MB-LW	-	Encoding Altimeter (-1k-35k ft, mbar, Lighted)	Aero Mechanism	Repair
8140B-35MB-LX	-	Encoding Altimeter (-1k-35k ft, mbar, Lighted)	Aero Mechanism	Repair
8140B-S20LW	-	Encoding Altimeter (-1k-20k ft, in.Hg, Lighted)	Aero Mechanism	Repair
820123-501	5000B	Attitude Gyro	Mooney	Repair
820192-501	5000B-1	Attitude Gyro	Mooney	Repair
820192-505	5000B-39	Attitude Gyro, Lighted	Mooney	Repair
820203-503	4000B-33	Directional Gyro, Lighted	Mooney	Repair
822-0400-001	VIR-33	Navigation Receiver	Collins	Repair
822-0416-001	IND-270A	Weather Radar Indicator	Collins	Repair
822-0416-002	IND-270A	Weather Radar Indicator	Collins	Repair
822-1111-001	VHF-21C	VHF Comm Transceiver	Collins	Repair
822-1112-001	VHF-21D	VHF Comm Transceiver	Collins	Repair
822-1113-001	VHF-22C	VHF Comm Transceiver	Collins	Repair
822-1113-021	VHF-22C	VHF Comm Transceiver	Collins	Repair
822-1113-023	VHF-22C	VHF Comm Transceiver	Collins	Repair
822-1114-001	VHF-22D	VHF Comm Transceiver	Collins	Repair
822-1114-021	VHF-22D	VHF Comm Transceiver	Collins	Repair
822-1114-023	VHF-22D	VHF Comm Transceiver	Collins	Repair
822-1120-001	CTL-22C	VHF COMM Control	Collins	Repair
822-1120-002	CTL-22C	VHF COMM Control	Collins	Repair
822-1120-003	CTL-22C	VHF COMM Control	Collins	Repair
822-1120-004	CTL-22C	VHF COMM Control	Collins	Repair
822-1120-005	CTL-22C	VHF COMM Control	Collins	Repair
822-1120-006	CTL-22C	VHF COMM Control	Collins	Repair
822-1120-007	CTL-22C	VHF COMM Control	Collins	Repair
822-1120-008	CTL-22C	VHF COMM Control	Collins	Repair
822-1120-009	CTL-22C	VHF COMM Control	Collins	Repair
822-1120-010	CTL-22C	VHF COMM Control	Collins	Repair
822-1120-011	CTL-22C	VHF COMM Control	Collins	Repair

Part Number	Model	Description	Manufacturer	Capability
822-1120-012	CTL-22C	VHF COMM Control	Collins	Repair
822-1120-013	CTL-22C	VHF COMM Control	Collins	Repair
822-1120-014	CTL-22C	VHF COMM Control	Collins	Repair
822-1120-015	CTL-22C	VHF COMM Control	Collins	Repair
822-1120-016	CTL-22C	VHF COMM Control	Collins	Repair
8-284-01	76450-01019-101	Tone Generator/Buffer Amplifier	ELDEC	Repair
843772-103	76550-01001-103	Caution/Advisory Panel	Teledyne	Repair
843772-149	76550-01001-149	Caution/Advisory Panel	Teledyne	Repair
850096-501	5000B-22	Attitude Gyro	Aero Commander	Repair
850202-BSC	1234T100	Turn & Slip Indicator	Aero Commander	Repair
8502C-3	-	Airspeed Indicator	Aero Mechanism	Repair
8502C-S20LW	-	Airspeed Indicator, Lighted	Aero Mechanism	Repair
8502C-SLM20LW	-	Airspeed Indicator, Lighted	Aero Mechanism	Repair
8503-S20LW	-	Altimeter (-1k-20k ft, in.Hg, Lighted)	Aero Mechanism	Repair
8503-S20LW-5V	-	Altimeter (-1k-20k ft, in.Hg, Lighted)	Aero Mechanism	Repair
851858-1	76550-00915-102	Master Warning Panel	Teledyne	Repair
868.541-910	AR4201	VHF Transceiver	Becker	Repair
874.361-921	AS3100-(12)-08	Audio Panel	Becker	Repair
879.101-921	AS3100-(12N)-09	Audio Panel	Becker	Repair
89000007-000001	KT74	Transponder	Bendix/King	Test/Recert
89000007-000002	KT74	Transponder	Honeywell	Test/Recert
892121-0350-P	209-075-395-1	Fire Detection Control Unit	Kidde	Test/Recert
892121-0350-P	209-075-395-001	Fire Detection Control Unit	Kidde	Test/Recert
892121-0350-R	-	Fire Detection Control Unit	Kidde	Test/Recert
893.927-921	AS3100-(12)-11	Audio Panel	Becker	Repair
8DJ131AAB1	-	Triple Tachometer	General Electric	Repair
8DJ131AAG1	-	Triple Tachometer	Ametek/GE	Repair
8DJ131AAG2	-	Triple Tachometer	Ametek/GE	Repair
8DJ131AAJ1	-	Triple Tachometer	Ametek/GE	Repair
8DJ131AAT2	-	Triple Tachometer	Ametek/GE	Repair
8DJ131LAE1	-	Triple Tachometer	Ametek/GE	Repair
8DJ131LAF2	-	Triple Tachometer	Ametek/GE	Repair
8DJ131LAN1	-	Triple Tachometer	Ametek/GE	Repair
8DJ131LAV1	-	Triple Tachometer	Ametek/GE	Repair
8DJ131LAW1	-	Triple Tachometer	Ametek/GE	Repair
8DJ131LAZ1	-	Triple Tachometer	Ametek/GE	Repair
8DJ131LBA1	-	Triple Tachometer	Ametek/GE	Repair
8DJ131LBK2	-	Triple Tachometer	Ametek/GE	Repair
8DJ131LBT2	-	Triple Tachometer	Ametek/GE	Repair
8DJ150FAC1	-	Dual Tachometer	Ametek/GE	Repair
8DJ150FAD1	-	Dual Tachometer	Ametek/GE	Repair
8DJ150FAE1	-	Dual Tachometer	Ametek/GE	Repair
8DJ150FAF1	-	Dual Tachometer	Ametek/GE	Repair
8DJ150FAH1	-	Dual Tachometer	Ametek/GE	Repair
8DJ150FAK1	-	Dual Tachometer	Ametek/GE	Repair
8DJ150LAC1	-	Dual Tachometer	Ametek/GE	Repair
8DJ150LAD1	-	Dual Tachometer	Ametek/GE	Repair
8DJ150LAE1	-	Dual Tachometer	Ametek/GE	Repair
8DJ150WAA1	-	Dual Tachometer	Ametek/GE	Repair
8DJ150WAC1	214-075-221-3	Dual Tachometer	Ametek/GE	Repair
8DJ150WAC1	214-075-221-003	Dual Tachometer	Ametek/GE	Repair
8DJ150WAD1	206-075-681-101	Dual Tachometer	Ametek/GE	Repair
8DJ150WAE1	206-075-681-3	Dual Tachometer	Ametek/GE	Repair
8DJ150WAE1	206-075-681-003	Dual Tachometer	Ametek/GE	Repair
8DJ150WAF1	206-075-681-1	Dual Tachometer	Ametek/GE	Repair
8DJ150WAF1	206-075-681-001	Dual Tachometer	Ametek/GE	Repair
8DJ150WAG1	-	Dual Tachometer	Ametek/GE	Repair
8DJ150WAH1	206-075-681-105	Dual Tachometer	Ametek/GE	Repair
8DJ81AAA1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81AAB1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81AAC1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81BAA1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81BLB4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81BLC4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAA1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAA2	-	Tachometer Indicator	Ametek/GE	Repair

Part Number	Model	Description	Manufacturer	Capability
8DJ81CAA4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAB2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAC1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAC2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAE1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAE2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAF1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAF2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAH1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAH2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAK1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAK2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAL1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAM1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAM2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAN1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAN2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAN4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAS2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAX2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAY2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CAZ2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CBA2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CBB2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CBD1	-	Tachometer Indicator	General Electric	Repair
8DJ81CBD4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CBK2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CBX2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CCK2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CCL2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CCM2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CDC2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CDE2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CDH2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CDR4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CDS4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CDW4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CDX4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CDY2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CDY4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CDZ4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CER4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81CFA4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81FAA1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81FAA2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAA1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAA2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAA4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAB2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAC1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAC2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAD1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAD2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAE1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAE2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAK1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAK2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAN2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAT1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAT2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAV2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAW1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAW2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAX2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAY2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LAZ2	-	Tachometer Indicator	Ametek/GE	Repair

Part Number	Model	Description	Manufacturer	Capability
8DJ81LBC2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LBD2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LBE2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LBF2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LBH2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LBK2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LBL2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LBS2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LBT2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LBX2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LCB2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LCD2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LCF2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LCK2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LCP4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LCR4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LCT4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LSC4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LVA4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LVB4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LVF4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LVG4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LVL4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWA1	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWA2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWA4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWB2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWC2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWC4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWH2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWM2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWM2U	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWN2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWR2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWR4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWS2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWS4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWT2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWT4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWV2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWY2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWY4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWZ2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LWZ4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXC2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXD2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXE2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXF2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXF4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXG2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXG4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXH2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXH2U	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXH4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXK2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXK4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXL2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXM2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXN2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXP2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXT2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXT4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXV2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXW2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXY2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LXZ2	-	Tachometer Indicator	Ametek/GE	Repair

Part Number	Model	Description	Manufacturer	Capability
8DJ81LYA2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LYB2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LYC2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LYP2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LYP4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LYT2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LYT2U	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LYT4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LYV2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LYV4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LYW2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LYX2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LYX4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LYZ2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LZB2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LZC2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LZC4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LZE2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LZE4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LZF2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81LZF4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WAG2	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WAG4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WAL4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WAP4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WAY4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WBA4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WBB4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WBC4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WBD4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WBF4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WBG4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WBL4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WBM4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WBS4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WBT4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WCF4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WCG4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WCR4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WCS4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WCT4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WCW4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WCX4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WDK4	-	Tachometer Indicator	Ametek/GE	Repair
8DJ81WDL4	-	Tachometer Indicator	Ametek/GE	Repair
9009-1016	-	Dual Temp & Pressure Indicator	INSCO	Repair
9009-1018	-	Dual Temp & Pressure Indicator	INSCO	Repair
9009-3003	206-075-187-1	Dual Temp & Pressure Indicator	INSCO	Repair
9009-3003	206-075-187-001	Dual Temp & Pressure Indicator	INSCO	Repair
9009-3004	206-075-188-1	Dual Temp & Pressure Indicator	INSCO	Repair
9009-3004	206-075-188-001	Dual Temp & Pressure Indicator	INSCO	Repair
9009-3009	-	Dual Temp & Pressure Indicator	INSCO	Repair
9009-3010	206-075-188-3	Dual Temp & Pressure Indicator	INSCO	Repair
9009-3010	206-075-188-003	Dual Temp & Pressure Indicator	INSCO	Repair
9009-3013	206-075-188-5	Dual Temp & Pressure Indicator	INSCO	Repair
9009-3013	206-075-188-005	Dual Temp & Pressure Indicator	INSCO	Repair
9009-3028	-	Dual Temp & Pressure Indicator	INSCO	Repair
9009-3029	-	Dual Temp & Pressure Indicator	INSCO	Repair
921012-1	TFM-138	VHF FM Transceiver	Technisonic	Repair
921012-1(Option B)	TFM-138B	VHF FM Transceiver	Technisonic	Repair
921012-2	TFM-138	VHF FM Transceiver	Technisonic	Repair
921012-2(Option B)	TFM-138B	VHF FM Transceiver	Technisonic	Repair
930-500-25-1	109-0811-46	Controllable Searchlight	Luminator	Repair
930-500-25-1	099-800-003	Controllable Searchlight	Luminator	Repair
93A055-00	A55	CVR Microphone	L3Harris	Repair
93A055-03	A55-3	CVR Microphone	L3Harris	Repair

Part Number	Model	Description	Manufacturer	Capability
93A055-10	A55B	CVR Microphone	L3Harris	Repair
93A055-20	A55B	CVR Microphone	L3Harris	Repair
93A055-30	A55B	CVR Microphone	L3Harris	Repair
93A055-40	A55B	CVR Microphone	L3Harris	Repair
93A055-45	A55B	CVR Microphone	L3Harris	Repair
93A055-50	A55B	CVR Microphone	L3Harris	Repair
93A055-55	A55B	CVR Microphone	L3Harris	Repair
93A055-60	A55B	CVR Microphone	L3Harris	Repair
93A055-65	A55B	CVR Microphone	L3Harris	Repair
93A055-66	A55B	CVR Microphone	L3Harris	Repair
93A055-67	A55B	CVR Microphone	L3Harris	Repair
93A055-95	A55B	CVR Microphone	L3Harris	Repair
93A150-20	A150	CVR Control Unit	L3Harris	Repair
93A151-00	A151	CVR Control Unit	L3Harris	Repair
93A151-01	A151-1	CVR Control Unit	L3Harris	Repair
93A151-20	A151B	CVR Control Unit	L3Harris	Repair
93A151-30	A151B	CVR Control Unit	L3Harris	Repair
93A151-40	A151B	CVR Control Unit	L3Harris	Repair
93A151-50	A151B	CVR Control Unit	L3Harris	Repair
93A152-00	A152	CVR Control Unit	L3Harris	Repair
93A152-01	A152-1	CVR Control Unit	L3Harris	Repair
93A152-02	A152-2	CVR Control Unit	L3Harris	Repair
93A152-04	A152-4	CVR Control Unit	L3Harris	Repair
93A152-20	A152B	CVR Control Unit	L3Harris	Repair
93A152-25	A152B	CVR Control Unit	L3Harris	Repair
93A152-30	A152B	CVR Control Unit	L3Harris	Repair
93A152-35	A152B	CVR Control Unit	L3Harris	Repair
93A152-40	A152B	CVR Control Unit	L3Harris	Repair
93A152-50	A152B	CVR Control Unit	L3Harris	Repair
93A152-60	A152B	CVR Control Unit	L3Harris	Repair
93A152-70	A152B	CVR Control Unit	L3Harris	Repair
941059-1	TFM-403	UHF/FM Transceiver	Technisonic	Repair
941059-1 (5V)	TFM-403	UHF/FM Transceiver	Technisonic	Repair
941059-2	TFM-403	UHF/FM Transceiver	Technisonic	Repair
941059-2 (5V)	TFM-403	UHF/FM Transceiver	Technisonic	Repair
9560N.558	-	Turn & Slip Indicator	United Instruments	Repair
9560N.559	-	Turn & Slip Indicator, Lighted	United Instruments	Repair
9560N.560	-	Turn & Slip Indicator, Lighted	United Instruments	Repair
9560N.561	-	Turn & Slip Indicator, Lighted	United Instruments	Repair
9560N.562	-	Turn & Slip Indicator, Lighted	United Instruments	Repair
9561N.563	-	Turn & Slip Indicator	United Instruments	Repair
9561N.564	-	Turn & Slip Indicator, Lighted	United Instruments	Repair
9561N.565	-	Turn & Slip Indicator, Lighted	United Instruments	Repair
9561N.566	-	Turn & Slip Indicator, Lighted	United Instruments	Repair
9561N.567	-	Turn & Slip Indicator, Lighted	United Instruments	Repair
9562N.568	-	Turn & Slip Indicator	United Instruments	Repair
9562N.569	-	Turn & Slip Indicator, Lighted	United Instruments	Repair
9562N.570	-	Turn & Slip Indicator, Lighted	United Instruments	Repair
9562N.571	-	Turn & Slip Indicator, Lighted	United Instruments	Repair
9562N.572	-	Turn & Slip Indicator, Lighted	United Instruments	Repair
961068-1	A710	Audio Control Panel	Technisonic	Repair
961068-2	A710	Audio Control Panel	Technisonic	Repair
961068-3	A710	Audio Control Panel	Technisonic	Repair
961068-4	A710	Audio Control Panel	Technisonic	Repair
961068-5	A710	Audio Control Panel	Technisonic	Repair
961068-6	A710	Audio Control Panel	Technisonic	Repair
961068-7	A710	Audio Control Panel	Technisonic	Repair
961068-8	A710	Audio Control Panel	Technisonic	Repair
961072-1	A711	Audio Control Panel	Technisonic	Repair
961072-2	A711	Audio Control Panel	Technisonic	Repair
961072-3	A711	Audio Control Panel	Technisonic	Repair
961072-4	A711	Audio Control Panel	Technisonic	Repair
961072-5	A711	Audio Control Panel	Technisonic	Repair
961072-6	A711	Audio Control Panel	Technisonic	Repair
961072-7	A711	Audio Control Panel	Technisonic	Repair
961072-8	A711	Audio Control Panel	Technisonic	Repair

Part Number	Model	Description	Manufacturer	Capability
961082-1	TFM-30	VHF/FM Transceiver (Low Band)	Technisonic	Repair
961082-1 (5V)	TFM-30	VHF/FM Transceiver (Low Band)	Technisonic	Repair
961082-2	TFM-30	VHF/FM Transceiver (Low Band)	Technisonic	Repair
961082-2 (5V)	TFM-30	VHF/FM Transceiver (Low Band)	Technisonic	Repair
96-380039	5000B-3	Attitude Gyro	Beechcraft	Repair
96-380047-1	5000B-28	Attitude Gyro, Lighted	Beechcraft	Repair
971083-1	TFM-500	VHF/UHF FM Transceiver	Technisonic	Repair
971083-1 (5V)	TFM-500	VHF/UHF FM Transceiver	Technisonic	Repair
971083-3	TFM-500	VHF/UHF FM Transceiver	Technisonic	Repair
971083-3 (5V)	TFM-500	VHF/UHF FM Transceiver	Technisonic	Repair
980-6115-001	-	Remote Microphone	Honeywell	Repair
980-6116-001	-	Microphone Monitor	Honeywell	Repair
980-6116-002	-	Microphone Monitor	Honeywell	Repair
980-6116-003	-	Microphone Monitor	Honeywell	Repair
980-6116-004	-	Microphone Monitor	Honeywell	Repair
980-6116-005	-	Microphone Monitor	Honeywell	Repair
980-6116-006	-	Microphone Monitor	Honeywell	Repair
980-6117-001	-	Microphone Monitor	Honeywell	Repair
980-6117-002	-	Microphone Monitor	Honeywell	Repair
980-6117-003	-	Microphone Monitor	Honeywell	Repair
980-6117-004	-	Microphone Monitor	Honeywell	Repair
980-6117-005	-	Microphone Monitor	Honeywell	Repair
980-6117-006	-	Microphone Monitor	Honeywell	Repair
980-6118-001	-	Preamplifier Module	Honeywell	Repair
9807-56	212-070-182-1	Hydraulic Pressure Indicator	Clifton Precision	Repair
9807-56	212-070-182-001	Hydraulic Pressure Indicator	Clifton Precision	Repair
981087-1	TDFM-136	VHF FM Transceiver	Technisonic	Repair
981087-1 (5V)	TDFM-136	VHF FM Transceiver	Technisonic	Repair
981087-2	TDFM-136	VHF FM Transceiver	Technisonic	Repair
981087-2 (5V)	TDFM-136	VHF FM Transceiver	Technisonic	Repair
9813-25-05	212-070-160-5	Dual Torque Indicator	Clifton	Repair
9813-25-05	212-070-160-121FM	Dual Torque Indicator	Clifton	Repair
9813-25-05	212-070-160-005	Dual Torque Indicator	Clifton	Repair
9813-25-07	212-070-160-7	Dual Torque Indicator	Clifton	Repair
9813-25-07	212-070-160-123FM	Dual Torque Indicator	Clifton	Repair
9813-25-07	212-070-160-007	Dual Torque Indicator	Clifton	Repair
9813-25-12	-	Dual Torque Indicator	Clifton	Repair
9813-25-13	-	Dual Torque Indicator	Clifton	Repair
9813-25-15	412-075-008-101	Dual Torque Indicator	Clifton	Repair
9813-25-16	-	Dual Torque Indicator	Clifton	Repair
9813-25-17	212-070-160-129FM	Dual Torque Indicator	Clifton	Repair
9813-25-17	212-070-160-101	Dual Torque Indicator	Clifton	Repair
9813-25-18	-	Dual Torque Indicator	Clifton	Repair
9813-25-19	-	Dual Torque Indicator	Clifton	Repair
9813-25-21	412-075-008-111	Dual Torque Indicator	Clifton	Repair
99002-3	5000B-9	Attitude Gyro	Piper	Repair
99003-3	4000B-9	Directional Gyro	Piper	Repair
990-3138-000	M1090	CVR Adapter	Honeywell	Repair
990-3342-013	M1045-J763-ETW3	Audio Panel	Baker Electronics	Repair
990-3342-015	M1045-J763-ESG3	Audio Panel	Baker Electronics	Repair
990-3342-027	M1045-J763-ETX3	Audio Panel	Baker Electronics	Repair
990-3342-028	M1045-J702-ESC3	Audio Panel	Baker Electronics	Repair
991095-1	TFM-550	VHF/VLO/UHF Multiband FM Transceiver	Technisonic	Repair
991095-1 (5V)	TFM-550	VHF/VLO/UHF Multiband FM Transceiver	Technisonic	Repair
991095-1 (5V) NV	TFM-550	VHF/VLO/UHF Multiband FM Transceiver	Technisonic	Repair
991095-1 NV	TFM-550	VHF/VLO/UHF Multiband FM Transceiver	Technisonic	Repair
991095-2	TFM-550	VHF/VLO/UHF Multiband FM Transceiver	Technisonic	Repair
991095-2 (5V)	TFM-550	VHF/VLO/UHF Multiband FM Transceiver	Technisonic	Repair
A2850-1	-	Rate Gyroscope	RC Allen	Repair
A2850-5	-	Rate Gyroscope	RC Allen	Repair
A301-61A	-	Audio Panel	Andrea	Repair
A301-61ACR	-	Audio Panel w/ CVR Output	Andrea	Repair
A301-6R	212-077-200-3	Audio Panel	Andrea	Repair
A301-6R	212-077-200-003	Audio Panel	Andrea	Repair
A301-6W	212-077-200-1	Audio Panel	Andrea	Repair
A301-6W	212-077-200-001	Audio Panel	Andrea	Repair

Part Number	Model	Description	Manufacturer	Capability
A301-6WCR	212-077-200-105	Audio Panel w/ CVR Output	Andrea	Repair
A301-6WCVR	212-077-200-105	Audio Panel w/ CVR Output	Andrea	Repair
A3-06-2749-1	ELT 1000	Emergency Locator Transmitter	Artex	Test/Recert
A3-06-2796-8	ELT 3000	ELT	Artex	Test/Recert
A3-06-2796-9	ELT 3000 HM	ELT	Artex	Test/Recert
A3-06-2880	ELT 345	Emergency Locator Transmitter	Artex	Test/Recert
A3-06-3005-1	ELT 4000	Emergency Locator Transmitter	Artex	Test/Recert
A-321600-1A	5000B-57	Attitude Gyro	R&K Engineering	Repair
A-321700-1A	4000B-39	Directional Gyro	R&K Engineering	Repair
A35-AAU-8A/A	-	Altimeter (-1k-35k ft)	Aerosonic	Repair
A35MA	-	Altimeter (-1k-35k ft)	Aerosonic	Repair
A35-MA-10-L	-	Altimeter (-1k-35k ft)	Aerosonic	Repair
A35-MA-10-L1	-	Altimeter (-1k-35k ft)	Aerosonic	Repair
A35-MA-10-L2	-	Altimeter (-1k-35k ft)	Aerosonic	Repair
A4503M8-1	S6156-61550-002	Landing Gear Control	Eaton	Repair
A50-MA-3	-	Altimeter (-1k-50k ft)	Aerosonic	Repair
A50-MA-4	-	Altimeter (-1k-50k ft)	Aerosonic	Repair
A8/A-10-3	-	Altimeter (-1k-50k ft)	Aerosonic	Repair
A8/A-10-4	-	Altimeter (-1k-50k ft)	Aerosonic	Repair
A80-AAU-7A/A	-	Altimeter (-1k-80k ft)	Aerosonic	Repair
A80-AAU-7A/A-110	-	Altimeter (-1k-50k ft)	Aerosonic	Repair
A80-AAU-7A/A-20	-	Altimeter (-1k-80k ft)	Aerosonic	Repair
A80-AAU-8A/A	-	Altimeter (-1k-80k ft)	Aerosonic	Repair
AA12-001	-	Audio Panel	NAT	Repair
AA12-002	-	Audio Panel	NAT	Repair
AA12-003	-	Audio Panel	NAT	Repair
AA12-004	-	Audio Panel	NAT	Repair
AA12-010	-	Audio Panel	NAT	Repair
AA34-200	-	Radio Interface Unit	NAT	Repair
AA34-300	-	Radio Interface Unit	NAT	Repair
AA34-301	-	Radio Interface Unit	NAT	Repair
AA38-300	-	Local ICS Loop	NAT	Repair
AA38-301	-	Local ICS Loop	NAT	Repair
AA80-001	-	InterVOX Interconnect	NAT	Repair
AA80-020	-	InterVOX Interconnect	NAT	Repair
AA80-060	-	InterVOX Interconnect	NAT	Repair
AA80-062	-	InterVOX Interconnect	NAT	Repair
AA95-210	-	Audio Control Panel	NAT	Repair
AA95-221	-	Audio Control Panel	NAT	Repair
AA95-452	-	Audio Control Panel	NAT	Repair
AA95-460	-	Audio Control Panel	NAT	Repair
AA95-462	-	Audio Control Panel	NAT	Repair
AA95-463	-	Audio Control Panel	NAT	Repair
AA95-464	-	Audio Control Panel	NAT	Repair
AA95-465	-	Audio Control Panel	NAT	Repair
AA95-472	-	Audio Control Panel	NAT	Repair
AA95-473	-	Audio Control Panel	NAT	Repair
AA95-488	-	Audio Control Panel	NAT	Repair
AA95-490	-	Audio Control Panel	NAT	Repair
AA95-498	-	Audio Control Panel	NAT	Repair
AA95-512	-	Audio Control Panel	NAT	Repair
AA95-557	-	Audio Control Panel	NAT	Repair
AA95-705	-	Audio Control Panel	NAT	Repair
AA95-706	-	Audio Control Panel	NAT	Repair
AA95-714	-	Audio Control Panel	NAT	Repair
AA95-715	-	Audio Control Panel	NAT	Repair
AA95-725	-	Audio Control Panel	NAT	Repair
AA95-728	-	Audio Control Panel	NAT	Repair
AA95-729	-	Audio Control Panel	NAT	Repair
AA95-759	-	Audio Control Panel	NAT	Repair
AA95-781	-	Audio Control Panel	NAT	Repair
AA95-857	-	Audio Control Panel	NAT	Repair
AA95-880	-	Audio Control Panel	NAT	Repair
AA95-894	-	Audio Control Panel	NAT	Repair
AA95-912N	-	Audio Control Panel	NAT	Repair
AA95-987	-	Audio Control Panel	NAT	Repair

Part Number	Model	Description	Manufacturer	Capability
AA95-MVH2	-	Audio Control Panel	NAT	Repair
AA95-RPCO	-	Audio Control Panel	NAT	Repair
AA96-001	-	Audio Control Panel	NAT	Repair
AA96-001N	-	Audio Control Panel	NAT	Repair
AA96-003	-	Audio Control Panel	NAT	Repair
AA96-400	-	Audio Control Panel	NAT	Repair
AA96-401	-	Audio Control Panel	NAT	Repair
AA96-RPD	-	Audio Control Panel	NAT	Repair
AA97-402	-	Audio Control Panel	NAT	Repair
AA97-402N	-	Audio Control Panel	NAT	Repair
AA97-426	-	Audio Control Panel	NAT	Repair
AA97-427	-	Audio Control Panel	NAT	Repair
AA97-427NB	-	Audio Control Panel	NAT	Repair
AA97-HGP1	-	Audio Control Panel	NAT	Repair
AA97-HGP2	-	Audio Control Panel	NAT	Repair
AA97-HGP3	-	Audio Control Panel	NAT	Repair
AA97-MSP	-	Audio Control Panel	NAT	Repair
AC-131	-	Airspeed Indicator	Karnish	Repair
AC-131A	-	Airspeed Indicator	Karnish	Repair
AK-350	-	Altitude Encoder	Ameri-King	Test/Recert
AK-450	-	Emergency Locator Transmitter	Ameri-King	Test/Recert
AMS42	-	Audio Panel, Dual-Channel	NAT	Repair
AMS42F	-	Audio Panel, Dual-Channel	NAT	Repair
AMS42FT	-	Audio Panel, Dual-Channel	NAT	Repair
AMS42T	-	Audio Panel, Dual-Channel	NAT	Repair
AMS43	-	Audio Panel, Single Channel	NAT	Repair
AMS43H	-	Audio Panel, Single Channel	NAT	Repair
AMS43TSO	-	Audio Panel, Single Channel	NAT	Repair
AMS44	-	Audio Panel, Dual-Channel	NAT	Repair
AMS44T	-	Audio Panel, Dual-Channel	NAT	Repair
AN5770-1	-	Manifold Pressure Gauge	US Gauge	Test/Recert
AN5770-1A	-	Manifold Pressure Gauge	US Gauge	Test/Recert
AR2008/25	COMM 2000	VHF Transceiver	Becker	Repair
AR2009	COMM 2000	VHF Transceiver	Becker	Repair
AR2009/25	COMM 2000	VHF Transceiver	Becker	Repair
AR2010	COMM 2000	VHF Transceiver	Becker	Repair
AR2010/25	COMM 2000	VHF Transceiver	Becker	Repair
AR2011	COMM 2000	VHF Transceiver	Becker	Repair
AR2011/25	COMM 2000	VHF Transceiver	Becker	Repair
AR3202-01-110	AR3202-(1)-110	VHF Transceiver	Becker	Repair
ASH584-1	-	Static Inverter	Leland	Repair
ASH584-2	-	Static Inverter	Leland	Repair
ASH584-3	-	Static Inverter	Leland	Repair
ASH584-4	-	Static Inverter	Leland	Repair
ASH584-5	-	Static Inverter	Leland	Repair
ASH584-6	-	Static Inverter	Leland	Repair
AT150	AT150 TSO	Transponder	Narco	Repair
AT-205-2	-	Fuel Totalizer	Foxboro	Repair
AT-205-3	-	Fuel Totalizer	Foxboro	Repair
AT-205-5	-	Fuel Totalizer	Foxboro	Repair
AT-205-8	-	Fuel Totalizer	Foxboro	Repair
AT-206-1	-	Fuel Totalizer	Foxboro	Repair
AT-206-2	-	Fuel Totalizer	Foxboro	Repair
AT-206-3	-	Fuel Totalizer	Foxboro	Repair
AT50	-	Transponder	Narco	Repair
AT50 TSO	-	Transponder	Narco	Repair
AT50A	AT50A TSO	Transponder	Narco	Repair
ATC4401-1-175	ATC4401-1	ATC Transponder	Becker	Repair
ATC4401-1-250	ATC4401-1	ATC Transponder	Becker	Repair
AW1842AR01	369A4512	Torque Indicator	Ametek	Test/Recert
AW1842AR02	369H4526	Torque Indicator	Ametek	Test/Recert
AW1842AR04	369H4526-7	Torque Indicator	Ametek	Test/Recert
AW1842AR05	369H4526-1	Torque Indicator	Ametek	Test/Recert
AW1842AR07	369H4526-11	Torque Indicator	Ametek	Test/Recert
AW2837AB01	C661062-0101	Airspeed Indicator	Ametek	Test/Recert
AW2837AB02	C661062-0102	Airspeed Indicator	Ametek	Test/Recert

Part Number	Model	Description	Manufacturer	Capability
AW2837AB03	-	Airspeed Indicator	Ametek	Test/Recert
AW2837AB04	-	Airspeed Indicator	Ametek	Test/Recert
AW2837AB05	C661063-0104	Airspeed Indicator	Ametek	Test/Recert
AW2837AC01	C661063-0101	Airspeed Indicator	Ametek	Test/Recert
AW2837AC02	C661063-0102	Airspeed Indicator	Ametek	Test/Recert
AW2837AC03	C661063-0103	Airspeed Indicator	Ametek	Test/Recert
AW2837AC06	C661063-0105	Airspeed Indicator	Ametek	Test/Recert
AW2837AC07	C661063-0106	Airspeed Indicator	Ametek	Test/Recert
AW2837AH01	14550-729-2	Airspeed Indicator	Ametek	Test/Recert
AW2837AJ01	-	Airspeed Indicator	Ametek	Test/Recert
B13-941.22.05.1.CW	-	Chronograph (3 Function, Round Case, 5V White)	Thommen	Repair
B13-944.22.00.0.A	-	Chronograph (3 Function, Round Case, Unlit)	Thommen	Repair
B13-944.22.28.2.A	704A47320011	Chronograph (3 Function, Round Case, 28V R/Wh)	Thommen	Repair
B13-944.32.05.1.CH	-	Chronograph (3 Function, ARINC Case, 5V White)	Thommen	Repair
B15-945.32.05.4.CD	-	Chronograph (2 Function, ARINC Case, 5V NVIS)	Thommen	Repair
B17.941.22.05.1.A	-	Chronograph (3 Function, Round Case, 5V White)	Thommen	Repair
B17-941.22.28.4.CR	-	Chronograph (3 Function, Round Case, 28V NVIS)	Thommen	Repair
B17-941.27.00.0.A	-	Chronograph (3 Function, Round Case, Unlit)	Thommen	Repair
B17-951.22.05.1.DG	-	Chronograph (3 Function, Round Case, 5V White)	Thommen	Repair
B17-951.22.05.4.AA	-	Chronograph (3 Function, Round Case, 5V NVIS)	Thommen	Repair
B17-952.22.05.3.A	-	Chronograph (3 Function, Round Case, 5V Red)	Thommen	Repair
B18-945.22.00.0.A	-	Chronograph (2 Function, Round Case, Unlit)	Thommen	Repair
B18-945.22.05.1.A	-	Chronograph (2 Function, Round Case, 5V White)	Thommen	Repair
B18-945.22.05.1.K	-	Chronograph (2 Function, Round Case, 5V White)	Thommen	Repair
B18-945.22.05.4.CR	-	Chronograph (2 Function, Round Case, 5V NVIS)	Thommen	Repair
B18-945.22.28.1.A	-	Chronograph (2 Function, Round Case, 28V White)	Thommen	Repair
B18-945.22.28.1.K	-	Chronograph (2 Function, Round Case, 28V White)	Thommen	Repair
B18-945.22.28.2.A	-	Chronograph (2 Function, Round Case, 28V R/Wh)	Thommen	Repair
B18-945.22.28.4.CR	-	Chronograph (2 Function, Round Case, 28V NVIS)	Thommen	Repair
B18-945.22.28.4.DN	-	Chronograph (2 Function, Round Case, 5V NVIS)	Thommen	Repair
B18-945.25.00.0.AH	-	Chronograph (2 Function, Round Case, Unlit)	Thommen	Repair
B18-945.32.28.1.AG	704A47320020	Chronograph (2 Function, ARINC Case, 28V White)	Thommen	Repair
B18-945.32.28.1.AJ	-	Chronograph (2 Function, ARINC Case, 28V White)	Thommen	Repair
B18-945.32.28.3.AG	-	Chronograph (2 Function, ARINC Case, 28V Red)	Thommen	Repair
B18-945.35.28.1.AF	-	Chronograph (2 Function, ARINC Case, 28V White)	Thommen	Repair
B18-945.35.28.1.AI	-	Chronograph (2 Function, ARINC Case, 28V White)	Thommen	Repair
B18-955.22.00.0.CL	-	Chronograph (2 Function, Round Case, Unlit)	Thommen	Repair
B18-955.22.00.0.CS	-	Chronograph (2 Function, Round Case, Unlit)	Thommen	Repair
B18-955.22.05.4.CG	-	Chronograph (2 Function, Round Case, 5V NVIS)	Thommen	Repair
B18-955.22.28.4.DC	-	Chronograph (2 Function, Round Case, 28V NVIS)	Thommen	Repair
B823-10	4300-2XX	Attitude Indicator	Robinson Helicopter	Repair
B823-12	4300-2XX	Attitude Indicator	Robinson Helicopter	Repair
B823-19	4300-2XX	Attitude Indicator	Robinson Helicopter	Repair
BH185R-154	-	Temperature Indicator	Howell	Repair
BH185R-154A	-	Temperature Indicator	Howell	Repair
BH185R-154B	-	Temperature Indicator	Howell	Repair
BH185R-154C	-	Temperature Indicator	Howell	Repair
BH185R-154D	-	Temperature Indicator	Howell	Repair
BJ1977A	-	Junction Box	TEAM	Repair
BJ1977B	-	Junction Box	TEAM	Repair
BJ1977C	-	Junction Box	TEAM	Repair
BJ1977D	-	Junction Box	TEAM	Repair
C2200-L4	-	Compass, Magnetic	Airpath	Repair
C2200-L4-1	-	Compass, Magnetic	Airpath	Repair
C2200-L4-1B	-	Compass, Magnetic	Airpath	Repair
C2200-L4-B	-	Compass, Magnetic	Airpath	Repair
C2300	-	Compass, Magnetic	Airpath	Repair
C2300-DL4	-	Compass, Magnetic	Airpath	Repair
C2300-DL4-1	-	Compass, Magnetic	Airpath	Repair
C2300-DL4-1B	-	Compass, Magnetic	Airpath	Repair
C2300-DL4-B	-	Compass, Magnetic	Airpath	Repair
C2300-DL4-CM-24	-	Compass, Magnetic	Airpath	Repair
C2300-DL4-CM-24B	-	Compass, Magnetic	Airpath	Repair
C2300-L4	-	Compass, Magnetic	Airpath	Repair
C2300-L4-24	-	Compass, Magnetic	Airpath	Repair
C2300-L4-24B	-	Compass, Magnetic	Airpath	Repair

Part Number	Model	Description	Manufacturer	Capability
C2300-L4-B	-	Compass, Magnetic	Airpath	Repair
C2350-DL4-CM	-	Compass, Magnetic	Airpath	Repair
C2350-DL4-CM-B	-	Compass, Magnetic	Airpath	Repair
C2350-DL4-CMi-B	-	Compass, Magnetic	Airpath	Repair
C2350-DL4-VF	-	Compass, Magnetic	Airpath	Repair
C2350-L4	-	Compass, Magnetic	Airpath	Repair
C2350-L4-24	-	Compass, Magnetic	Airpath	Repair
C2350-L4-M23	-	Compass, Magnetic	Airpath	Repair
C2350-L4VM-23	-	Compass, Magnetic	Airpath	Repair
C2400-L4P	-	Compass, Magnetic	Airpath	Repair
C2400-L4P-1	-	Compass, Magnetic	Airpath	Repair
C2400-L4P-1A	-	Compass, Magnetic	Airpath	Repair
C2400-L4P-1AB	-	Compass, Magnetic	Airpath	Repair
C2400-L4P-1B	-	Compass, Magnetic	Airpath	Repair
C2400-L4P-2	-	Compass, Magnetic	Airpath	Repair
C2400-L4P-24	-	Compass, Magnetic	Airpath	Repair
C2400-L4P-24B	-	Compass, Magnetic	Airpath	Repair
C2400-L4P-2A	-	Compass, Magnetic	Airpath	Repair
C2400-L4P-5B	-	Compass, Magnetic	Airpath	Repair
C2400-L4P-B	-	Compass, Magnetic	Airpath	Repair
C2400-L4T-1BB	-	Compass, Magnetic	Airpath	Repair
C2400-L4V2W-5B	C660501-0301	Compass, Magnetic	Airpath	Repair
C2400-L4VFM-12	-	Compass, Magnetic	Airpath	Repair
C2400-L4VFM-12B	-	Compass, Magnetic	Airpath	Repair
C2400-L4VFM-24	-	Compass, Magnetic	Airpath	Repair
C2400-L4VFM-24B	-	Compass, Magnetic	Airpath	Repair
C2400-L4VM-12	-	Compass, Magnetic	Airpath	Repair
C2400-L4VM-12B	-	Compass, Magnetic	Airpath	Repair
C2400-L4VM-24	-	Compass, Magnetic	Airpath	Repair
C2400-L4VM-24B	-	Compass, Magnetic	Airpath	Repair
C2400-L4VT	-	Compass, Magnetic	Airpath	Repair
C2400-L4VT-1A	-	Compass, Magnetic	Airpath	Repair
C2400-L4VT-1B	-	Compass, Magnetic	Airpath	Repair
C2400-L4VT-1BB	-	Compass, Magnetic	Airpath	Repair
C2400-L4VT-24	-	Compass, Magnetic	Airpath	Repair
C2400-L4VT-B	-	Compass, Magnetic	Airpath	Repair
C-4000	-	ELT, Pointer Sentry	Pointer	Test/Recert
C661001-0502	5000F	Attitude Gyro	Cessna	Repair
C661001-0512	5000F-1	Attitude Gyro	Cessna	Repair
C661002-0301	4000B-2	Directional Gyro	Cessna	Repair
C661002-0302	4000B-1	Directional Gyro	Cessna	Repair
C661002-0506	RCA11A-2	Directional Gyro	RC Allen	Repair
C661003-0506	RCA82A-11	Turn Rate Indicator	Cessna	Repair
C661003-0506	1394T100 Z	Turn Coordinator	Cessna	Repair
C661003-0507	RCA82A-4	Turn Rate Indicator	Cessna	Repair
C661004-0101	1234T100	Turn & Slip Indicator, Lighted	Cessna	Repair
C661010-0202	-	Airspeed Indicator	Sigma-Tek	Repair
C661030-0301	RCA56-8	Turn & Bank Indicator	RC Allen	Repair
C661030-0301	1234T100	Turn & Slip Indicator	Cessna	Repair
C661031-0101	1234T100	Turn & Slip Indicator	Cessna	Repair
C661033-0101	1234T100	Turn & Slip Indicator	Cessna	Repair
C661052-0101	RCA15BK-7	Directional Gyro	RC Allen	Repair
C661053-0101	RCA11A-14	Directional Gyro	RC Allen	Repair
C661053-0101	4000B-6	Directional Gyro	Cessna	Repair
C661053-0102	4000B-20	Directional Gyro	Cessna	Repair
C661054-0101	4000B-11	Directional Gyro, Lighted	Cessna	Repair
C661055-0101	5000F-2	Attitude Gyro	Cessna	Repair
C661055-0102	5000F-3	Attitude Gyro	Cessna	Repair
C661055-0103	5000F-8	Attitude Gyro	Cessna	Repair
C661055-0104	5000F-12	Attitude Gyro	Cessna	Repair
C661055-0105	5000F-13	Attitude Gyro	Cessna	Repair
C661056-0101	5000F-5	Attitude Gyro, Lighted	Cessna	Repair
C661056-0201	5000F-7	Attitude Gyro, Lighted	Cessna	Repair
C661056-0202	5000F-10	Attitude Gyro, Lighted	Cessna	Repair
C661056-0203	5000F-11	Attitude Gyro, Lighted	Cessna	Repair
C661075-0101	200-5C	Directional Gyro	Cessna	Repair

Part Number	Model	Description	Manufacturer	Capability
C661075-0103	RCA11A-12	Directional Gyro	RC Allen	Repair
C661075-0104	4000B-12	Directional Gyro	Cessna	Repair
C661075-0107	4000HR	Directional Gyro	Sigma-Tek	Repair
C661076-0101	5000F-6	Attitude Gyro	Cessna	Repair
C661076-0106	5000F-9	Attitude Gyro	Cessna	Repair
C661076-0108	5000F-14	Attitude Gyro	Cessna	Repair
C661077-0101	4000B-32	Directional Gyro, Lighted	Cessna	Repair
CM2639-1	-	Compass, Magnetic	Airpath	Repair
CM2639-3	-	Compass, Magnetic	Airpath	Repair
CM2639-4	-	Compass, Magnetic	Airpath	Repair
CM2639-5	-	Compass, Magnetic	Airpath	Repair
COM120	COM 120 TSO	VHF Transceiver	Narco	Repair
COM120/20	COM 120/20 TSO	VHF Transceiver	Narco	Repair
CP1766G	-	Audio Control Panel	TEAM	Repair
CP1766GB01	-	Audio Control Panel	TEAM	Repair
CP1766GB02	-	Audio Control Panel	TEAM	Repair
CP1766H	-	Audio Control Panel	TEAM	Repair
CP1766J	-	Audio Control Panel	TEAM	Repair
CP1766K	-	Audio Control Panel	TEAM	Repair
CP1976A1	-	Audio Control Panel	TEAM	Repair
CP1976A2	-	Audio Control Panel	TEAM	Repair
CP1976AA01	-	Audio Control Panel	TEAM	Repair
CP1976AA02	-	Audio Control Panel	TEAM	Repair
CP1976AA03	-	Audio Control Panel	TEAM	Repair
CP1976B1	-	Audio Control Panel	TEAM	Repair
CP1976B2	-	Audio Control Panel	TEAM	Repair
CP1976C	-	Audio Control Panel	TEAM	Repair
CP1976DA02	-	Audio Control Panel	TEAM	Repair
CP1976EA01	-	Audio Control Panel	TEAM	Repair
CP1976EB01	-	Audio Control Panel	TEAM	Repair
CP1976FA01	-	Audio Control Panel	TEAM	Repair
CP1976FB01	-	Audio Control Panel	TEAM	Repair
CP1976GA01	-	Audio Control Panel	TEAM	Repair
D120-P2-T	-	Altitude Encoder (20k ft)	Trans-Cal	Test/Recert
D22061-04-004	-	Altimeter (-1k-80k ft, in.Hg)	Kollsman	Repair
D22061-04-010	-	Altimeter (-1k-80k ft, in.Hg)	Kollsman	Repair
D22061-22-010	-	Altimeter (-1k-80k ft, in.Hg)	Kollsman	Repair
DDL-OC119A	76450-01076-105	Dual Repeater Indicator	Ametek	Repair
DK100	-	Underwater Acoustic Beacon	Dukane Seacom	Test/Recert
DK120	-	Underwater Acoustic Beacon	Dukane Seacom	Test/Recert
DK120/90	-	Underwater Acoustic Beacon	Dukane Seacom	Test/Recert
DK130	-	Underwater Acoustic Beacon	Dukane Seacom	Test/Recert
DK140	-	Underwater Acoustic Beacon	Dukane Seacom	Test/Recert
DK290-11	-	Underwater Locating Device	Dukane Seacom	Test/Recert
DK290-12	-	Underwater Locating Device	Dukane Seacom	Test/Recert
DK290-13	-	Underwater Locating Device	Dukane Seacom	Test/Recert
DL404-109	412-075-010-111	Triple Tachometer	Diehl	Repair
DL404-7	212-070-108-103	Triple Tachometer	Diehl	Repair
DL412-55	212-075-037-105	Tachometer Indicator	Diehl	Repair
DL412-64	212-075-037-109	Tachometer Indicator	Diehl	Repair
DME890	-	DME Interrogator	Narco	Repair
E-04	-	Emergency Locator Transmitter	ACK Technologies	Test/Recert
EA5171-0100-CES	C661018-0100	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-0101-CES	C661060-0101	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-0102-CES	C661060-0102	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-0103-CES	C661060-0103	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-0104-CES	C661060-0104	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-0105-CES	C661060-0105	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-0106-CES	C661060-0106	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-0107-CES	C661060-0107	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-0108-CES	C661060-0108	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-0109-CES	C661060-0109	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-010-MAL	-	Airspeed Indicator (35-175 Knots)	Sigma-Tek	Repair
EA5171-0110-CES	C661060-0110	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-0111-CES	C661060-0111	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-0112-CES	C661060-0112	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
EA5171-0113-CES	C661060-0113	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-0114-CES	C661060-0114	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-011-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-012-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-013-MAL	-	Airspeed Indicator (35-175 Knots)	Sigma-Tek	Repair
EA5171-014-MAL	-	Airspeed Indicator (35-175 Knots)	Sigma-Tek	Repair
EA5171-015-MAL	-	Airspeed Indicator (35-175 Knots)	Sigma-Tek	Repair
EA5171-016-MAL	-	Airspeed Indicator (35-175 Knots)	Sigma-Tek	Repair
EA5171-017-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-01-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-01-ROB	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-02-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-0300-CES	C661018-0300	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-03-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-04-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-05-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-0600-CES	C661018-0600	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-06-MAL	-	Airspeed Indicator (35-175 Knots)	Sigma-Tek	Repair
EA5171-07-MAL	-	Airspeed Indicator (35-175 Knots)	Sigma-Tek	Repair
EA5171-08-MAL	-	Airspeed Indicator (35-175 Knots)	Sigma-Tek	Repair
EA5171-09-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-1	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-10	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-101-CES	S-1470-1	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-101-MON	820006-1	Airspeed Indicator	Sigma-Tek	Repair
EA5171-102-CES	S-1470-2	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-103-CES	S-1470-3	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-104-CES	S-1470-4	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-105-CES	S-1470-5	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-106-CES	S-1470-6	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-107-CES	S-1470-7	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-108-CES	S-1470-8	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-109-CES	S-1470-9	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-10-CES	C661064-0104	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5171-11	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-110-CES	S-1470-10	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-111-CES	S-1470-11	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-112-CES	S-1470-12	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-113-CES	S-1470-13	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-114-CES	S-1470-14	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-11-CES	C661064-0105	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5171-12	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-121-CES	S-1470-21	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-12-CES	C661064-0106	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5171-13	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-13-CES	C661064-0107	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5171-14	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-14-CES	C661064-0108	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5171-15	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-15-CES	C661064-0109	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5171-16	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-16-CES	C661064-0110	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5171-17	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-17-CES	C661064-0111	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5171-18	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-18-CES	C661064-0112	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5171-19	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-1-AC	-	Airspeed Indicator (40-180 MPH)	Sigma-Tek	Repair
EA5171-1-ACA	-	Airspeed Indicator (0-180 Knots)	Sigma-Tek	Repair
EA5171-1-BEL	-	Airspeed Indicator (40-180 MPH)	Sigma-Tek	Repair
EA5171-1-CES	C661010-1001	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-1-FRD	-	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5171-1L-AC	-	Airspeed Indicator (40-180 MPH, Lighted)	Sigma-Tek	Repair
EA5171-1L-BEL	-	Airspeed Indicator (40-180 MPH)	Sigma-Tek	Repair
EA5171-1L-MAL	-	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5171-1-MON	820216	Airspeed Indicator	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
EA5171-1-TAC	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-1-VAR	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-2	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-20	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-201-MON	820217	Airspeed Indicator	Sigma-Tek	Repair
EA5171-202-CES	S-1538-2	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-203-CES	S-1538N3	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-204-CES	S1538N4	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-205-CES	S-1538N5	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-21	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-22	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-23	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-24	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-25	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-26	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-27	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-28	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-29	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-2-AC	-	Airspeed Indicator (40-180 MPH)	Sigma-Tek	Repair
EA5171-2-ACA	-	Airspeed Indicator (0-180 Knots)	Sigma-Tek	Repair
EA5171-2-BEL	-	Airspeed Indicator (40-180 MPH)	Sigma-Tek	Repair
EA5171-2-CES	C661010-1002	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-2L	-	Airspeed Indicator (35-175 Knots)	Sigma-Tek	Repair
EA5171-2L-AC	-	Airspeed Indicator (40-180 MPH, Lighted)	Sigma-Tek	Repair
EA5171-2-MON	820216-501	Airspeed Indicator	Sigma-Tek	Repair
EA5171-3	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-3-AC	-	Airspeed Indicator (40-180 MPH)	Sigma-Tek	Repair
EA5171-3-BEL	-	Airspeed Indicator (40-180 MPH)	Sigma-Tek	Repair
EA5171-3-CES	C661010-1003	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-3L	-	Airspeed Indicator (35-175 Knots)	Sigma-Tek	Repair
EA5171-3L-AC	-	Airspeed Indicator (40-180 MPH, Lighted)	Sigma-Tek	Repair
EA5171-3-MON	820216-503	Airspeed Indicator	Sigma-Tek	Repair
EA5171-4	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-4-BEL	-	Airspeed Indicator (40-180 MPH)	Sigma-Tek	Repair
EA5171-4-CES	C661010-1004	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-4L-AC	-	Airspeed Indicator (40-180 MPH, Lighted)	Sigma-Tek	Repair
EA5171-4-MON	820296-501	Airspeed Indicator	Sigma-Tek	Repair
EA5171-5	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-5-BEC	169-380009-5	Airspeed Indicator	Sigma-Tek	Repair
EA5171-5-BEL	-	Airspeed Indicator (40-180 MPH)	Sigma-Tek	Repair
EA5171-5-CES	C661010-1005	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-5L-AC	-	Airspeed Indicator (40-180 MPH, Lighted)	Sigma-Tek	Repair
EA5171-5-MON	820296-503	Airspeed Indicator	Sigma-Tek	Repair
EA5171-6	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-6-CES	C661010-1006	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5171-7	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-7-CES	C661064-0101	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5171-8	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-8-CES	C661064-0102	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5171-9	-	Airspeed Indicator	Sigma-Tek	Repair
EA5171-9-CES	C661064-0103	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5172-01L-CES	C661064-L0221	Airspeed Indicator (35-210 Knots, Lighted)	Sigma-Tek	Repair
EA5172-0200-CES	C661020-0200	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5172-0201-CES	C661060-0201	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5172-0201-CES	C661020-0201	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5172-0202-CES	C661060-0202	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5172-0203-CES	C661060-0203	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5172-0204-CES	C661060-0204	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5172-0205-CES	C661060-0205	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5172-0206-CES	C661060-0206	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5172-0207-CES	C661060-0207	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5172-0208-CES	C661060-0208	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5172-0209-CES	C661060-0209	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5172-0210-CES	C661060-0210	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5172-02L-CES	C661064-L0238	Airspeed Indicator (35-210 Knots, Lighted)	Sigma-Tek	Repair
EA5172-03L-CES	C661064-L0239	Airspeed Indicator (35-210 Knots, Lighted)	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
EA5172-0701-CES	C661010-0701	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5172-1	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-10	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-101-AA	13-801016-1	Airspeed Indicator	Sigma-Tek	Repair
EA5172-101-CES	S1471N1	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-101-MON	820296-505	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5172-101-ROB	-	Airspeed Indicator (40-220 Knots)	Sigma-Tek	Repair
EA5172-101-SOC	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-102-AA	13-801016-2	Airspeed Indicator	Sigma-Tek	Repair
EA5172-102-CES	S1471N2	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-102-MON	820296-507	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5172-102-SOC	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-103-AA	13-801016-3	Airspeed Indicator	Sigma-Tek	Repair
EA5172-103-MON	820296-509	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5172-103-SOC	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-104-AA	13-801016-4	Airspeed Indicator	Sigma-Tek	Repair
EA5172-104-CES	S1471N4	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-104-MON	820296-511	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5172-105-AA	13-801016-5	Airspeed Indicator	Sigma-Tek	Repair
EA5172-106-AA	13-801016-6	Airspeed Indicator	Sigma-Tek	Repair
EA5172-106-CES	S1471N6	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-107-CES	S1471N7	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-108-CES	S1471N8	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-109-CES	S1471N9	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-10-BN	-	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-10-CES	C661064-0202	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-11	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-111-BEC	36-380015-11	Airspeed Indicator	Sigma-Tek	Repair
EA5172-111L-BEC	58-380038-11	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-113-BEC	36-380015-13	Airspeed Indicator	Sigma-Tek	Repair
EA5172-113L-BEC	58-380038-13	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-115-BEC	36-380015-15	Airspeed Indicator	Sigma-Tek	Repair
EA5172-11-BEC	35-380036-11	Airspeed Indicator	Sigma-Tek	Repair
EA5172-11-BN	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-11-CES	C661064-0203	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-12	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-12-BN	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-12-CES	C661064-0204	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-13	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-13-BEC	35-380036-13	Airspeed Indicator	Sigma-Tek	Repair
EA5172-13-BN	NB-09-1663	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-13-CES	C661064-0205	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-13L-BEC	58-380019-13	Airspeed Indicator (40-250 MPH, Lighted)	Sigma-Tek	Repair
EA5172-14-BEC	36-380033-1	Airspeed Indicator	Sigma-Tek	Repair
EA5172-14-BN	NB-09-2257-01	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-14-CES	C661064-0206	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-14L-BEC	36-380034-1	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-15-BEC	36-380033-3	Airspeed Indicator	Sigma-Tek	Repair
EA5172-15-BN	NB-09-1661	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-15-CES	C661064-0207	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-15L-BEC	36-380034-3	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-16-BEC	36-380033-5	Airspeed Indicator	Sigma-Tek	Repair
EA5172-16-BN	NB-09-1823	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-16-CES	C661064-0208	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-16L-BEC	36-380034-5	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-17-BEC	36-380033-9	Airspeed Indicator	Sigma-Tek	Repair
EA5172-17-CES	C661064-0209	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-17L-BEC	36-380046-3	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-18-CES	C661064-0210	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-18L-BEC	36-380046-5	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-19-CES	C661064-0211	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-1-AA	13-801013-1	Airspeed Indicator	Sigma-Tek	Repair
EA5172-1-AC	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-1-AER	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-1-ALA	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-1-BEL	-	Airspeed Indicator	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
EA5172-1-CES	C661010-0601	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-1-FAC	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-1L	-	Airspeed Indicator (30-220 Knots, Lighted)	Sigma-Tek	Repair
EA5172-1L-AC	-	Airspeed Indicator (40-250 MPH, Lighted)	Sigma-Tek	Repair
EA5172-1L-AER	-	Airspeed Indicator (40-220 Knots, Lighted)	Sigma-Tek	Repair
EA5172-1L-BEC	58-380019-1	Airspeed Indicator (40-250 MPH, Lighted)	Sigma-Tek	Repair
EA5172-1L-BEL	-	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-1L-FAC	-	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-1L-SAB	-	Airspeed Indicator (0-220 Knots, Lighted)	Sigma-Tek	Repair
EA5172-1-MON	820216-505	Airspeed Indicator (0-250 MPH)	Sigma-Tek	Repair
EA5172-1-PA	-	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-1-PIT	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-1-ROB	-	Airspeed Indicator (60-400 KM/HR)	Sigma-Tek	Repair
EA5172-1-SAB	6127276-041	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-1-VA	-	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5172-2	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-201-AA	7SCF005-1	Airspeed Indicator	Sigma-Tek	Repair
EA5172-202-CES	S1388-2	Airspeed Indicator (0-400 KM/HR)	Sigma-Tek	Repair
EA5172-20-CES	C661064-0212	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-21-CES	C661064-0213	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-22-CES	C661064-0214	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-23-CES	C661064-0215	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-24-CES	C661064-0216	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-25-CES	C661064-0217	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-26-CES	C661064-0218	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-27-CES	C661064-0219	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-28-CES	C661064-0220	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-29-CES	C661064-0221	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-2-AA	13-801013-2	Airspeed Indicator	Sigma-Tek	Repair
EA5172-2-BEL	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-2-BN	-	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-2-CES	C661010-0602	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-2L	-	Airspeed Indicator (30-220 Knots, Lighted)	Sigma-Tek	Repair
EA5172-2L-AC	-	Airspeed Indicator (40-250 MPH, Lighted)	Sigma-Tek	Repair
EA5172-2L-FAC	-	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-2L-SAB	6127276-035	Airspeed Indicator (0-220 Knots, Lighted)	Sigma-Tek	Repair
EA5172-2-MON	820216-507	Airspeed Indicator (0-250 MPH)	Sigma-Tek	Repair
EA5172-2-PA	-	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-2-PIT	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-2-ROB	-	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5172-2-SAB	-	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-2-VA	-	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5172-3	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-30-CES	C661064-0222	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-31-CES	C661064-0223	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-32-CES	C661064-0224	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-33-CES	C661064-0225	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-34-CES	C661064-0226	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-35-CES	C661064-0227	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-36-CES	C661064-0228	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-37-CES	C661064-0229	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-38-CES	C661064-0230	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-39-CES	C661064-0231	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-3-AA	5801013-1	Airspeed Indicator	Sigma-Tek	Repair
EA5172-3-BEL	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-3-BN	-	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-3-CES	C661010-0603	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-3L	-	Airspeed Indicator (30-220 Knots, Lighted)	Sigma-Tek	Repair
EA5172-3L-BEC	58-380019-3	Airspeed Indicator (40-250 MPH, Lighted)	Sigma-Tek	Repair
EA5172-3L-FAC	-	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-3-PA	-	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-3-PIT	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-3-VA	-	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5172-4	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-40-CES	C661064-0232	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-41-CES	C661064-0233	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
EA5172-42-CES	C661064-0234	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-43-CES	C661064-0235	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-44-CES	C661064-0236	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-45-CES	C661064-0237	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-46-CES	C661064-0238	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-47-CES	C661064-0239	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-4-AA	13-801013-3	Airspeed Indicator	Sigma-Tek	Repair
EA5172-4-BEL	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-4-BN	-	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-4-CES	C661010-0604	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-4L	-	Airspeed Indicator (30-220 Knots, Lighted)	Sigma-Tek	Repair
EA5172-4-PIT	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-5	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-513L-MON	820296-513	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-515L-MON	820296-515	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-517L-MON	820296-517	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-519L-MON	820296-519	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-521L-MON	820296-521	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-523L-MON	820296-523	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5172-525L-MON	820296-525	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5172-5-AA	5801013-2	Airspeed Indicator	Sigma-Tek	Repair
EA5172-5-BN	-	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-5-CES	C661010-0605	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-5L	-	Airspeed Indicator (30-220 Knots, Lighted)	Sigma-Tek	Repair
EA5172-5L-BEC	58-380019-5	Airspeed Indicator (40-250 MPH, Lighted)	Sigma-Tek	Repair
EA5172-5-PIT	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-6	T67M-83-301	Airspeed Indicator	Sigma-Tek	Repair
EA5172-6-BN	-	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-6-CES	C661010-0606	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-6L	-	Airspeed Indicator (30-220 Knots, Lighted)	Sigma-Tek	Repair
EA5172-6-PIT	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-7	T67M-83-375	Airspeed Indicator	Sigma-Tek	Repair
EA5172-7-BEC	35-380036-7	Airspeed Indicator	Sigma-Tek	Repair
EA5172-7-BN	-	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-7-CES	C661010-0607	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-7L	-	Airspeed Indicator (30-220 Knots, Lighted)	Sigma-Tek	Repair
EA5172-7-PIT	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-8	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-8-BN	-	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-8-CES	C661010-0608	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-8L	-	Airspeed Indicator (30-220 Knots, Lighted)	Sigma-Tek	Repair
EA5172-8-PIT	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5172-9	-	Airspeed Indicator	Sigma-Tek	Repair
EA5172-9-BEC	35-380036-9	Airspeed Indicator	Sigma-Tek	Repair
EA5172-9-BN	-	Airspeed Indicator (30-220 Knots)	Sigma-Tek	Repair
EA5172-9-CES	C661064-0201	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5172-9L	-	Airspeed Indicator (30-220 Knots, Lighted)	Sigma-Tek	Repair
EA5173-0101-CES	-	Airspeed Indicator (40-250 Knots)	Sigma-Tek	Repair
EA5173-0201-CES	C661040-0201	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0202-CES	C661040-0202	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0203-CES	C661040-0203	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0204-CES	C661040-0204	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0205-CES	C661040-0205	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0206-CES	C661040-0206	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0208-CES	C661040-0208	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0209-CES	C661040-0209	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0210-CES	C661040-0210	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0211-CES	C661040-0211	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0212-CES	C661040-0212	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0213-CES	C661040-0213	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0215-CES	C661040-0215	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0216-CES	C661040-0216	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0217-CES	C661040-0217	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0218-CES	C661040-0218	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0219-CES	C661040-0219	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-0301-CES	C661064-0301	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
EA5173-1	-	Airspeed Indicator (0-300 MPH)	Sigma-Tek	Repair
EA5173-100-BEC	50-384162	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-101	-	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-101L	-	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5173-101-ROB	-	Airspeed Indicator (0-260 MPH)	Sigma-Tek	Repair
EA5173-102	-	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-102L	-	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5173-103	-	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-103L	-	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5173-104	T67G-83-301	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-104L	-	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5173-105	A-321400-1A	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-106	-	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-107	T67R-83-301	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-108	-	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-109	-	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-10-ACM	850232-509	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-10-GAF	5/N-80-442	Airspeed Indicator (35-250 Knots)	Sigma-Tek	Repair
EA5173-10-RAM	2052-4	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5173-110	-	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-111	-	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-11-ACM	850234-511	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-11-RAM	2052-1	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5173-12-ACM	850232-513	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-12-RAM	2052-5	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-13-ACM	850232-515	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-14-ACM	850232-507	Airspeed Indicator (0-500 KM/HR)	Sigma-Tek	Repair
EA5173-15-ACM	850232-511	Airspeed Indicator (0-500 KM/HR)	Sigma-Tek	Repair
EA5173-16-ACM	850232-517	Airspeed Indicator (0-500 KM/HR)	Sigma-Tek	Repair
EA5173-17-ACM	850232-519	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-18-ACM	850232-521	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-19-ACM	850234-513	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-19-BEC	50-384024-19	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5173-1-ACM	850232-501	Airspeed Indicator (0-300 MPH)	Sigma-Tek	Repair
EA5173-1-BD	-	Airspeed Indicator (0-300 MPH)	Sigma-Tek	Repair
EA5173-1-GAF	-	Airspeed Indicator (35-250 Knots)	Sigma-Tek	Repair
EA5173-1-RAM	2052-9	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-1-ROB	-	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-1-TS	-	Airspeed Indicator (0-300 MPH)	Sigma-Tek	Repair
EA5173-2	-	Airspeed Indicator (0-300 MPH)	Sigma-Tek	Repair
EA5173-20-ACM	850234-515	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-21-ACM	850234-517	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-22-ACM	850234-519	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-23-ACM	850234-521	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-24-ACM	850234-523	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-25-ACM	850234-525	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-26-ACM	850234-527	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-27-ACM	850234-529	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-28-ACM	850234-531	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-29-ACM	850234-533	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-2-ACM	850234-505	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-2-GAF	-	Airspeed Indicator (35-250 Knots)	Sigma-Tek	Repair
EA5173-2-RAM	2052-2	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-30-ACM	850232-525	Airspeed Indicator (0-500 KM/HR)	Sigma-Tek	Repair
EA5173-31-ACM	850232-523	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-32-ACM	850234-535	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-33-ACM	850232-531	Airspeed Indicator (0-280 Knots)	Sigma-Tek	Repair
EA5173-35-ACM	850232-539	Airspeed Indicator (0-280 Knots)	Sigma-Tek	Repair
EA5173-37-ACM	850232-543	Airspeed Indicator (0-280 Knots)	Sigma-Tek	Repair
EA5173-39-ACM	850232-545	Airspeed Indicator (0-280 Knots)	Sigma-Tek	Repair
EA5173-3-ACM	850232-503	Airspeed Indicator (0-300 MPH)	Sigma-Tek	Repair
EA5173-3-GAF	-	Airspeed Indicator (35-250 Knots)	Sigma-Tek	Repair
EA5173-3-RAM	2052-3	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-41-ACM	850232-547	Airspeed Indicator (0-280 Knots)	Sigma-Tek	Repair
EA5173-43-ACM	850232-549	Airspeed Indicator (0-280 Knots)	Sigma-Tek	Repair
EA5173-45-ACM	850232-551	Airspeed Indicator (0-280 Knots)	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
EA5173-47-ACM	850232-553	Airspeed Indicator (0-280 Knots)	Sigma-Tek	Repair
EA5173-49-ACM	850232-555	Airspeed Indicator (0-280 Knots)	Sigma-Tek	Repair
EA5173-49-BEC	50-384024-49	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5173-4-ACM	850232	Airspeed Indicator (0-300 MPH)	Sigma-Tek	Repair
EA5173-4-GAF	-	Airspeed Indicator (35-250 Knots)	Sigma-Tek	Repair
EA5173-4-RAM	2052-13	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-51-BEC	50-384024-51	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5173-53-BEC	50-384024-53	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5173-5-ACM	850232-505	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-5-GAF	1/N-80-442	Airspeed Indicator (35-250 Knots)	Sigma-Tek	Repair
EA5173-5-RAM	2052-10	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-63-BEC	50-384024-63	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5173-6-ACM	850234-501	Airspeed Indicator (0-300 MPH)	Sigma-Tek	Repair
EA5173-6-GAF	2/N-80-442	Airspeed Indicator (35-250 Knots)	Sigma-Tek	Repair
EA5173-6-RAM	2052-12	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-7-ACM	850234-507	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5173-7-GAF	3/N-80-442	Airspeed Indicator (35-250 Knots)	Sigma-Tek	Repair
EA5173-7-RAM	2052-11	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-8-ACM	850234	Airspeed Indicator (0-300 MPH)	Sigma-Tek	Repair
EA5173-8-GAF	4/N-80-442	Airspeed Indicator (35-250 Knots)	Sigma-Tek	Repair
EA5173-8-RAM	2052-14	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5173-9-ACM	850234-509	Airspeed Indicator (0-300 MPH)	Sigma-Tek	Repair
EA5173-9-BEC	50-384024-9	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5173-9-GAF	-	Airspeed Indicator (35-250 Knots)	Sigma-Tek	Repair
EA5173-9-RAM	2052-8	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5174-001PT-BEC	108-384009-5	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair
EA5174-002PT-BEC	108-384013-1	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair
EA5174-0100-CES	C661017-0100	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-0101-CES	C661061-0101	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-0102-CES	C661061-0102	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-0103-CES	C661061-0103	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-0104-CES	C661061-0104	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-0105-CES	C661061-0105	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-0106-CES	C661061-0106	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-01PTL-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-01PT-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-01T	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-01T-ACM	-	Airspeed Indicator (0-160 Knots)	Sigma-Tek	Repair
EA5174-01T-BEC	-	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair
EA5174-02PT	-	Airspeed Indicator	Sigma-Tek	Repair
EA5174-02PTL	-	Airspeed Indicator (40-200 MPH, Lighted)	Sigma-Tek	Repair
EA5174-02PTL-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-02PT-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-02T-BEC	-	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair
EA5174-0300-CES	C661017-0300	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-0301-CES	C661020-0301	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-03PTL	-	Airspeed Indicator (40-200 MPH, Lighted)	Sigma-Tek	Repair
EA5174-03PTL-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-03PT-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-03T-BEC	-	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair
EA5174-04PT	-	Airspeed Indicator	Sigma-Tek	Repair
EA5174-04PTL	-	Airspeed Indicator (40-200 MPH, Lighted)	Sigma-Tek	Repair
EA5174-04PT-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-04T-BEC	-	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair
EA5174-05PT	-	Airspeed Indicator	Sigma-Tek	Repair
EA5174-05PTL	-	Airspeed Indicator (40-200 MPH, Lighted)	Sigma-Tek	Repair
EA5174-05PT-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-05T-BEC	-	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair
EA5174-06PT-MAL	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-06T-BEC	-	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair
EA5174-07T-BEC	-	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair
EA5174-1	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-10	50908-1	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-101-BEC	169-380097-1	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-101T-BEC	-	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair
EA5174-102T-BEC	-	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
EA5174-103-BEC	169-380097-3	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-103T-BEC	-	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair
EA5174-105-BEC	169-380097-5	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-10-CES	C661065-0103	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-10-PIP	62143-10	Airspeed Indicator	Sigma-Tek	Repair
EA5174-11	-	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-11-BEC	169-380048-11	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-11-CES	C661065-0104	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-12	20353-9	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-12-CES	C661065-0105	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-13	50908-2	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-13-BEC	169-380048-13	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-13-CES	C661065-0106	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-14	50023-2	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-14-CES	C661065-0107	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-15	-	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-15-CES	C661065-0108	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-16-CES	C661065-0111	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-17	-	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-17-CES	C661065-0112	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-18	51178-1	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-19	51178-2	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-1-ACM	-	Airspeed Indicator (40-160 Knots)	Sigma-Tek	Repair
EA5174-1-BEC	169-380048-1	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-1-CES	C661010-0101	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-1-PIP	62143	Airspeed Indicator	Sigma-Tek	Repair
EA5174-1PT-BEC	169-380102-1	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair
EA5174-2	50947-3	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-20	51178-3	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-201-BEC	108-384009-1	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-203-BEC	108-384009-3	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-205-BEC	108-384009-5	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-21	51178-4	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-22	51178-5	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-23	51178-6	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-24	51178-7	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-25	-	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-27	20353-13	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-29	50947-4	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-2-CES	C661010-0102	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-2-PIP	62143-2	Airspeed Indicator	Sigma-Tek	Repair
EA5174-3	20353-9	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-30	50947-5	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-31	50947-6	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-32	51084-3	Airspeed Indicator (60-320 KM/HR)	Sigma-Tek	Repair
EA5174-33	-	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-34	50908-4	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-35	50947-8	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-36	50908-3	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-37	51178-8	Airspeed Indicator (60-320 KM/HR)	Sigma-Tek	Repair
EA5174-38	20353-19	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-39	20353-21	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-3-BEC	169-380048-3	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-3-CES	C661010-0103	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-3-PIP	62143-3	Airspeed Indicator	Sigma-Tek	Repair
EA5174-3PT-BEC	169-380102-3	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair
EA5174-4	50947-1	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-40	50947-9	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-4-CES	C661010-0104	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-4-PIP	62143-4	Airspeed Indicator	Sigma-Tek	Repair
EA5174-5	50947-2	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-5-BEC	169-380048-5	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-5-CES	C661010-0105	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-5PT-BEC	169-380102-5	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair
EA5174-6	50947-1 Rev.B	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-6-CES	C661010-0106	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
EA5174-7	50947-2 Rev.B	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-7-BEC	169-380048-7	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-7-CES	C661010-0107	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-7PT-BEC	169-380102-7	Airspeed Indicator (40-170 Knots)	Sigma-Tek	Repair
EA5174-8	50947-3 Rev.B	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-8-CES	C661065-0101	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5174-9	51084-1	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-9-BEC	169-380048-9	Airspeed Indicator (40-200 MPH)	Sigma-Tek	Repair
EA5174-9-CES	C661065-0102	Airspeed Indicator (35-170 Knots)	Sigma-Tek	Repair
EA5175-01L-CES	C661065L0221	Airspeed Indicator (35-210 Knots,Lighted)	Sigma-Tek	Repair
EA5175-01PT	-	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5175-01T	-	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-01T-AA	5804024-1	Airspeed Indicator (0-240 MPH)	Sigma-Tek	Repair
EA5175-01T-ACM	-	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-01T-BEL	-	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-01T-MON	-	Airspeed Indicator (0-240 MPH)	Sigma-Tek	Repair
EA5175-0200-CES	C661019-0200	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-0201-CES	C661061-0201	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-0202-CES	C661061-0202	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-0203-CES	C661061-0203	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-0204-CES	C661061-0204	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-0205-CES	C661061-0205	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-0206-CES	C661061-0206	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-0207-CES	C661061-0207	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-0208-CES	C661061-0208	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-0209-CES	C661061-0209	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-0210-CES	C661061-0210	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-0211-CES	C661061-0211	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-02L-CES	C661065L0238	Airspeed Indicator (35-210 Knots,Lighted)	Sigma-Tek	Repair
EA5175-02PTL	-	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5175-02T	-	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-02T-ACM	-	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-03L-CES	C661065L0239	Airspeed Indicator (35-210 Knots,Lighted)	Sigma-Tek	Repair
EA5175-03PTL	-	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5175-03T-AA	5804024-2	Airspeed Indicator (0-240 MPH)	Sigma-Tek	Repair
EA5175-03T-ACM	-	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-0400-CES	C661019-0400	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-0401-CES	C661020-0401	Airspeed Indicator (40-240 MPH)	Sigma-Tek	Repair
EA5175-04L	-	Airspeed Indicator (35-200 Knots,Lighted)	Sigma-Tek	Repair
EA5175-04PT	-	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5175-04PTL	-	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-04T-ACM	-	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-05L	-	Airspeed Indicator (35-200 Knots,Lighted)	Sigma-Tek	Repair
EA5175-05PT	-	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5175-05PTL	-	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-05T-AA	5804024-3	Airspeed Indicator (0-240 MPH)	Sigma-Tek	Repair
EA5175-05T-ACM	-	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-06L	-	Airspeed Indicator (35-200 Knots,Lighted)	Sigma-Tek	Repair
EA5175-06PT	-	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5175-06PTL	-	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-06T-ACM	-	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-07L-CIR	12727-001	Airspeed Indicator (35-215 Knots,Lighted)	Sigma-Tek	Repair
EA5175-07T-ACM	-	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-08T-ACM	-	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-09L	-	Airspeed Indicator (35-200 Knots,Lighted)	Sigma-Tek	Repair
EA5175-09T-ACM	-	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-1	20353-11	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-101T	-	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5175-101T-AA	7SCF006-1	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-101T-BEC	-	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5175-101TL-BEC	-	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5175-10-CES	C661010-0210	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-10L	-	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5175-10PTL-MON	820308-535	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-10T-ACM	-	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-11-CES	C661010-0211	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
EA5175-11L-CIR	13562-002	Airspeed Indicator (35-215 Knots,Lighted)	Sigma-Tek	Repair
EA5175-11PTL-MON	820308-537	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-11T-ACM	-	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-12-CES	C661010-0212	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-12L-CIR	13562-003	Airspeed Indicator (35-215 Knots,Lighted)	Sigma-Tek	Repair
EA5175-12PTL-MON	820308-539	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-12T-ACM	-	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-13	51273-1	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-13-CES	C661010-0213	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-13L-CIR	12727-003	Airspeed Indicator (35-215 Knots,Lighted)	Sigma-Tek	Repair
EA5175-13PTL-MON	820308-541	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-13T-ACM	-	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-14	51273-2	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5175-14-CES	C661010-0214	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-14L-CIR	13562-004	Airspeed Indicator (35-215 Knots,Lighted)	Sigma-Tek	Repair
EA5175-14PTL-MON	820308-543	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-15	51618-2	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5175-15-CES	C661010-0215	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-15L-CIR	13562-005	Airspeed Indicator (35-215 Knots,Lighted)	Sigma-Tek	Repair
EA5175-16	51618-1	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-16-CES	C661065-0201	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-16L-CIR	13562-006	Airspeed Indicator (35-215 Knots,Lighted)	Sigma-Tek	Repair
EA5175-16PTL-MEY	450014-11	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-17	51273-4	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5175-17-CES	C661065-0202	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-17L-CIR	13562-007	Airspeed Indicator (35-215 Knots,Lighted)	Sigma-Tek	Repair
EA5175-17PTL-CES	S26033-047	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5175-18	51273-5	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-18-CES	C661065-0203	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-19	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-19-CES	C661065-0204	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-19PTL-CES	S3325-3	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5175-1-ACM	-	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-1-AYR	20353-3	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5175-1-CES	C661010-0201	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-1PT-BEC	36-380067-1	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5175-1PTL-APS	172861-3	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-1PTL-MON	820308-517	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-1PT-ROB	-	Airspeed Indicator (60-380 KM/HR)	Sigma-Tek	Repair
EA5175-1PT-SOC	-	Airspeed Indicator (60-380 KM/HR)	Sigma-Tek	Repair
EA5175-1T-AA	5804056-1	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-1TL	-	Airspeed Indicator (40-240 MPH, Lighted)	Sigma-Tek	Repair
EA5175-1TL-BEC	-	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5175-1TL-BEL	-	Airspeed Indicator (40-240 MPH, Lighted)	Sigma-Tek	Repair
EA5175-20	20353-15	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-20-CES	C661065-0205	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-20PTL-CES	S3325-4	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5175-21	-	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-21-CES	C661065-0206	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-21PTL-CES	S3325-5	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5175-22	-	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5175-22-CES	C661065-0207	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-22PTL-CES	S26033-075	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5175-23	-	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5175-23-CES	C661065-0208	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-23PTL-CES	S3325-7	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5175-24	51618-3	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-24-CES	C661065-0209	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-24PTL-CES	S3325-8	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5175-25	51618-4	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5175-25-CES	C661065-0210	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-25PTL-CIR	-	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-26	51618-5	Airspeed Indicator (60-400 KM/HR)	Sigma-Tek	Repair
EA5175-26-CES	C661065-0211	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-26PTL-CIR	13562-001	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-27	51273-6	Airspeed Indicator (60-400 KM/HR)	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
EA5175-27-CES	C661065-0212	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-27PTL-MEY	450014-12	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-28	-	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5175-28-CES	C661065-0213	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-28PTL-CES	S3325-9	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5175-29	51273-7	Airspeed Indicator (40-210 Knots)	Sigma-Tek	Repair
EA5175-29-CES	C661065-0214	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-29PTL-CES	S3325-10	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5175-2-ACM	-	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-2-CES	C661010-0202	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-2-PIP	67433-2	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-2PTL-MON	820308-519	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-2PT-SOC	-	Airspeed Indicator (60-380 KM/HR)	Sigma-Tek	Repair
EA5175-30-CES	C661065-0215	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-30PTL-CES	S3325-11	Airspeed Indicator (40-200 Knots, Lighted)	Sigma-Tek	Repair
EA5175-31-CES	C661065-0216	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-32-CES	C661065-0217	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-33-CES	C661065-0218	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-34-CES	C661065-0219	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-35-CES	C661065-0220	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-36-CES	C661065-0221	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-37-CES	C661065-0222	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-38-CES	C661065-0223	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-39-CES	C661065-0224	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-3-ACM	850232-533	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-3-CES	C661010-0203	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-3PT-BEC	36-380067-3	Airspeed Indicator (40-200 Knots)	Sigma-Tek	Repair
EA5175-3PTL-MON	820308-521	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-3PT-SOC	-	Airspeed Indicator (60-380 KM/HR)	Sigma-Tek	Repair
EA5175-3T-AA	5804056-2	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-40-CES	C661065-0225	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-41-CES	C661065-0226	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-42-CES	C661065-0227	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-43-CES	C661065-0228	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-44-CES	C661065-0229	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-45-CES	C661065-0230	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-46-CES	C661065-0231	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-47-CES	C661065-0232	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-48-CES	C661065-0233	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-49-CES	C661065-0234	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-4-ACM	850232-535	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-4-CES	C661010-0204	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-4PTL-MON	820308-523	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-501PT-MON	820308-501	Airspeed Indicator	Sigma-Tek	Repair
EA5175-503PT-MON	820308-503	Airspeed Indicator	Sigma-Tek	Repair
EA5175-505PT-MON	820308-505	Airspeed Indicator	Sigma-Tek	Repair
EA5175-507PT-MON	820308-507	Airspeed Indicator	Sigma-Tek	Repair
EA5175-509PT-MON	820308-509	Airspeed Indicator	Sigma-Tek	Repair
EA5175-50-CES	C661065-0235	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-511PT-MON	820308-511	Airspeed Indicator	Sigma-Tek	Repair
EA5175-513PT-MON	820308-513	Airspeed Indicator	Sigma-Tek	Repair
EA5175-515PT-MON	820308-515	Airspeed Indicator	Sigma-Tek	Repair
EA5175-51-CES	C661065-0236	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-52-CES	C661065-0237	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-53-CES	C661065-0238	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-54-CES	C661065-0239	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-55-CES	C661065-0240	Airspeed Indicator (35-210 Knots)	Sigma-Tek	Repair
EA5175-5-ACM	850232-537	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-5-CES	C661010-0205	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-5PTL-MON	820308-525	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-5T-AA	5804056-3	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-6-ACM	850232-541	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-6-CES	C661010-0206	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-6PTL-MON	820308-527	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-7-CES	C661010-0207	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-7PTL-MON	820308-529	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
EA5175-7T-AA	5804056-4	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5175-8-CES	C661010-0208	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-8PTL-MON	820308-531	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-9	51273-3	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-9-CES	C661010-0209	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-9-PIP	62143-9	Airspeed Indicator (40-250 MPH)	Sigma-Tek	Repair
EA5175-9PTL-MON	820308-533	Airspeed Indicator (40-210 Knots, Lighted)	Sigma-Tek	Repair
EA5175-9T-AA	5804056-5	Airspeed Indicator (0-200 Knots)	Sigma-Tek	Repair
EA5176-001-AYR	20353-9	Airspeed Indicator (0-300 MPH)	Sigma-Tek	Repair
EA5176-002-AYR	20353-10	Airspeed Indicator (0-300 MPH)	Sigma-Tek	Repair
EA5176-0101-CES	C661040-0101	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5176-0102-CES	C661040-0102	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5176-0103-CES	C661040-0103	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5176-0104-CES	C661040-0104	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5176-01PT	-	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5176-01PTL	-	Airspeed Indicator (0-260 Knot, Lighted)	Sigma-Tek	Repair
EA5176-01PTL-BEL	-	Airspeed Indicator (40-300 MPH, Lighted)	Sigma-Tek	Repair
EA5176-0301-CES	C661065-0301	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5176-101-BEC	100-384051-1	Airspeed Indicator	Sigma-Tek	Repair
EA5176-101L-BEC	58-380010-1	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-103-BEC	100-384051-3	Airspeed Indicator	Sigma-Tek	Repair
EA5176-103L-BEC	58-380010-3	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-105L-BEC	58-380010-5	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-107-BEC	100-384051-7	Airspeed Indicator	Sigma-Tek	Repair
EA5176-107L-BEC	58-380010-7	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-109-BEC	100-384051-9	Airspeed Indicator	Sigma-Tek	Repair
EA5176-109L-BEC	58-380010-9	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-111L-BEC	58-380010-11	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-113L-BEC	58-380010-13	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-11-BEC	102-380001-11	Airspeed Indicator	Sigma-Tek	Repair
EA5176-11L-BEC	102-380002-11	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-11PTL-BEC	58-380093-11	Airspeed Indicator (40-260 Knot, Lighted)	Sigma-Tek	Repair
EA5176-11-SAC	27-86022-11	Airspeed Indicator (0-300 Knots)	Sigma-Tek	Repair
EA5176-13-BEC	102-380001-13	Airspeed Indicator	Sigma-Tek	Repair
EA5176-13L-BEC	102-380002-13	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-13PTL-BEC	58-380093-13	Airspeed Indicator (40-260 Knot, Lighted)	Sigma-Tek	Repair
EA5176-15-BEC	102-380001-15	Airspeed Indicator	Sigma-Tek	Repair
EA5176-15L-BEC	102-380002-15	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-15PTL-BEC	58-380093-15	Airspeed Indicator (40-260 Knot, Lighted)	Sigma-Tek	Repair
EA5176-15PT-PIP	41507-15	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5176-15-SAC	27-86022-15	Airspeed Indicator (0-300 Knots)	Sigma-Tek	Repair
EA5176-16PT-PIP	41507-16	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5176-17-BEC	102-380001-17	Airspeed Indicator	Sigma-Tek	Repair
EA5176-17L-BEC	102-380002-17	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-17PTL-BEC	58-380093-17	Airspeed Indicator (40-260 Knot, Lighted)	Sigma-Tek	Repair
EA5176-17PT-PIP	41507-17	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5176-17-SAC	27-86022-17	Airspeed Indicator (0-300 Knots)	Sigma-Tek	Repair
EA5176-18PT-PIP	41507-18	Airspeed Indicator (0-260 Knots)	Sigma-Tek	Repair
EA5176-19-BEC	102-380001-19	Airspeed Indicator	Sigma-Tek	Repair
EA5176-19L-BEC	102-380002-19	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-1-BEC	102-380001-1	Airspeed Indicator	Sigma-Tek	Repair
EA5176-1-CES	CM-3301-1	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5176-1L	-	Airspeed Indicator (0-300 Knots, Lighted)	Sigma-Tek	Repair
EA5176-1L-BEC	102-380002-1	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-1L-BEL	-	Airspeed Indicator (40-300 MPH, Lighted)	Sigma-Tek	Repair
EA5176-1PT-BEC	58-380092-1	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5176-1PTL-BEC	58-380093-1	Airspeed Indicator (40-260 Knot, Lighted)	Sigma-Tek	Repair
EA5176-1-SAC	27-86022-1	Airspeed Indicator (0-300 Knots)	Sigma-Tek	Repair
EA5176-1TL-BEC	-	Airspeed Indicator (40-260 Knots, Lighted)	Sigma-Tek	Repair
EA5176-201L-BEC	58-380037-1	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-203L-BEC	58-380037-3	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-205L-BEC	58-380037-5	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-207L-BEC	58-380037-7	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-209L-BEC	58-380037-9	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-211L-BEC	58-380037-11	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-213-BEC	99-384043-13	Airspeed Indicator	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
EA5176-213L-BEC	58-380037-13	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-215L-BEC	58-380037-15	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-217L-BEC	58-380037-17	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-219L-BEC	58-380037-19	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-21-BEC	102-380001-21	Airspeed Indicator	Sigma-Tek	Repair
EA5176-21L-BEC	102-380002-21	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-221L-BEC	58-380037-21	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-223L-BEC	58-380037-23	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-225-BEC	99-384043-25	Airspeed Indicator	Sigma-Tek	Repair
EA5176-225L-BEC	58-380037-25	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-227-BEC	99-384043-27	Airspeed Indicator	Sigma-Tek	Repair
EA5176-227L-BEC	58-380037-27	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-229-BEC	99-384043-29	Airspeed Indicator	Sigma-Tek	Repair
EA5176-229L-BEC	58-380037-29	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-231-BEC	99-384043-31	Airspeed Indicator	Sigma-Tek	Repair
EA5176-231L-BEC	58-380037-31	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-233-BEC	99-384043-33	Airspeed Indicator	Sigma-Tek	Repair
EA5176-233L-BEC	58-380037-33	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-235L-BEC	58-380037-35	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-237L-BEC	58-380037-37	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-239L-BEC	58-380037-39	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-23-BEC	102-380001-23	Airspeed Indicator	Sigma-Tek	Repair
EA5176-23L-BEC	102-380002-23	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-241L-BEC	58-380037-41	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-243L-BEC	58-380037-43	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-245L-BEC	58-380037-45	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-247L-BEC	58-380037-47	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-249L-BEC	58-380037-49	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-251L-BEC	58-380037-51	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-25-BEC	102-380001-25	Airspeed Indicator	Sigma-Tek	Repair
EA5176-25L-BEC	102-380002-25	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-27-BEC	102-380001-27	Airspeed Indicator	Sigma-Tek	Repair
EA5176-27L-BEC	102-380002-27	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-29-BEC	102-380001-29	Airspeed Indicator	Sigma-Tek	Repair
EA5176-29L-BEC	102-380002-29	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-2-CES	CM-3301-2	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5176-2L-BEL	518081-1	Airspeed Indicator (40-300 MPH, Lighted)	Sigma-Tek	Repair
EA5176-2PT-BEC	58-380092-3	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5176-301L-BEC	36-380042-1	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-303-BEC	60-384024-3	Airspeed Indicator	Sigma-Tek	Repair
EA5176-303L-BEC	36-380042-3	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-307-BEC	60-384024-7	Airspeed Indicator	Sigma-Tek	Repair
EA5176-309-BEC	60-384024-9	Airspeed Indicator	Sigma-Tek	Repair
EA5176-311-BEC	60-384024-11	Airspeed Indicator	Sigma-Tek	Repair
EA5176-313-BEC	60-384024-13	Airspeed Indicator	Sigma-Tek	Repair
EA5176-315-BEC	60-384024-15	Airspeed Indicator	Sigma-Tek	Repair
EA5176-317-BEC	60-384024-17	Airspeed Indicator	Sigma-Tek	Repair
EA5176-319-BEC	60-384024-19	Airspeed Indicator	Sigma-Tek	Repair
EA5176-31-BEC	102-380001-31	Airspeed Indicator	Sigma-Tek	Repair
EA5176-31L-BEC	102-380002-31	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-321-BEC	60-384024-21	Airspeed Indicator	Sigma-Tek	Repair
EA5176-323-BEC	60-384024-23	Airspeed Indicator	Sigma-Tek	Repair
EA5176-325-BEC	60-384024-25	Airspeed Indicator	Sigma-Tek	Repair
EA5176-327-BEC	60-384024-27	Airspeed Indicator	Sigma-Tek	Repair
EA5176-329-BEC	60-384024-29	Airspeed Indicator	Sigma-Tek	Repair
EA5176-331-BEC	60-384024-31	Airspeed Indicator	Sigma-Tek	Repair
EA5176-333-BEC	60-384024-33	Airspeed Indicator	Sigma-Tek	Repair
EA5176-335-BEC	60-384024-35	Airspeed Indicator	Sigma-Tek	Repair
EA5176-337-BEC	60-384024-37	Airspeed Indicator	Sigma-Tek	Repair
EA5176-339-BEC	60-384024-39	Airspeed Indicator	Sigma-Tek	Repair
EA5176-33-BEC	102-380001-33	Airspeed Indicator	Sigma-Tek	Repair
EA5176-33L-BEC	102-380002-33	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-341-BEC	60-384024-41	Airspeed Indicator	Sigma-Tek	Repair
EA5176-343-BEC	60-384024-43	Airspeed Indicator	Sigma-Tek	Repair
EA5176-35-BEC	102-380001-35	Airspeed Indicator	Sigma-Tek	Repair
EA5176-35L-BEC	102-380002-35	Airspeed Indicator, Lighted	Sigma-Tek	Repair

Part Number	Model	Description	Manufacturer	Capability
EA5176-37-BEC	102-380001-37	Airspeed Indicator	Sigma-Tek	Repair
EA5176-37L-BEC	102-380002-37	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-39-BEC	102-380001-39	Airspeed Indicator	Sigma-Tek	Repair
EA5176-39L-BEC	102-380002-39	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-3-BEC	102-380001-3	Airspeed Indicator	Sigma-Tek	Repair
EA5176-3-CES	CM-3301-3	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5176-3L-BEC	102-380002-3	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-3PT-BEC	58-380092-5	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5176-3PTL-BEC	58-380093-3	Airspeed Indicator (40-260 Knot, Lighted)	Sigma-Tek	Repair
EA5176-3-SAC	27-86022-3	Airspeed Indicator (0-300 Knots)	Sigma-Tek	Repair
EA5176-4-CES	CM-3301-4	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5176-4PT-BEC	58-380092-7	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5176-5-BEC	102-380001-5	Airspeed Indicator	Sigma-Tek	Repair
EA5176-5-CES	CM-3301-5	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5176-5L-BEC	102-380002-5	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-5PT-BEC	58-380092-9	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5176-5PTL-BEC	58-380093-5	Airspeed Indicator (40-260 Knot, Lighted)	Sigma-Tek	Repair
EA5176-5-SAC	27-86022-5	Airspeed Indicator (0-300 Knots)	Sigma-Tek	Repair
EA5176-6	-	Airspeed Indicator	Sigma-Tek	Repair
EA5176-6-CES	CM-3301-6	Airspeed Indicator (40-300 MPH)	Sigma-Tek	Repair
EA5176-6PT-BEC	58-380092-11	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5176-7	-	Airspeed Indicator	Sigma-Tek	Repair
EA5176-7-BEC	102-380001-7	Airspeed Indicator	Sigma-Tek	Repair
EA5176-7L-BEC	102-380002-7	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-7PT-BEC	58-380092-13	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5176-7PTL-BEC	58-380093-7	Airspeed Indicator (40-260 Knot, Lighted)	Sigma-Tek	Repair
EA5176-7-SAC	27-86022-7	Airspeed Indicator (0-300 Knots)	Sigma-Tek	Repair
EA5176-8	-	Airspeed Indicator	Sigma-Tek	Repair
EA5176-8PT-BEC	58-380092-15	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5176-9-BEC	102-380001-9	Airspeed Indicator	Sigma-Tek	Repair
EA5176-9L-BEC	102-380002-9	Airspeed Indicator, Lighted	Sigma-Tek	Repair
EA5176-9PT-BEC	58-380092-17	Airspeed Indicator (40-260 Knots)	Sigma-Tek	Repair
EA5176-9PTL-BEC	58-380093-9	Airspeed Indicator (40-260 Knot, Lighted)	Sigma-Tek	Repair
EA5177-1	-	Airspeed Indicator (40-400 Knots)	Sigma-Tek	Repair
ELT10	ELT-10	Emergency Locator Transmitter	Narco	Test/Recert
FQ4026-12011	S3281-2	Indicator, Fuel Level	Rochester Gauges	Repair
FQ4026-12020	S3281-2	Fuel Quantity Indicator, Dual	Rochester Gauges	Repair
G-4433A	-	ADF Control Panel	Gables	Repair
G-4434	-	VHF Comm Control Panel	Gables	Repair
G-4434A	-	VHF Comm Control Panel	Gables	Repair
G-4436A	-	Transponder Control Panel	Gables	Repair
G-4518	-	NAV/DME Control Panel	Gables	Repair
G5400-1	-	Landing Light	Grimes	Repair
G-5400-1	-	Landing Light	Grimes	Repair
G5400-15	-	Landing Light	Grimes	Repair
G-5400-15	-	Landing Light	Grimes	Repair
G5400-16	-	Landing Light	Grimes	Repair
G5400-17	-	Landing Light	Grimes	Repair
G-5400-17	-	Landing Light	Grimes	Repair
G5400-18	-	Landing Light	Grimes	Repair
G5400-2	-	Landing Light	Grimes	Repair
G5400-3	-	Landing Light	Grimes	Repair
G-5400-3	-	Landing Light	Grimes	Repair
G5400-4	-	Landing Light	Grimes	Repair
G5400-5	-	Landing Light	Grimes	Repair
G-5400-5	-	Landing Light	Grimes	Repair
G5400-6	212-075-139-1	Landing Light	Grimes	Repair
G5400-6	212-075-139-001	Landing Light	Grimes	Repair
G5400-6	-	Landing Light	Grimes	Repair
G-5400-6	-	Landing Light	Grimes	Repair
G6250-1	-	Searchlight, Controllable	Grimes	Repair
G6250-4	-	Searchlight, Controllable	Grimes	Repair
G6250-5	-	Searchlight, Controllable	Grimes	Repair
G6250-6	-	Searchlight, Controllable	Grimes	Repair
H140ABM2	-	Horizon Gyro	Thales	Repair
H140ACM2	-	Horizon Gyro	Thales	Repair

Part Number	Model	Description	Manufacturer	Capability
H140ADM2	-	Horizon Gyro	Thales	Repair
H140AMM	-	Horizon Gyro	Thales	Repair
H140ARM2	-	Horizon Gyro	Thales	Repair
H140ASM2	-	Horizon Gyro	Thales	Repair
H140ATM2	-	Horizon Gyro	Thales	Repair
H140AUM2	-	Horizon Gyro	Thales	Repair
H140BAM2	-	Horizon Gyro	Thales	Repair
H140BHM2	-	Horizon Gyro	Thales	Repair
H140BKM	-	Horizon Gyro	Thales	Repair
H140BLM	-	Horizon Gyro	Thales	Repair
H140CAM1	-	Horizon Gyro	Thales	Repair
H140CJM1	-	Horizon Gyro	Thales	Repair
H140CLM1	-	Horizon Gyro	Thales	Repair
H140CPM1	-	Horizon Gyro	Thales	Repair
H140CQM3	-	Horizon Gyro	Thales	Repair
H140CRM1	-	Horizon Gyro	Thales	Repair
H140CSM1	-	Horizon Gyro	Thales	Repair
H140CWM	-	Horizon Gyro	Thales	Repair
H140DCM	-	Horizon Gyro	Thales	Repair
H140JAM1	-	Horizon Gyro	Thales	Repair
H140JBM	-	Horizon Gyro	Thales	Repair
H140JDM1	-	Horizon Gyro	Thales	Repair
H140JJM1	-	Horizon Gyro	Thales	Repair
H140JKM1	-	Horizon Gyro	Thales	Repair
H140JLM	-	Horizon Gyro	Thales	Repair
H140JSM3	-	Horizon Gyro	Thales	Repair
H140JTM1	-	Horizon Gyro	Thales	Repair
H140JUM2	-	Horizon Gyro	Thales	Repair
H140JVM2	-	Horizon Gyro	Thales	Repair
H140JWM1	-	Horizon Gyro	Thales	Repair
H140JYM1	-	Horizon Gyro	Thales	Repair
H140KAM	-	Horizon Gyro	Thales	Repair
H140KBM	-	Horizon Gyro	Thales	Repair
H140KDM	-	Horizon Gyro	Thales	Repair
H140KRM	-	Horizon Gyro	Thales	Repair
ID824	ID-824 TSO	VOR/LOC Indicator	Narco	Repair
ID825	ID-825 TSO	VOR/LOC/GS Indicator	Narco	Repair
ID826	ID-826 TSO	VOR/LOC/GS Indicator	Narco	Repair
J8000-01	RCA11A-1	Directional Gyro	RC Allen	Repair
J8000-02	RCA11A-2	Directional Gyro	RC Allen	Repair
J8000-03	RCA11A-3	Directional Gyro	RC Allen	Repair
J8000-04	RCA11A-4	Directional Gyro	RC Allen	Repair
J8000-05	RCA11A-8	Directional Gyro	RC Allen	Repair
J8000-05F	RCA11A-8F	Directional Gyro	RC Allen	Repair
J8000-06	RCA11A-9	Directional Gyro	RC Allen	Repair
J8000-07	RCA11A-10	Directional Gyro	RC Allen	Repair
J8000-08	RCA11A-11	Directional Gyro	RC Allen	Repair
J8000-09	RCA11A-12	Directional Gyro	RC Allen	Repair
J8000-10	RCA11A-14	Directional Gyro	RC Allen	Repair
J8000-11	RCA11A-15	Directional Gyro	RC Allen	Repair
LT-50(A)	-	Dimmer Control	KGS Electronics	Test/Recert
MD113-1	114-380048-1	Oxygen Pressure Indicator	Mid-Continent	Repair
MD114-1	114-380027-1	Pressure Gauge, Pneumatic	Mid-Continent	Repair
MD114-3	114-380027-3	Pressure Gauge, Pneumatic	Mid-Continent	Repair
MD114-5	114-380027-5	Pressure Gauge, Pneumatic	Mid-Continent	Repair
MD200-302	-	Course Deviation Indicator	Mid-Continent	Test/Recert
MD200-302(5V)	-	Course Deviation Indicator	Mid-Continent	Test/Recert
MD200-303	-	Course Deviation Indicator	Mid-Continent	Test/Recert
MD200-303(5V)	-	Course Deviation Indicator	Mid-Continent	Test/Recert
MD200-306	-	Course Deviation Indicator	Mid-Continent	Test/Recert
MD200-306(5V)	-	Course Deviation Indicator	Mid-Continent	Test/Recert
MD200-307	-	Course Deviation Indicator	Mid-Continent	Test/Recert
MD200-307(5V)	-	Course Deviation Indicator	Mid-Continent	Test/Recert
MD41-1024	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1028	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1028(5V)	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair

Part Number	Model	Description	Manufacturer	Capability
MD41-1034	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1038	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1038(5V)	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1048	-	HTAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1048(5V)	-	HTAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1058	-	HTAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1058(5V)	-	HTAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1204	-	Terrain Awareness ACU	Mid-Continent	Limited Repair
MD41-1208	-	Terrain Awareness ACU	Mid-Continent	Limited Repair
MD41-1208(5V)	-	Terrain Awareness ACU	Mid-Continent	Limited Repair
MD41-1214	-	Terrain Awareness ACU	Mid-Continent	Limited Repair
MD41-1218	-	Terrain Awareness ACU	Mid-Continent	Limited Repair
MD41-1218(5V)	-	Terrain Awareness ACU	Mid-Continent	Limited Repair
MD41-1244	-	Terrain Awareness ACU	Mid-Continent	Limited Repair
MD41-1248	-	Terrain Awareness ACU	Mid-Continent	Limited Repair
MD41-1248(5V)	-	Terrain Awareness ACU	Mid-Continent	Limited Repair
MD41-1254	-	Terrain Awareness ACU	Mid-Continent	Limited Repair
MD41-1258	-	Terrain Awareness ACU	Mid-Continent	Limited Repair
MD41-1258(5V)	-	Terrain Awareness ACU	Mid-Continent	Limited Repair
MD41-1308	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1308(5V)	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1318	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1318(5V)	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1324	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1328	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1328(5V)	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1334	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1338	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1338(5V)	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1364	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1368	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1368(5V)	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1374	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1378	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1378(5V)	-	TAWS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1404A	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1408A	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1408A(5V)	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1414A	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1418A	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1418A(5V)	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1464A	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1468A	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1468A(5V)	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1474A	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1478A	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1478A(5V)	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1484W	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1488W	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1494W	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1498W	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1510	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1511	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1512	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1513	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1514	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1515	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1817	-	Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-1844	-	Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-244	-	Relay Unit (24 Pole, 14V)	Mid-Continent	Test/Recert
MD41-248	-	Relay Unit (24 Pole, 28V)	Mid-Continent	Test/Recert
MD41-324	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-328	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-328(5V)	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-334	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-338	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair

Part Number	Model	Description	Manufacturer	Capability
MD41-338(5V)	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-424	013-00029-01	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-428	013-00029-00	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-428(5V)	013-00029-02	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-434	013-00029-06	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-438	013-00029-05	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-438(5V)	013-00029-07	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-444	013-00029-11	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-448	013-00029-10	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-448(5V)	013-00029-12	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-454	013-00029-16	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-458	013-00029-15	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-458(5V)	013-00029-17	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-524	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-528	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-528(5V)	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-534	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-538	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-538(5V)	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-624	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-628	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-628(5V)	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-634	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-638	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-638(5V)	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-924	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-928	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-928(5V)	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-934	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-938	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MD41-938(5V)	-	GPS Annunciation Control Unit	Mid-Continent	Limited Repair
MI-585134	PRIMUS-40	Radar Indicator	Sperry	Repair
MI-585134-1	PRIMUS-40	Radar Indicator	Sperry	Repair
MI-585134-2	PRIMUS-40	Radar Indicator	Sperry	Repair
MI-585134-3	PRIMUS-40	Radar Indicator	Sperry	Repair
MI-585134-4	PRIMUS-40	Radar Indicator	Sperry	Repair
MI-585134-5	PRIMUS-40	Radar Indicator	Sperry	Repair
MI-585134-6	PRIMUS-40	Radar Indicator	Sperry	Repair
MI-585134-7	PRIMUS-40	Radar Indicator	Sperry	Repair
MI-585135	PRIMUS-40	Radar Transceiver	Sperry	Repair
MI-585135-1	PRIMUS-40	Radar Transceiver	Sperry	Repair
MI-585135-2	PRIMUS-40	Radar Transceiver	Sperry	Repair
MI-585136	PRIMUS-40	Antenna Pedestal	Sperry	Repair
MI-585136-1	PRIMUS-40	Antenna Pedestal	Sperry	Repair
MI-585280	RTA-1003	Receiver Transmitter Antenna	Sperry	Repair
MI-585280-1	RTA-1003	Receiver Transmitter Antenna	Sperry	Repair
MI-585300	RT-5001	Radar Receiver Transmitter	Sperry	Repair
MI-585300-1	RT-5001	Radar Receiver Transmitter	Sperry	Repair
MI-585300-4	RT-5001	Radar Receiver Transmitter	Sperry	Repair
MI-585301	DI-5001	Digital Radar Indicator	Sperry	Repair
MI-585301-1	DI-5001	Digital Radar Indicator	Sperry	Repair
MI-585301-2	DI-5001	Digital Radar Indicator	Sperry	Repair
MI-585301-3	DI-5001	Digital Radar Indicator	Sperry	Repair
MI-585302	AP-5001	Antenna Pedestal	Sperry	Repair
MI-585302-1	AP-5001	Antenna Pedestal	Sperry	Repair
MI-585467	WA-700	Antenna Pedestal	Sperry	Repair
MI-585467-1	WA-700	Antenna Pedestal	Sperry	Repair
MI-585467-2	WA-700	Antenna Pedestal	Sperry	Repair
MK12E TSO	MK-12E	NAV/COMM Radio	Narco	Repair
MX300	-	NAV/COMM Transceiver	TKM	Repair
NAV121	NAV121 TSO	Navigation System (VOR/LOC)	Narco	Repair
NAV122	NAV122 TSO	Navigation System (VOR/LOC/GS/MKR)	Narco	Repair
NAV122A	NAV122A TSO	Navigation System (VOR/LOC/MKR w/ GS Display)	Narco	Repair
NAV824	NAV 824 TSO	Navigation Receiver	Narco	Repair
NAV825	NAV 825 TSO	Navigation Receiver	Narco	Repair
NPX138-000	-	VHF FM Transceiver	NAT	Repair

Part Number	Model	Description	Manufacturer	Capability
NPX138-050	-	VHF FM Transceiver	NAT	Repair
NPX138-070	-	VHF FM Transceiver	NAT	Repair
NPX138N-000	-	VHF FM Transceiver	NAT	Repair
NPX138N-050	-	VHF FM Transceiver	NAT	Repair
NPX138N-070	-	VHF FM Transceiver	NAT	Repair
NPX138N-100	-	VHF FM Transceiver	NAT	Repair
NPX138N-150	-	VHF FM Transceiver	NAT	Repair
NPX138N-170	-	VHF FM Transceiver	NAT	Repair
NPX138N-500	-	VHF FM Transceiver	NAT	Repair
NPX138N-550	-	VHF FM Transceiver	NAT	Repair
NPX138N-570	-	VHF FM Transceiver	NAT	Repair
PA110-015	-	Power Amplifier, 110W	NAT	Repair
PA220-010	-	Power Amplifier, 220W	NAT	Repair
PC-125	-	Static Inverter	Flite-Tronics	Repair
PC-125-123B	-	Static Inverter	Flite-Tronics	Repair
PC-125-123C	-	Static Inverter	Flite-Tronics	Repair
PC-125-12B	-	Static Inverter	Flite-Tronics	Repair
PC-125-2A	-	Static Inverter	Flite-Tronics	Repair
PC-125-3A	-	Static Inverter	Flite-Tronics	Repair
PC-125-4A	-	Static Inverter	Flite-Tronics	Repair
PC-125-9A	-	Static Inverter	Flite-Tronics	Repair
PC-125A	-	Static Inverter	Flite-Tronics	Repair
PC-15	-	Static Inverter	Flite-Tronics	Repair
PC-15A	-	Static Inverter	Flite-Tronics	Repair
PC-15B	-	Static Inverter	Flite-Tronics	Repair
PC-15B(D)	-	Static Inverter	Flite-Tronics	Repair
PC-15B(E)	-	Static Inverter	Flite-Tronics	Repair
PC-15B(F)	-	Static Inverter	Flite-Tronics	Repair
PC-15B(G)	-	Static Inverter	Flite-Tronics	Repair
PC-15BC	-	Static Inverter	Flite-Tronics	Repair
PC-15BC(A)	-	Static Inverter	Flite-Tronics	Repair
PC-15BC(D)	-	Static Inverter	Flite-Tronics	Repair
PC-15BC(E)	-	Static Inverter	Flite-Tronics	Repair
PC-15BC(H)	-	Static Inverter	Flite-Tronics	Repair
PC-15D	-	Static Inverter	Flite-Tronics	Repair
PC-15E	-	Static Inverter	Flite-Tronics	Repair
PC-15F	-	Static Inverter	Flite-Tronics	Repair
PC-15G	-	Static Inverter	Flite-Tronics	Repair
PC-17	-	Static Inverter	Marathon	Repair
PC-17-1	-	Static Inverter	Marathon	Repair
PC-17-2	-	Static Inverter	Marathon	Repair
PC-17-3	-	Static Inverter	Marathon	Repair
PC-17-3A	-	Static Inverter	Marathon	Repair
PC-17-3B	-	Static Inverter	Marathon	Repair
PC-250	-	Static Inverter	Flite-Tronics	Repair
PC-250-1A	-	Static Inverter	Flite-Tronics	Repair
PC-250-1B	-	Static Inverter	Flite-Tronics	Repair
PC-250-1C	-	Static Inverter	Flite-Tronics	Repair
PC-250-2A	-	Static Inverter	Flite-Tronics	Repair
PC-251	-	Static Inverter	Flite-Tronics	Repair
PC-251-15A	-	Static Inverter	Flite-Tronics	Repair
PC-251-15B	-	Static Inverter	Flite-Tronics	Repair
PC-251-1C	-	Static Inverter	Flite-Tronics	Repair
PC-251-3A	-	Static Inverter	Flite-Tronics	Repair
PC-251-3B	-	Static Inverter	Flite-Tronics	Repair
PC-251-5A	-	Static Inverter	Flite-Tronics	Repair
PC-350	-	Static Inverter	Avionic Instruments	Repair
PC-350-1A	-	Static Inverter	Avionic Instruments	Repair
PC-350-1B	-	Static Inverter	Avionic Instruments	Repair
PC-350-2A	-	Static Inverter	Avionic Instruments	Repair
PC-350-34A	-	Static Inverter	Avionic Instruments	Repair
PC-350-4A	-	Static Inverter	Avionic Instruments	Repair
PC-50	-	Static Inverter	Flite-Tronics	Repair
PS-240	-	Power Inverter	EMP Electronics	Repair
PS304	-	Static Inverter	EMP Electronics	Repair
PS304-1	-	Static Inverter	EMP Electronics	Repair

Part Number	Model	Description	Manufacturer	Capability
PS50030-2-3	1234T100	Turn & Slip Indicator, Lighted	Piper	Repair
PS50030-2-4	1234T100	Turn & Slip Indicator	Piper	Repair
PS50030-3-5	1394T100 Z	Turn Coordinator	Piper	Repair
PS50126-5	4000B-26	Directional Gyro	Piper	Repair
PS50127-8	5000B-32	Attitude Gyro	Piper	Repair
PS50127-9	5000B-29	Attitude Gyro	Piper	Repair
PS50128-2-3	1234T100	Turn & Slip Indicator	Piper	Repair
RC-30-V	-	Vertical Speed Indicator, Instantaneous	Aerosonic	Repair
RC-30-V-10	-	Vertical Speed Indicator, Instantaneous	Aerosonic	Repair
RC-30-V-10-1	-	Vertical Speed Indicator, Instantaneous	Aerosonic	Repair
RC-30-VIL	212-070-239-1	Vertical Speed Indicator, Instantaneous	Aerosonic	Repair
RC-30-VIL	212-070-239-001	Vertical Speed Indicator, Instantaneous	Aerosonic	Repair
RC-30-VIL-1	-	Vertical Speed Indicator, Instantaneous	Aerosonic	Repair
RC-30-VIL-2	-	Vertical Speed Indicator, Instantaneous	Aerosonic	Repair
RC60V10	-	Vertical Speed Indicator, Instantaneous	Aerosonic	Repair
RC-60-V-10	-	Vertical Speed Indicator, Instantaneous	Aerosonic	Repair
RC-60-V-10A	RC60V10A	Vertical Speed Indicator, Instantaneous	Aerosonic	Repair
RC-60-V-10A	C661009-0101RX	Vertical Speed Indicator, Instantaneous	Aerosonic	Repair
RC-60-V-10A	C661009-0101	Vertical Speed Indicator, Instantaneous	Aerosonic	Repair
RC-60-VIL-1	-	Vertical Speed Indicator, Instantaneous	Aerosonic	Repair
RCA15C-1	-	Directional Gyro	RC Allen	Repair
RCA15C-3	-	Directional Gyro	RC Allen	Repair
RCA15C-4	-	Directional Gyro	RC Allen	Repair
RCA15CM-1	-	Directional Gyro	RC Allen	Repair
RCA15CM-2	-	Directional Gyro	RC Allen	Repair
RCS-60-IL	-	Vertical Speed Indicator	Aerosonic	Repair
RS08-001	-	Remote Switch	NAT	Repair
RS08-350	-	Remote Switch	NAT	Repair
RS08-500	-	Remote Switch	NAT	Repair
RS12-020	-	Remote Switch	NAT	Repair
RS12-030	-	Remote Switch	NAT	Repair
RS12-350	-	Remote Switch	NAT	Repair
RS24-020	-	Remote Switch	NAT	Repair
RS24-350	-	Remote Switch	NAT	Repair
S1301N2	-	Manifold Pressure Gauge	US Gauge	Test/Recert
S-1303-2	1234T100	Turn & Slip Indicator	Cessna	Repair
S15KAW	S-15-KAW	Airspeed Indicator (10-150 knots)	Aerosonic	Repair
S15KILR1	S-15-KILR-1	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR1	S15-KILR-1	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR1	212-070-122-1	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR1	212-070-122-001	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR11	S-15-KILR-11	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR11	S15-KILR-11	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR11	212-070-122-11	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR11	212-070-122-011	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR19	S-15-KILR-19	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR19	S15-KILR-19	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR19	212-070-122-19	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR19	212-070-122-019	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR2	S-15-KILR-2	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR2	S15-KILR-2	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR20	S-15-KILR-20	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR20	S15-KILR-20	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR9	S-15-KILR-9	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR9	S15-KILR-9	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR9	212-070-122-9	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S15KILR9	212-070-122-009	Airspeed Indicator, 0-150 Knots	Aerosonic	Repair
S1820502-01	406AP	ELT	Kannad	Repair
S1820502-02	406AP	ELT	Kannad	Repair
S1820502-04	406AP-H	ELT	Kannad	Repair
S1821502-01	406AF	ELT	Kannad	Repair
S1821502-02	406AF	ELT	Kannad	Repair
S1821502-06	406AF-6D	ELT	Kannad	Repair
S1822502-01	406AF-H	ELT	Kannad	Repair
S1822502-02	406AF-H	ELT	Kannad	Repair
S1823502-01	406AS	ELT	Kannad	Repair

Part Number	Model	Description	Manufacturer	Capability
S1823502-02	406AS	ELT	Kannad	Repair
S1823502-03	406AS-TNC	ELT	Kannad	Repair
S1823502-05	406 Survival	ELT	Kannad	Repair
S1824502-01	121AF	ELT	Kannad	Repair
S1824502-02	121AF	ELT	Kannad	Repair
S1826502-02	121AF-H	ELT	Kannad	Repair
S1840501-01	406AF-Compact	ELT	Kannad	Repair
S1840501-04	406AF-Compact(ER)	ELT	Kannad	Repair
S1850501-01	INTEGRA AP (ER)	ELT	Kannad	Repair
S1850501-02	INTEGRA AP	ELT	Kannad	Repair
S1850501-03	INTEGRA AP (ER-N)	ELT	Kannad	Repair
S1851501-01	INTEGRA AF (ER)	ELT	Kannad	Repair
S1851501-02	INTEGRA AF	ELT	Kannad	Repair
S1851501-03	INTEGRA AF (ER-N)	ELT	Kannad	Repair
S1852501-01	INTEGRA AF-H (ER)	ELT	Kannad	Repair
S1852501-02	INTEGRA AF-H	ELT	Kannad	Repair
S1852501-03	INTEGRA AF-H (ER-N)	ELT	Kannad	Repair
S1854501-01	INTEGRA AP-H (ER)	ELT	Kannad	Repair
S1854501-02	INTEGRA AP-H	ELT	Kannad	Repair
S1854501-03	INTEGRA AP-H (ER-N)	ELT	Kannad	Repair
S3326-1	5000B-67	Attitude Gyro, Lighted	Cessna	Repair
S3326-2	5000B-75	Attitude Gyro, Lighted	Cessna	Repair
S3330-1	4000HR-5	Directional Gyro, Lighted	Cessna	Repair
S3330-2	4000C-15	Directional Gyro, Lighted	Cessna	Repair
S6145-61172-001	-	Auxiliary Floatation Control Panel	Sikorsky	Repair
S6155-61092-1	S6155-61092-001	Fuel Management Panel	Sikorsky	Repair
S6155-61092-2	S6155-61092-002	Fuel Management Panel	Sikorsky	Repair
S6155-61584-2	S6155-61584-002	Cargo Sling Control	Sikorsky	Repair
S6190-60045-2	S6190-60045-002	Channel Monitor	Sikorsky	Repair
S6190-60045-4	S6190-60045-004	Channel Monitor	Sikorsky	Repair
S6190-60045-5	S6190-60045-005	Channel Monitor	Sikorsky	Repair
S6190-60060-4	S6190-60060-004	AFCS Control Panel	Sikorsky	Repair
S6190-60060-41	S6190-60060-041	AFCS Control Panel	Sikorsky	Repair
S6192-61090-1	S6192-61090-001	Lag Amplifier	Sikorsky	Repair
S6192-61090-2	S6192-61090-002	Lag Amplifier	Sikorsky	Repair
SEL-O19BC	206-075-680-103	TOT Indicator	Ametek	Repair
SEL-O19BD	206-075-680-105	TOT Indicator	Ametek	Repair
SEL-O19BU	206-075-680-107	TOT Indicator	Ametek	Repair
SEL-O19BW	206-075-680-101	TOT Indicator	Ametek	Repair
SEL-O19DR	206-375-005-101	TOT Indicator	Ametek	Repair
SEL-O19DS	206-375-006-101	TOT Indicator	Ametek	Repair
SEL-O19DT	206-375-007-101	TOT Indicator	Ametek	Repair
SEL-O19ED	206-375-009-101	TOT Indicator	Ametek	Repair
SEL-OC19AM	76450-01076-106	Turbine Temperature Indicator	Ametek	Repair
SEL-OC19AP	76450-01076-107	Turbine Temperature Indicator	Ametek	Repair
SEL-OC19BF	350A-82-1283-02	Indicator, Turbine Outlet Temperature	Ametek	Repair
SEL-OC19BF	350A82128302	Indicator, Turbine Outlet Temperature	Ametek	Repair
SEL-OC19BF-03	350A-82-1283-03	Indicator, Turbine Outlet Temperature	Ametek	Repair
SEL-OC19BF-03	350A82128303	Indicator, Turbine Outlet Temperature	Ametek	Repair
SEL-OC19BF-SD	350A-82-1283-SD	Indicator, Turbine Outlet Temperature	Ametek	Repair
SEL-OC19BF-SD	350A821283SD	Indicator, Turbine Outlet Temperature	Ametek	Repair
SEL-OC19EH	704A47632051	T4 Indicator	Ametek	Repair
SEL-OC19EJ	212-075-067-109	ITT Indicator	Ametek	Repair
SEL-OC29F	76450-01076-101	Tachometer Indicator	Ametek	Repair
SETL-OC329A	76450-01076-103	Triple Tachometer	Ametek	Repair
SLZ9065	D3B	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9066	D3WB	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9067	D6B	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9068	D6WB	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9155	D6H	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9211	D6T	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9239	D6WC	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9270	D6HB	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9415	D3E	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9416	D6E	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9603	D3WBL	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair

Part Number	Model	Description	Manufacturer	Capability
SLZ9620	D6LW	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9635	D3F	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9638	D6A	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9669	D6F	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9669-2	D6F	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9706	D6LE	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9851	D6LP	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SLZ9851-1	D6LP	Vertical Speed Indicator, Inertial-Lead	Teledyne	Repair
SSD120-30A	-	Altitude Encoder (30k ft)	Trans-Cal	Test/Recert
SSD120-30AE	-	Altitude Encoder (30k ft, Extended Temp)	Trans-Cal	Test/Recert
SSD120-30N	-	Altitude Encoder (30k ft)	Trans-Cal	Test/Recert
SSD120-30NE	-	Altitude Encoder (30k ft, Extended Temp)	Trans-Cal	Test/Recert
SSD120-35A	-	Altitude Encoder (35k ft)	Trans-Cal	Test/Recert
SSD120-35AE	-	Altitude Encoder (35k ft, Extended Temp)	Trans-Cal	Test/Recert
SSD120-35N	-	Altitude Encoder (35k ft)	Trans-Cal	Test/Recert
SSD120-35NE	-	Altitude Encoder (35k ft, Extended Temp)	Trans-Cal	Test/Recert
SSD120-42A	-	Altitude Encoder (42k ft)	Trans-Cal	Test/Recert
SSD120-42AE	-	Altitude Encoder (42k ft, Extended Temp)	Trans-Cal	Test/Recert
SSD120-42N	-	Altitude Encoder (42k ft)	Trans-Cal	Test/Recert
SSD120-42NE	-	Altitude Encoder (42k ft, Extended Temp)	Trans-Cal	Test/Recert
VSDL-OC403A	9912147-12	Fuel Quantity Indicator	Ametek	Repair