

Part Number	Model	Description	Manufacturer	Capability
2000	2000	ELT	POINTER	Test/Recert
3000	3000	ELT	POINTER	Test/Recert
4000	4000	ELT	POINTER	Test/Recert
7004	7004	HEADSET	PELTOR	Repair
7005	7005	HEADSET	PELTOR	Repair
7030	7030	V.S.I. 0-3000 FEET	UNITED	Test/Recert
8100	8100	AIRSPED INDICATOR	UNITED	Test/Recert
8125	8125	AIRSPED INDICATOR	UNITED	Test/Recert
11900	PM1000TSO	INTERCOM	PSENG	Repair
11920	PM1000IITSO	INTERCOM	PSENG	Repair
11922	PM1000IITSO	INTERCOM	PSENG	Repair
11932	PM3000	INTERCOM 6 PL	PSENG	Repair
41650	R-443A	RECEIVER G/S	ARC	Repair
42100	R-443B	RECEIVER G/S	ARC	Repair
99391	PA-1010B	POWER AMP	SUNAIR	Repair
99680	RE-1200	HF TRANSCEIVER	SUNAIR	Repair
99681	RE-*	HF TRANSCEIVER	SUNAIR	Repair
99718	RE-600	RE-600 HF	SUNAIR	Repair
99896	SCU10-HF	SCU10-HF	SUNAIR	Repair
99912	RE-1000	RCVR/EXC	SUNAIR	Repair
99914	PA-1010A	PA/PWR SUP (ASB-100A)	SUNAIR	Repair
920607	TBS-150	VHF Base Stn	TECHNISONIC	Repair
1045017	SPH-5	HELMET	GENTEX	Repair
4001018	RTA-161A	RTA-161A	BENDIX	Repair
25410036	7000 RCU	LORAN RECEIVER	ANI	Test/Recert
25410038	7000	LORAN 7000 CDU	ANI	Test/Recert
5110001903	0900-1840-22	EMERGENCY POWER UNIT	JET	Repair
8033100095	RE-800	RCVR/EXCTR ASB-850	SUNAIR	Repair
010-00010-00	GPS100STD	GPS RCVR	GARMIN	Repair
010-00015-00	GPS100STD	GPS SYSTEM	GARMIN	Repair
010-00057-02	GPS100AVD	RCVR	GARMIN	Repair
010-00062-00	GPS 150	RECEIVER	GARMIN	Repair
010-00099-00	GNC250	GPS/COMM	GARMIN	Repair
010-00135-00	GTX320	TRANSPONDER	GARMIN	Repair
010-00159-00	GPS155XL	GPS RCVR	GARMIN	Repair
010-10057-00		28-14v Converter	GARMIN	Repair
011-00010-00	GPS 100	GPS RECEIVER	GARMIN	Repair
011-00017-00		GPS RECEIVER	GARMIN	Repair
011-00054-00	GPS 150	GPS RECEIVER	GARMIN	Repair
011-00082-00	GNC 250	GPS RECEIVER	GARMIN	Repair
011-00433-00	GNC300XL	GPS RCVR	GARMIN	Repair
01184-0101	CP125	AUDIO PANEL	NARCO	Repair
01185-0102	COM 11B	VHF COMM	NARCO	Repair
01-200-103		ALTIMETER	SMITHS IND	Test/Recert
013-00029-01	MD41	GPS/NAV ANNUN	MID CONT	Limited-Repair
013-00029-10	MD41	GPS/NAV ANNUN	GARMIN	Limited-Repair
013-00033-00	GI-106	CDI/GS/GPS	GARMIN	Limited-Repair
03753-0302	AR-850	ALTITUDE ENCODER	NARCO	Test/Recert
03753-0304	AR-850	ALTITUDE REPORTER	NARCO	Test/Recert
03972-2245-5	369H6425-5D	DIMMER CONT UNIT	AUTRONICS	Repair
05-01-002A	DEFT 1	ELT	DEFT	Test/Recert

Part Number	Model	Description	Manufacturer	Capability
0514.187-910	AR3202-(01)-110	VHF TCVR	BECKER	Repair
060-00015-0000	KG-102A	DIRECTIONAL GYRO	BENDIX/KING	Repair
060-0015-00	KG-102A	DIRECTIONAL GYRO	KING	Repair
062-0009-00	KA93/KY92	BASE STN	KING	Repair
064-01051-0070	KY-97A	VHF TRASCIEVER	KING	Repair
064-01052-0070	KY-96A	VHF TRASCIEVER	BENDIX/KING	Repair
064-01053-0030	KY-197A	VHF TRASCIEVER	BENDIX/KING	Repair
064-01053-0060	KY-197A	VHF TRASCIEVER	BENDIX/KING	Repair
064-01054-0030	KY-196A	VHF TRASCIEVER	BENDIX/KING	Repair
064-01054-0060	KY-196A	VHF TRASCIEVER	BENDIX/KING	Repair
064-1003-00	KTR-900	VHF TRASCIEVER	KING	Repair
064-1004-00	KTR-9000	VHF TRASCIEVER	KING	Repair
064-1006-00	KTR-900A	VHF TRASCIEVER	KING	Repair
064-1009-00	KTR-905	VHF TRASCIEVER	KING	Repair
064-1009-01	KTR905E	VHF TRASCIEVER	KING	Repair
064-1015-00	KTR-953	HF-REC/EXCITER	KING	Repair
064-1016-00	KCU-951	HF CONTROL	KING	Repair
064-1017-00	KAC-952	HF POWER AMP & COUPL	KING	Repair
064-1019-00	KY-196	VHF COMM RADIO	KING	Repair
064-1019-01	KY-196E	VHF COMM RADIO	KING	Repair
064-1019-02	KY-196	VHF COMM RADIO	KING	Repair
064-1019-05	KY-196	VHF COMM RADIO	KING	Repair
064-1020-00	KY-92	VHF COMM/TRANS.	KING	Repair
064-1021-00	KY-197	VHF COMM RADIO	KING	Repair
064-1021-05	KY-197	VHF COMM RADIO	KING	Repair
064-1023-00	KTR-908	VHF TRASCIEVER	KING	Repair
064-1023-04	KTR-908	VHF TRASCIEVER	KING	Repair
064-1051-60	KY-97A	VHF COMM RADIO	KING	Repair
064-1051-70	KY-97A	VHF COMM RADIO	KING	Repair
064-1052-60	KY-96A	VHF COMM RADIO	KING	Repair
064-1053-30	KY-197A	VHF COMM RADIO	KING	Repair
064-1054-30	KY-196A	VHF COMM RADIO	KING	Repair
065-0035-01	KC 291	YAW CONTROL	KING	T.B.D.
066-01062-0000	KT-76A	TRANSPONDER	BENDIX/KING	Repair
066-01062-0010	KT-76A	TRANSPONDER	BENDIX/KING	Repair
066-01066-0025	KDM-706A	DME TCVR	BENDIX/KING	Repair
066-01067-0000	KN-53	NAV RCVR GS	BENDIX/KING	Repair
066-01067-0010	KN-53	NAV RECEV GS SC PLUS	BENDIX/KING	Repair
066-01068-0001	KN-62A	DME W/HARMONIC FILTE	BENDIX/KING	Repair
066-01068-0004	KN-62A	DME SC PLUS	BENDIX/KING	Repair
066-01069-0001	KDI-572	DME IND 5V LT	BENDIX/KING	Repair
066-01070-0001	KN-63	REMOTE MOUNT DME	BENDIX/KING	Repair
066-01077-0001	KDF-806	ADF Receiver	BENDIX/KING	Repair
066-01148-0101	KLN-89B	GPS RCVR	BENDIX/KING	Repair
066-01156-0101	KT-76C	TRANSPONDER	BENDIX/KING	Repair
066-03034-0000	KI-203	VOR/LOC IND	BENDIX/KING	Repair
066-03046-0007	KI-525A	HSI	BENDIX/KING	Repair
066-03056-0001	KI-208	VOR/LOC IND	BENDIX/KING	Repair
066-03056-0002	KI-209	VOR/LOC/GS IND	BENDIX/KING	Repair
066-03056-0011	KI-209A	VOR/LOC/GS IND	BENDIX/KING	Repair
066-03063-0000	KI-227	ADF INDICATOR	BENDIX/KING	Repair

Part Number	Model	Description	Manufacturer	Capability
066-03063-0001	KI-227	ADF INDICATOR	BENDIX/KING	Repair
066-03091-0001	IN-2025B	RADAR INDICATOR	BENDIX/KING	Repair
066-04031-1121	KLN-90B	GPS RCVR	BENDIX/KING	Repair
066-04031-1122	KLN-90B	GPS RCVR	BENDIX/KING	Repair
066-04031-1221	KLN-90B	GPS RCVR	BENDIX/KING	Repair
066-04031-1222	KLN-90B	GPS RCVR	BENDIX/KING	Repair
066-04034-0102	KLN-900	GPS BLK AM DB	BENDIX/KING	T.B.D.
066-1020-02	KT-75R	TRANSPONDER	KING	Repair
066-1021-01		MARKER BEACON	KING	Repair
066-1023-00	KR-85	RECEIVER ADF	KING	Repair
066-1024-03	KMA-20	AUDIO/MB PANEL	KING	Repair
066-1024-09	KMA-20	AUD CONT/MKR BCN RCR	KING	Repair
066-1024-13	KMA-20	AUDIO/MB PANEL	KING	Repair
066-1024-16	KMA-20	AUDIO PANEL	KING	Repair
066-1025-00	KXP-750A	TRANSPONDER	KING	Repair
066-1027-00	KNR-660A	VOR/LOC-RCVR	KING	Repair
066-1029-00/01	KN-65	DME TRANSCIEVER	KING	Repair
066-1029-02	KN-65A	DME TRANSCIEVER	KING	Repair
066-1029-03	KN-65A	DME TRANSCIEVER	KING	Repair
066-1033-00	KN-73	GLIDESLOPE RECEIVER	KING	Repair
066-1034-00	KT-76	TRANSPONDER	KING	Repair
066-1034-01	KT-76	TRANSPONDER	KING	Repair
066-1034-02	KT-78	TRANSPONDER	KING	Repair
066-1034-03	KT-78	TRANSPONDER	KING	Repair
066-1034-05	KT-78	TRANSPONDER	KING	Repair
066-1034-10	KT-78	TRANSPONDER	KING	Repair
066-1035-00	KGM-691	GS/MKR RCVR	KING	Repair
066-1035-02	KGM-691	GS/MKR RCVR	KING	Repair
066-1037-08	KDM-705	DME R/T	KING	Repair
066-1038-00	KR-86	ADF RECEIVER	KING	Repair
066-1041-00	KXP-755	TRANSPONDER	KING	Repair
066-1044-00	KMR-675	RECEIVER/MB	KING	Repair
066-1047-00	KDF-805	ADF RECEIVER	KING	Repair
066-1047-01	KDF-805	ADF RECEIVER	KING	Repair
066-1048-00	KRA-405	RAD ALT TCVR	KING	Repair
066-1048-02	KRA-405	RAD ALT TCVR	KING	Repair
066-1053-00	KT-79	TRANSPONDER	KING	Repair
066-1055-03	KMA-24	AUDIO PANEL	KING	Repair
066-1055-50	KMA-24H	AUDIO PANEL	KING	Repair
066-1055-52	KMA-24H	AUDIO PANEL	KING	Repair
066-1055-65	KMA-24H	AUDIO CONTROL	KING	Repair
066-1055-70	KMA-24H	AUDIO PANEL	KING	Repair
066-1055-71	KMA-24H	AUDIO PANEL	KING	Repair
066-1061-01	KRA-10A	RADAR ALTIMETER	KING	Repair
066-1061-03	KRA-10A	RAD ALT R/T	KING	Repair
066-1062-00	KT-76A	TRANSPONDER	KING	Repair
066-1062-01	KT-76A	TRANSPONDER	KING	Repai
066-1062-02	KT-76A	TRANSPONDER	KING	Repair
066-1062-10	KT-76A	TRANSPONDER	KING	Repair
066-1063-00	KN-75	GL/SLOPE RCVR	KING	Repair
066-1066-00	KDM-706	DME	KING	Repair

Part Number	Model	Description	Manufacturer	Capability
066-1066-22	KDM-706A	DME RT	KING	Repair
066-1067-00	KN-53	NAV/GS RCVR	KING	Repair
066-1067-01	KN-53	NAV RCVR	KING	Repair
066-1068-00	KN-62A	DME	KING	Repair
066-1069-00	KDI-572	DME INDICATOR	KING	Repair
066-1069-01	KDI-572	DME INDICATOR	KING	Repair
066-1070-00	KN-63	DME	KING	Repair
066-1070-01	KN-63	DME	KING	Repair
066-1071-00	KXP-756	TRANSPONDER	KING	Repair
066-1072-00	KR-87	ADF RECEIVER	KING	Repair
066-1072-04	KR-87	ADF RECEIVER	KING	Repair
066-1077-00	KDF-806	ADF RECEIVER	KING	Repair
066-1078-00	KNR-634	NAV RECEIVER	KING	Repair
066-1078-08	KNR-634	NAV RECEIVER	KING	Repair
066-1088-00	KN-64	DME XCEIVER/IND.	KING	Repair
066-1089-00	KA-120	SER->PAR CONV	KING	Repair
066-3003-00	KDI-570	DME IND.	KING	Repair
066-3008-02	KI-201C	VOR IND.	KING	Repair
066-3011-01	KNI-520	NAV IND.	KING	Repair
066-3012-01	KA-35	MARKER LIGHT ASSY	KING	Repair
066-3014-01	KNI-580	ADF INDICATOR	KING	Repair
066-3014-03	KNI-580	ADF INDICATOR	KING	Repair
066-3017-00	KI-225	ADF IND	KING	Repair
066-3017-01	KI-225	ADF IND	KING	Repair
066-3018-00	KI-265	DME INDICATOR	KING	Repair
066-3025-01	KI-214	CDI/ILS IND	KING	Repair
066-3032-10	KDI-571	DME IND.	KING	Repair
066-3032-11	KDI-571	DME IND.	KING	Repair
066-3034-00	KI-203	VOR/LOC CONV.	KING	Repair
066-3034-01	KI-203	VOR/LOC/CVTR IND.	KING	Repair
066-3034-04	KI-206	VOR/ILS IND	KING	Repair
066-3042-03	KNI-581	RADIO MAGNETIC IND	KING	Repair
066-3044-01	KNI-416	RAD ALT IND.	KING	Repair
066-3046-00	KI-525A	HIS	KING	Repair
066-3046-01	KI-525A	HSI	KING	Repair
066-3046-05	KI-525A	HSI	KING	Repair
066-3046-07	KI-525A	HSI	KING	Repair
066-3047-00	KI-266	DME INDICATOR	KING	Repair
066-3051-00	KEA-127	ENCODER	KING	Test/Recert
066-3054-01	KI-250	INDICATOR/RAD ALT	KING	Repair
066-3056-00	KI-208	VOR/LOC IND	KING	Repair
066-3056-01	KI-209	ILS INDICATOR	KING	Repair
066-3060-00	KNI-582	RMI INDICATOR	KING	Repair
066-3062-02	KEA-346	ALTIMETER	KING	Test/Recert
066-3063-00	KI-227	ADF INDICATOR	KING	Repair
066-3064-05	KEA-103A	ALTIMETER	KING	Test/Recert
066-3064-05	KEA-130A	ENCODING ALTIMETER	KING	Test/Recert
066-3114-00	IN-812A	COLOR RADAR IND	KING	Repair
066-4003-00	KN-74	RNAV	KING	Repair
066-4004-00	KN-77	VOR/LOC CONVERTER	KING	Repair
066-4007-00	KNR-630	NAV RCVR	KING	Repair

<b>Part Number</b>	<b>Model</b>	<b>Description</b>	<b>Manufacturer</b>	<b>Capability</b>
066-4007-02	KNR 632	RECEIVER	KING	Repair
066-4008-00	KNS-80	NAV UNIT	KING	Repair
066-4009-00	KN-72	VOR/LOC CONVERT	KING	Repair
066-4010-00	KNS-81	NAV	KING	Repair
069-01021-0000	KY-195B	VHF COMM	BENDIX/KING	Repair
069-01024-0042	KX-155	NAV/COMM	BENDIX/KING	Repair
069-01025-0021	KX-165	NAV/COM/GS/CVT	BENDIX/KING	Repair
069-01028-1101	KX-125	NAV/COM 25KHZ 14V	BENDIX/KING	Repair
069-01029-0201	KLX-135	TCVR VHF/GPS	BENDIX/KING	T.B.D.
069-1010-04	KI-211C	VOR/LOC IND	KING	Repair
069-1014-00	KX-170	NAV/COMM	KING	Repair
069-1017-00	KX-170A	NAV/COMM	KING	Repair
069-1018-00	KY-195	DUAL COMM.	KING	Repair
069-1019-00	KX-175B	NAV/COMM	KING	Repair
069-1019-01	KX-175BE	NAV/COMM	KING	Repair
069-1020-00	KX-170B	NAV/COMM TRANSCIEVER	KING	Repair
069-1020-01	KX-170B	NAV/COMM SYS	KING	Repair
069-1020-02	KX-170B	TRANS, VHF	KING	Repair
069-1021-00	KY-195B	VHF COMM	KING	Repair
069-1022-00	KX-145	NAV/COMM	KING	Repair
069-1024-00	KX-155	NAV/COMM	KING	Repair
069-1024-01	KX-155	NAV/COMM	KING	Repair
069-1024-04	KX-155	NAV/COMM	KING	Repair
069-1024-05	KX-155	NAV/COMM	KING	Repair
069-1024-09	KX-155	NAV/COMM	KING	Repair
069-1024-30	KX-155	NAV/COMM	KING	Repair
069-1024-31	KX-155	NAV/COMM	KING	Repair
069-1024-34	KX-155	NAV/COMM	KING	Repair
069-1024-35	KX-155	NAV/COMM	KING	Repair
069-1024-39	KX-155	NAV/COMM	KING	Repair
069-1024-42	KX-155	NAV/COMM	KING	Repair
069-1024-43	KX-155	NAV/COMM	KING	Repair
069-1025	KX-165	NAV/COMM	KING	Repair
069-1025-0025	KX-165	NAV/COMM	BENDIX/KING	Repair
069-1025-25	KX-165	NAV/COMM	BENDIX/KING	Repair
070-00041-0001	KX-99	PORT NAV/COM	BENDIX/KING	Repair
071-0004-00	KA-43	2 X 5 CONV	BENDIX/KING	Repair
071-01052-0000	KMT-112	FLUX VALVE	BENDIX/KING	Repair
071-01234-0000	KA-44B	ADF LOOP ANT	BENDIX/KING	Repair
071-01242-0000	KA-51B	SLAVE CTL 14V BLK	BENDIX/KING	Repair
071-01284-0004	KFS-586A	Control	BENDIX/KING	Repair
071-01330-0003	RT1401B	RADAR TCVR	BENDIX/KING	Repair
071-01508-0201	KA-90	RMI/HSI ADAPTER KA90	BENDIX/KING	T.B.D.
071-01508-0202	KA-90	RMI/SLEWED HSI ADAPT	BENDIX/KING	T.B.D.
071-01553-0200	KA-92	GPS ANTENNA	BENDIX/KING	Test/Recert
071-02009-0002	KA-134	AUDIO PANEL	BENDIX/KING	Repair
071-1006-11	KA-42	ADF LOOP ANT	KING	Test/Recert
071-1012-12	KFS-590B	VHF CONTROL	KING	Repair
071-1012-14	KFS-590B	RECEIVER/VHF CONTROL	KING	Repair
071-1013-06	KFS-560	CONTROL NAV	KING	Repair
071-1034-00	KA-36	ADF LOOP ANT	KING	Test/Recert

Part Number	Model	Description	Manufacturer	Capability
071-1038-02	KFS-575	XPDR CONTROL	KING	Repair
071-1041-00	KA-39	VOLTAGE CONVERTER	KING	Repair
071-1041-01	KA-39	POWER CONV	KING	Repair
071-1043-02	KFS-570B	CONTROL ATC	KING	Repair
071-1052-00	KMT-112	FLUX VALVE	KING	Repair
071-1053-04	KA-51A	SLAVING ACC.	KING	Repair
071-1066-00	KFS-580B	ADF CONTROL	KING	Repair
071-1066-03	KFS-580B	ADF CONTROL	KING	Repair
071-1076-00	KDA-697	RMI ADAPTER	KING	Repair
071-1098-00	KA-42A	ADF LOOP ANT	KING	Test/Recert
071-1114-00	KA-131	RAD ALT ANT	KING	Test/Recert
071-1114-01	KA-131	RAD ALT ANT	KING	Test/Recert
071-1133-00	KA-42B	ADF ANTENNA	KING	Test/Recert
071-1147-00	KA-133	VOLTAGE CONV.	KING	Repair
071-1192-04	KFS-576	CONTROL XPNDR	KING	Repair
071-1192-08	KFS-576	CONTROL XPNDR	KING	Repair
071-1192-14	KFS-576	CONTROL XPNDR	KING	Repair
071-1192-16	KFS-576	CONTROL XPNDR	KING	Repair
071-1192-18	KFS-576	CONTROL XPNDR	KING	Repair
071-1192-26	KFS-576	CONTROL XPNDR	KING	Repair
071-1196-00	KA-44	ADF ANTENNA	KING	Test/Recert
071-1210-04	KFS-586	ADF CONTROL	KING	Repair
071-1215-25	KFS-598	VHF CONTROL	KING	Repair
071-1215-35	KFS-598	VHF CONTROL	KING	Repair
071-1215-38	KFS-598	VHF CONTROL	KING	Repair
071-1215-40	KFS-598	VHF CONTROL	KING	Repair
071-1215-55	KFS-598	VHF CONTROL	KING	Repair
071-1215-70	KFS-598	VHF CONTROL	KING	Repair
071-1216-12	KFS-564	NAV CONTROL HEAD	KING	Repair
071-1234-00	KA-44B	ADF ANTENNA	KING	Test/Recert
071-1276-08	KFS-576A	CONTROL XPNDR	KING	Repair
071-1276-09	KFS-576A	CONTROL XPNDR	KING	Repair
071-1276-10	KFS-576A	CONTROL XPNDR	KING	Repair
071-1276-11	KFS-576A	CONTROL XPNDR	KING	Repair
071-1378-00	RS-811A	RADAR SENSOR	KING	Repair
071-2008-00	KA-25A	ISO AMP	KING	Repair
071-2009-02	KA-134	AUDIO PANEL	KING	Repair
0900-0250-30	TRT-250D	TRANSPONDER	TERRA	Repair
0900-0405-00	TX760D	VHF COMM	TERRA	Repair
0900-0418-00	TMA330D	AUDIO PANEL	TERRA	Repair
0900-4099-01	AT-3000	ALTITUDE ENC.	TERRA	Test/Recert
100-1301-100		VHF COMM CONTROL	EDWARDS RA	Test/Recert
100-1301-220		VHF NAV CONTROL	EDWARDS RA	Test/Recert
10035-11326		ALTIMETER,PRESS.35K	AEROSONIC	Test/Recert
10035-11424		ALTIMETER	AEROSONIC	Test/Recert
101420-01205		ALTIMETER PRESSURE	AEROSONIC	Test/Recert
101420-01249S		ALTIMETER; ENCODING	AEROSONIC	Test/Recert
101420-11798		ALTIMETER	AEROSONIC	Test/Recert
101435-01211		ALTIMETER ENCODING	AEROSONIC	Test/Recert
101627-11705		ENCODING ALTIMETER	AEROSONIC	Test/Recert
101720-01354		ALTIMETER	AEROSONIC	Test/Recert

Part Number	Model	Description	Manufacturer	Capability
101720-01393		ALTIMETER	AEROSONIC	Test/Recert
101720-111005		ALTIMETER 20K LIGHTD	AEROSONIC	Test/Recert
101720-11810		ALTIMETER	AEROSONIC	Test/Recert
101735-011002		ALTIMETER	AEROSONIC	Test/Recert
101735-01455		ALTIMETER	AEROSONIC	Test/Recert
101935-09692L		ENCODER	AEROSONIC	Test/Recert
102-0007-01		ARTIFICIAL HORIZON	R.C.ALLEN	Repair
102-0054-03		GYRO HORIZON (5 DEG)	RC ALLEN	Repair
102-0054-05		ATTITUDE INDICATOR	RC ALLEN	Repair
102200-01818		ALTIMETER ENCODING	AEROSONIC	Test/Recert
102200-11833		ALTIMETER ALT RPTING	AEROSONIC	Test/Recert
10962-2		FREQUENCY SENSOR	SIKORSKY	Test/Recert
11-100-011		ALTIMETER	INSTRUMENT	Test/Recert
111302-(5)		HSI	ASTRONAUTICS	Repair
111303-(4)		ATT INDICATOR	ASTRONAUTICS	Repair
117M-6		CHADWICK BALANCER	CHADWICK H	Repair
1234T100-3TZ		TURN & SLIP 12-32V	EGC	Repair
1234T100-7ATZ		TURN & SLIP IND	EGC	Repair
1234T1007TZ		INDICATOR 2 MIN TURN	EGC	Repair
124-044		FUEL PRESSURE GAUGE		T.B.D.
124-444-12		T.O.T. GAUGE		Test/Recert
12507G-18	H10-40	HEAD SET	DAVID CLARK	Repair
1301-1001		ALTIMETER	AEROSONIC	Test/Recert
1301-2001		ALTIMETER	AEROSONIC	Test/Recert
13-3006-1		ALTIMETER		Test/Recert
135M-11		STROBEX LIGHT	CHADWIC	Repair
13824-02-0109	TNL-2000	GPS	TRIMBLE	Repair
13824-03-0304	TLN-3000	GPS	TRIMBLE	Repair
13824-12-0110	TNL-2000A	GPS		Repair
1394T100-3		TURN & SLIP IND.	EGC	Repair
1394T100-7Z		TURN COORIDINATOR	EGC	Repair
1394T100-7Z		TURN COORIDINATOR	EGC	Repair
1394-T100-7Z		TURN COORD, 11 DEG.	EGC	Repair
142640-01-01		ATTITUDE INDICATOR		T.B.D.
1455-1		CAUTION PANEL	UNITED CON	Repair
1455-1B		CAUTION PANEL		Repair
1456-1B		CAUTION PANEL		Repair
14653-10	TNL-2000A	GPS RECEIVER	TRIMBLE	Repair
1527-01		ANTENNA GPS	GARMIN	Test/Recert
152HL2W3		TOT INDICATOR	LEWIS ENG.	Test/Recert
156-0010		STROBE POWER SUPPLY	AEROFLASH	Repair
1564-1		TURBINE SPD DETECTOR	AVTECH	Repair
16248-20		ANTENNA GPS	TRIMBLE	Test/Recert
1636-6H-B1		VERTICAL SPEED IND.		Test/Recert
1778686-655	C-6D	COMPASS IND.	SPERRY	Repair
177M-6		BALANCER	CHADWICK H	Repair
177M-6A		STROBEX BALANCER	CHADWIC	Repair
1866-1		AUDIO PANEL	AVTEC	Repair
192A		CHADWICK		Repair
1A250(1D)		250VA STATIC INVERTE		Repair
1C338		AUTOCONTROL IIIB	EDO-AIRE	Repair

Part Number	Model	Description	Manufacturer	Capability
1D720		AUTOPILOT CTL	EDO-AIRE	Repair
1U022		ADF RECEIVER	BENDIX	Repair
1U02205	T-12D	ADF Receiver	BENDIX COR	Repair
1U027-01	551 A	ADF INDICATOR	BENDIX	Repair
1U149-010	5000E	ATT GYRO	SIGMATEC	Repair
1U149-012	5000B-40	ATT GYRO	SIGMATEC	Repair
1U262-001-39	4000B-30	DG UNLIT	SIGMATEC	Repair
1U262-001-9	4000B-8	DG UNLIT	SIGMATEC	Repair
1U262-004-15	4000C-1	DG (A/P)	SIGMATEC	Repair
1U262-007-40	4000HR-2	DG UNLIT	SIGMATEC	Repair
1U262-010-41	4000HR-3	DG	SIGMATEC	Repair
200-2748-001	KA-44	AMPLIFIER	KING	Test/Recert
200-3		DIRECTIONAL GYRO	A.I.M.	Repair
200-5		DIRECTIONAL GYRO	A.I.M.	Repair
205-001-042-001		CYCLIC GRIP 205/212	BELL	Repair
205-001-046-1		CYCLIC GRIP 205/212	BELL	Repair
205-070-2823		LOADMETER	BELL	Repair
205-074-001-2AACLI		RPM LIMIT DETECTOR	BELL	Repair
205-1A		DIRECTIONAL GYRO	AIM	Repair
206-070-263-101		INDICATOR/ALTIMETER	UNITED	Test/Recert
206-070-264-5		AIRSPD INDICATOR	UNITED	Test/Recert
206-070-268-13		TORQUE METER	INSCO	T.B.D.
206-070-278-5		VSI 0-6000 FPM	AEROSONIC	Test/Recert
206-070-473-3		INSTRUMENT CLUSTER	ATLAN	Repair
206-070-989-001		TORQUE GAUGE	INSCO	T.B.D.
206-075-185-001		TORQUE IND.	INSCO	T.B.D.
206-075-185-101		TORQUE METER	INSCO	T.B.D.
206-075-187-001		PRESS TEMP INDICATOR	BELL	T.B.D.
206-075-187-1		IND., OIL TEMP/PRESS	INSCO	T.B.D.
206-075-188-5		IND., OIL TEMP/PRESS	INSCO	T.B.D.
206-075-364-5		INVERTER 28VDC-115AC	BELL	Test/Recert
206-075-545-001		SENSOR, RPM	BELL	Test/Recert
206-075-545-5		206 RPM SENSOR	BELL	Test/Recert
206-351-0001-1		INSTURMENT CLUSTER	ATLANTIC S	Repair
2085181-1701		INTERPHONE AMPLIFIER	BENDIX	T.B.D.
209-070-262-003		FUEL PSI INDICATOR		T.B.D.
209-070-262-009		INDICATOR/TEMP PRESS		T.B.D.
209-070-262-101		INDICATOR ENG OIL		T.B.D.
209-070-262-9		INDICATOR ENG OIL		T.B.D.
209-070-263-001		IND DUAL VOLT AC/DC		Repair
209-070-263-003		VOLTMETER		Repair
209-070-263-3		VOLTMETER	ROGERSON K	Repair
209-070-264-001		INDICATOR-AM METER		Repair
209-070-264-3		AMP METER DUAL	KRATOS	Repair
209-070-280-005		FIRE T-HANDLE #1	BELL	Repair
209-070-280-007		SWITCH,FIRE HANDLE 2	BELL	Repair
209-075-325-009		MASTER CAUTION IND.	BELL	Repair
209-075-325-027		CAUTION PANEL	BELL	Repair
209-075-325-033		CAUTION PANEL	BELL	Repair
209-075-325-045		ANNUNCIATOR PANEL	BELL	Repair
209-075-325-27		ANNUNCIATOR PANEL	BELL	Repair



Part Number	Model	Description	Manufacturer	Capability
209-075-325-33		ANNUNCIATOR PANEL	BELL	Repair
209-075-326-001		RPM LIM WARNING DET	BELL	Repair
209-075-326-1		RPM LIMIT DETECTOR	BELL	Repair
209-075-326-101		DETECTOR, RPM LIMIT	BELL	Repair
209-075-326-5		RPM LIMIT DETECTOR	BELL	Repair
209-075-365-3		GYROSCOPE DISPLACE	JET	T.B.D.
209-075-387-001		POWER SUPPLY		T.B.D.
209-075-395-001		CONTROL FIRE DETECT.	KIDDE AERO	T.B.D.
209-7A2		EGT INDICATOR		T.B.D.
212-070-108-005		TRIPLE TACH IND	BENDIX/AME	T.B.D.
212-070-108-007		TRIPLE TACH IND	BENDIX/AME	T.B.D.
212-070-108-103		TRIPLE TACH IND	VDO	T.B.D.
212-070-116-25		INDICATOR TEMP	KRATOS	T.B.D.
212-070-122-11		AIRSPPEED INDICATOR		Test/Recert
212-070-122-9		AIRSPPEED IND		Test/Recert
212-070-160-007		DUAL TORQUE IND.		T.B.D.
212-070-160-07		DUAL TORQUE IND	CLIFTON	T.B.D.
212-070-238-003		ALTIMETER, 35K, LTS	AEROSONIC	Test/Recert
212-070-238-007		ALTIMETER, 35K, LTS	AEROSONIC	Test/Recert
212-070-238-7		ALTIMETER	AEROSONIC	Test/Recert
212-073-927-003		SERVO CONTROLLER		T.B.D.
212-075-036-101		CBOX OIL TMP / PSI		T.B.D.
212-075-224-005		PANEL ASSY		T.B.D.
212-075-406-105		CONTROL PANEL		T.B.D.
212-075-420-1		INDICATOR ITT		T.B.D.
212-075-420-3		INDICATOR ITT		T.B.D.
212-075-540-021		SENSOR		T.B.D.
212-075-602-017		CABLE ASSY C-BOX RH		Repair
212-075-962-001		POWER SUPPLY	PACIFIC EL	Repair
212-077-163-001		COMPASS CONTROL		Repair
212-077-200-001		AUDIO CONTROL	ANDREA	Repair
212-077-200-003		AUDIO PANEL	ANDREA	Repair
212-706-053-005		INDICATOR SWITCH		T.B.D.
214-074-280-107		RPM LIMIT BOX		Repair
214-075-100-15		ANNUNCIATOR PANEL		Repair
214-075-244-001		RATE TRANSMITTER GYR		T.B.D.
214-075-244-1		RATE GYRO	HONEYWELL	T.B.D.
214-075-456-001		ANTI COLLISION LGT		T.B.D.
214-075-456-003		ANTI-COLLISION LGT		T.B.D.
214-175-122-111		CAUTION PANEL	AEROSPACE	Repair
214-175-278-101		ALTIMETER (ENCODING)	AEROSONIC	Test/Recert
22-169-018LBW		INSTRUMENT CLUSTER		T.B.D.
22-373-01-1A		ALTIMETER	GARWIN	Test/Recert
22-374-B01-2		ALTIMETER	CESSNA	Test/Recert
22-37701		ALTIMETER		Test/Recert
2245-5		DIMMER CONT UNIT	AUTRONICS	Repair
22-977		ALTIMETER	GARWIN	Test/Recert
22-977-02-1A		ALTIMETER		Test/Recert
230-218-09-1210		AIRSPPEED IND	MCLEOD INS	Test/Recert
2312C		TURBINE TEMP. IND.	BARFIELD	Test/Recert
2312G		TURBINE TEMP TESTER	BARFIELD	Test/Recert

Part Number	Model	Description	Manufacturer	Capability
2312G-8		TURBINE TEMP TESTER	BARFIELD	Test/Recert
23-501-.**	5000B-.**	ATT GYRO	SIGMA-TEK	Repair
23-501-019		ATTITUDE GYRO	EDO-AIRE	Repair
23-501-031-1	5000B-38	ATT GYRO	SIGMATEK	Repair
23-501-04-2	5000 E-8	Att Gyro 5000E-8	EDO-AIR	Repair
23-501-043-3	5000M-12	ATT GYRO 5000M-12	SIGMA-TEK	Repair
23-501-05-2		ATTITUDE GYRO A/P	SIGMA-TEK	Repair
23-501-06-12	5000B-24	ATT Gyro 5000B-24	SIGMA TEK	Repair
23-501-06-16	5000B-36	ATT GYRO	SIGMA-TEK	Repair
23-501-06-9	5000B-20	ATT GYRO	SIGMA-TEK	Repair
25410036-4		REC COMPUTER UNIT	ADVANCED N	Test/Recert
2579483-1		ROLL TRANSMITTER	SPERRY	T.B.D.
2586261-1		CONTROLLER DIGITAL	SPERRY	T.B.D.
2587193-43		C-14A GYRO COMPASS	SPERRY	T.B.D.
2593379-001		DUAL REMOTE COMPSTR	SPERRY	Repair
270-2436-040	613L-3	TRANSPONDER CONTROL	COLLINS	Repair
270-2436-060	613L-3	TRANSPONDER CONTROL	COLLINS	Repair
270-2436-080	613L-3	TRANSPONDER CONTROL	COLLINS	Repair
2857193-43	C-14A	GYRO COMP ASSY	SPERRY	T.B.D.
3000-1		ELT	POINTER	Test/Recert
3000-11		ELT	POINTER	Test/Recert
300-2101-001		GUARD CARD	WULFSBERG	Repair
300-2102	RT9600/RT7200	TONE MODULE	WULFSBERG	Repair
300-2102-000	RT9600/RT7200	TONE BOARD	WULFSBERG	Repair
300-2169-000	RT9600/RT7200	FM GUARD RX	WULFSBERG	Repair
30-1254-3		STROBE LITE	BELL	T.B.D.
30-231-9		SMOKE DETECTOR	BELL	T.B.D.
30-231R-7B		SMOKE DETECTOR	BELL	T.B.D.
30-326ET-1		CONTROL AMPLIFIER	PYROTECTOR	Repair
30-326-ET-1		FIRE DETECTION SYS	PYROTECTOR	Repair
305-1AL		DIRECTIONAL GYRO	AIM	T.B.D.
3051BL		ATT GYRO IND 28V	AIM	T.B.D.
31240-2014		MARKER BEACON RCVR	ARC	Repair
31640-0000	1N-514R	COURSE DEV IND	ARC	Repair
31640-0001	1N-514R	COURSE DEV IND	ARC	Repair
32350-0001	1N-514R	COURSE DEV IND	ARC	Repair
35060-1122		VERTICAL SPEED IND		Test/Recert
350A-82-1277-01		Turb. Speed Detector	AVTECH	Repair
36109-1L11A3		RMI INDICATOR		T.B.D.
369D24137		FUEL QUANTITY GUAGE	ROCHESTER	T.B.D.
369H6425		DIMMER CONTROL UNIT	AUTRONICS	Repair
37-1001-1		ALTIMETER W/ SIG GEN	AIRCRAFT I	Test/Recert
371BK-10-01		ALTIMETER	KOLLSMAN	Test/Recert
371K-05		ALTIMETER	KOLLSMAN	Test/Recert
37500-220		ALTIMETER 20000 FT	BADIN-CROU	Test/Recert
37500-280		ALTIMETER 20000 FT	BADIN-CROU	Test/Recert
38210-490		VSI (VARIOMETER)	BADIN	Test/Recert
38399-490-02		AIRSPPEED		Test/Recert
389.528-910		VHF TRANSCEIVER	BECKER	Repair
39360-1114		REC-TRANSMITTER	CESSNA A/C	Repair
39380-1114	RT-528A	COMM	CESSNA	Repair

Part Number	Model	Description	Manufacturer	Capability
400-0044-000		VHF REC/TRANS.	WULFSBERG	Repair
400-0050	RT9600	VHF AM TRANSCEIVER	WULFSBERG	Repair
400-0052	RT9600	VHF FM TRANSCEIVER	WULFSBURG	Repair
400-0052-000	RT9600	VHF FM TRANSCEIVER	WULFSBURG	Repair
400-0052-002	RT9600	VHF FM TRANSCEIVER	WULFSBURG	Repair
400-0052-008	RT9600	VHF FM TRANSCEIVER	WULFSBURG	Repair
400-0052-024	RT9600	VHF FM TRANSCEIVER	WULFSBURG	Repair
400-0052-025	RT9600	VHF FM TRANSCEIVER	WULFSBURG	Repair
400-0052-026	RT9600	VHF FM TRANSCEIVER	WULFSBURG	Repair
400-0052-027	RT9600	VHF FM TRANSCEIVER	WULFSBURG	Repair
400-0052-2	RT9600	VHF FM TRANSCEIVER	WULFSBURG	Repair
400-0060	C-961	CONTROL UNIT	WULFSBERG	Repair
400-0073-000	C-962	CONTROL UNIT	WULFSBERG	Repair
400-0073-010	C-962	CONTROL PANEL	WULFSBURG	Repair
400-0084-000	C-722	FM CONTROL	WULFSBURG	Repair
400-0084-010	C-722A	CONTROL UNIT,	WULFSBURG	Repair
400-0087-000	RT7200	FM TRANSCEIVER	WULFSBURG	Repair
400-0087-001	RT7200	FM TRANSCEIVER	WULFSBURG	Repair
400-0087-002	RT7200	FM TRANSCEIVER	WULFSBURG	Repair
4000-10		ELT	POINTER	Test/Recert
400-0102-000	RT-138	FM TRANSCEIVER	WULFSBURG	Repair
400-0102-002	RT138	FM TRANSCEIVER	WULFSBURG	Repair
400-0106-000	C-1000	FM CONTROL	WULFSBURG	Repair
400-0106-010	C-1000	CONTROL HEAD	WULFSBURG	Repair
4000-11		ELT POINTER AF	POINTER	Test/Recert
400-012785-00	RT-***	FLEXCOMM FM TCVR	WULFSBURG	Repair
400-0140-024	RT9600F-24	FM TRANSCEIVER	WULFSBURG	Repair
400-0140-058	RT9600F	TRANSCEIVER/FM	WULFSBURG	Repair
400-0140-076	RT9600F	TRANSCEIVER	WULFSBURG	Repair
400-0140-124	RT9600F	TRANSCEIVER/FM	WULFSBURG	Repair
400-014525-00	RT138	FM TRANSCEIVER	WULFSBURG	Repair
400-014525-000	RT138	FM TRANSCEIVER	WULFSBURG	Repair
400-014525-02	RT-138F	FM TRANSCEIV	WULFSBURG	Repair
4000172-8503		HORIZONTAL DISPLAY	BENDIX	T.B.D.
4000240-5101		SERVO AMP. IND.	BENDIX	Repair
4000393-0101	201F	ADF RECEIVER	BENDIX	Repair
4000417-4101		TRANSPONDER, ATC	BENDIX	Repair
4000502-0101	RT-1201A	RADAR	BENDIX	Repair
4000503-0203	IN1202A	INDICATOR,	BENDIX	Repair
4000503-0210	IN1202A	RADAR IND	BENDIX	Repair
4000504-0301	DA-1203A	ANTENNA DR. ASSY RDR	BENDIX	Repair
4000525-1212	AA-1212	ANTENNA ARRAY	BENDIX	Repair
4000763-3101	RT-131A	RADAR R/T	BENDIX	Repair
4000764-3201	IN-132A	RADAR IND	BENDIX	Repair
4000790-4406	DA-144A	RADAR ANTENNA	BENDIX	Repair
4000831-0101	RT-1401A	RADAR TCVR	BENDIX	Repair
4000831-0102	RT1401B	RADAR TCVR	BENDIX	Repair
4000831-0103	RT1401B	RADAR TCVR	BENDIX	Repair
4000831-0105	RT1401B	RADAR TCVR	BENDIX	Repair
4000833-0201	IN1402A	RADAR INDICATOR	BENDIX	Repair
4000833-0202	IN-1402A	RADAR INDICATOR	BENDIX	Repair

Part Number	Model	Description	Manufacturer	Capability
4000833-0207	IN-1402B	RADAR INDICATOR	BENDIX	Repair
4000833-0208	IN-1402B	RADAR INDICATOR	BENDIX	Repair
4000946-5201	IN-152A	RADAR INDICATOR	BENDIX	Repair
4001018-6102	ART-161A	RADAR TCVR	BENDIX	Repair
4001018-6106	ART-161A	RADAR TCVR	BENDIX	Repair
4001098-0201	IN-1202B	RADAR INDICATOR	BENDIX	Repair
4001291-2103	IN-2021A	RADAR INDICATOR	BENDIX	Repair
4001670-2501	IN-2025A	RADAR INDICATOR	BENDIX	Repair
4001670-2503	IN-2025A	RADAR INDICATOR	BENDIX	Repair
4001670-2511	IN-2025B	RADAR INDICATOR	BENDIX	Repair
4001670-2512	IN-2025B	RADAR INDICATOR	BENDIX	Repair
4001670-2513	IN-2025B	RADAR INDICATOR	BENDIX	Repair
4001921-5101	RT-1151A	RADAR TCVR	BENDIX	Repair
4001922-5202	IN-1152A	RADAR INDICTOR	BENDIX	Repair
4001922-5203	IN-1152A	COLOR RADAR INDICATO	BENDIX	Repair
4004437-901	RT-220	RADAR ALT.	SPERRY	Repair
4007339-901	RA-***	RAD ALT IND	SPERRY	Repair
4012395-905		CONTROLLER/MODE SEL.	SPERRY	T.B.D.
4014267-901	RA-215	INDICATOR, RAD ALT	SPERRY	Repair
4020936-901		TARSYNN GYRO ASSY	SPERRY	T.B.D.
4025008-902		HELIPILOT COMPUTER	SPERRY	T.B.D.
4025008-920		HELIPILOT COMPUTER	SPERRY	T.B.D.
41340-0001	RA-346A	RECEIVER ACCESSORY	ARC	T.B.D.
41420-0028	RT-359A	TRANSPONDER	ARC	Repair
41420-1114	RT-359A	TRANSPONDER	ARC	Repair
41420-1128	RT-359A	TRANSPONDER	ARC	Repair
41630-0028	RTA-432A	ACCESSORY UNIT	ARC	T.B.D.
41740-1114	RT-328A	NAV/COMM	ARC	Repair
41830-1000	RT-432A	TRANSCEIVER	ARC	Repair
42100-0000	R-443B	GLIDESLOPE RCVR	ARC	Repair
42430-1114	RT-328C	NAV COMM	ARC	Repair
42450-1114	RT-308C	NAV COMM	ARC	Repair
42540-2114	EA-401A	ENCODING ALTIMETER	ARC	Test/Recert
428-2003	428-2003	ALTITUDE ENCODER	IIMORROW	Test/Recert
45-0013-7	45-0013-7	LANDING LIGHT	GRIMES	Repair
45010-1000	IN-514B	VOR/LOC IND	ARC	Repair
45010-2000	IN-525B	VOR/ILS IND	ARC	Repair
453-0150	ELT110-4	ELT	ARTEX	Test/Recert
455-0422	ELT110-406HM	ELT	ARTEX	Test/Recert
455-7013-01	ELT100HM	ELT	ARTEX	Test/Recert
46660-1000	RT-385A	NAV/COMM XCEIVER	ARC	Repair
46660-1100	RT-385A	TRANSCEIVER	ARC	Repair
46860-1200	IN-385A	VOR INDICATOR	ARC	Repair
46860-2000	IN-386A	VOR/ILS CONV.IND.	ARC	Repair
47360-1000	RT-485A	REC/TRANS.		Repair
5006-1038		INDICATOR TEMP	INSCO	T.B.D.
500DC(BELL)(5)	500DC(BELL)(5)	GYRO HORIZON	AIM	Repair
500DCF	500DCF	ATTITUDE GYRO (AIM)	AIM	T.B.D.
501-1075-04	PS-823B	EMERG PWR SUPP	J.E.T.	Repair
501-1075-06	PS-823B	EMERG PWR SUPP	J.E.T.	Repair
501-1228-02	PS-823B	EMERG PWR SUPP	J.E.T	Repair

Part Number	Model	Description	Manufacturer	Capability
501-1228-04	PS-823B	EMERG PWR SUPP	J.E.T	Repair
501-1318-01	PS-823B	STATIC CONVERTER	J.E.T.	Repair
5020-1	5020-1	CVR AUDIO MIXER	AVTECH	T.B.D.
5020-2	5020-2	CVR AUDIO MIXER DUAL	AVTECH	T.B.D.
5035P2-25	5035P2-25	ENCODING ALTIMETER	UNITED	Test/Recert
5035P2-P	5035P2-P	ENCODING ALTIMETER	UNITED	Test/Recert
5035P-P20	5035P-P20	ENCODING ALTIMETER	UNITED	Test/Recert
5035P-P22	5035P-P22	ENCODING ALTIMETER	UNITED	Test/Recert
5035P-P23	5035P-P23	ALTIMETER ENCODING	UNITED	Test/Recert
5035P-P40	5035P-P40	ENCODING ALTIMETER	UNITED	Test/Recert
5035P-P-40	5035P-P-40	ENCODING ALTIMETER	UNITED	Test/Recert
504-0006-914	300-14	HORIZON GYRO 5 DEG	AIM	T.B.D.
504-0010-907	500DC(BELL)(5)	GYRO HORIZON 500DC	AIM	Repair
504-0017-901	510-1A	GYRO HORIZON 5 DEG	AIM	Repair
504-0033-902	305-2*	GYRO HORIZON IND	AIM	Repair
505-0002-9XX	200DC( )	DIR. GYRO	AIM	T.B.D.
505-0010-9XX	200DCL	DIR. GYRO	AIM	T.B.D.
505-0023-907		DIRECTIONAL GYRO	AIM	T.B.D.
505-0031-902	205-1()	DIRECTIONAL GYRO	AIM	Repair
505-0031-904	205-1BL	DIRECTIONAL GYRO	AIM	Repair
506-0021-901	HSI-610-1	HSI-610-1 INDICATOR	AIM	T.B.D.
507-0020-910	TC120-**	TURN COORDINATOR	AIM	T.B.D.
519-22702-001	519-22702-001	ENCODING ALTIMETER	INTER. DYN	Test/Recert
519-22702-031	519-22702-031	35000 FT ENC ALT.	INTER. DYN	Test/Recert
520-5160-006	520-5160-006	IND, COURSE SELECTOR	AERONETICS	T.B.D.
520-7100-001	NC7100	RMI CONVERTER	AERONETIC	T.B.D.
522-2357-00	614L-8	ADF CONTROL	COLLINS	Repair
522-2357-011	614L-8	ADF CONTROL	COLLINS	Repair
522-2466-004	618M1	VHF TRANCEIVER	COLLINS	Repair
522-2587-00	51Y-4A	ADF RCVR	COLLINS	Repair
522-2587-012	51Y-4A	ADF RCVR	COLLINS	Repair
522-2587-015	51Y-4A	ADF RCVR	COLLINS	Repair
522-2638-006	331A-3G	IND. HSI,	COLLINS	Repair
522-2644-011	328A-3G	SLAVING ACCESSORY	COLLINS	Repair
522-2866-000	356C-4	ISOLATION AMPLIFIER	COLLINS	Repair
522-2867-000	356F-3	SPEAKER AMPLIFIER	COLLINS	Repair
522-2899-000	387C-4	AUDIO CONTROL	COLLINS	Repair
522-3616-201	313N-4D	CONTROL NAV	COLLINS	Repair
522-3616-202	313N-4D	CONTROL NAV	COLLINS	Repair
522-3616-504	313N-4D	NAV/DME CONTROL	COLLINS	Repair
522-3617-000	313N-5A	VHF CONTROL	COLLINS	Repair
522-3617-001	313N-5A	VHF CONTROL	COLLINS	Repair
522-3617-003	313N-5A	VHF CONTROL	COLLINS	Repair
522-3617-500	313N-5A	VHF CONTROL	COLLINS	Repair
522-3617-503	313N-5A	VHF CONTROL	COLLINS	Repair
522-3763-002	346B-3	AUDIO CONTROL CENTER	COLLINS	Repair
522-3876-001	51Z-6	MARKER BEACON RECEIV	COLLINS	Repair
522-4088-203	618M-2B	VHF TCVR	COLLINS	Repair
557-4111-202	IVA557	RMI INDICATOR	AEROSPATIA	Repair
557-4131-902	IVA557	RMI INDICATOR	AEROSPATIA	Repair
570-074-080-003	570-074-080-003	TRANSDUCER	BELL	Test/Recert

Part Number	Model	Description	Manufacturer	Capability
570-074-080-3	570-074-080-3	TRANSDUCER	BELL	Test/Recert
570-074-100-1	570-074-100-1	SENSOR AMP	BELL	Repair
571-25005-012	571-25005-012	35000 FT ENC. ALT.	BELL	Test/Recert
574-074-140-003	574-074-140-003	PANEL AFCS CONTROL	BELL	Repair
574-074-140-3	574-074-140-3	PANEL-SCAS CONTROL	BELL	Repair
574-074-150-001	574-074-150-001	AFCS TRIM CONTROL	BELL	Repair
590-1104	A-33	GPS ANTENNA	IIMORROW	Test/Recert
5932A-0201	5932A-0201	ALTIMETER	UNITED	Test/Recert
5932-BH01	5932-BH01	ALTIMETER PRESSURE	UNITED	Test/Recert
5932-BH5	5932-BH5	ALTIMETER/INDICATOR	UNITED	Test/Recert
5932P	5932P	ALTIMETER	UNITED	Test/Recert
5934-1	5934-1	ALTIMETER	UNITED	Test/Recert
5934A-1	5934A-1	ALTIMETER	UNITED	Test/Recert
5934-A74	5934-A74	ALTIMETER	UNITED	Test/Recert
5934D-1	5934D-1	ALTIMETER	UNITED	Test/Recert
5934P	5934P	ALTIMETER	UNITED	Test/Recert
5934P-1	5934P-1	ALTIMETER	UNITED	Test/Recert
5934P-3	5934P-3	ALTIMETER 20K TSO,D	UNITED	Test/Recert
5934PA	5934PA	ALTIMETER	UNITED	Test/Recert
5934PA-1	5934PA-1	ALTIMETER	UNITED	Test/Recert
5934PA-3	5934PA-3	ALTIMETER	UNITED	Test/Recert
5934PA-A76	5934PA-A76	ALTIMETER	UNITED	Test/Recert
5934PAD-1	5934PAD-1	ALTIMETER	UNITED	Test/Recert
5934PAI	5934PAI	ALTIMETER	UNITED	Test/Recert
5934PD-1	5934PD-1	ALTIMETER	UNITED	Test/Recert
5934PD-3	5934PD-3	ALTIMETER	UNITED	Test/Recert
60-3274-1	60-3274-1	POWER SUPPLY, STROBE	GRIMES	Repair
60-3274-4	60-3274-4	POWER SUPPLY	GRIMES	Repair
60-3274-5	60-3274-5	POWER SUPPLY, STROBE	GRIMES	Repair
61550-61353-101	61550-61353-101	MASTER CAUTION PANEL	SIKORSKY	Repair
61553-109-4	61553-109-4	T4 INDICATOR	JAEGER	Test/Recert
622-0555-003	RMI 332C-10	RMI	COLLINS	Repair
622-0876-001	VIR-30A	VOR/LOC RCVR	COLLINS	Repair
622-0876-004	VIR-30A	VOR/LOC RCVR	COLLINS	Repair
622-0876-011	VIR-30A	VOR/LOC RCVR	COLLINS	Repair
622-0877-001	VIR-30M	VOR/LOC RCVR	COLLINS	Repair
622-1204-002	339H4	INDICATOR/RAD ALT	COLLINS	Repair
622-1204-003	339H4	INDICATOR ALTIMETER	COLLINS	Repair
622-1205-003	339H*	ALTIMETER INDICATOR	COLLINS	Repair
622-1233-001	DME-40	DME TRANCEIVER	COLLINS	Repair
622-1233-01	DME-40	DME TRANCEIVER	COLLINS	Repair
622-1234-002	339F12	DME INDICATOR	COLLINS	Repair
622-1234-012	339F12	INDICATOR	COLLINS	Repair
622-1270-001	TDR-90	TRANSPONDER,	COLLINS	Repair
622-1334-002	VHF-20B	RECEIVER-TRANSMITTER	COLLINS	Repair
622-1879-001	VHF-20A	VHF TRANCEIVER	COLLINS	Repair
622-1879-002	VHF-20A	VHF TRANCEIVER	COLLINS	Repair
622-2012-011	339F-12A	DME INDICATOR	COLLINS	Repair
622-2012-012	339F-12A	DME INDICATOR	COLLINS	Repair
622-2078-001	VHF-251	VHF TRANCEIVER	COLLINS	Repair
622-2079-001	VHF-250	VHF TRANCEIVER	COLLINS	Repair

Part Number	Model	Description	Manufacturer	Capability
622-2080-001	VIR-351	NAV RCVR	COLLINS	Repair
622-2080-011	VIR-351	VIR-351 NAV RCVR	COLLINS	Repair
622-2082-003	IND-350	NAV. IND	COLLINS	Repair
622-2084-001	GLS-350	GS RCVR	COLLINS	Repair
622-2085-001	MKR-350	MARKER RCVR	COLLINS	Repair
622-2092-001	TDR-950	TRANSPONDER	COLLINS	Repair
622-2093-001	PWC-150	VOLT CONV	COLLINS	Repair
622-2175-001	339F-12B	DME INDICATOR	COLLINS	Repair
622-2175-002	339F-12B	DME INDICATOR	COLLINS	Repair
622-2176-001	339F-***	DME INDICATOR	COLLINS	Repair
622-2362-001	ADF-60A	RECEIVER	COLLINS	Repair
622-2363-001	ANT-60A	ADF ANTENNA	COLLINS	Repair
622-2506-009	RMI-36	INDICATOR,RMI	COLLINS	Repair
622-2882-001	TCR-200	HF TRANSCEIVER	COLLINS	Repair
622-2882-002	TCR-200	HF REC/EXCITER	COLLINS	Repair
622-2883-001	PWR200	HF PWR AMP	COLLINS	Repair
622-2884-001	AAC-200	ANTENNA COUPLER	COLLINS	Repair
622-2884-004	AAC-200	ANTENNA COUPLER	COLLINS	Repair
622-2885	CTL-200	HF CONTROL	COLLINS	Repair
622-2885-001	CTL-200	HFCONTROL	COLLINS	Repair
622-3101-001	AUD-251H	AUDIO PANEL	COLLINS	Repair
622-3101-011	AUD-251H	AUDIO PANEL	COLLINS	Repair
622-3101-251	AUD-251H	AUDIO PANEL	COLLINS	Repair
622-3201-001	ALT-50	TRANSCEIVER/RAD ALT	COLLINS	Repair
622-3363-001	VHF-251E	VHF TRANCEIVER	COLLINS	Repair
622-3594-016	ADI-84A	INDICATOR	COLLINS	T.B.D.
622-3670-001	DME-451	DME TRANCEIVER	COLLINS	Repair
622-3671-001	IND-450	DME INDICATOR	COLLINS	Repair
622-3672-001	IND-451	DME INDICATOR	COLLINS	Repair
622-3915-002	IND-40	DME INDICATOR	COLLINS	Repair
622-4477-001	IND-350A	NAV INDICATOR	COLLINS	Repair
622-4478-001	IND351A	NAV INDICATOR	COLLINS	Repair
622-4490-001	CTL-201A	HF-200 CONTROL	COLLINS	Repair
622-4523-015	CTL-20	COMM CONTROL	COLLINS	Repair
622-4524-063	CTL-30	NAV CONTROL	COLLINS	Repair
622-4524-064	CTL-30	NAV CONT. DIGITAL 28	COLLINS	Repair
622-4524-088	CTL-30	NAV CONTROL	COLLINS	Repair
622-4526-015	CTL-60	ADF CONTROL	COLLINS	Repair
622-4526-016	CTL-60	ADF CONTROL	COLLINS	Repair
622-4527-007	CTL-90	TRANSPONDER CONT	COLLINS	Repair
622-4527-016	CTL-90	TRANSPONDER CONT	COLLINS	Repair
622-4545-001	CTL-220	HF CONTROL	COLLINS	Repair
622-4545-003	CTL-220	HF 220 CONTROL	COLLINS	Repair
622-4545-004	CTL-220	HF 220 CONTROL	COLLINS	Repair
622-4545-006	CTL-220	HF 220 CONTROL	COLLINS	Repair
622-5337-001	TCR-220	HF TRANSCEIVER	COLLINS	Repair
622-6137-001	VIR32	VOR/LOC/GS/MB RCVR	COLLINS	Repair
622-6137-201	VIR32	VOR/LOC/GS/MB RCVR	COLLINS	Repair
622-6263-001	DME42	DME TRANSCIEVER	COLLINS	Repair
622-6263-003	DME42	DME TRANSCIEVER	COLLINS	Repair
622-6389-001	VHF-21A	VHF TRANCEIVER	COLLINS	Repair

Part Number	Model	Description	Manufacturer	Capability
622-6389-011	VHF-21A	VHF TRANCEIVER	COLLINS	Repair
622-6513-001	ANT-312	RADAR ANT.	COLLINS	Repair
622-6520-008	CTL-22	VHF CONTROL	COLLINS	Repair
622-6521-015	CTL-32	VHF NAV CONTROL	COLLINS	Repair
622-6521-016	CTL-32	VHF NAV CONTROL	COLLINS	Repair
622-6522-006	CTL-62	ADF CONTROL	COLLINS	Repair
622-6522-007	CTL-62	ADF CONTROL	COLLINS	Repair
622-6522-008	CTL-62	ADF CONTROL	COLLINS	Repair
622-6523-004	CTL-92	ATC CONTROL	COLLINS	Repair
622-6523-008	CTL-92	ATC CONTROL	COLLINS	Repair
622-6524-003	IND-42A	DME IND	COLLINS	Repair
622-6557-001	TCR-230	HF TRANSCIEVR	COLLINS	Repair
622-6590-001	CAD-62	CONTROL ADAPT	COLLINS	Repair
622-6614-001	CTL-230	HF CONTROL	COLLINS	Repair
622-6614-003	CTL-230	HF CONTROL	COLLINS	Repair
622-6614-023	CTL-230	HF CONTROL	COLLINS	Repair
622-6614-024	CTL-230	HF CONTROL	COLLINS	Repair
622-6667-001	PWR-230	HF PWR AMP	COLLINS	Repair
622-8134-001	622-8134-001	HF SWR SENSOR	COLLINS	Repair
627934-3	RESCU 88C	RESCU 88C		Test/Recert
628-7125-002	628-7125-002	MODE CONTROLLER	COLLINS	Repair
628-8132-001	ATM-200	INDICATOR, HF	COLLINS	Repair
629-7902-001	629-7902-001	MARKER BCN RCVR	COLLINS	Repair
6710K010	6710K010	ALTIMETER	KOLLSMAN	Test/Recert
671BK	671BK	Altimeter 50K	KOLLSMAN	Test/Recert
671BK-010	671BK-010	ALTIMETER	KOLLSMAN	Test/Recert
671BU-010	671BU-010	ALTIMETER	KOLLSMAN	Test/Recert
671CPX-4-037D	671CPX-4-037D	ALTIMETER	KOLLSMAN	Test/Recert
686-4033-100	686-4033-100	WIND SCREEN WIPER CT	AEROSPATIAL	Repair
7000839-904	RA-315	RADIO ALTIMETER IND	SPERRY	Repair
7001840-934	RT-300	RAD ALT TCVR	HONEYWELL	T.B.D.
704A-47-632-051	704A-47-632-051	T4 INDICATOR	JAEGER	T.B.D.
716.707-918	716.707-918	VOLTAGE CONVERTER	BECKER	Repair
7600-01804-103	7600-01804-103	AFCS IND PNL	SIKORSKY	Repair
761272-3	761272-3	AFCS INDICATOR PANEL	SIKORSKY	Repair
76304-07009-107	76304-07009-107	DUCT/INLET AIR	SIKORSKY	Repair
76304-07009-113	76304-07009-113	DUCT/INLET AIR	SIKORSKY	Repair
76304-07900-107	76304-07900-107	BELLMOUTH HEATER	SIKORSKY	Repair
76304-07900-109	76304-07900-109	SNOW SHIELD	SIKORSKY	Repair
76304-07900-113	76304-07900-113	DUCT/INLET AIR	SIKORSKY	Repair
76306-07902-101	76306-07902-101	FLAME DETECTOR	SIKORSKY	Test/Recert
76401-01101-042	76401-01101-042	CYCLIC STICK	SIKORSKY	Repair
76401-01101-043	76401-01101-043	CYCLIC STICK	SIKORSKY	Repair
76450-01019-101	76450-01019-101	TONE GENERATOR	SIKORSKY	Test/Recert
76450-01072-106	76450-01072-106	IND. HYD OIL PRESS	SIKORSKY	T.B.D.
76450-01076-101	76450-01076-101	IND. GAS GEN. TACH	SIKORSKY	T.B.D.
76450-01076-103	76450-01076-103	IND. TRIPLE TACH	SIKORSKY	T.B.D.
76450-01076-105	76450-01076-105	IND. T5 DIG.REPEATER	SIKORSKY	T.B.D.
76450-01076-106	76450-01076-106	INDICATOR T5 ANALOG	SIKORSKY	T.B.D.
76450-01076-107	76450-01076-107	IND. ENG PTIT	SIKORSKY	T.B.D.
76450-01076-110	76450-01076-110	IND. GAS GEN TACH	SIKORSKY	T.B.D.



Part Number	Model	Description	Manufacturer	Capability
76450-01078-101	76450-01078-101	IND. OIL PRESS/TEMP	SIKORSKY	T.B.D.
76450-01078-103	76450-01078-103	IND. FUEL QUANTITY	SIKORSKY	T.B.D.
76450-01078-104	76450-01078-104	IND. HYD OIL PRESS	SIKORSKY	T.B.D.
76450-01078-106	76450-01078-106	IND. TOURQUE DUAL	SIKORSKY	T.B.D.
76450-01078-112	76450-01078-112	IND. XMSN OIL P&T	SIKORSKY	T.B.D.
76550-01001-103	76550-01001-103	CAUTION/ADV. PANEL	SIKORSKY	Repair
76550-01001-104	76550-01001-104	MASTER CAUTION W.PNL	SIKORSKY	Repair
76550-01001-149	76550-01001-149	MASTER CAUTION PANEL	SIKORSKY	Repair
76550-01008-101	76550-01008-101	DIMMER UNIT	SIKORSKY	Repair
76550-01008-102	76550-01008-102	DIMMER CONTROL	SIKORSKY	Repair
76550-01008-103	76550-01008-103	DIMMER CONTROL	SIKORSKY	Repair
76550-02005-101	76550-02005-101	SEARCH LIGHT	SIKORSKY	Repair
76550-02005-102	76550-02005-102	SEARCH LIGHT	SIKORSKY	Repair
76550-03007-105	76550-03007-105	INVERTER AC POWER	SIKORSKY	Repair
76550-03033-041	76550-03033-041	PALLET ASSY	SIKORSKY	Repair
766.739-910	AR-3202	VHF COMM	BECKER	Repair
76900-01803-101	76900-01803-101	CONTROL PANEL AFCS	SIKORSKY	Repair
76900-01804-103	76900-01804-103	INDICATOR PANEL	SIKORSKY	Repair
76900-01805-101	76900-01805-101	AIRSPD SWITCH, 40K	SIKORSKY	Repair
76900-01805-102	76900-01805-102	AIRSPD SWITCH, 60K	SIKORSKY	Repair
76900-01813-101	76900-01813-101	PRESSURE TRANSDUCER	SIKORSKY	T.B.D.
76900-01821-101	76900-01821-101	TRANSDUCER	SIKORSKY	T.B.D.
777-1492-001	51Y-7	ADF RECEIVER	COLLINS	Repair
777-1492-004	51Y-7	ADF RECEIVER	COLLINS	Repair
777-1493-006	614L-11	CONTROL ADF-60A	COLLINS	Repair
787-6366-012	614L-12	ADF CONTROL	COLLINS	Repair
792-6275-003	614L-13	CONTROL, ADF	COLLINS	Repair
792-6657-001	VHF-20	TRANSCEIVER VHF	COLLINS	Repair
792-6657-003	VHF-20	TRANSCEIVER VHF	COLLINS	Repair
792-6657-004	VHF-20	RECEIVER-TRANSMITTER	COLLINS	Repair
7K187	SHARC 7K	ELT , SHARC 7K	SHARC	Test/Recert
8000 SERIES	8000 SERIES	Airspeed Ind	UNITED	Test/Recert
80-0092-7		#2 CAUTION PANEL	GRIMES	Repair
80-0093-1		CAUTION PANEL	GRIMES	Repair
80-0093-5		PANEL CAUTION	GRIMES	Repair
80-0331-1		CAUTION PANEL	GRIMES	Repair
80-0331-3		CAUTION PANEL	GRIMES	Repair
80265-00-0304	TNL-3100	GPS-LORAN	TRIMBLE	Repair
80265-01-0210	TNL-2101	GPS RDU	TRIMBLE	Repair
80265-01-0211	TNL 2100	GPS RDU	TRIMBLE	Repair
8033-100095	ASB-850	HF XCVR	SUNAIR	Repair
80415-00-0601	TNL-1000	GPS RCVR	TRIMBLE	Repair
80415-10-0611	TNL-1000	GPS RCVR	TRIMBLE	Repair
80446-00	TNL-1000	GPS RCVR	TRIMBLE	Repair
80446-10	TNL-1000	GPS RCVR	TRIMBLE	Repair
80821-00	TNL-2000T	GPS RCVR	TRIMBLE	Repair
80821-00-0218	TNL-2000T	GPS RCVR	TRIMBLE	Repair
80822-00	TNL-2100T	GPS RCVR	TRIMBLE	Repair
80822-00-0212	TNL-2100T	GPS RCVR	TRIMBLE	Repair
80822-00-0218	TNL-2100T	GPS RCVR	TRIMBLE	Repair
8095536-8101		RADAR SENSOR	BENDIX	T.B.D.

Part Number	Model	Description	Manufacturer	Capability
8095537-8101		COLOR RADAR IND	BENDIX	T.B.D.
81085-21	TNL-2100T	GPS	TRIMBLE	Repair
81086-31	TNL-3100T	GPS/LORAN	TRIMBLE	Repair
81087-20	TNL-2000T	GPS	TRIMBLE	Repair
81088-30	TNL-3000T	GPS/LORAN	TRIMBLE	Repair
8140B-35	8140B-35	ALTIMETER	AERO MECH	Test/Recert
8140B-S20LW MB	8140B-S20LW	ALTIMETRE/ENCODING	AERO MECH	Test/Recert
81439-00-0232	TNL-2101	GPS RCVR	TRIMBLE	Repair
81440-02-241A	TNL-2101 I/O	GPS RCVR	TRIMBLE	Repair
81463-01	2000 APP	GPS RCVR	TRIMBLE	Repair
81464-00	2101 APP	GPS RCVR	TRIMBLE	Repair
81465-00	2101 I/O	GPS RCVR	TRIMBLE	Repair
8503-S20LW	8503-S20LW	ALTIMETER	AERO MECH	Test/Recert
861605-2	861605-2	VHF BASE STATION	TECHNISONI	Repair
868.541-910	AR-4201	VHF COMM	BECKER	Repair
876.471-915	ATC-3401	TRANSPONDER	BECKER	Repair
890.502-910	AR-3209-11	VHF TRANS	BECKER	Repair
892121-0350P		CONTROL UNIT	WALTE KIDD	Test/Recert
892121-0350-P		CONT. UNIT FIRE DET.	WALTE KIDD	Test/Recert
901006-2		TRANSCEIVER VHF/AM	TECHNISONIC	Repair
921012-1	TFM-138	TFM-138G VHF FM	TECHNISONIC	Repair
921012-2	TFM-138	TFM-138 VHF FM TCVR	TECHNISONIC	Repair
93-A152-2		CONTROL UNIT	FAIRCHILD	Repair
93-A152-20		CVR CONTROL	FAIRCHILD	Repair
93-A152-30		A152B CVR CONTROL	FAIRCHILD	Repair
93-A152-70		CONTROL UNIT CVR	LORAL/ FAI	Repair
941059-1	TFM---403	TRANSCEIVER TFM-403G	TECHNISONI	Repair
9550B		TURN AND SLIP	UNITED INS	T.B.D.
9599-607-12158	IND-021	INDICATOR IND021	TRT	Repair
961068-2	A710	AUDIO PANEL	TECHNISONIC	Repair
961072-2	A711	AUDIO PANEL	TECHNISONIC	Repair
980-6116-00X		CVR CONT WITH MIC	ALLIEDSIGN	T.B.D.
980-6117-003		CVR Control w/o Mic	ALLIEDSIGN	T.B.D.
980-6117-00X		CVR Control w/o Mic	ALLIEDSIGN	T.B.D.
990-3138-000	M1090	CVR ADAPTER M1090	BAKER	T.B.D.
990-3138-000	M1090	CVR MIC/AUDIO ADAPT	BAKER	T.B.D.
A152-2	A-152	CONTROL UNIT	FAIRCHILD	T.B.D.
A1600	A-1600	INDICATOR TURN &SLIP		T.B.D.
A-30		ENCODER	ACK	Test/Recert
A301-6		AUDIO CONTROL PANEL	ANDREA	Repair
A301-61		AUDIO CONTROL PANEL	ANDREA	Repair
A301-6R		AUDIO CONTROL PANEL	ANDREA	Repair
A301-6W		AUDIO CONTROL PANEL	ANDREA	Repair
A35MA		ALTIMETER	AEROSONIC	Test/Recert
A-35-MA-10L		ALTIMETER	AEROSONIC	Test/Recert
A413A,HDA-CF-14/28		STROBE POWER SUPPLY	WHELEN	Repair
A413A,HDA-DF-28		STROBE POWER SUPPLY	WHELEN	Repair
A4503M8-1		LDG GEAR CONTROL		T.B.D.
A80-AAU-7A/A-20		ALTIMETER		Test/Recert
AA12-001		AUDIO PANEL	NAT	Repair
AA12-002		AUDIO PANEL	NAT	Repair

Part Number	Model	Description	Manufacturer	Capability
AA12-003		AUDIO PANEL (POLICE)	NAT	Repair
AA20-050H		PA INTERNAL/EXTERNAL	NAT	Repair
AA20-430		CABIN PA	NAT	Repair
AA22-160		SIREN/PA CONTROL	NAT	Repair
AA22-492		SIREN PA CONTROL	NAT	Repair
AA31-002		ICS MODE SELECTOR	NAT	Repair
AA31-502		ICS MODE SELECTOR	NAT	Repair
AA36-001		ICS TIE ADAPTER	NAT	Repair
AA37-001		ALERTING SYSTEM	NAT	Repair
AA80-001		INTERVOX ICS 4 PLACE	NAT	Repair
AA80-020		INTERVOX,ICS 4 PLACE	NAT	Repair
AA80-060		INTERVOX ICS 6 PLACE	NAT	Repair
AA80-062		INTERVOX ICS 6 PLACE	NAT	Repair
AA85-001		INTERCOM 6 PLACE	NAT	Repair
AA90-011		AUDIO CONTROLLER	NAT	Repair
AA90-016		ICS BOX	NAT	Repair
AA90-427		AUDIO CONTROLLER	NAT	Repair
AA90-450		AUDIO CONTROL PANEL	NAT	Repair
AA95-705		AUDIO PANEL	NAT	Repair
AA95-706		AUDIO PANEL	NAT	Repair
AC31-2B		HF ANTENNA CONTROL	SPILSBURY	Repair
AC31-3		SPILSBURY VSWR SHNT	SPILSBURY	Repair
AC-31B		HF ANT SYSTEM	SPILSBURY	Repair
AC31B1		HF antenna	SPILSBURY	Repair
AC31B-2		SPILSBURY VSWR MTR	SPILSBURY	Repair
AC31C-2		SPILSBURY SWR METER	SPILSBURY	Repair
AC-31D-2		CONTROL ANT	SPILSBURY	Repair
AIRCOM 55		INTERCOM	UNIVERSITY	Repair
AK-350		ENCODER, ALT	AMERKING	Test/Recert
AK-450		ELT TRANSMITTER	AMERI-KING	Test/Recert
AMS40		AUDIO PANEL	NAT	Repair
AMS42		AUDIO PANEL	NAT	Repair
AMS42F		AUDIO PANEL	NAT	Repair
AMS43		AUDIO PANEL	NAT	Repair
AMS43TSO		AUDIO PANEL	NAT	Repair
AMS44		AUDIO PANEL	NAT	Repair
AN5760-4B		ALTIMETER	BUESCHER-E	Test/Recert
AR3202		TRANSCEIVER VHF	BECKER	Repair
AR3202-01-110		VHF COMM	BECKER	Repair
AR3202-1-01		VHF-TRANSCEIVER	BECKER	Repair
AR3203-01-110		VHF TRANSCEIVER	BECKER	Repair
AR-500		MODE C ENCODER	NARCO	Test/Recert
AR-850		ALTITUDE REPORTER	NARCO	Test/Recert
AR-850-20K		ALTITUDE REPORTER	NARCO	Test/Recert
AR-850-25K		Altitude Reporter	NARCO	Test/Recert
ASB-60		POWER AMP	SUNAIR	Repair
ASH584-5		AC INVERTER	LEYLEND	Repair
AT150		TRANSPONDER	NARCO	Repair
AT150TSO		TRANSPONDER	NARCO	Repair
AT-3000		ENCODER	TERRA	Test/Recert
AT50		TRANSPONDER	NARCO	Repair

Part Number	Model	Description	Manufacturer	Capability
AT50A		TRANSPONDER	NARCO	Repair
AT50A TSO		TRANSPONDER	NARCO	Repair
C-4000		ELT	POINTER	Test/Recert
C661070-0101		ALTIMETER	UNITED INS	Test/Recert
C661071-0101		ALTIMETER	UNITED INS	Test/Recert
C661076-0103		GYRO HORIZON	AIM	Repair
C-823A/AIC-10		CONTROL, INTERPHONE	ANDREA	Repair
C-824A/AIC-10		CONTROL PANEL	ANDREA	Repair
C-826/AIC-10		CONTROL PANEL	ANDREA	Repair
CH201-01FL		TACCOM CONTROL	NAT	Repair
CH201-0R0		TAC/COM CONTROL	NAT	Repair
CH202-0RF		CONTROL HEAD	NAT	Repair
CH250-010		FM COMMUNICATION SYS	NAT	Repair
CH250-0NR		FM CONTROL	NAT	Repair
CIR-11-2		ELT		Test/Recert
COM 10A		VHF TRANSCEIVER	NARCO	Repair
COM 11		VHF TRANSCEIVER	NARCO	Repair
COM 111 B TSO		VHF TRANSCEIVER	NARCO	Repair
COM 120 TSO		VHF TRANSCEIVER	NARCO	Repair
COM 810		VHF TRANSCEIVER	NARCO	Repair
COM11A		VHF TRANSCEIVER	NARCO	Repair
COM11B		VHF TRANSCEIVER	NARCO	Repair
COM120/20		VHF TRANSCEIVER	NARCO	Repair
CP126ATSO		AUDIO PANEL	NARCO	Repair
CP135TSO		AUDIO PANEL W/INT MB	NARCO	Repair
CP-136M		AUDIO PANEL	NARCO	Repair
CP136TSO		AUDIO PANEL	NARCO	Repair
CP1766G		AUDIO PANEL	TEAM	T.B.D.
CP1976A		AUDIO CONTROL	TEAM	T.B.D.
CP1976A1		CONTROL	TEAM	T.B.D.
D120-P2T		BLIND ENCODER		Test/Recert
D120-P2-T		ALTITUDE ENCODER		Test/Recert
DM 8.1		ELT	DORNE&MARG	Test/Recert
DM ELT 1-3		ELT TRANSMITTER	DORNE&MARG	Test/Recert
DM ELT 6		ELT	DORNE&MARG	Test/Recert
DM ELT 6.1		ELT	DORNE&MARG	Test/Recert
DM ELT 8.1		ELT	DORNE&MARG	Test/Recert
DM ELT14-1-1		ELT	DORNE&MARG	Test/Recert
DM6.1		ELT	DORNE&MARG	Test/Recert
DME 890		DME INTERRIGATOR	NARCO	Repair
DM-ELT6		ELT	DORNE&MARG	Test/Recert
DM-ELT6.1		ELT	DORNE&MARG	Test/Recert
DTE-12-001		DATA ENTRY DTMF CONT	NAT	Repair
DTE-12-501		DATA ENTRY/ DTMF	NAT	Repair
E-01		ELT ; ACK TECHNOLOGY	ACK	Test/Recert
EB-2BCD		E.L.T.	MARTECH	Test/Recert
EBC-102A		ELT	EBC	Test/Recert
ELT 110-4		ELT TRANSMITTER	ARTEX	Test/Recert
ELT 6.1		ELT TRANSMITTER	DORNE&MARG	Test/Recert
ELT 910		E.L.T.	NARCO	Test/Recert
ELT10		EMERGENCY LOCATER	NARCO	Test/Recert

Part Number	Model	Description	Manufacturer	Capability
ELT-100		EMERGENCY LOCATOR	ARTEX	Test/Recert
ELT-100HM		ELT System Helicopt	ARTEX	Test/Recert
ELT-10C		ELT	NARCO	Test/Recert
ELT110-4		ELT TRANSMITTER	ARTEX	Test/Recert
ELT110-6		ELT	ARTEX	Test/Recert
ELT-200		EMERGENCY LOCATOR	ARTEX	Test/Recert
ELT-6C		DORNE & MARGOLIN ELT	DORNE&MARG	Test/Recert
ELT8.1		ELT	DORNE&MARG	Test/Recert
ELT910		NARCO ELT910	NARCO	Test/Recert
G-4433A		CONTROL HEAD, ADF	GABLES	Repair
G-4434		CONTROL	GABLES	Repair
G-4434A		CONTROL HEAD/VHF	GABLES	Repair
G-4435		VHF NAV CONTROL HEAD	GABLES	Repair
G-4436A		CONTROL TRANSPONDER	GABLES	Repair
G-4457		NAV/COMM CONTROL	GABLES ENG	Repair
G-4518		NAV CONTROL	GABLES	Repair
G-4704		VHF CONTROL	GABLES ENG	Repair
GC11050-6		P.C. BOARD		Repair
G-5774		NAV COM CONTROL	GABLES	Repair
G-708-1		INTERPHONE AMP	GABLES ENG	
H10-00		HEADSET LISTEN ONLY	DAVID/CLARK	Repair
H10-17		HEADSET HELICOPTER	DAVID/CLARK	Repair
H10-30		HEADSET DAVID/CLARK	DAVID/CLARK	Repair
H10-36		HEADSET/DC HIGH IMPE	DAVID/CLARK	Repair
H10-37		HEADSET	DAVID/CLARK	Repair
H10-46		HEADSET	DAVID/CLARK	Repair
H10-66		HEADSET: DUAL IMPED	DAVID/CLARK	Repair
H20-10		HEADSET DAVID CLARK	DAVID/CLARK	Repair
H20-16		HEADSET HELICOPTER	DAVID/CLARK	Repair
HDT3	HDT3	STROBE POWER SUPPLY	WHELEN	Repair
IC-A200	IC-A200	VHF AM TRANSCEIVER	ICOM	Repair
IC-A200M	IC-A200	TRANSCEIVER	ICOM	Repair
ID-250A	ID250A/ARN	RMI indicator	BENDIX	Test/Recert
IFR 45-20	45-20	ALTIMETER 20,000FT	FLIGHT RES	Test/Recert
KA-10	KA-10	ISOLATION AMPLIFIER	KING	Repair
KA-25	KA-25	AUDIO AMPLIFIER	KING	Repair
M-1035 B-1	M-1035	AUDIO SYSTEM	SMITH IND	Repair
M1035 BADA-ABA1	M-1035	AUDIO CONTROL SYSTEM	BAKER ELEC	Repair
M-1035 K-2	M-1035	AUDIO BOX	SMITH AUDI	Repair
M-1035-B-2	M-1035	AUDIO SYSTEM	SMITH	Repair
M1050-T317-01	M-1050	AUDIO AMPLIFIER	BAKER	Repair
M1080B	M1080B	AUDIO AMPLIFIER	BAKER	T.B.D.
MD40-61	MD40-61	CDI FOR GPS, NO LTG	MID CONTIN	Repair
MD40-61L28	MD40-61L28	CDI FOR GPS, 28V LTG	MID CONTIN	Repair
MD40-61L5	MD40-61L5	CDI FOR GPS, 5V LTG	MID CONTIN	Repair
MD40-62	MD40-62	CDI FOR GPS, NO LTG	MID CONTIN	Repair
MD41-***	MD41-***	GPS SW/ANNUNCIATOR	MID-CONTIN	Limited-Repair
MD41-324	MD41-324	GPS/NAV SW KLN90B	MID CONTIN	Limited-Repair
MD41-328	MD41-328	GPS SW/ANNUNCIATOR	MID-CONTIN	Limited-Repair
MD41-328(5V)	MD41-328(5V)	GPS/NAV SWITCH	MID-CONTIN	Limited-Repair
MD41-524	MD41-524	GPS-NAV Control	MID CONTIN	Limited-Repair

Part Number	Model	Description	Manufacturer	Capability
MD41-528	MD41-528	GPS/NAV SW KLN89B	MID CONTIN	Limited-Repair
MD41-538	MD41-538	GPS-NAV Control	MID CONTIN	Limited-Repair
MD41-628-5V	MD41-628-5V	ANNUNCIATOR CONTROL	MID-CONTIN	Limited-Repair
MD41-638	MD41-638	GPS/NAV CONT TRIMBLE	MID CONTIN	Limited-Repair
MD41-928	MD41-928	GPS/NAV SW KLN900	MID-CONTIN	Limited-Repair
MI-585134	PRIMUS-40	PRIMUS40 INDICATOR	RCA	Repair
MI-585134-5	PRIMUS-40	INDICATOR/RADAR PRIM	RCA	Repair
MI-585135-1	PRIMUS-40	PRIMUS 40 R/T	RCA	Repair
MI-585135-2	PRIMUS-40	PRIMUS40 R/T	RCA	Repair
MI-585136	PRIMUS-40	PRIMUS40 ANT PED	RCA	Repair
MI-585300	RT-5001	RECEIVER TRANSMITTER	SPERRY	Repair
MI-585301-1	DI-5001	RADAR INDICATOR	SPERRY	Repair
MI-585302	AP-5001	ANTENNA DRIVE	SPERRY	Repair
MK12-D	MK-12D	NAV/COM	NARCO	Repair
MK12D TSO	MK-12D	NAV/COM	NARCO	Repair
MK-12D-CESSNA	MK-12D	NAV/COM, CESSNA VER.	NARCO	Repair
MK12ETSO	MK-12E	VHF/NAV COMM	NARCO	Repair
MP-10	MP-10	CONVERTER	NARCO	Repair
NAV-112	NAV-112	RECEIVER VOR/LOC/GS	NARCO	Repair
NAV-121 TSO	NAV-121	VOR RCVR/INDICATOR	NARCO	Repair
NAV-122 TSO	NAV-122	VOR/ILS/MKR RCVR/IND	NARCO	Repair
NAV-824 TSO	NAV-824	NAV	NARCO	Repair
NAV-825 TSO	NAV-825	NAV/GS RCVR	NARCO	Repair
NT030B-000	NT-30	VHF LOW BAND TCVR	NAT	Repair
NT136-000W/R	NT-136	VHF FM TRANSCIEVER	NAT	Repair
NT150	NT-150	VHF FM TRANSCIEVER	NAT	Repair
NT150-000/WR	NT-150	TRANSCIEVER VHF FM	NAT	Repair
NT150-050	NT-150	VFH FM TCVR w/GUARD	NAT	Repair
NT-150W/R	NT-150	VHF FM TRANSCIEVER	NAT	Repair
NT-403	NT-403	VHF TRANSCIEVER	NAT	Repair
NT403-000/WR	NT-403	TRANSCIEVER UHF	NAT	Repair
PA-110-010	PA-110	PA AMP	NAT	Repair
PA110-015	PA-110	POWER AMPLIFIER	NAT	Repair
PA220-010	PA-220	LOUDHAILER P.A. 220W	NAT	Repair
PA250-001	PA-250	POWER AMP 250 WATTS	NAT	Repair
PC-12A	PC-12A	28V-14V CONVERTER	FLITE-TRON	Repair
PC-15BC	PC-15BC	INVERTER 250VA/400HZ	FLITE-TRON	Repair
PC17-3	PC17-3	STATIC INVERTER600VA	FLITE-TRON	Repair
PC-17-3	PC-17-3	INVERTER/STATIC	FLITE TRON	Repair
PC-50	PC-50	STATIC INVERTER 50VA	FLITE TRON	Repair
PM21908	PM-21908	Cyclic Grip	MASON	Repair
PM22700	PM-22700	CYCLIC GRIP	MASON	Repair
R88A-0351-011		ALTIMETER	KOLLSMAN	Test/Recert
RC-30-VIL-1		VERTICAL SPEED IND	RC ALLEN	Test/Recert
RCA26BK-12		GYRO HORIZON	RC ALLEN	Repair
RCA26BK-6		ATTITUDE GYRO 28 V	RC ALLEN	Repair
RCA26BK-7		ATTITUDE GYRO 28V	RC ALLEN	Repair
RCA82A-11		TURN CO-ORDINATOR	RC ALLEN	T.B.D.
RCA-82A-11		TURN COORDINATOR	RC ALLEN	T.B.D.
RS08-001		REMOTE SWITCH	NAT	Repair
RS12-020		RELAY	NAT	Repair

Part Number	Model	Description	Manufacturer	Capability
S6155-61092		FUEL PANEL ASSEMBLY	SIKORSKY	Repair
S6155-61092-1		PANEL ASSY, FUEL MGT	SIKORSKY	Repair
S6155-61560-025		CAUTION/PANEL	SIKORSKY	Repair
S6155-61562-001		PANEL ASSY.	SIKORSKY	Repair
S6155-62104-003		CHIP DET,RELAY BOARD	SIKORSKY	Repair
S6156-61550-001		LANDING GEAR CONTROL	SIKORSKY	Repair
S6156-61550-002		LANDING GEAR CONTROL	SIKORSKY	Repair
S6157-62561-5		CAUTION/ADVISORY	SIKORSKY	Repair
S6157-62561-7		CAUTION ADVISORY PNL	SIKORSKY	Repair
S6190-60045-005		CHANNEL MONITOR	SIKORSKY	Repair
S6190-60060-004		PANEL/AFCS	SIKORSKY	Repair
S6190-60060-041		AFCS CONTROL PANEL	SIKORSKY	Repair
S6192-61090-001		AMPLIFIER-LAG	SIKORSKY	Repair
S6192-61090-002		SINGLE CHANNEL LAG A	SIKORSKY	Repair
S6192-61090-1		LAG AMPLIFIER	SIKORSKY	Repair
SA-40-1		AIRSPD IND.	UNITED	Test/Recert
SA-DF-14/28		STROBE LIGHT	WHELEN	Repair
SCU10		HF CONTROL, SUNAIR	SUNAIR	Repair
SHARC 7		ELT	SHARC	Test/Recert
SPA-400		INTERCOM	SIGTRONICS	Test/Recert
SSD120-15		ENCODER	TRANS-CAL	Test/Recert
SSD120-20		ENCODER	TRANS-CAL	Test/Recert
SSD120-30		ENCODER 30000FT	TRANS-CAL	Test/Recert
STA-300C-1	STA-300	HF ANTENNA	SPILSBURY	Repair
TEL82	TEL-82	ELT	TECHNISONIC	Test/Recert
TFM-138		VHF FM TRANSCEIVER	TECHNISONIC	Repair
TFM-138B/G		VHF/FM TRANSCIEVER	TECHNISONIC	Repair
TFM-138G		VHF FM TRANSCEIVER	TECHNISONIC	Repair
TFM-30/G		LOW BAND VHF/FM TCVR	TECHNISONIC	Repair
TFM-403/G		UHF/FM TRANSCEIVER	TECHNISONIC	Repair
TFM-403/R		UHF Transceiver	TECHNISONIC	Repair
TH250-2FE		RADIO CONTROL	NAT	Repair
TH250-2NE		CONTROL HEAD FM NAT	NAT	Repair
TH250-2NN		CONTROL HEAD NAT	NAT	Repair
TH250-2QE		CONTROL HEAD	NAT	Repair
TH250-2QF		CONTROL HEAD	NAT	Repair
TH250-2UN		FM CONTROL	NAT	Repair
TH250-2VN		TAC/COM CONTROL	NAT	Repair
TH350-14NNA		TAC/COM CONTROL	NAT	Repair
TH350-8NNA		TAC/COM CONTROL	NAT	Repair
TH360-4ZZY		SLAVE CONTROL	NAT	Repair
TH360-8ZZY		SLAVE CONTROL	NAT	Repair
TH360-8ZZZY		SLAVE CONTROL	NAT	Repair
TNL2000		GPS APPROACH REC'R	TRIMBLE	Repair
TNL2000A		VFR GPS System	TRIMBLE	Repair
TNL2100T		GPS Receiver	TRIMBLE	Repair
TNL2101-I/O		Approach GPS	TRIMBLE	Repair
TNL2101-I/O-PLUS		Approach GPS	TRIMBLE	Limited-Repair



**Maxcraft Avionics Ltd.**  
**AMO 33-90**  
**Component Maintenance Capabilities**

*phone 604.465.3080*  
*fax 604.465.3084*  
*email: sales@maxcraft.ca*

<b>Part Number</b>	<b>Model</b>	<b>Description</b>	<b>Manufacturer</b>	<b>Capability</b>
	SIGNED COPY IN	LOCATED IN STND PROC	MANUAL IN QA OFFICE	